

Networks • Communications

DECnet-DOS

Mini-Reference Guide

AA-GV32A-TV

8870000

DECnet-DOS

Mini-Reference Guide

Order No. AA-GV32A-1V

Apr. 1988

This document contains quick reference information on the commands and command syntax for DECnet-DOS utilities. The utilities and their commands (or parameters and switches) are listed in alphabetical order by utility.

Supersession/Update Information:
Operating System and Version:

This is a new manual.
V8-DOS V2.11
PC-DOS V2.10
PC-DOS V3.10
DECnet-DOS V1.1
DECnet-Rainbow V1.1

9181150

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

The software described in this document is furnished under a license and may only be used or copied in accordance with the terms of such license.

No responsibility is assumed for the use or reliability of software or equipment that is not supplied by Digital or its affiliated companies.

Copyright © 1988 by Digital Equipment Corporation

The postage prepaid Reader's Comments form on the last page of this document requests the user's critical evaluation to assist us in preparing future documentation.

The following are trademarks of Digital Equipment Corporation:

DEC
DECmate
DECnet
DECUS
DECwriter
DIBCL

MASSBUS

PDP
PDS
Professional
Rainbow
NETS
NSX
NT
ULTRIX


ULTRIX-32
ULTRIX-32M
JNIBUS
VAX
VAXcluster
VMS
VT
WorkFrontier

MS[®] and XENIX[™] are trademarks of Microsoft Corporation.

IBM is a registered trademark of International Business Machines Corporation.

PC/AT and Personal Computer AT are trademarks of International Business Machines Corporation.

This manual was produced by Networks and Communications Publications.



FAL SWITCHES

The File Access Listener (FAL) provides a way for you to let other nodes access files on your node. The purpose of the FAL utility is to listen for and receive remote access requests from the network. When FAL detects a request to copy a file from your node, it first checks the type of access privilege contained in the request. FAL has the proper privilege for access to your node. FAL sends the file data back to the requesting node. You can control the way FAL operates by using switches.

Format

FAL [options]

Valid FAL switches are:

- ASCII (A)
- DIRANY (D)
- DIRHOLD (H)
- LOG (L)

To use these switches, you must type them on the command line after the FAL command.

ASCII

When you use the ASCII switch, all files are transferred as ASCII files.

Format

ASCII

/BINARY

When you use the **/BINARY** switch, all files are transferred as binary (or image) files.

Format

/BINARY

/ERROR

When you use the **/ERROR** switch, **FAL** will report an error to the remote node if the requesting node is attempting to overwrite an existing file.

Format

/ERROR

/LOG

When you use the **/LOG** switch, **FAL** logs the type of access contained in every request it receives. The information is displayed on the screen if the **/ALGO** switch is not used. If you do not wish the information to appear at your terminal, you can redirect it to an output file.

Format

/LOG:filename

MAIL COMMANDS

The MAIL utility lets you send mail messages and text files to other nodes in the network. The MAIL commands are:

EXIT
HELP
MAIL
SEND

EXIT

The EXIT command allows you to leave the Mail utility.

Format

EXIT

HELP

HELP provides information about the MAIL commands and switches.

Format

HELP [topic]

Mail HELP topics and qualifiers include:

/EDIT	Mail Functions
/EXT	SEND
/INIT FILE	SEND Functions
/MAIL	/SUBJECT

MAIL and SEND

Both the MAIL command and the SEND command allow you to send mail messages and text files to other users in the network. These commands may be used interchangeably.

Format:

MAIL/[switch] [Name]

Valid MAIL or SEND switches are:

/EDIT
/SUBJECT

MAIL PARAMETERS

When you first use the MAIL utility, you are prompted for information. The MAIL program uses this information each time you run the utility. This information is stored in a file called after the INIT flag called MAIL.DAT. The INIT flag can be set to a list of these mail parameters:

REPLY__ADDRESS
DEFAULT__NODE
CARBON__COPY
EDITOR
PERSONAL__MESSAGE

REPLY__ADDRESS

You first define the REPLY__ADDRESS parameter when you first run the MAIL utility. It is necessary for other users to have a way to respond to your messages or to send you mail. The REPLY__ADDRESS appears as part of the "Reply to" information string.

Format:

REPLY__ADDRESS = *username@hostname*

DEFAULT__NODE

DEFAULT__NODE always points to the address for nodes that you communicate. Once you have defined the DEFAULT__NODE in the INIT file, you can send mail to any location that node simply by specifying the node name.

Format:

DEFAULT__NODE = *hostname*

CARBON_COPY

CARBON_COPY is the address to which a copy of your mail message is sent. Each time you send a mail message, a copy of that message automatically goes to the CARBON_COPY address.

Format

CARBON_COPY = hostname:username

EDITOR

EDITOR specifies which editor for the mail program will use when you want to edit mail messages. You must use the EDIT switch with a mail command if you want to edit a message or a text file before you send it.

Format

EDITOR = editorname

PERSONAL_MESSAGE

The PERSONAL_MESSAGE is a message that other users see whenever you send them mail. The message can contain your name and phone number, or it can be any other descriptive text you wish to create.

Format

PERSONAL_MESSAGE = description text

NCP COMMANDS

The Network Control Program (NCP) is the DECnet management utility that accepts commands from your terminal to perform certain network functions. The NCP commands let you identify your node to other nodes in the network, establish node names and default access control information for other nodes, change network parameters, and monitor network activity and network error statistics.

The NCP commands are:

CLEAR ACCESS	SET LINK
CLEAR EXECUTOR	SET LINK
CLEAR NODE	SET KNOWN LINKS
COPY KNOWN NODES	SET NODE
DEFINE CIRCUIT	SHOW ACCESS
DEFINE EXECUTOR	SHOW CIRCUIT
DEFINE LINE	SHOW EXECUTOR
EXIT	SHOW LAT
HELP	SHOW LINE
MONITOR LOGGING	SHOW LINKS
QUIT	SHOW NODE
READ LOGGING	ZERO CIRCUIT
SET ACCESS	ZERO EXECUTOR
SET CIRCUIT	ZERO LAT
SET FQDN	ZERO LINK
SET EXECUTOR	

CLEAR ACCESS

The CLEAR ACCESS command removes access information for the designated user or for all users. The access information is stored on a per user basis. It includes the password and access type. PAK uses this information to provide a local file access.

Format

CLEAR ACCESS [USER name]

or

CLEAR ALL ACCESS

CLEAR EXECUTOR

The CLEAR EXECUTOR command removes specific executor node parameters from the local node's database.

Format

CLEAR EXECUTOR [RECEIVE PASSWORD]
[TRANSMIT PASSWORD]

NOTE

These passwords are used to establish a link to DDMP when it is needed.

CLEAR NODE

The CLEAR NODE command removes parameters stored on the local node for all or the specified known nodes or all remote nodes known to the local node.

Format

CLEAR KNOWN NODES

or

CLEAR NODE NODE-ID [ALL
ISLN
PASSWORD
ACCOUNT
LAT HOST]

COPY KNOWN NODES

The COPY KNOWN NODES command copies the node database to a file, leaving out any access information that may be contained in the database.

Format

COPY KNOWN NODES TO FILE-1

DEFINE CIRCUIT

The **DEFINE CIRCUIT** command defines the character string for the circuit state (ON or OFF). The state you choose will not take effect until the next time you reboot your system.

Format

```
DEFINE CIRCUIT STATE {ON |  
                      {OFF}}
```

DEFINE EXECUTOR

The **DEFINE EXECUTOR** command sets several characteristics. These characteristics will not take effect until the next time you reboot your system.

Format

```
DEFINE EXECUTOR ADDRESS nnn/addr:aaa  
                  MAXIMUM BUFFERS number  
                  MAXIMUM LINKS number  
                  NAME nnnn name  
                  GLOBAL : BUFFER SIZE number
```


DEF INE LINE

This DEFINE LINE command defines the state of the line. It becomes effective with the next system reboot.

Format

```
DEFINE LINE STATE {ON |  
                  {OFF}  
                RECEIVE BUFFERS n
```

EXIT

The EXIT command allows you to exit from NCP and save parameter changes.

Format

```
EXIT
```

HELP

The HELP command displays information about NCP commands on your system.

Format

```
HELP [parameter] [verb] [entry]
```

MONITOR LOGGING

The MONITOR LOGGING command will display network events as they are being logged. You can stop the display of information logging by pressing any key on the keyboard. You can also use CTRL-C to stop the display and exit from RCP at the same time.

Format

MONITOR LOGGING [TO FILE]

QUIT

The QUIT command allows you to exit from RCP, and gives you the choice of saving or deleting any network changes you may have made. If you have not made any changes, RCP simply exits. If you have made changes, RCP gives a prompt for you to verify if you either want you want to save these changes.

Format

QUIT

READ LOGGING

The READ LOGGING command displays the contents of the event logging buffer. It may be redirected to a specified output file.

Format

READ LOGGING [TO FILE]

SET ACCESS

The SET ACCESS command sets incoming access information for the designated user. The access information is set on a per-user basis, and it includes the password and share-type.

Format

```
SET ACCESS JCLN username  
      | PASSWORD password  
      | access type
```

There are four types of access. They are:

NOHL – no access for this user. This is the default.

READ – provides read only access.

WRITE – provides write only access.

ALL – provides both read and write access.

SET CIRCUIT

The SET CIRCUIT command defines or modifies circuit information.

Format

```
SET CIRCUIT {owner} {HELD | OWNED | DEFEND | RECOVER | STATE}  
                {ON | OFF}
```

SET FCHO

The SET FCHO command determines whether a redirected input file is displayed on your screen as the file is executed. The default is OFF (no display).

Format

```
SET FCHO {ON | OFF}
```

SET EXECUTOR

The SET EXECUTOR command sets the executor node's parameters or characteristics.

Format

SET EXECUTOR ADDRESS node address
 DELAY FAC. CH number
 DELAY WEIGHT number
 IDENTIFICATION keyword
 INACTIVE TIME seconds
 INCOMING TIME seconds
 NAME node name
 OUTGOING TIME seconds
 RECEIVE PASSWORD password
 RECEIVE PIPE QUOTA number
 RETRANS. FAC. CH number
 SEGMENT OUTPUT SIZE bytes
 STATION
 TRANSMIT ASS. WGT password
 TRANSMIT PIPE QUOTA number

SET KNOWN (or ACTIVE) LINKS

The SET KNOWN (or ACTIVE) LINKS command breaks all link connections that are not set with the socket option, SO_KEEPALIVE, and frees the associated sockets.

Format

```
SET {KNOWN|LINKS|STATE} ON :  
    {ACTIVE LINKS}
```

SET LINE

The SET LINE command defines or modifies line configuration.

Format

```
SET LINE {yes-no} {  
    DEVICE {COM 1  
             COM 2  
    }  
    MODEM {NULL  
           NULL  
    }  
    SPEED {speed rate  
    }  
    STATE {OFF  
           ON  
    }
```

NOTE

Information for DEVICE, MODEM, and the SPEED applies to asynchronous (TTY) configuration only.

SET LINK

The SET LINK command terminates logical link connections that are associated with a specific socket. The socket is also detached.

Format

SET LINK *socket* *STATUS* OFF

SET NODE

The SET NODE command assigns a node name plus access control information to a unique node address.

Format

SET { NODE *node-address* NAME *node-name* [*access-ctrl*
[LAT-HIGH]]
KNOWN NODE FROM *node-id*
NODE *node-id* FROM *node-id* }

SHOW CIRCUIT

The SHOW CIRCUIT command displays all the information you see with the GET CIRCUIT command, as well as certain system information. You can either display the information on your screen or redirect it to an output file at the local node.

Format

```
SHOW CIRCUIT [showing] [CHARACTERISTICS] [COUNTERS]  
[STATUS] [SUMMARY] [IO & W]
```

SHOW EXECUTOR

The SHOW EXECUTOR command displays the executor node information. You can either display the information on your screen, or redirect it to an output file at the local node.

Format

```
SHOW EXECUTOR [CHARACTERISTICS] [COUNTERS]  
[STATUS] [SUMMARY] [IO & W]
```


SHOW KNOWN ACCESS

The `SHOW KNOWN ACCESS` command displays the contents of the incoming access database, which is stored in the file `ULC\ACCESS.DAT`. If a password is set for the database, it only appears on the screen as three dots (...).

Format

`SHOW KNOWN ACCESS [TO file]`

SHOW LAT

The `SHOW LAT` command displays information about the LAT file you may be using. The information may be directed to a file. This command only works if you have LAT installed on your node.

Format

`SHOW LAT [COUNTERS] [TO file]`

SHOW LINE

The SHOW LINE command displays line information. You can either display the information on your screen or redirect it to an output file at the local node.

Format

```
SHOW LINE [key(s)] [CHARACTERISTICS] [TO file(s)]  
[COUNTERS]  
[STATUS]  
[SUMMARY]
```

SHOW LINKS

The SHOW LINKS command displays summary type information for the specified logical links.

Format

```
SHOW (KNOWN LINKS) [TO file(s)]  
(ACTIVE LINKS)
```

SHOW NODE

The SHOW NODE command displays node information. You can either display the information on your screen, or redirect it to an output file at the keyboard.

Format

SHOW NODE (name) [STATUS] [TO FILE]

or

SHOW { KNOWN NODES
ACTIVE NODES
ADJACENT NODES }

ZERO CIRCUIT

The ZERO CIRCUIT command zeroes the counters for the circuit.

Format

ZERO CIRCUIT (circuit) [COUNTS]

ZERO EXECUTION

The ZERO EXECUTION command zeroes the counters associated with an execution until the next node.

Format

ZERO EXECUTION [COUNTERS]

ZERO LAT

The ZERO LAT command zeroes the counters for the LAT line. This command only works if you have LAT installed on your board.

Format

ZERO LAT [COUNTERS]

ZERO LINE

The ZERO LINE command zeroes the counters for the line.

Format

ZERO LINE [WINDG] [COUNTERS]

NDU COMMANDS FOR VIRTUAL DISKS

The Network Device Utility (NDU) allows you to access up to four virtual disk volumes at a time. Each remote volume is file-based and is treated as if it were a hard disk.

The following NDU commands allow you to control the use of remote files as virtual disk volumes.

CLOSE

The CLOSE command ends the connection between the specified drive and the virtual disk file on the remote node.

Format

CLOSE DRIVE remote

or

CLOSE NODE node-name NDISK file-name

CHILATL

The **CREATE** command creates and formats a new removable file, which is treated as a hard disk, and establishes a connection between a volume name at your local node and the file.

Format

```
CREATE NODE my-volume NDISK my-name [ DRIVE drive  
[ LSH access-ctrl  
[ ACCESS (R/W  
[ RO  
[ ALLOCATION n  
[ MAX n
```

DELETE

The **DELETE** command deletes an existing virtual disk file on a remote node.

Format

```
DELETE NODE node-name NDISK my-name [ LSH access-ctrl
```

or

```
DELETE = DRIVE drive
```

HELP

This HELP is a 1000-byte function about NDU commands - it will list

Format:

HELP [command/verb]
[verb]

OPEN

The OPEN command establishes a connection between your local node and an existing remote virtual disk share on the DeUnet node.

Format:

OPEN NODE remote NODE DiskName [DRIVE letter
USER username
ADDRESS (IP)
(PORT)]

SHOW

The SHOW command causes NDU to report on the status of all virtual disk(s) and printer

Format:

SHOW STATUS

NDU COMMANDS FOR VIRTUAL PRINTERS

The Network Device Utility (NDU) allows you to access and virtual printer software. The remote node which provides the virtual printer sends any text you output to the printer device NPRINT in a temporary file. When you stop using the virtual printer, this temporary file is queued for printing at the default printer on the remote node.

The following NDU commands allow you to direct text to a remote node to be queued for printing at a later time.

CLOSE

The CLOSE command ends the connection between the device NPRINT and the file on the remote node. The file is then queued to be printed on the remote printer. After the file is printed, it is deleted.

Format

CLOSE PRINTLN

CREATEIL and OPEN

The CREATEIL and OPEN commands function in the same way. Either command creates a new virtual printer file and makes it ready for use. The printer file is created and then linked to the device NPRINT.

Format

CREATEIL NDU= node name [NPRINT file name] [USER address-id]

OPENPRINTLN NDU= node name [NPRINT file name] [USER address-id]

HELP

The **HELP** command displays information about RDU commands on your screen.

Format

HELP [command(s)
or
only _

SHOW

The **SHOW** command causes RDU to report on the status of all virtual disks(s) and printer.

Format

SHOW STATUS

NFT COMMANDS

The Network File Transfer Utility (NFT) is a network program that allows you to access remote files. Using NFT, you can copy files between the local disk and remote nodes, delete local and remote files, display remote file contents, run batch files on remote nodes, and copy files on remote nodes.

The following NFT commands allow you to perform various actions on local and remote files.

APPEND

The APPEND command adds the contents of one or more input files to the end of an existing output file. You can append either ASCII or binary files to or from remote nodes.

Depending on its position in a command, a file specification can be either input (source) or output (destination).

Format

APPEND /switch|input file output file

or

APPEND /switch|

File(s)? input file

To? output file

Use APPEND switches as:

MSDI
DELETE
IMAGE
MLOG
PRINT
SUBMIT

COPY

The COPY command creates a new file or a new version of a file in the destination code. You can use the COPY command to copy files from the local code to the remote code, or from that remote code to the local code.

Format

COPY[switch] [path:file] [path:file]

or

COPY[switch]

File:input file

To: output file

Valid switches to COPY to a remote node are

ALLOCATION = yes	MACYTH
ASG	MARS = yes
BLOCK	MCLOG
CC = yes	MOSPAR
DELETE	PRINT
FIXED = yes	REUNIT
IMAGE	VARIALE
ISA	YES = yes

^aOnly 2-methyl-5-oxo-2,5-dihydrofuran-3-carboxylic acid was used.

JASCI
 FIDOK
 FFACE
 NOCONVERT
 NOLOG

DELETE

The **DELETE** command deletes one or more specified files or directories.

Format

DELETE [/a] [/b] [/d] [/f] [/q]

or

DELETE [/a] [/b] [/d] [/f] [/q]

FILE [/a] [/b] [/d] [/f] [/q]

DIRECTORY

The **DIRECTORY** command displays a list of local or remote file names, including the size (in blocks) and the time and date the file was last modified or created.

Format

DIRECTORY [/a] [/b] [/d] [/f] [/q]

Valid **DIRECTORY** switches are:

/BRIEF

/FULL

LX

The LX command exits from an MFT console and returns control to the DOS operating system.

Format

LX

HELP

The HELP command displays information about MFT commands and switches on your screen.

Format

```
HELP [command word]  
      [option]
```

PRINT

The PRINT command queues a remote file to be printed on a remote printer. You must indicate the file to be printed. The file will be printed on the system default printer.

Format

PRINT [device] [file name]

or

PRINT[*node*]
FILE[*file*] *file-spec*

FILE[*file*] *file-spec*

Valid PRINT switches are

•DELETE

•NOLOG

SL

The SLI command allows you to set default access control information as well as disk scheduling information for a particular node.

There are no valid switches for the SLI command.

Format

SET *node-spec* [*file-spec*]

or

SFT

Node ? *node-spec* [*file-spec*]

The *node-spec* in this case is a remote node name, followed by access control information (in quotation marks). For example:

REFRSH "RUTCH password"

SHOW

The SHOW command displays the temporary default table of remote access information for the specified node. The `password` is not displayed on the screen; instead, the character string `password` is displayed in its place.

There are no valid switches for the SHOW command.

Format

```
SHOW [username]
```

SUBMIT

The SUBMIT command requests that the specified command file be run on the remote node. The specified remote node must support batch mode file submission and execution.

Format

```
SUBMIT [NODE] [command-file]
```

or

```
SUBMIT [NODE]  
File(s) [command-file]
```


TYPE

The TYPE command displays the contents of a local or remote file on your screen. `%j, %g, %d` will be removed for ASCII files only.

Format

TYPE file-spec

or

TYPE _

Field#file-spec

NTU COMMANDS

The Network Test Utility (NTU) allows you to find any information about your node and how it is interacting with the network. You can use NTU to diagnose problems you may have in connecting your node to the network. It also enables you to monitor any of the network components. The NTU also provides, if you perform various tests, what it does the operation of each component. This includes the operation of your local node, the communication to the remote node, and the communication hardware between them.

The AT Command Set

CLEAR ACCESS	SET ECHO
CLEAR ACCOUNT	SET LENGTH
CLEAR COUNT	SET LINE STATE
CLEAR DEFAULTS	SET LINK
CLEAR LENGTH	SET PASSWORD
CLEAR PASSWORD	SET USER
CLEAR USER	SET WITH
CLEAR WITH	SHOW ACTIVE LINKS
EXIT	SHOW ACTIVE NODES
HELP	SHOW ADJACENT NODE
LOOP CIRCUIT (LOOP)	SHOW CIRCUIT
LOOP CIRCUIT (ETHER)	SHOW DEFAULTS
LOOP EXECUTOR	SHOW EXECUTION
LOOP LINE CONTROLLER	SHOW KNOWN LINKS
LOOP NODE	SHOW KNOWN NODES
MIRSH	SHOW LINK
MONITOR LOGGING	SHOW NODE
READ LOGGING	ZERO CIRCUIT
SET ACCOUNT	ZERO EXECUTION
SET CIRCUIT	ZERO LINK
SET CCLK	

CLEAR ACCESS

The CLEAR ACCESS command removes the user's password, and accounting information that was stored by a previous SET or LOOP command.

Format

CLEAR ACCESS

CLEAR ACCOUNT

The CLEAR ACCOUNT command clears the accounting information that was stored by a previous SET or LOOP command.

Format

CLEAR ACCOUNT

CLEAR COUNT

The CLEAR COUNT command resets the number that indicates how many times you want to repeat a given file test to its default value of 1.

Format

CLEAR COUNT

CLEAR DEFAULTS

The CLEAR DEFAULTS command resets all the lockwork parameters to their original values, which are: null for user id, password, and account; 40 for COUNT; 40 for LENGTH; and MIXED for TYPE.

Format

CLEAR DEFAULTS

CLEAR LENGTH

The CLEAR LENGTH command resets the number that indicates the maximum length to its default value of 40.

Format

CLEAR LENGTH

CLEAR PASSWORD

The CLEAR PASSWORD command removes the password that was stored by a previous SET or LOCK command.

Format

CLEAR PASSWORD

CLEAR USER

The **CLEAR USER** command erases the user-id that you initially stored with the **SET** or **LOGP** command.

Format

CLEAR USER

CLEAR WITH

The **CLEAR WITH** command resets the binary format indicator in the last message to its default value of MIXED. (See **SET WITH** for more details.)

Format

CLEAR WITH-

EXIT

The **EXIT** command is for you leave NT. Whenever you issue this command, NT attempts to restore the DECnet link to the ON state. (You can exit with **CTRL-Z** after the exit from NT.)

Format

EXIT

HELP

The `HELP` command provides information about the RTU commands. Entering `HELP` alone results in a display of the available commands. You can further qualify the information you seek by specifying `HELP` followed by a command name (and optionally an entry).

Format

`HELP [command] [entry [entry]]`

LOOP CONNECT (or Asynchronous DDCMP Configuration)

The `LOOP CONNECT` command enables loopbacks for the DECUat module. These tests verify that network communication is possible between your local node and the adjacent node, or between your local node and a local or remote modem.

In synchronous DDCMP configuration, this command causes RTU to run a loopback test to a loopback plug, a modem, or an adjacent node. When you issue this command, RTU displays a menu for you to select the location of the loopback connector.

Format

`LOOP CONNECT [COUNT,n] [WITH ONERZERDES'XED] [LENGTH,n]`

LOOP CIRCUIT (for Ethernet Configurations)

The LOOP CIRCUIT command allows you to test for the DECnet circuit. These tests verify that network communication is possible between your local node and a remote node.

For Ethernet configurations, this command releases NUI to run a loopback test to a specific Ethernet address or to a multicast Ethernet address.

Format

LOOP CIRCUIT [WITH ONESZERDESMIXED] [[FNST <n>] [COUNT <n>]

or

LOOP CIRCUIT NODE <nnnn>

[WITH ONESZERDESMIXED] [[FNST <n>] [COUNT <n>]

or

LOOP CIRCUIT PHYSICAL ADDRESS <nnnn> <nnnn> <nnnn>

[WITH ONESZERDESMIXED] [LENGTH <n>] [COUNT <n>]

LOOP EXECUTOR

The LOOP EXECUTOR command invokes the key test for your local (non-ISA) module. It verifies the operation of your local module by checking if a local network software. This test will fail if your local module (non-ISA) was not properly installed.

Format

LOOP EXECUTOR [COUNT *n*] [WITH MIXED NONZEROES] [LENGTH *n*]

LOOP LINE CONTROLLER

The LOOP LINE CONTROLLER command performs a loopback test within your local module, at the data bus level. The command can only be used when EISA not configurations are required the use of the DECNA Key Lock Connector (part number 12-22196-01).

Format

LOOP LINE CONTROLLER

LOOP NODE

The LOOP NODE command invokes the loop test for the remote node. It verifies that your node can communicate with a specific remote node. To perform this test, you need to include any network parameters that are necessary for accessing the loopback mirror on the remote node. These parameters may include the nodeid, the user-id, the password, and the timeout.

Format

```
LOOP NODE nodeid [ USER userid  
                  PASSWORD password  
                  ACCOUNT account  
                  COUNT n  
                  WITH ONLY ZEROES | MIXED  
                  LENGTH n ]
```

MIRROR

The MIRROR command allows a LOOP NODE test to be run from a remote system that supports the LOOP NODE test (such as a TFCnet-UCS v1.1 system). The maximum size of a message that LOOP will loop back is 65,535 bytes.

Format

MIRROR

MONITOR LOGGING

The **MONITOR LOGGING** command displays network events as they are being logged. You can stop the display of information logging by pressing any key on the keyboard. You can also use **Ctrl-C** to stop the display and exit from RTRJ at the same time.

Format

MONITOR LOGGING [TO No-W]

READ LOGGING

The **READ LOGGING** command causes the system to display information about network events that is contained in the event logging buffer. These events are logged continuously. **READ LOGGING** lets you read the most current network information.

The information appears on the screen in front of you, or you can redirect the output to a specific file.

Format

READ LOGGING [TO No-W]

SET ACCOUNT

The **SET ACCOUNT** command lets you specify the account to use for accessing the main or a remote node. You can use up to 38 characters to define the account.

Format

SET ACCOUNT account

SET CIRCUIT

The SET CIRCUIT command defines or modifies circuit information.

Format

```
SET CIRCUIT [circuit] {  
    HELLO TIMER {seconds}  
    OWNER {TAPCON}  
        {OFF}  
    SERVICE {DISABLED}  
        {ENABLED}  
    STATE {ON}  
        {OFF}
```

SET COUNT

The SET COUNT command lets you specify the number of times to repeat any of the RTU tests. The default value is 1, but you can change this at any time using SET COUNT. You can assign any value that is in the range of 1 to 99,999.

Format

```
SET COUNT =
```

SET LOGO

The SET LOGO command determines whether a redressed input file is displayed on your screen as the file is processed. The default is OFF (no value).

Format

```
SET LOGO {ON|OFF}
```

SET LENGTH

The SET LENGTH command lets you specify the length of header messages to be sent over the network. The default value is 40, but you can change it at any time using SET LENGTH. You can assign any value from 1 up to 512.

Format

```
SET LENGTH n
```

SET LINE STATE

This command allows you to turn the state of the line to OFF or ON. The line is then immediately removed that connects your node to the adjacent node.

Format

```
SET LINE STATE {OFF|ON}
```

SET LINK

The SET LINK command is an interface logical link connection (ILLC) one associated with a specific socket. The socket is a socket ID.

Format

SET LINK socket STATE OFF

SET PASSWORD

The SET PASSWORD command lets you specify the password to use to establish a link for on the remote node. You can use up to 32 characters to define the password.

Format

SET PASSWORD password

SET USER

The SET USER command lets you specify the user's control information necessary for accessing the remote node. You can use the user's name or the user's link address with this command. (If you decide to provide the user's name, you must also provide the appropriate password for that name.)

Format

SET USER user-id

SET WITH

The SET WITH command lets you specify the type of format to use for sending feedback messages. The format is always binary (ONES and ZEROES), unless you have enabled as to how the binary numbers are displayed. There are three ways to change the binary format:

- ALLONES (11111111)
- ALLZEROS (00000000)
- MIXED ONES and ZEROES (01101010)

The default format is MIXED.

Format

SET WITH {ONES
 ZEROS
 MIXED }

SHOW ACTIVE LINKS

The SHOW ACTIVE LINKS command displays summary type information for all active links between the execution node and the adjacent node (or other remote nodes with active logical links to your node).

Format

SHOW ACTIVE LINKS [TO Node]

SHOW ACTIVE NODES

The **SHOW ACTIVE NODES** command displays the router node, the adjacent node, and a list of all the nodes that currently have an active link to your local node.

Format

SHOW ACTIVE NODES [*TO SW-n*]

SHOW ADJACENT NODE

The **SHOW ADJACENT NODE** command displays information for the adjacent node.

Format

SHOW ADJACENT NODE [*TO SW-n*]

SHOW CIRCUIT

The **SHOW CIRCUIT** command displays information about the gateway circuit.

Format

SHOW CIRCUIT (*gateway*)

CHARACTERISTICS
COUNTERS
STATUS
SUMMARY

 [*TO SW-n*]

SHOW DEFAULTS

The **SHOW DEFAULTS** command displays all of the current default values as either by the system or with the SET or LOOP command. **SHOW DEFAULTS** displays the values for the following:

- Loop Count
- Data Length
- Data Type
- Case Sensitive (if applicable)
- Password (if applicable)
- Account (if applicable)

Format

SHOW DEFAULTS

SHOW EXECUTOR

The SHOW EXECUTOR command displays information on local node's local node.

Format

```
SHOW EXECUTOR [CHARACTERISTICS] [COUNTERS] [STATUS] [SUMMARY] [USNode]
```

SHOW KNOWN LINKS

The SHOW KNOWN LINKS command displays summary type information for all known links known to the local node.

Format

```
SHOW KNOWN LINKS [USNode]
```

SHOW KNOWN NODES

The SHOW KNOWN NODES command displays a list of all nodes that are known to DEDnet on your local node. You can set these nodes by using NUP. You can perform RTU tasks (new tasks that require the use of node names) only to nodes that are known by your system.

Format

```
SHOW KNOWN NODES [USNode]
```

SHOW LINE

The SHOW LINE command displays information about the DECnet line (QASYNC or ETHER) that you are using to communicate with the network.

Format

```
SHOW LINE [show-s] [CHARACTERISTICS] [TO show-s]  
[COUNTERS]  
[STATUS]  
[SUMMARY]
```

SHOW NODE

The SHOW NODE command displays local information about a remote node, which you specify by its network address. The node information appears on the screen in front of you.

Format

```
SHOW NODE node-n [STATUS] [TO show-s]  
[SUMMARY]
```

ZERO CIRCUIT

The ZERO CIRCUIT command resets all the counters on the circuit to zero.

Format

```
ZERO CIRCUIT [show-s] [COUNTERS]
```

ZLHO EXECUTOR

The ZLHO EXECUTOR command resets all the counters for your local node to zero.

Format

ZLHO EXECUTOR (COUNTERS)

ZLHO LINK

The ZLHO LINK command resets all the counters for your link to zero.

Format

ZLHO LINK (Node ID) (COUNTERS)

SETHOST PARAMETERS AND SWITCHES

The network dialer terminal utility (referred to as SETHOST) connects your node to a host node and allows you to exchange data at a defined data rate to the host node. Each time you connect or log on to a host, the connection creates a session.

You can establish links by connecting to a host node (LAT and CTERM), when SETHOST connects your node to a host node, it connects via a link that is a LAT link if installed. If a SETHOST link attempts to connect your node to a LAT link. This is the default. If LAT is not available, then SETHOST attempts to connect your node using CTERM. You can force CTERM over LAT as the default by using the CTERM switch.

The maximum number of concurrent sessions you can obtain data is equal to the number of network links you established with the NUP command, DEFINE EXECUTOR MAXIMUM LINKS. The number of sessions can depend on the number of links that are currently active.

SETHOST provides a command interface to create and modify sessions using. SETHOST also provides a menu interface which is displayed whenever a session is interrupted. This guide describes the switches used with the SETHOST command interface. For information about the SETHOST menu, refer to the OLCHSETHOST User's Guide.

The SETHOST command, its parameters, and various switches allow you to create, modify, and manage your remote sessions. You can use the parameters and the switches in the command line, or you can use them at the SETHOST prompt.

Format

SETHOST [node-name or address] [session]

NOTE

Any switches that can take arguments will accept a space, a colon (:), or an equals sign (=) as delimiters to separate the switch from its argument.

!ABORT

The **!ABORT** switch lets you specify what tasks you want to abort. You can abort a single session or you can abort all sessions. To view the current sessions, use the **!SHOW** switch.

Format

```
!ABORT = n  
ALL
```

!CTERM

The **!CTERM** switch specifies that CTERM protocol be used for the connection. The default is to attempt to use LPT protocol first. If the LPT attempt fails, the connection is made using CTERM. Only CTERM provides support for multiple sessions.

Format

```
!CTERM
```

!EDIT

The **!EDIT** switch lets you choose the type of command line editing you can perform during your remote session. This switch only applies to C-OS/2 systems or systems that support command line editing.

Format

```
!EDIT = edit-mode
```

The `/res` editing modes are:

`OVERSTRIKE`
`INSERT`
`NONE`

`/EXIT`

The `/EXIT` switch lets you exit from `GETHOST`. You can enter the switch after you have typed the `GETHOST` command.

Format

`/Exit`

`/HELP`

The `/HELP` switch displays the main help text screen for `GETHOST`.

Format

`/HELP = topic`

You can get help on the following topics:

node-spec	<code>@</code>	<code>'</code>	<code>?</code>	
<code>/ERRRDN</code>	<code>/TAKE</code>	<code>/LOC</code>	<code>/HELP</code>	<code>/SAVEDDEFAULT</code>
<code>/SHOW</code>	<code>/EDIT</code>	<code>/ABORT</code>	<code>/EXIT</code>	<code>/GTFRM</code>
keyboard layout	context switching			
syntax	changing default editing mode			

LATSE-NAME

The LATSE-NAME parameter lets you specify the LAT service to use for establishing a remote session.

Format

SET HOST latseaname

LOG

The LOG switch lets you record the terminal session in a log file. You can specify a file name for recording the session. If you do not specify a name, the default file name is REE8000.LOG.

Format

LOG on=quit

MODE-SPFC

The MODE-SPFC parameter lets you specify the DFO or node name or DED node name address to use for establishing a remote session.

Format

SET HOST mode=quit

#SAVEDEFAULT

This switch lets you save the switch settings to be used as the defaults for all future sessions. The #SAVEDEFAULT switch only works with the #EDIT and the #CTERPA switches. If you use #SAVEDEFAULT and do not specify any switches to be saved, it has no effect.

When you use this switch, SETHOST places your specified *Host* in a file called SET-HOST.DEP in the ULEcho directory. Built OSs made this file whenever you use the utility.

Format

#SAVEDEFAULT

#SESSION

The #SESSION switch specifies the session number to use for reconnection to a host. You can use the #FQDN switch to determine which sessions are available. You can then use #SESSION to re-establish a connection to a particular session. This switch only applies to CTERPA hosts or systems that support multiple sessions.

Format

#SESSION *Ln*

ISHOW

The *ISHOW* switch displays a list of the current sessions and the hosts that connect them to your node. This switch only applies to CTERM hosts or systems that support multiple sessions.

Format

ISHOW

ITAKE

The *ITAKE* switch calls command *take* on the host and sends the file to remote node's processor.

Format

ITAKE = *file*

or

@*file* *name*

1.4.3.1 COMMENTS

What do you think of this manual? Your comments and suggestions will be used to improve the quality and usefulness of our publications.

Please rate this manual:

	Poor			Excellent		
Appearance	1	2	3	4	5	
Readability	1	2	3	4	5	
Examples	1	2	3	4	5	
Classification	1	2	3	4	5	
Comments	1	2	3	4	5	

Do you find errors in this manual? If so, please specify the section and page number(s).

General comments:

Suggestions for improvement:

Name _____ Date _____

Title _____ Organization _____

Company _____ Street _____

City _____ State/Country _____ Zip Code _____



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY LABEL

FIFTH CLASS PERMIT NO. 33 MAYNARD MASS.

POSTAGE WILL BE PAID BY ADDRESSEE

digital

SOFTWARE DOCUMENTATION
550 KING STREET
LITTLETON, MA 01460-1289


1. The first step is to identify the problem or question that needs to be addressed. This involves understanding the context and the specific requirements of the task.


2. Next, it is essential to gather relevant information and data. This can be done through research, consultation with experts, or by analyzing existing resources.


3. Once the information is gathered, the next step is to analyze it and identify the key factors that influence the outcome. This often involves breaking down the problem into smaller, more manageable parts.

4. After analysis, a plan or strategy should be developed. This plan should outline the steps that need to be taken to solve the problem or answer the question.

5. The final step is to implement the plan and monitor the progress. This involves putting the plan into action and making adjustments as needed based on the results.









digital

AA-GV32A-IV

Printed in U.S.A.