

TU78 Subsystem

Pocket Service Guide

Issued By
Training Department

FOR REFERENCE ONLY
NOT MAINTAINED

Prepared by Educational Services
of
Digital Equipment Corporation

1st Edition, May 1981
2nd Edition, March 1984

Copyright © 1981, 1984 by Digital Equipment Corporation

All Rights Reserved

The material in this manual is for informational purposes and is subject to change without notice.

Digital Equipment Corporation assumes no responsibility for any errors that may appear in this manual.

Printed in U.S.A.

NOTICE

This equipment generates, uses, and may emit radio frequency energy. The equipment has been type tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such radio frequency interference. Operation of this equipment in a residential area may cause interference, in which case the user at his own expense may be required to take whatever measures may be required to correct the interference.

The following are trademarks of Digital Equipment Corporation, Maynard, Massachusetts.

DEC	DECNET	IAS
DECUS	DECsystem-10	MASSBUS
DIGITAL	DECsystem-20	PDP
	DECwriter	RSLS
PDP	DIGOL	RSX
UNIBUS	UniSystem	VMS
VAX	OMNIBUS	VI
Os/2		

CONTENTS

1 INTRODUCTION

1.1	General	1
1.2	Subsystem Overview	1
1.3	TM78 Assemblies	1
1.4	TO78 Assemblies	1
1.5	Operator Controls and Indicators	1
1.6	Maintenance Controls and Indicators	11
1.6.1	TM78 Controls and Indicators	12
1.6.2	TO78 Controls and Indicators	12
1.7	Tools	12
1.8	Spares Kit Lists	16
1.8.1	TM78 Spares Kit	16
1.8.2	TO78 Spares Kit	17
1.9	Recommended Spares Levels (RSL)	18
1.9.1	Additional TM78 RSL Parts	18
1.9.2	Additional TO78 RSL Parts	18
1.10	Related Documents	21
1.11	System Diagnostics	23

2 TROUBLESHOOTING

2.1	Introduction	24
2.2	On-Line Diagnostics	24
2.3	In-Line Diagnostics	24
2.4	Error Log	24
2.5	Status Indicators for Troubleshooting	24
2.6	Error Codes	25
2.7	TM78 Maintenance Panel	42
2.7.1	Keypad Function Summary	42
2.7.2	Errors	45
2.7.3	Parameters	46
2.7.4	Maintenance Instructions	55
2.7.5	Sample Maintenance Routine	58
2.8	Test Pairs	58

iv CONTENTS

3 CHECKS AND ADJUSTMENTS

3.1	Parts Replacement	63
3.2	Quick Reference Adjustment Specification	63
3.3	Write Current Adjustments	76

APPENDIX A SUBSYSTEM MASSBUS REGISTERS

APPENDIX B EXTENDED SENSE BYTES

FIGURES

1-1	Dual-Power TU78 Subsystem	2
1-2	TM78 Front View	3
1-3	TM78 Module Layout (Back View) Showing Maintenance Indicators	4
1-4	TU78 Assemblies (Front View)	6
1-5	TU78 Assemblies (Back View)	7
1-6	TU78 Card Cage Showing Maintenance Controls and Indicators	8
1-7	TU78 Operator Control Panel	9
1-8	HV422 Power Supply Showing Maintenance Indicators and Controls	12
1-9	Door Safety Interlock Switch	14
2-1	TM78 Maintenance Panel	43
2-2	Sample Write/Read Routine	59
3-1	GCR/PT Preamp I PCB A Test Points	73
3-2	Interconnect F1 PCB A	74
3-3	Vacuum Valve and Pressure Valve	75
3-4	Write Head Current Waveform	78
A-1	RH20 and RH780 Addresses	80
A-2	Control and Status Register	81
A-3	Data Transfer Interrupt Register	83
A-4	Tape Control Register	84
A-5	Drive Type Register	85
A-6	Tape Unit Status Register	86
A-7	Motion Interrupt Code Register	87
A-8	Motion Command Register	88
A-9	Hardware Control Register	91
A-10	Configuration/Status Register	92
A-11	Control Register	93
A-12	Status Register	94
A-13	Virtual Address Register	95
A-14	Byte Counter Register	95
A-15	Diagnostic Register	96
A-16	Map Register	97

D-1	Read Path Status Byte	98
D-2	Read Microcontroller Command Byte	100
D-3	Parity Read Channel Status Byte	101
D-4	ECC Status Byte	102
E-5	Channel (N) Track & Head Byte	103
E-6	IU Port Status Byte	104
E-7	CAS Port (N) Status Byte	105
E-8	MASSETS C Bus Status Byte	105
E-9	MASSETS D Bus Status Byte	106
E-10	Write Microcontroller Error Byte	106
E-11	Interrupt Status Byte	107
E-12	TL78 Status Byte	107
E-13	MLA Status A Byte	109
E-14	MLA Status B Byte	109
E-15	MLA IU Diagnostics Byte	110
E-16	Relay Control Byte	110
E-17	IU Software Status	111
E-18	Transfer Control Byte	111
	TL78 Subsystem Detailed	
	Block Diagram	112
	Write Path Troubleshooting Diagram	113
	Read Path Troubleshooting Diagram	113

T-431.78

1	TL78 Controls	10
1-2	TL78 Indicators	11
1-3	TL78 Maintenance Controls	16
2-1	TM78/TL78 Diagnostics	25
2-2	In-Line Self-Test Microdiagnostics	26
2-3	Troubleshooting Indicator Functions	27
2-4	Interrupt Code & Failure Code	29
2-5	Keyboard Error/Status Codes	45
2-6	Parameter Items	46
2-7	Maintenance Instruction Codes	55
3-1	Checklist/Adjustments When Replacing	
	Parts	63
3-2	Adjustment Specifications	66
3-3	Vacuum and Pressure Valve	
	Components	78
A-1	Data Transfer Function Codes	82
A-2	Nondata Transfer Function Codes	89
B-1	Read Microcontroller Status Codes	99
B-2	Read Microcontroller Command	
	Codes	101



1 INTRODUCTION

1.1 GENERAL

This document is designed for use by a person trained to service a TUX subsystem. A TUX subsystem is made up of a MASSBUS controller (RHX1), a TM78 formatter, and a TUX tape transport. Procedures are short, and support a maintenance philosophy of module replacement.

This chapter presents an overview of the formatter and transport for quick review. Chapter 2 is troubleshooting information. Use of error logs, diagnostics, and maintenance panel locators allow rapid location of malfunctions. Chapter 3 lists all adjustments in quick reference format.

Programming information is not provided but register summaries for each hardware family type are found in Appendix A. Appendix B lists the extended sense registers available in the diagnostic and error log products.

1.2 SUBSYSTEM OVERVIEW

The TUX subsystem is shown in Figure 1-1. The example shown is a dual-ported TM78 formatter, controlling four TUX transports. A detailed block diagram of the subsystem may be found on the layout at the end of this book.

1.3 TM78 ASSEMBLIES

Major TM78 assemblies are shown in Figures 1-2 and 1-3.

1.4 TUX ASSEMBLIES

Major TUX assemblies are shown in Figures 1-4, 1-5, and 1-6.

1.5 OPERATOR CONTROLS AND INDICATORS

All operator controls and indicators are on the TUX control panel. Figure 1-7 shows the panel. Table 1-1 lists the controls and their functions, and Table 1-2 lists the indicators and their functions.

2 INTRODUCTION




Figure 1 Double-Tiered TUI78 System

4 INTRODUCTION




Figure 4-3 TM78 Module Layout (Back View) Showing Maintenance Indicators (Sheet 1 of 2)

2 INTRODUCTION




Figure 1-4 T173 Assembly (Front View)




Figure 1-1 T178 Card Cage Showing Maintenance Controls and Indicators




Figure 1-7 TU78 Operator Control Panel

10 INTRODUCTION

Table 1-1 TLT3 Controls

Control	Function										
Part Select Switch	It selects the MASSBUS I/O port(s) allowed to send commands to this tape transport.										
	<table> <tr> <th>Switch Position</th><th>Function</th></tr> <tr> <td>0</td><td>Transport connected to MASSBUS port A</td></tr> <tr> <td>1</td><td>Transport connected to MASSBUS port B</td></tr> <tr> <td>2</td><td>Transport connected to both MASSBUS ports A and B</td></tr> <tr> <td>3</td><td>Transport disconnected from both MASSBUS ports and placed in maintenance mode (available to TLT3 form factor maintenance panel)</td></tr> </table>	Switch Position	Function	0	Transport connected to MASSBUS port A	1	Transport connected to MASSBUS port B	2	Transport connected to both MASSBUS ports A and B	3	Transport disconnected from both MASSBUS ports and placed in maintenance mode (available to TLT3 form factor maintenance panel)
Switch Position	Function										
0	Transport connected to MASSBUS port A										
1	Transport connected to MASSBUS port B										
2	Transport connected to both MASSBUS ports A and B										
3	Transport disconnected from both MASSBUS ports and placed in maintenance mode (available to TLT3 form factor maintenance panel)										
LOAD/REW	It starts one of three sequences: - With no tape in path, it initiates a load sequence. - With tape in path but not tensioned, it starts a midroll load sequence. In a midroll load sequence the tape loads and runs in reverse direction to RCT. - With tape in path and tensioned, and the transport off-line, the tape rewinds to RCT. If the tape is at RCT or if the transport is on-line, no action occurs.										
ON-LINE	It switches the transport off-line or on-line.										
UNLOAD	If the TLT3 is off-line, it unloads the tape to rewind and unload. If the tape is at RCT, it unloads. If the TLT3 is on-line, button has no effect.										
RESET	Terminates all functions and clears a load fault.										

Table 4-2. TC78 Indicators

Indicator	Meaning
Power	DC and system logic power are present.
RD1	Tape is at RD1.
On-line	TC78 is on-line. The transport returns to the off-line mode if any of the following occurs: 1. ON-LINE button is pressed. 2. External rewind/unload command is received. 3. Vacuum column interlock is broken. 4. AC power is lost. 5. RESET button is pressed. 6. Front door opens.
File Protect	Tape cast without a write enable ring has been loaded on the transport.
Load Fault	Load fault has occurred. 1. Autoload sequence has failed to load a tape from a 267 mm (10.5 in) reel after two tries. 2. Load sequence has failed to load tape from a 216 mm or 7 7/8 in (22.5 mm or 7 in) reel.
1600	Tape transport set to read or write at 1600 bits/in (PB mode).
6250	Tape transport set to read or write at 6250 bits/in (GCR mode).

1.6 MAINTENANCE CONTROLS AND INDICATORS

Maintenance controls and indicators may be found on the TM78 logic gate (front and back), the TM78 power supply (H/422), the TC78 logic gate, and the front of the TC78 base assembly.

12 INTRODUCTION

1.6.1 TM78 Controls and Indicators

Figure 1-2 shows the front of the TM78 logic gate and details the maintenance controls. The maintenance panel is described in Chapter 2. To the right of the maintenance panel is a DIP switch matrix. The DIP switches select the MASSBUS drive address for both ports and sets either or both ports on or off-line. A dual port TM78 is considered off-line for maintenance purposes only when both ports are placed off-line.

Figure 1-3 shows the back of the logic gate and details some of the maintenance indicators that may be used for troubleshooting. Table 2-2 lists the indicators and describes their functions.

Figure 1-8 shows the front of the H7422 power supply and details the maintenance indicators and adjustments.

1.6.2 TU78 Controls and Indicators

Figure 1-9 shows a detail of the base assembly and points out the door safety interlock switch. This switch must be defeated to perform certain maintenance adjustments. To defeat the switch pull its actuator arm down and out with a spring hook.

The rest of the TU78 maintenance controls and indicators are on PCBAs in the card cage assembly (Figure 1-6). Table 1-3 lists the TU78 maintenance controls and Table 2-3 lists the indicators.

1.7 TOOLS

In addition to the standard DIGITAL tool kit, the following tools are needed to service the TM78/TU78.

Description	DEC Part Number	Included in Spares Kit
Dual trace oscilloscope with two X10/X1 probes	—	No
Digital voltmeter		No
Two pin/layer dual-height needle extenders	W900	No
Real motor containing ltr.	29-25306	Yes




Fig. 1-5 H7471 Power Supply Showing Maintenance Points and Controls




Figure 1-9 Door Safety Interlock Switch

Description	DEC Part Number	Included in Spares Kit
Red Torque locating bar	26-33207	Yes
PCBA extender	29-21218	Yes
Lower restraint tube fitting	29-23228	Yes
Differential pressure gauge (0-10 inch H ₂ O)	25-11620	Yes
Differential pressure gauge (0-5 PSI)	29-11636	Yes

Description	DRC Part Number	Included in Spurer kit
Portable accessory package for gauges (2 needed)	29-11647	Yes
Tachometer (digital readout)	29-11635	Yes
Tape caliper	47-00038	Yes
Xcelite Lambs	29-10582	Yes
7 inch calibrator	29-11625	Yes
5/32 inch $\times$ 4 inch Ballpoint hex driver	29-11620	Yes
Master skew bar (1200 ft)	29-19024	No
Magna-Sec tape developer	29-15871	No
50X microscope with graticule	29-20273	No
Herr sink compound	99-08268	Yes
Inspection mirror (donut type)	29-19662	No
Cleaning kit	TU-001	(comes with 1078)
Standard output tape	29-1169	No

16 INTRODUCTION

Table 1-3 TM78 Maintenance Controls

Control	Location	Purpose
Motion 1	MIA PCBA	It moves transport forward or reverse when on-line and in manual mode.
Read/Write	MIA PCBA	It selects read or write mode when on-line and in manual mode.
Density	MIA PCBA	It selects 1600 or 6250 RPI density when on-line and in manual mode.
Auto/Man	MIA PCBA	It selects auto (transport operation to format) or test mode. When in test (or manual) mode, transport must be on-line for other MIA switches to function.
Data Pattern Sel.	MIA PCBA	It selects a repeating 3-frame pattern when on-line and in manual mode.
AGC Exercise	Read PCBA	It allows Read PCBA to lock AGC to the ARA burst, or to run free.
Motion 2	Control M7 PCBA	It moves transport forward or reverse, on or off-line.
Read Servo On/Off	Read servo PCBA	It disables the read servo amplifiers so that certain adjustments can be made.

1.8 SPARES KIT LISTS

1.8.1 TM78 Spares Kit (A2-W0342-B)

The following lists the contents of the TM78 Spares Kit.

Part Number	Description
M8950	Read data sync module
M8951	FCC module
M8953	CRC/ACRC module

DEC

Part Number	Description
M8951	Read path microcontroller module
M8952	TC port module
M8953	MA89BUS data interface module
M8957	Command address space module
M8958	Write translator module
M8959	Write micro/byte assembly module
M8960	Microcomputer module
54-14174	Maintenance keypad/display
H7476	Power supply regulator ± 15.0 V
H7490	Power supply regulator -5.0 V
H7441	Power supply regulator $+5.0$ V
54-14182	AC/DC line board

1.3.2 T1078 Spares Kit (A2 WDMF-H)

The following lists the contents of the T1078 Spares Kit:

DEC

Part Number	Description
29-23766	GCR/Pls presump 1 PCBA
29-23770	Interconnect F1 PCBA
29-23769	MIA PCBA
29-23762	WRIT's PCBA
29-23763	READ PCBA
29-23764	Control M3 PCBA
29-23765	Capstan/regulator PCBA
29-23751	Recd servo PCBA
29-23718	Extensor PCBA
29-23996	Comp servo belt, 30/60 Hz
29-23989	Blower belt, 30/60 Hz, 1.0 Altitude
29-23991	Blower belt, 60 Hz, 1.0 Altitude
29-23220	Muffler
29-23259	Air filter
70-17282-15	15' T1U bus cable
29-10562	Handle
29-11625	7 inch extension
29-11630	5/12 inch load-end allen driver
39-11001	Phillips screw driver blade
29-11635	Tachometer

1B INTRODUCTION

DEC

Part Number	Description
29-11636	Gauge, 0-5 PSI
29-11638	Gauge, 0-30 inch HgO
29-11647	Accessory kit for gauges (2)
29-23206	Centering tool
29-23207	Locating bar
29-23226	Tube fitting

1.9 RECOMMENDED SPAREPARTS LEVELS (RSL)

In addition to the spares kit contents, the following parts are recommended to repair 98 percent of all possible failures.

1.9.1 Additional TM78 RSL Parts

The following are additional RSL parts for the TM78.

DEC

Part Number	Description
BC0063-05	25 ft MASSBUS cable
13-10930-01	230 Vac fan
13-11079-00	Pushbutton switch
29-1164-04	DIP switch
70-17381-00	Flat cable
70-17403-00	Backplane

1.9.2 Additional TU78 RSL Parts

The following are additional RSL parts for the TU78.

DEC

Part Number	Description
12-17916-02	Termin. coaxial 250 V
29-16280-00	Switch, MICRO
29-22216-00	Sense assy, reel
29-23217-00	Sense assy, pack
29-23236-00	Motor assy, reel
29-23218-00	Switch, pressure
29-23239-00	Switch, pressure
29-23242-00	BOF/BOI assy
29-23245-00	TIP assy
29-23246-00	Transducer assy, vacuum

DEC

Part

Number

Description

29-23247-00	Circuit breaker
29-23248-00	Valve assy, vacuum
29-23249-00	Valve assy, pressure
29-23250-00	Bearing, air
29-23251-00	Bearing, air
29-23252-00	Bearing, air
29-23253-00	Compressor
29-23259-00	Motor, gear drv
29-23267-00	Motor, ac
29-23267-00	Switch, backstop detect
29-23286-00	Blower assy (Below SN SP002386)
29-24013	Blower assy (SN SP002386 and above)
29-23308-00	Relay reed SS 12 Vdc
29-23331-00	Cable, flat ribbon (AMTII)
29-23332-00	Thread block 2
29-23323-00	Thread block 4
29-23324-00	Thread block assy
29-23325-00	Thread block assy
29-23326-00	Thread block assy
29-23475-00	Hub reel
29-23765-00	Head, R/W
29-23768-00	Motor assy, capstan
29-23771-00	Controls assy
10-17649-00	18,000 MFD 25V — 75-103
12-14405-00	Door, tape transport, front
29-23308-00	Hub, machined
29-23309-00	Flange, foot
29-23311-00	Interconnect DI
29-23215-00	Door assy, buffer bus
29-23219-00	Spring, compression
29-23232-00	Spring, bellows
29-23233-00	Washer
29-23241-00	Cleaver, tape
29-23235-00	Guide plate "B"
29-23236-00	Guide plate "C"

20 INTRODUCTION

DEC Part Number	Description
29-23258-00	Transformer
29-23279-00	Filter, RFI
29-23281-00	Guide, Air
29-23284-00	Hub, motor 50 Hz
29-23285-00	Hub, motor 60 Hz
29-23286-00	Catch, spring
29-23288-00	Receptacle, fastener
29-23309-00	47000 MFD 15 W VDC $\pm 75\%$ -10%
29-23310-00	61000 MFD 50 W VDC $\pm 102\%$ -10%
29-23311-00	RECT, BRDG 25 A 100 PN
29-23312-00	RECT, BRDG 10 A 100 A
29-23320-00	330 20 W 10% Ww
29-23361-00	Cap plug
29-23655-00	Kir, van hose/tubing
70-17143-00	Fan assembly TU78
90-07221-00	Fuse, reg blow, 5 A, 350 V
90-08835-00	Fuse, reg blow, 20 A, 32 V
90-08838-00	Fuse, reg blow, 10 A, 32 V
29-11691-00	Tape MSTR OTPT 1200X1/2
29-16871-00	Magnette
29-19224-00	Tape, master skew 1200
29-20275-00	Microscope 20 X
47-00035	Tape crimper
90-08368	Thermal compound

1.10 RELATED DOCUMENTS

The following list describes documents related to the TUCS subsystem.

Title	Document Number	Contents
TM78 Magnetic Tape Formatter User's Guide	EK-OTM78-UG	Description, programming, and installation information of the TM78
TM78 Magnetic Tape Formatter Technical Manual	EK-OTM78-TM	Theory of operation, programming information, installation, and maintenance of the TM78 Formatter and 117122 Power Supply
TU78 Magnetic Tape Transport User's Guide	EK-OTU78-UG	Description, installation instructions, and operating procedures for the TU78
TU78 Magnetic Tape Transport Technical Manual, Volume 1	EK-OTU78-TM	Schematics and logic print- outs of TU78
TU78 Magnetic Tape Transport Technical Manual, Volume 2	EK-OTU78-TM	Description, installation, operation, theory, and maintenance of TU78

22 INTRODUCTION

Title	Document Number	Contents
TM78 Magnetic Tape Transport I/PB	BK-TM78-IP	Exploded views and parts lists of TM78
872 Power Controller IPB	BK-00872-IP	Exploded views and parts lists of 872
874 Power Controller IPB	BK-00874-IP	Exploded views and parts lists of 874
RIT20 MASSBUS Controller Link Description	EK-RH20-1.00	Description of RIT20 MASSBUS controller
RH780 MASSBUS Adaptor Technical Description	EK-RH780 TD	Programming and theory of RH780 MASSBUS adaptor
Field Maintenance Print. Set	MP01061	Engineering drawings for TCT8 mechanics and cabinet, engineering drawings and parts lists for TM78 mechanics and logic, TM78 power supply chassis, -5 volt regulator, -15 volt regulator, and +5 volt regulator

1.11 SYSTEM DIAGNOSTICS

The following are system diagnostics for both the TU78 and TM78.

		Diagnostic Name	
Title		DTCSYSTEM-20	VAX
A.	Control Logic Test	DTTLJ	EYMAE
B.	Data Reliability	DTTLJ	EYMAA

2 TROUBLESHOOTING

2.1 INTRODUCTION

This chapter gives a short description of the tools available for troubleshooting a failure in the subsystem. They include troubleshooting flows, on-line and on-line diagnostic programs, error log summaries, status indicators, and a maintenance panel for accessing the formatter/transport off-line.

2.2 ON-LINE DIAGNOSTICS

Table 2-1 lists and describes the on-line (system level) diagnostics available for each hardware family.

2.3 IN-LINE DIAGNOSTICS

A total of 37 in-line microdiagnostics run continuously when the subsystem is idle. If a microdiagnostic fails to operate correctly, the TM78 raises an attention interrupt to the host CPU(s). Each microdiagnostic may be called up individually for single loops or repair verification. This is done through the TM78 maintenance panel. Table 2-2 lists each microdiagnostic and its test number.

2.4 ERROR LOGS

All DEC operating systems, under which the TU78 runs, support an error logging scheme. At a minimum, all MASSBUS registers are read and stored away each time a hard or uncorrectable error occurs. MASSBUS registers are listed in Appendix A. As an error log option, the extended sense summary may also be read and stored away. The extended sense summary is a 60-byte field of internal TM78 and TU78 registers. Extended sense tables for each of four possible TU78s are updated after each error. The extended sense bytes are listed in Appendix B.

2.5 STATUS INDICATORS FOR TROUBLESHOOTING

In addition to the TM78 maintenance panel, a total of 29 LED indicators are available for troubleshooting. Table 2-3 lists each indicator, its function, and location.

Table 2-4 IM78/TU78 Diagnostics

DLCSYSTEM-30	VAX	Description
Control Logic Test		
DEFLU	EVMAID	The Control Logic Test tests MASSBUS controller and PMA formatter logic. It also tests subsystem basic command functions while checking for proper tape motion timing. The test must be run from each CPU separately, through both MASSBUS ports (if dual port option is present). The test provides error information to the user via console or lineprinter.
Data Reliability		
DELUJ	EVMAA	The Data Reliability Test tests TM-3 circuitry by writing and reading predetermined data patterns and recording modes. The test provides error information to the user via console or lineprinter. The test may be run in dual port mode (from dual CPUs) driving two or more transports.

2.6 ERROR CODES

The IM78 sends an interrupt code and a failure code to the host CPU at the completion of any command. These same codes are put into the maintenance display at the completion of a command issued through the maintenance keypad. Table 2-4 lists each interrupt code in numerical order followed by each failure code that could occur within that interrupt mode.

Note that certain interrupt codes imply that the command completed without error or a nondata record was found (codes 01-06). Others indicate that the transport was not in the correct state to operate on the command, or that another command is necessary (codes 07-27). Still others indicate a possible hardware or software failure (codes 30-33). Interrupt code 27 is a unique code in that it applies only to keypad commands.

Table 2.2 In-Line Half-Test Microdiagnostics

Test Number	Description
0	Write microcontroller self-test (M8950)
1	Translator ROM parity test (M8951)
2	Read path microcontroller self-test (M8952)
3	Read channel 0 (slot AB12) self-test
4	Read channel 1 (slot AB13) self-test
5	Read channel 2 (slot AB14) self-test
6	Read channel 3 (slot AB15) self-test
7	Read channel 4 (slot AB16) self-test
10	Read channel 5 (slot CD13) self-test
11	Read channel 6 (slot CD14) self-test
12	Read channel 7 (slot CD15) self-test
13	Read channel 8 (slot CD16) self-test
14	Read path error correction self-test (M8953)
15	Microcomputer RAM memory self-test (Loc 40000-40777)
16	Microcomputer RAM memory self-test (Loc 41000-41777)
17	Microcomputer RAM memory self-test (Loc 42000-42777)
20	Microcomputer RAM memory self-test (Loc 43000-43777)
21	Microcomputer RAM memory self-test (Loc 44000-44777)
22	Microcomputer RAM memory self-test (Loc 45000-45777)
23	Microcomputer RAM memory self-test (Loc 46000-46777)
24	Microcomputer RAM memory self-test (Loc 47000-47777)
25	Loop write-to-read at TU port 0 in GCR
26	Loop write-to-read at TU port 0 in PE
27	Loop write-to-read at TU port 1 in GCR
30	Loop write-to-read at TU port 1 in PE
31	Loop write-to-read at TU port 2 in GCR
32	Loop write-to-read at TU port 2 in PE
33	Loop write-to-read at TU port 3 in GCR
34	Loop write-to-read at TU port 3 in PE
35	Loop write-to-read at MIA 0 in GCR
36	Loop write-to-read at MIA 0 in PE
37	Loop write-to-read at MIA 1 in GCR
40	Loop write-to-read at MIA 1 in PE
41	Loop write-to-read at MIA 2 in GCR
42	Loop write-to-read at MIA 2 in PE
43	Loop write-to-read at MIA 3 in GCR
44	Loop write-to-read at MIA 3 in PE

Table 2-3 Troubleshooting Indicator Functions

Indicator Number on Figure	Function	Possible Failing FRU
1-2 1*	A channel has failed. These nine indicators reflect the quality of the data stream for each channel or track. They indicate loss of SYN or parity dropout. Nonlatched.	• TU78 transport • TL Bus cable (n/d) • M8950
1-3 2*	A parity error has occurred in the ECC primaries buffer. Latched.	• M8951
1-3 3*	There has been a TL mismatch in parity error. Wrong Parity was received at the TU port on the WCS line. Latched.	• TL bus cable (n/a) • TU78 M14 • M8953
1-3 4*	V _{CC} for the MASSBUS transceivers is out of specification. Nonlatched.	• H7490 • H7491 • TM78 backplane
1-3 5*	Wrong parity was received at the MASSBUS port on a control bus command word. Latched.	• MASSBUS cable • RIMX controller • M8957
1-3 6*	A parity error has occurred in the read/scribe microcontroller. Latched.	• M1938
1-3 7*	A parity error has occurred in the write microcontroller. Latched.	• M1939

*The number in the store of the indicator is 0-1.

Table 2.3 Troubleshooting Indicator Functions (Cont.)

Indicator Number on Figure	Function	Possible Fault
1-2 8 [†]	A parity error has occurred in the microcomputer program ROM. Extra.	MS968
1-8 9 [†]	-1 V regulator 1 is ok (supplies COM read path).	- H7441 - Any module in slots 10-16
1-8 10 [†]	+1 V regulator 4 is ok (supplies COM write path. MASSBUS ports TU ports and micro computer).	- H7441 - Any module in slots 1-9
1-8 11 [†]	5 V regulator is ok.	- U7450 - MS955 (slot 1 or 2) - MS957 (slot 2 or 4)
1-8 12 [†]	5 V regulator 2 is ok.	- U7476 - Any MS953
1-8 13 [†]	12 V regulator 3 is ok.	- H7476 - Any MS954
1-8 14 [†]	Power is being applied to the H7437 power supply.	- H7422 circuit breaker tripped - H7422 power cord - H7422 supply
1-6 15 [†]	A command to read command address on the WCS lines was received at the MIA with wrong parity.	- TU bus cable (MIA) - M8857 - TU78 MIA
1-6 16 [†]	MIA PCDA machine sense switch 54 is in MANUAL position.	Flip switch to AUTO

[†]The normal state of the indicator is off.

[‡]The normal state of the indicator is on.

Table 2-4 Interrupt Code to Failure Code

Int Code	Name	Failure Code
01	DONE*	01 - Extended sense data not updated 02 - Extended sense data updated and contains something of interest
02	DATA MARK*	Always zero
03	HOV*	01 - Command was issued with both HOV 02 - Saw HOV indicator after tape motion started 03 - ARA ID detected
04	HOV*	00 - Extended sense data not updated 01 - Extended sense data updated and contains something of interest
05	LOGICAL EOT*	Always zero
06	NO OP*	Always zero
07	REWINDING†	Always zero
08	FEI*	Always zero
09	NOT READY*	01 - TLI is on-line but not ready (possible when TLI is manually rewound or loading) 02 - Data error has occurred and the command cannot be performed until error status has been presented and a TLI CLEAR received

*The interrupt code is used for nondata transfer or data transfer.

†The interrupt code is used for nondata transfer only.

Table 2-3 Interrupt Code to Failure Code (Cont.)

Int Code	Name	Failure Code
		05 Access to TL is off track at FL, is either winding or taking a DSB from another MANSION or keypad command
12	NOT AVAIL*	Always zero
13	OFFICIAL*	Always zero
14	NOT EXECUTABLE*	Always zero
15	NOT CAPABLE*	01 No record found within 25.0 (7.6 m) of tape 02 ID burst within PS or GCR 03 ARA ID not found 04 No GCR found or ID burst (PS) or ARA ID burst (GCR)
17	DS COND*	Always zero
20	LONG REC†	00 Extended sense data not updated 01 Extended sense data updated and contains something of interest
21	SHORT REC†	00 Extended sense data not updated 01 Extended sense data updated and contains something of interest
22	RETRY†	01 CRC error, ACRC error, printer mis-match, no response within two-track interval in RECOVERing from this code generated by write & CLR operations)

Table 2-4 Interrupt Code to Failure Code (Cont.)

Int Code	Name	Failure Code
		03 = CRC error, ACRC error in uncorrectable error in ECCSTA register (This code generated by read PCR operation)
		09 = Uncorrectable error in ECCSTA register (This code generated by read PE operation)
		0a = AMTB, pointer value of uncorrectable, least one error or single-bit error set in ECCSTA register (This code generated by write PE operation)
		0f = Address error in ECCSTA register
		0e = Address error hit set in RPTAFL and RPAFL registers (This code generated by write PE operation)
		07 = More than one write hit set in RPTAFL and RPAFL registers (This code generated by write CE operation)
		10 = RSTAT command code
		11 = CRC characters from WHC and RMT do not match (This code generated by write PE operation)

* The interrupt code is used for no data transfer in data transfer.

† The interrupt code is used for transfer to each only.

‡ The interrupt code is used for CMDE indication.

§ The interrupt code is used for test results.

Table 2-4 Interrupt Code to Failure Code (Cont.)

Int. Code	Name	Failure Code
		12 – MASSBUS data bus parity error (write)
		13 – Removed length mismatch during entry opposite transfer method data has been transferred
		14 – Page occurrence is not beyond L.O.F.
27	READ DPP?	Same as Int. Code 27
34	UNREPAIDABLE?	Same as Int. Code 27
25	ERROR?	Same as Int. Code 22
26	ECT ERROR?	Same as Int. Code 22
27	PAID TAMP?	Same as Int. Code 22
30	TM FAULT A?	01 – Illegal command code
		02 – Data transfer error, undetected while transfer transfer command is progress on some tape
		03 – With error check ECODE (ERR CNT register = 0 address 128 register for reason – may be illegal format or Skip Count codes)
		04 – RIN not received from MASSBUS controller
		05 – Command from read micro-controller to check readout did not start command loaded into RMC LMD register
		06 – FDC ROM parity error (Mem51)
		07 – XMC ROM parity error (Mem58)

Table 2-4 Interrupt Code to Failure Code (Cont)

Int Code	Name	Failure Code
10		Command read from RMC register RCMLE did not match command loaded into RCMD register (this code generated when Verify ID Bus command loaded during write of RMT event)
11		Command read from RMC register RCMLE did not match command loaded into RCMD register (this code generated when Verify AKA Bus command loaded during write of ROL event)
12		Command read from RMC register RCMLE did not match command register (this code generated when Verify AKA ID command loaded during write of ROT event)
13		Command read from FMC register FCMLE did not match command loaded into RCMD register (this code generated when Verify Gap command loaded during write ROT event)
14		Command read from RMC register RCMLE did not match command loaded into RCMD register (this code generated when Read ID Bus command loaded during read of RMT event)

The interrupt code is used for multiple locations or data transfer.

• The interrupt code is used for data transfer only.

• The interrupt mark is used for TMTB (bit 0).

• The interrupt mark is used for data transfer.

Table 2-4 Interrupt Code to Failure Code (Cont)

Int Code	Name	Failure Code
		14 Command read from RMC register RCMLP did not match command loaded into RCMD register (this code generated when Read ID Data command loaded during read of BOT area)
		15 Command read from RMC register RCMLP did not match command loaded into RCMD register (this code generated when Verify AREA command loaded during read of BOT area)
		16 Command read from RMC register RCMLP did not match command loaded into RCMD register (this code generated when Verify Gap command loaded during read of BOT area)
		17 Command read from RMC register RCMLP did not match command loaded into RCMD register (this code generated when Find Gap command loaded during Find Gap routine)
20	WMC LBL 1 not set in extended sense routine	
21	PL parity error on data as it leaves translator (checked at translator output)	
22	NMC DONE did not set (M8958, M8959)	
23	WMC ROM PL or RD FE set in WMC LRR register (M8958, M8959, M8959)	

Table 2-4. Interrupt Code to Failure Code (Cont.)

Int. Code	Assn.	Failure Code
		32 - WMC DONE did not set (M8953, M8959) 33 - WMC ROM PE or RD PE set in WMCERR register (M8959, M8962, M8963) 34 - TU PAULT A ^a
		E1 - TU status parity error (M894) E2 - TU command parity error (M8955) G2 - Rewinding tape went ok, but G4 - Tape went ok ready during D9F G5 - TU's MD status changed during D9F H6 - Capstan did not reach velocity within 2 ms forward or 4 ms reverse H7 - TU velocity drifted after up or down tape writing started H8 - TU LMD did not load correctly to start tape motion in selected function routine (example: tape forward (write) - looks for forward, write, and motion in reverse - looks for reverse and motion) J1 - TU CMD did not load correctly to set C100, J05, J0 J2 - TU CMD did not load correctly to set tape motion to write B071, B072, B073 J3 - TU CMD did not load correctly to backup tape to B071 after failing to write B071, B0 J4 - Failed to write density ID Bin 4 successfully. Looks for 076 correct sample and a 1260

^a The interrupt code is used for non tape transfer or data transfer

Table 2.4 Interrupt Code to Failure Code (Ucode)

Int. Code	Name	Failure Code
15		Failed to write ARA ID correctly. Looks for 1/4 inch perfect cylinders in ARA head.
16		Failed to write ARA ID correctly. Looks for 1/4 inch perfect, not < 2 inches.
17		ARA error bit set in MTA status B register.
21		Could not find a gap after the ID code was written correctly.
22		TU CMD.DK not automatically inserted tape mark to end ID burst.
23		Take out looking for DDI after detecting ARA ID burst.
24		Failed to write tape mark correctly.
25		Velocity marks passed, but tape never came up to speed while trying to reposition for relief of writing tape mark.
26		TU CMD.DK not automatically inserted tape mark at 1.5 inch gap source.
27		Could not detect a gap in Frame Gap routine. Gap must be at least 3/2 inch black tape on 7 tracks (AMTDC = 1.6 inch).
30		Could not detect a gap after writing record.
31		Read path terminated before entire record was written. Less than 257 byte count = erase position. If more than 257 byte count = erase/write problem or bad spot on tape.

Table 2-4. Interrupt Code as Failure Code (Cont.)

Int Code	Name	Failure Code
		32 - Cassette not fast enough after writing record, tape read path is terminated early. Starts looking for gap 0.15 inch before record is read.
		33 - TUCMD did not load correctly to backup for entry of write tape mark.
		34 - TUCMD did not load correctly while trying to reposition for entry of writing tape mark.
		35 - TUCMD did not load correctly to backup, entry resulted DOT ID.
		36 - Transient loading for ROT after failure to write ROT ID.
		37 - ROT did not command while writing all gaps before starting to write record.
		40 - TUCMD did not load correctly to set PC tape density after entry of write DOT ID burst.
		41 - TUCMD did not load correctly to set OCR tape density after writing Density ID.
		42 - TUCMD did not load correctly to set PR tape density after entry of read from ROT.
		43 - TUCMD did not load correctly to set UCR tape density after writing a UCR Density ID burst.

Table 2-4 Interrupt Code to Failure Code (Cont.)

Int Code	Name	Failure Code
02	INITIALIZATION	43 - TUCMD-B is not allowed to set GCR tape density after receiving a GCR Density HD burst
		00 - RST0 interrupt occurred with READY different (A1/D0 LCH)
		01 - Power failed interrupt
		02 - S085 interrupt for unknown reason on channel 5.5
		03 - S085 interrupt for unknown reason on channel 6.5
		04 - P083 interrupt for unknown reason on channel 7
		05 - S082 interrupt for unknown reason on channel 7.5
		06 - CAS entry count expired (greater than 255)
		07 - CAS count down reached for entry line 1
		09 - Queue entry not allowed (no free queue entry)
		11 - S085 queue entry already full
		12 - S085 RDM port error
		13 - In line test 0: WMC (write microcontroller) self test failed - M8959-M8957
		14 - In line test 1: XMC ROM (translator microcontroller) parity error M8958-M8956-M8960
		15 - In line test 2: RMC (read microcontroller) self test failed M8953-M8960
		16 - In line test 3: RDM channel 0 self test failure M8950 (also A1121)

Table 2-4 Interrupt Code to Failure Code (Cont.)

Int Code	Name	Failure Code
17	In-line test 4; RPM1 channel 1 self-test failure M8950 (slot A813)	
20	In-line test 5; RPM2 channel 2 self-test failure M8950 (slot A314)	
21	In-line test 6; RPM2 channel 3 self-test failure M8950 (slot A812)	
22	In-line test 7; RPM1 channel 4 self-test failure M8950 (slot A816)	
23	In-line test 10; RPM1 channel 3 self-test failure M8950 (slot C813)	
24	In-line test 11; RPM1 channel 4 self-test failure M8950 (slot C814)	
25	In-line test 12; RPM1 channel 7 self-test failure M8950 (slot C815)	
26	In-line test 13; RPM1 channel 8 self-test failure M8950 (slot C816)	
27	In-line test 14; RPM1 error correction self-test M8950 M8950-M8950	
30	In-line test 15; 40000-40777 RAM memory failure M8960	
31	In-line test 16; 41000-41777 RAM memory failure M8960	

- * The interrupt code is used for no data transfer or data transfer.
- † The interrupt code is used for module transfer only.
- ‡ The interrupt code is used for TMTs initiated.
- ¶ The interrupt code is used for data transfer.

Table 2-4 Interrupt Code to Failure Code (Cont.)

Int Code	Name	Failure Code
31	In-line test 16; loop write to read at TL port 0 = GCR	RAM memory failure MS960
32	In-line test 17; loop write to read at TL port 0 = GCR	RAM memory failure MS960
33	In-line test 18; loop write to read at TL port 0 = GCR	RAM memory failure MS960
34	In-line test 19; loop write to read at TL port 0 = GCR	RAM memory failure MS960
35	In-line test 20; loop write to read at TL port 0 = GCR	RAM memory failure MS960
36	In-line test 21; loop write to read at TL port 0 = GCR	RAM memory failure MS960
37	In-line test 22; loop write to read at TL port 0 = GCR	RAM memory failure MS960
38	In-line test 23; loop write to read at TL port 0 = GCR	RAM memory failure MS960
39	In-line test 24; loop write to read at TL port 0 = GCR	RAM memory failure MS960
* 40	In-line test 25; loop write to read at TL port 0 = GCR	
* 41	In-line test 26; loop write to read at TL port 0 = GCR	
* 42	In-line test 27; loop write to read at TL port 0 = GCR	
* 43	In-line test 28; loop write to read at TL port 0 = GCR	
* 44	In-line test 29; loop write to read at TL port 0 = GCR	
* 45	In-line test 30; loop write to read at TL port 0 = GCR	
* 46	In-line test 31; loop write to read at TL port 0 = GCR	
* 47	In-line test 32; loop write to read at TL port 0 = GCR	
* 48	In-line test 33; loop write to read at TL port 0 = GCR	
* 49	In-line test 34; loop write to read at TL port 0 = GCR	

Table 2-4 Interrupt Code to Failure Code (HARD)

Int Code	Name	Failure Code
		* 50 = In-line test 35; loop write to read at MTA 0 = GCR
		* 51 = In-line test 35; loop write to read at MTA 0 = PE
		* 52 = In-line test 37; loop write to read at MTA 1 = GCR
		* 53 = In-line test 40; loop write to read at MTA 1 = PE
		* 54 = In-line test 41; loop write to read at MTA 2 = GCR
		* 55 = In-line test 42; loop write to read at MTA 2 = PE
		* 56 = In-line test 43; loop write to read at MTA 3 = GCR
		* 57 = In-line test 44; loop write to read at MTA 3 = PE
34	MB FAIL	01 = Control bus parity error (Write)
		02 = Direct MASS BUS register referenced
67	KEY FAIL	01 = Keypad entry error
		02 = Td76 not off line
		03 = Td76 input error code

* The interrupt code is used for nondata transfer or data transfer.

* The interrupt code is used for nondata transfer only.

2.7 TM78 MAINTENANCE PANEL

A firmware driven TM78 maintenance panel provides access to the operational microcode functions, internal hardware registers, and the resident microdiagnostics.

A table of instructions may be created in RAM through the keypad to emulate the formatter or a single tape transport. Many functions of the maintenance panel can be used while the TM78 is on line and performing tape operations for a host CPU. Added maintenance functions are provided when the TM78 is returned off-line from the host.

NOTE

Because the operational microcode must time-share or interfere the host commands and the maintenance commands, use of the keypad while on line causes slower response time to the commands issued by the host. Therefore, be sure to check with the system operator before using the maintenance panel to see if this latency is acceptable. If not, use the interruption delay in parameter item No. 2 (Table 2.6).

The maintenance panel includes a 20 key keypad and a 6-digit decimal display cluster. Figure 2-1 shows a detailed view of the maintenance panel.

2.7.1 Keypad Function Summary

The following is a summary of the keypad functions.

Miscellaneous Keys

- | | |
|-----|---|
| ENA | Pressing this key once enables the keypad. Pressing this key again disables the keypad. |
| CLR | CLEAR erases a number in the display and stops a looping command. |




Figure 3-1 TMS78 Maintenance Panel

Numeric Keys

0 — 7

The eight numeric keys specify one of the following before a control or operation key is pressed.

Memory address
Memory data
Internal I/O hardware address
Internal I/O hardware data
Parameter item number
Parameter data
Instruction item number
Instruction op-code

Control Keys

INS

The INSTRUCTION key is used to examine and modify any of the sixteen instruction locations.

HDW	The HARDWARE key is used to examine and modify most of the 377 1M18 internal I/O controllers. (Appendix B of the <i>1M18 Technical Manual</i> .)
PAR	The PARAMETER key is used to examine and modify the set of parameter items that control the microcode in performing maintenance functions.
MEM	The MEMORY key is used to examine and modify locations within the microcomputer's memory space.
NXT	The NEXT key causes the next sequential item or location of the group (INS, HDW, PAR, or MEM) selected last to be examined.
DEP	The DEPOSIT key is used to modify the contents of an item or location.

Operation Keys

EXE	The EXECUTE key is used to execute a single maintenance instruction one time only.
REP	The REPEAT key causes a single maintenance instruction code to be executed repeatedly.
STA	The START key initiates the execution of instructions previously deposited into the instruction item group.

CON The **CONTINUE** key may be used to continue the maintenance instruction program at the item number saved when it was last stopped.

2.7.2 Errors

An error code is displayed whenever a command cannot be performed. Table 2-5 lists all the error codes and the reason for the error.

Table 2-5 Key pad Error/Status Codes

Code in Display	Meaning
E 001	Value of item number or location is too large for this group.
E 002	Value of item number or location is slightly at high limit when NXT key was pressed.
E 003	No maintenance was required before display.
E 004	Parameter function is requested (such as modifying a RAM or hardware location) with TMR on line.
E 005	ROM address is not in use.
E 006	Illegal instruction code is selected for an instruction item.
77 01	Excess is detected when attempting to execute a maintenance instruction on a TMR. Either the TMR is secured by parameter item 11 or its maintenance mode (part select A), or the adjustment secured is out of acceptable tolerance.
77 02	Privileged maintenance instruction is requested with TMR on line.
77 03	Illegal instruction code is selected when using ROM or R&P keys.

2.7.3 Parameters

Table 2-6 lists each parameter location and a description of how it conditions or affects the hardware when running maintenance panel instructions.

Table 2-6 Parameter Items

Item Number	Read/Write	Initialized Value	Description																					
0	R/W	000	MASSBUS Port/Type and port select This item selects and/or uses MASSBUS port and one of four Type unit ports to communicate with. <table><tr><th>Bit</th><th>Value</th><th>Port Selected</th></tr><tr><td>7</td><td>0</td><td>MASSBUS A</td></tr><tr><td>7</td><td>1</td><td>MASSBUS B</td></tr><tr><td>10</td><td>0</td><td>TU Port 0</td></tr><tr><td>10</td><td>1</td><td>TU Port 1</td></tr><tr><td>10</td><td>2</td><td>TU Port 2</td></tr><tr><td>10</td><td>3</td><td>TU Port 3</td></tr></table> This item corresponds to hardware register 3'0-W.	Bit	Value	Port Selected	7	0	MASSBUS A	7	1	MASSBUS B	10	0	TU Port 0	10	1	TU Port 1	10	2	TU Port 2	10	3	TU Port 3
Bit	Value	Port Selected																						
7	0	MASSBUS A																						
7	1	MASSBUS B																						
10	0	TU Port 0																						
10	1	TU Port 1																						
10	2	TU Port 2																						
10	3	TU Port 3																						
1	R/W	000	Program run control This item is used by the STA and CON programs. When this item is any number other than 0, a program can be single-stepped without a fault at a time. When this item is 0 the program can run.																					
3	R/W	000	Instruction delay This item is used to insert a delay between each instruction pass when in LOOP mode. The larger the number the longer the																					

Table 2-6 Parameter Items (Cont.)

Item Number	Read/Write	Initialized Value	Description
			delay. This delay can be used to capture the input on last LPI through put, to allow to put a delay between instruction execution.
3	R/W	000	General-Purpose counter. This counter can be loaded, counted, and tested by maintenance instructions.
4	R	000	Branch status. Six bits to indicate by which instructions (L and by conditional branch instructions). Bit 0: error Bit 1: end of tape Bit 2: tape mark
5	R	000	Interrupt code (Table 2-5)
6	R	000	Fail, reason (Table 2-5). Items 3 and 6 contain the execute status returned by the last tape command or in-line diagnostic control instruction. Program control and privileged instructions return execute status but do not write into these parameter items. These items make it possible to run a program that parks the tape, commands, and halts if an error is detected. The reason error can be identified by examining these parameter items after the program halts.

Table 2-6 Parameter Hexes (Cont)

Item Number	Read/Write	Initial/Val	Description																																	
9	R	00	Program continue address The CON key uses this item to determine next instruction address																																	
10	R/W	*	In-line diagnostics index This item selects an on-line diagnostic program for maintenance instruction 15. Refer to Table 2-2 for a listing of the in-line tests available.																																	
11	R/W	01	Data format and skip count Determines maintenance instruction values 1 through 10 and corresponds to hardware register 020 W. Initialised to range from 1 with a zero skip count. <table><tr><th>Bit</th><th>Value</th><th>Description</th></tr><tr><td>7</td><td></td><td>Not used</td></tr><tr><td>6:1</td><td></td><td>Format Control</td></tr><tr><td>0</td><td>0</td><td>Hex mode</td></tr><tr><td>1</td><td>1</td><td>Decimal mode</td></tr><tr><td>2</td><td>0</td><td>16 compatible</td></tr><tr><td>3</td><td>0</td><td>16 core dump</td></tr><tr><td>4</td><td>0</td><td>10 high density compatible</td></tr><tr><td>5</td><td>0</td><td>Image (skip count less than 100)</td></tr><tr><td>6</td><td>0</td><td>10 high density dump</td></tr><tr><td>7</td><td>0</td><td>Image 1</td></tr></table>	Bit	Value	Description	7		Not used	6:1		Format Control	0	0	Hex mode	1	1	Decimal mode	2	0	16 compatible	3	0	16 core dump	4	0	10 high density compatible	5	0	Image (skip count less than 100)	6	0	10 high density dump	7	0	Image 1
Bit	Value	Description																																		
7		Not used																																		
6:1		Format Control																																		
0	0	Hex mode																																		
1	1	Decimal mode																																		
2	0	16 compatible																																		
3	0	16 core dump																																		
4	0	10 high density compatible																																		
5	0	Image (skip count less than 100)																																		
6	0	10 high density dump																																		
7	0	Image 1																																		

Table 2-6 Parameter Items (Cont)

Item Number	Read/Write	Initialized Value	Description
		00	Skip Count
		01	Skip 1 byte
		02	Skip 2 bytes
		03	Skip 3 bytes
		04	Skip 4 bytes
		05	Skip 5 bytes
		06	Skip 6 bytes
		07	Skip 7 bytes
		08	Skip 8 bytes
		09-15	Illegal
13	R/W	020	Write function clock control
14	R/W	037	Read back function clock control
15	R/W	031	Read PE function clock control
16	R/W	020	LOOP write command function clock control
			Items 12 – 15 are 16 data loaded into the clock control register before the function is performed. Refer to hardware register 0C0 W in TM18 Technical Manual for a description of the bit combinations.
18	R/W	00000	Write record size
			This 16-bit item is the hexadecimal value by which data, user program instructions to examine the size of the record written. It is used by read data maintenance instructions as the expected record size.

*Item value is not initialized by erasing register.

Table 2-6 Parameter Items (Cont.)

Item Number	Read/Write	Initialized Value	Description
17	R	000000H	Read record size This 16-bit item is returned by read data instructions as actual size of record read.
20	R/W	000000H	Write data This 16-bit item is written into the DDR by write data instructions.
21	R	000000H	Read data This 16-bit item concerns the contents of the DDR after the last read data instruction, if performed in image format. It is cleared on every read in address format.
22	R	*	Last fatal interrupt code for port A
23	R	*	Last fatal interrupt code for port B Items 22 and 23 are a history of last fatal interrupt code (right justified).
24	R	*	Last fatal failure code for port A
25	R	*	Last fatal failure code for port B Items 24 and 25 are a history of the last fatal failure code (left justified).

Table 2-8 Parameter Items (Cont)

Item Number	Read/Write	Initialized Value	Description
The remaining items are stored whenever the execution of a tape unit operation results in an error. The error status in the hardware registers is saved so it can be initialized by maintenance personnel. A copy of these parameters for each tape unit also is available by the host CP (CP001.SNVS01) command.			
26	R	*	Command code is being executed on bus error
27	R	*	Interrupt code is 0 bus right justified
30	R	*	File code is 0 bus right justified

NOTES

Items 26 through 30 are written with zeros when these locations are written as a result of the keypad hardware dump instruction.

Items 31 through 41 are hardware registers.

Register Contents

31	R	*	0	Read next word in file
32	R	*	1	Read path diagnostic bits
33	R	*	2	Read path status
34	R	*	3	Read path CMD
35	R	*	90	AV PIC
36	R	*	3	RC done
37	R	*	22	Flag 547
40	R	*	23	Mark 2
41	R	*	24	End mark
42	R	*	25	RC per bit
43	R	*	26	Postamble det
44	R	*	27	Data
45	R	*	30	CRC
46	R	*	31	Corrected data
47	R	*	33	FCC status
50	R	*	40	Channel E TIF bus
51	R	*	41	Channel E TIF bus

*Item value is not initialized by enabling keypad.

Table 2-6 Parameter Items (Cont.)

Item Number	Read/Write	Initialized Value	Description
			Register Contents
32	R	*	Channel 2 TIF bus
33	R	*	Channel 3 TIF bus
34	R	*	Channel 4 TIF bus
35	R	*	Channel 5 TIF bus
36	R	*	Channel 6 TIF bus
37	R	*	Channel 7 TIF bus
38	R	*	Channel 8 TIF bus
39	R	*	Channel 9 TIF bus
40	R	*	TIF bus
62	R	*	AMTIF
63	R	*	Port Status
64	R	*	Read data
65	R	*	CAS status
66	R	*	CBUS status
67	R	*	DAL status
70	R	*	WMC status
71	R	*	TU select 0
72	R	*	TU select 1
73	R	*	Write data
74	R	*	Byte counter <70h>
75	R	*	Byte counter <75h>
76	R	*	Par. counter <70h>
77	R	*	Par. counter <75h>
100	R	*	Error counter <70h>
101	R	*	Error counter <75h>
102	R	*	DDR/MDD A
103	R	*	DDR/MDD B
104	R	*	WMC Error
105	R	*	Interrupt status
106	R	*	MIA status
107	R	*	MIA status A
108	R	*	MIA status B
111	R	*	Serial NR. A
112	R	*	Serial NR. B
113	R	*	TU diagnostics
114	R	*	Retry counter
This item counts the number of retry requests given. A zero means tape unit is not in error recovery.			
115	R	*	Retry level bits

Table 2-6 Parameter Items (Cont.)

Item Number	Read/Write	Initialized Value	Description
			Bit 5 = initial command moved tape in reverse Bit 6 = initial command was a read Bit 7 = last retry requested with respect to direction of initial command
1.6	R	*	TU software status Bit 0 = DSE command in progress Bit 1 = moving tape command in progress Bit 2 = tape unit is ok Bit 3 = initial command (NOI) in progress Bit 4 = moved in reverse direction last Bit 5 = last operation wrote on tape Bit 6 = last record seen was tape mark Bit 7 = block is part 8 of 16 in command
1.7	R	*	Transfer Status (selected) If a new transfer is the control word for last data transfer command Bits 0-2 = write clock select Bits 3-5 = read clock select Bits 6-7 = PLO bypass Bit 7 = low read threshold
1.20	R	*	Bit 2 suppresses end format control

*Then value is not initialized by enabling keypad.

Table 2-6 Parameter Reset (Cont.)

Item Number	Read/Write	Initialized Value	Description
			This item is a copy of Miss out register contains entry support, format, and skip count.
140	R	*	Keypad enable flag
			This item is enable when keypad is enabled.
141			Not used
142			Not used
143	R	*	MIA register 0, TUNTS status
144	W	*	MIA register 0, TUNTS data
145	R	*	MIA register 1, MIA status
146	W	*	MIA register 1, TUNTS data
147	R	*	MIA register 2, MIA status
148	W	*	MIA register 2, AMTIE loop
149	R	*	MIA register 3, serial No. 1
150	W	*	MIA register 3, hexadecimal
151	R	*	MIA register 4, serial No. 2
152	W	*	MIA register 4, hexadecimal
153	R	*	MIA register 5, serial No. 3
154	W	*	MIA register 5, hexadecimal
155	R	*	MIA register 6, serial No. 4
156	W	*	MIA register 6, hexadecimal
157	R/W	*	MIA register 7, pattern generator data
158			Not used
159			Not used
160			Not used
161			Not used
162			Not used
163			Not used
164			Not used
165			Not used
166			Not used
167			Not used
168			Not used
169			Not used
170			Not used
171			Not used
172			Not used
173			Not used
174			Not used
175			Not used
176			Not used
177			Not used
178			Not used
179			Not used
180			Not used
181			Not used
182			Not used
183			Not used
184			Not used
185			Not used
186			Not used
187			Not used
188			Not used
189			Not used
190			Not used
191			Not used
192			Not used
193			Not used
194			Not used
195			Not used
196			Not used
197			Not used
198			Not used
199			Not used
200			Not used
201			Not used
202			Not used
203			Not used
204			Not used
205			Not used
206			Not used
207			Not used
208			Not used
209			Not used
210			Not used
211			Not used
212			Not used
213			Not used
214			Not used
215			Not used
216			Not used
217			Not used
218			Not used
219			Not used
220			Not used
221			Not used
222			Not used
223			Not used
224			Not used
225			Not used
226			Not used
227			Not used
228			Not used
229			Not used
230			Not used
231			Not used
232			Not used
233			Not used
234			Not used
235			Not used
236			Not used
237			Not used
238			Not used
239			Not used
240			Not used
241			Not used
242			Not used
243			Not used
244			Not used
245			Not used
246			Not used
247			Not used
248			Not used
249			Not used
250			Not used
251			Not used
252			Not used
253			Not used
254			Not used
255			Not used

*Item value is not initialized by enabling keypad.

2.7.4 Maintenance Instructions

A table of 16 maintenance instructions may be assembled and run using the INS, STA and CON keys. Some instructions may also be executed with the FTF and REP keys. The transport being exercised must be selected in part 23. Table 2-7 lists all available maintenance instruction codes, their description, and the parameter item codes that influence the execution of that instruction. Tape Commands (Group A), Program Control (Group B), and In-Line diagnostic control instructions (Group C) may all be run while the TM78 is on-line or on-line with the host CPU using another transport. However, privileged instructions (Group D) require that both parts of the TM78 be placed off-line.

Table 2-7 Maintenance Instruction Codes

Instruction Code	Description	Controlling Parameter Items (Table 2-6)
A. Tape Commands (Nonprivileged)		
1	Read and unload tape	0,1
2	Read tape	0,1
10	Write tape mark - PE	0,1,12
17	Write tape mark - GCR	0,1,12
1	Space one record forward	0,1,13,14
21	Space one record backward	0,1,13,14
11	Space forward one record or file	0,1,13,14
12	Space reverse one record or file	0,1,13,14
45	Erase extended gap - PE	0,1
46	Erase extended gap - GCR	0,1
51	Long write-to-read at TU per - PE	0,1,15
52	Long write-to-read at TU per - GCR	0,1,15
53	Long write-to-read at MIA	0,1,15
54	Long write-to-read at MIA per 94 - GCR	0,1,15

Table 2-7 Maintenance Instruction Codes (Cont.)

Instruction Code	Description	Controlling Parameter Items (Table 2-6)
67	Write data = PB	0, 1, 12, 16, 20
68	Write data = GCR	0, 1, 12, 16, 20
69	Read forward	0, 1, 12, 16, 20, 21
70	Read reverse	0, 1, 12, 16, 20, 21

B. Program Control Instructions (Do Not Use with EXE/REP keys)

0	NO-OP	0
2	Halt	0
4	Increment counter +1	1, 5
6	Decrement counter -1	1, 5
10	Update parameter item # 76 through 171 with current hardware status *	0, 1
12	Display contents of counter.	1, 5
14	Display contents of parameter item addressed by address 12	1, 5
100 + n	Load counter with n (n = 0 - 75)	1, 5
200 + x	Branch if error status	1, 2
220 + x	Branch if no error status	1, 2
240 + x	Branch if EOT detected	1, 4
260 + x	Branch if no EOT detected	1, 4
300 + x	Branch if tape mark detected	1, 4
320 + x	Branch if no tape mark detected	1, 4
440 + x	Branch if counter not zero	1, 5
500 + x	Unconditional branch	0

* Refer to note on page 51.

x = the number (0 to 15) of next instruction if "error" condition is true

Table 2-7 Maintenance Instruction Codes (Cont.)

Instruction Code	Description	Controlling Parameter Items (Table 2-6)
4. In-Line Diagnostic Control Instructions		
16	Run in-line diagnostic (Table 2-2)	1,10,15
32	Run tape speed adjustment routine	1
34	Run start ramp adjustment routine	1
36	Run forward stop ramp adjustment routine	1
40	Run reverse stop ramp adjustment routine	1
43	Write 13 mm (0.5 in) record pattern generator PB	1,3,12,147
44	Write 13 mm (0.5 in) record using pattern generator - GCR	1,3,12,147
5. Privileged Instructions (157H must be off-line)		
26	Write continuously at 3200 FRPI in all tracks	0,17
40	Write continuously at 9042 FRPI in all tracks	0, 2
46	Write continuously using pattern generator PB	0,3,12,147
50	Write continuously using pattern generator - GCR	0,3,12,147

2.7.5 Sample Maintenance Routine

Figure 2-2 shows the program flow for a sample write/read maintenance routine. This routine writes a record, reads it backward and forward, then repeats the operation till the EOT marker is reached where the tape is rewound. A tally of all read errors is put into the display for each tape pass. If a write error occurs, many important TM78/TU78 registers are saved in parameter locations. Then the program halts so that these parameters can be analyzed.

The program coding is shown below.

Instruction Address	Instruction Code	Description
0	7	Rewind tape
1	100	Clear counter
2	61 (63)	Write PE (GCR)
3	240	If EOT, branch to start
4	214	If error, branch to save
5	77	Read reverse
6	211	If error, branch to count update
7	71	Read forward
10	222	Branch to write if no error
11	4	Increment counter +1
12	12	Put count in display
13	362	Branch to write
14	14 14	Save registers <i>These are saved continuously!</i>
15	2	Halt
16	363	Branch to write after continue
17		

2.8 TEST POINTS

The following list includes all troubleshooting test points available on the TU78 PCBAs and the corresponding signal name.

Control M2 PCBA

- TP 1 - GND
- TP 2 - GND
- TP 3-17 - UNUSED
- TP13 - +5 V DC
- TP14 - LDI/O
- TP15 - CLK B (100 KHZ)
- TP16 - LDI-2
- TP17 - UNUSED
- TP18 - NLDP1




Figure 2-2 Sample Write/Read Routine

Control M2 PC5A

TP19 - CLK F (10 MHz)
 TP20 - CLK A (1 MHz)
 TP22 - U71 S CAPSTAN REV
 TP23 - U63 S
 TP24 - U66-S ARDY
 TP25 - GND
 TP26 - GND
 TP27 - 1DF J
 TP28 - 1DF G
 TP29 - U72-11 RWS
 TP30 - MAINT FUNCTION
 TP31 - MAINT FUNCTION
 TP32 - 1DF 2
 TP33 - NTAP 2
 TP34 - N5-20 S

Control M2 PCB A

TP33 1 OF 3
 TP16 - NBOOT
 TP27 - STL
 TP28 - NBOOT
 TP39 - CLK C (10 KHZ)
 TP40 - TACH AMP
 TP41 1 OF 3
 TP42 2 OF 3
 TP43 - LOW TAPE SENSOR
 TP44 - NLDPS
 TP45 - LDS (LOAD FAULT SENSE)
 TP46 - BKW
 TP47 - MRL
 TP48 - ADP N/O
 TP49 - GND
 TP50 - GND
 TP51 - NPSL
 TP53 - THO
 TP54 - CO N/O
 TP55 - CO N/O
 TP56 - 1.146-5 UNLD
 TP57 - S LIMIT N/O
 TP58 - NSMRL
 TP59 - TOR N/O
 TP60 - VAC N/O
 TP61 - T LIMIT N/O
 TP62 - NENTLE
 TP63 - NCOC (CLOSE CART CMD)
 TP64 - SRP
 TP65 - SRR
 TP66 - TRF
 TP67 - TRR
 TP68 - THDS
 TP69 - NCOC (CART OPEN CMD)
 TP70 - NRSAL (REEL SERVO TNAID)
 TP71 - PNL RST
 TP72 - NXFR

Read PCB A

TP 1
 TP 2
 TP 3-9 UNUSED
 TP10 TRK 9/3 ACTIVE (CH4 & 6)
 TP11 TRK 9/1 ACTIVE (CH4 & 5)
 TP12-19 UNUSED
 TP20 U29-L

TP21 CLAR
 TP22 ST1 CLOCKS
 TP23 UNUSED
 TP24 UNUSED

Wedge PCBA

TP 1 CLK 1
 TP 2 V PED
 TP 3 V STEP
 TP 4 V WRT
 TP 5 CLK 2
 TP 6 V PED AT Q27/28 WD2
 TP 7-9 UNUSED
 TP14 GWR (RTWIND RAMP)

Capstan/Regulator PCBA

TP 1 GND
 TP 2 GND
 TP 3-5 UNUSED
 TP11 -5 V DC
 TP12 V SENSE
 TP13 MOTOR CURRENT
 TP14 GND
 TP15 -15 VDC
 TP16 UNUSED
 TP17 UNUSED
 TP18 -15 VDC
 TP19 MOTOR VOLTAGE
 TP20-24 UNUSED
 TP49 CAPSTAN GND
 TP50 CAPSTAN GND
 TP51 NGPT
 TP52 ANALOG TACH
 TP53 UNUSED
 TP54 UNUSED
 TP55 SPARE1
 TP56 CART SOL RET
 TP57 VAC SOL RET
 TP58 WP SOL RET
 TP59 PRES SOL RET
 TP60-64 UNUSED
 TP65 5.5 VAC
 TP66-69 UNUSED
 TP70 NGPORS1
 TP71 CART MTR (+)
 TP72 UNUSED

Interconnect F1 PCBs

TP 1 S POS
 TP 2 T POS 2
 TP 3 TIF
 TP 4 N PKSN
 TP 5 LUT
 TP 6 BOT
 TP 7 GND

Host Servo PCBs

TP 1
 TP 2
 TP 3 +36 V (T)
 TP 6 TM (+)
 TP 5 TM (-)
 TP10 -36 V (T)
 TP12 +36 V (S)
 TP14 SM (-)
 TP16 SM (+)
 TP18 -36 V (S)
 TP20 UNUSED
 TP21 NIDA
 TP22 NIDH
 TP23 NSDA
 TP24 NSDB
 TP29 GND
 TP30 GND
 TP31 Q2 (COLL)
 TP32 REEL SERVO BRAKE
 TP33 -5 V (S) TO ALL IC'S
 TP34 UNUS'D
 TP35 TPOS
 TP36 NTRRTSET NTRF
 TP38 SUM AMP OUT NIDCA/B
 TP39 SUM AMP OUT I/U LOOP COMP
 TP40 NAL (REEL SERVO ENAB)
 TP41 NUNILK
 TP42 +15 V DC
 TP43 UNUSED
 TP44 +15 V DC
 TP45 1.25 KHZ T-WAVE GEN
 TP46 SPOS
 TP47 ON INPT
 TP48 SUM AMP OUT SUP LOOP COMP
 TP49 NSRF 1
 TP50 NSRR
 TP51 SUM AMP OUT NSDA/B
 TP52 NSRF 2

3 CHECKS AND ADJUSTMENTS

3.1 PARTS REPLACEMENT

Table 3-1 lists the corrective check or adjustment that must be made when replacing certain parts in the subsystem. If a part is not listed in the table, then no corresponding check or adjustment is required.

3.2 QUICK REFERENCE ADJUSTMENT SPECIFICATION

Table 3-2 provides a quick reference to the various TM78/TU78 adjustment specifications. Figures 3-1 and 3-2 show the location of various controls and switches on the TU 78 PCGA. Figure 3-3 shows the air values with their test points and adjustments.

Table 3-1 Checks/Adjustments When Replacing Parts

Part Replaced	Check or Adjustment	Paragraph
Read/write console hard	Clear Transport Power Capstan servo adjusted Read/write adjustments	4.3.4 ^a 5.5.1 ^a 5.5.3 ^a 6.5.2 ^a
Capstan motor	System control to Encoder reel control to Reel skew	6.5.4.1 ^a 6.5.4.2 ^a 6.5.5.1 ^a
Supply reel mate	Supply reel end speed tape loop position	6.5.5.2 ^a 6.5.5.4 ^a

^aTU78 Technical Manual (Vol II)

Table A-1 Checks/adjustments When Replacing Parts (Cont.)

Part Replaced	Check or Adjustment	Paragraph
Takeup reel motor	Takeup reel lead speed Takeup position	6.5.6.3 ⁺ 6.5.6.4 ⁹
AC motor	Vacuum/ pressure	6.5.4 ⁴
Blower	System vacuum Takeup reel vacuum	6.5.4.1 ⁹ 6.5.4.2 ⁹
Compressor	Air bearing pressure Thread lock and cartridges pressure	6.5.4.3 ⁹ 6.5.4.4 ⁴
Read PCBAs	FE gain	6.5.7.5 ⁹
Write PCBAs	Write current FE gain	6.5.7.6 ⁹ 6.5.7.2 ⁺
Capstan Servo PCBAs	Power Capstan servo adjustments FE gain	6.5.1 ⁺ 6.5.3 ⁺ 6.5.7.3 ⁹
Reel servo PCBAs	Reel servo adjustments Dynamic brake check	6.5.6 ⁹ 6.5.6.1 ⁴
Pretension PCBAs	PT gain	6.5.7.3 ⁵
Inter-control FE PCBAs	EOT/NOT sensor Back sense sensor Takeup position	6.5.3 ⁺ 6.5.3 ⁹ 6.5.6.4 ⁴

Table 3.1 Checks/Adjustments When Replacing Parts (Cont)

Part Replaced	Check or Adjustment	Paragraph
Main operation panel	Keypad/display power on check	3.5.1.1*
H7441	+5 V	3.7.5†
H7446	+15 V	3.7.5†
H7490	-5 V	3.7.5†

NOTE.

The paragraph number listed is for the full procedure found in the applicable technical manual.

*T138 Technical Manual (Vol II)

†T438 Technical Manual

Table 3.2 Adjustment Specifications

Parameter	Specified Value and Tolerance	Test Point	Adjustment	Adjustment Paragraph
NOTE: Supply Voltage is 5 V				
Type Fault Sensors (AC/DC/UF sensor)	0 Vdc ± 0.1 Vdc ± 0.1 Vdc	Capacitor/regulator, TP11	Capacitor/regulator, R179	6.3.1
	0 Vdc ± 0.1 Vdc with 100 μ F/100 μ F not under sensor	Interconnect PL, TP5(-); TP5(+)	Interconnect FI, R22	6.3.2
Back sensor	0.5 Vdc max with 100 μ F/100 μ F sensor led in Test with 470 μ F	Interconnect F-, TP4(+); TP2(-)	Interconnect FI, R17	6.3.3

Table 3-2 Adjustment Specifications (Cont.)

Parameter	Specified Value and Tolerance	Test Point	Adjustment	Adjustment Paragraph
Vacuum/Air Pressure System Control	34 inches of water with tape running forward (1.1 inch water)	Cripple reel port	Butterfly valve	6.5.4.1
Takeup reel control	1.9 inches of water (1.1 inch water)	Takeup reel vacuum port	Vacuum valve Fluction plate	6.5.4.2
Air bearing pressure	1.75 PSI (± 0.25 PSI) with tape running forward	Air bearing pressure port	Pressure valve AEP valve	6.5.4.3
Thread block pressure	34 inches of water (1.7 inches of water)	Thread block pressure port	Thread block pressure adjustment screw	6.5.4.4
Cartridge pressure	2.5 inches of water (116.5 inches of water with unit dry loaded, should be greater than 5.0 inches of water)	Cartridge pressure port	Cartridge pressure screw	6.5.4.5

Table 3-2 Adjusting Specifications (Contd)

Parameter	Specification Value and Test/step	Test Point	Adjustment	Adjustment Paragraph
Capstan servo Type fixed	Use TMTS maintenance panel Keyed OP Code = 12 (RFP) Display value = 1.00	-	Capstan regulator, R7	6.5.4
Forward start ramp	Use TMTS maintenance panel Keyed OP Code = 14 (RFP) Display value = 1.00 → 2	-	Capstan regulator, R9	6.5.5
Reverse start ramp	Use TMTS maintenance panel Keyed OP Code = 36 (RFP) Display value = 1.00 → 2	-	Capstan regulator, R6	6.5.5

Table 3-2 Adjustment Specifications (Cont.)

Parameter	Specified Value and Tolerance	Test Point	Adjustment	Adjustment Paragraph
Reverse stop ramp	Loc 11678 Countdown to prod Keepce UP Code = 40 (RCP) Display value = L03 = 2	-	Change magnification	6.5.5
Reel Servo Servo offset	No rotation of supply reel hub		Reel servo PCB A R76	6.5.5.1
Supply reel load time	55 rpm (1.5 rev) Reel servo at R6 TR60 and TR65 to generate CLP40;	-	Reel servo PCB A R52	6.5.6.2

Table 3.7 Adjustment Specifications (Cont.)


Parameter	Specified Value and Tolerance	Test Point	Adjustment	Adjustment Paragraph
Tape speed Full speed	180 rpm (±8 rpm) Read servo PCLN 1P00 and 1P03 to ground (TP48)		Read servo PCRA 301	6.5.5.2
-000.0000 position Read/Write	Refer to procedure in TM	-	-	6.5.5.3
Size (voluntary)	Clean tape path Landing step with tuning skew tape - 1.2 Gs maximum. Adjust for minimum	-	Head nut/tilt screw	6.3.4 6.3.7.1

Table 3-2 Adjustment Specifications (4000)

Parameter	Specified Value and Tolerances	Test Point	Adjustment	Adjustment Paragraph
Watts current	Refer to Figure 6-3 in TM		-	6.5.6.2
Ph. gain	1.25 V PP at Pump output resistor wiring all's are standard output type	Pump output resistor upper lead R1 R4 R7 R10 R13 R16 R19 R22 R25	Row 1 PCB A Potentiometer R705 R805 R705 R705 R405 R305 R205 R905 R905	6.5.7.3

Table 3-2 Adjustment Specifications (Cont.)

Parameter	Specified Value and Tolerance	Test Point	Adjustment	Adjustment Paragraph
TE178 Power +5 V (load 200 Ω)	5 Vdc $\pm$ 0.1 Vdc	A10A2	A7422 Resistor 2	TE178 Tech Manual Table 3-1
+5 V (zero load and control)	5 Vdc $\pm$ 0.1 Vdc	A20A2	IT722 Resistor 4	Table 3-3
-5 V	5.0 Vdc $\pm$ 0.5 Vdc	A01A2	H7422 Resistor 1	Table 3-10



Figures 2-4. GCR/PE Preamp + PCBs Test Points




Figure 3-2 Interconnect FI PCBA
a. L1/L2 Model






Figure 3-3 Interconnect FI PCBA
a. Currrent Model



VACUUM VALVE DETAIL



PRESSURE VALVE DETAIL

D-32866

Fig. 6-53 Vacuum Valve and Pressure Valve

Table 3-3 Vacuum and Pressure Valve Components

Reference	Description
A	Vacuum valve inlet pipe
B	Return air connections
C	Butterfly valve adjustment screw
D	Battery reel vacuum adjustment screw
E	Vacuum pressure switch
F	Battery reel vacuum port
G	Tape on reel switch
H	Vacuum input (to pneumatic assembly)
I	Butterfly valve lock nut
J	Air bearing pressure adjustment screw
K	Pressure input (to pneumatic assembly)
L	Thread block pressure adjustment screw
M	Thread block pressure port
N	Air bearing pressure pad

A.3 WRITE CURRENT ADJUSTMENTS

1. Verify power supply voltages according to Paragraph 6.2.1.
2. Load any write enable. 267 mm (10 7/8 in) tape to SOT. Leave the transport off-line.
3. Set the MIA switches as follows:

S1 = TWD (right)
 S2 = WRI (right)
 S3 = 1000 (left)
 S4 = MAN (right)

Data pattern (U106) signals all ones (all switches forward)

A. Phase Flooded Write Current Adjustments

1. Connect an oscilloscope to write PCBA (Figure 6-18) test point 6. Set the scope as follows:

Vertical, ch1 = 1.0 V/div, ac (X 0 probe)
 Horizontal = 0.2 μ s/div
 Sync = $\rightarrow$, Ch 1, 60

2. Place transport on-line. The tape starts moving forward.
3. Adjust write PCBA potentiometer R55 (PE step) for a 1.25 μ s $\pm$ 0.1 μ s positive pulse width.
4. Place transport off-line. The tape stops moving.
5. Move the scope probe to write PCBA TP3. Change the vertical scaling to 2.0 V/div, ac.
6. Place transport on-line.
7. Adjust write PCBA potentiometer R10 (PE step) for a 18.75 Vdc $\pm$ 0 Vdc level.

8. Move the strip probe to write PCBA TP2.
 9. Adjust write PCBA potentiometer R36 (PI pedestal) for a -6.0 Vdc (0 Vdc level).
 10. Place the transport on-line and rewind the tape to BOT.
- B. Group Coded Write Current Adjustments (Transport Off-line, Loaded, and at BOT, Port Switch to 0)**

Figure 3-4 shows the control waveform for the pedestal current and strip current at the tape head. You may want to use this figure as a reference. The GCR write current adjustments involve potentiometers R29, R22 and R48 on the write PCBA. To make these adjustments, proceed as follows.

NOTE:

Use a DVM for all measurements at TP2 and TP3 on the write PCBA.

1. Set MLA switches S1, S2, S3, and S4 to the right. Data path data (U196) equals all ones (all switches forward).
2. Place AGC switch (S1) on the rear module on the right.
3. Adjust R22 to set TP3 to 0 V.
4. Adjust R36 to set TP2 to 0 V.
5. Using a 10X probe, set an oscilloscope to 100 mv/div and 0.5 us/div. Place the probe on track 5 (R13) of the GCR/PI drawing 1 PCBA (Figure 2-2).
6. Load a standard output tape (or a good scratch tape) with the write protect ring in place. Place the transport on-line to start the tape moving.




Figure 3-4 Write Head Current Waveform

7. Adjust R39 counterclockwise (CCW) for peak amplitude. (The pedestal write current is low at the approximate start of the 100 percent saturation range.)
8. Measure and record the dc voltage at TP3.
9. Continue to adjust R39 CCW until the waveform amplitude begins to decrease. (This is the approximate end of the 100 percent saturation range.)
10. Measure and record the dc voltage at TP2. Place the transist off-line to stop tape motion.
11. Add the two voltages recorded in steps 8 and 10. Divide this sum by 2. Record the result of the division.
12. Place the transistor on-line and adjust R39 clockwise (CW) until TP3 is at the voltage calculated in step 11.
13. Adjust the scope's vertical sensitivity until the waveform's peak-to-peak amplitude covers the entire screen (8 unit).

14. Adjust R39 CCW until the peak-to-peak amplitude covers 7.5 cm (about 105 percent to guarantee media saturation). Then measure and record the voltage at TP5.
15. Set TP5 back to the voltage indicated in step 14.
16. Set the scope to 100 percent amplitude over 8 cm as in step 15.
17. Adjust R39 CW until the peak-to-peak amplitude covers 7.0 cm (about 95 percent saturation).
18. Adjust R29 until TP3 is at the voltage recorded in step 14. (The pedestal amp current is now set to about the 105 percent saturation point.)
19. Move the scope probe to TP6 on the write PCBAs. Using R48 (CUR step limit), set TP6 to 200 mV—10 percent at the 20 percent point.
20. Place the AGC switch back to the left position.

If any value is outside the specified range, perform this entire H.U. still cannot be met, the following field replaceable units should be suspected as being defective.

The Ready/Write/Tense Head
 The Write PCBAs
 The Read PCBAs
 The Preamp PCBAs

APPENDIX A SUBSYSTEM MASSBUS REGISTERS

Address	Register Name	Register Description
0000	0000	0000
0001	0001	0001
0002	0002	0002
0003	0003	0003
0004	0004	0004
0005	0005	0005
0006	0006	0006
0007	0007	0007
0008	0008	0008
0009	0009	0009
0010	0010	0010
0011	0011	0011
0012	0012	0012
0013	0013	0013
0014	0014	0014
0015	0015	0015
0016	0016	0016
0017	0017	0017
0018	0018	0018
0019	0019	0019
0020	0020	0020
0021	0021	0021
0022	0022	0022
0023	0023	0023
0024	0024	0024
0025	0025	0025
0026	0026	0026
0027	0027	0027
0028	0028	0028
0029	0029	0029
0030	0030	0030
0031	0031	0031
0032	0032	0032
0033	0033	0033
0034	0034	0034
0035	0035	0035
0036	0036	0036
0037	0037	0037
0038	0038	0038
0039	0039	0039
0040	0040	0040
0041	0041	0041
0042	0042	0042
0043	0043	0043
0044	0044	0044
0045	0045	0045
0046	0046	0046
0047	0047	0047
0048	0048	0048
0049	0049	0049
0050	0050	0050
0051	0051	0051
0052	0052	0052
0053	0053	0053
0054	0054	0054
0055	0055	0055
0056	0056	0056
0057	0057	0057
0058	0058	0058
0059	0059	0059
0060	0060	0060
0061	0061	0061
0062	0062	0062
0063	0063	0063
0064	0064	0064
0065	0065	0065
0066	0066	0066
0067	0067	0067
0068	0068	0068
0069	0069	0069
0070	0070	0070
0071	0071	0071
0072	0072	0072
0073	0073	0073
0074	0074	0074
0075	0075	0075
0076	0076	0076
0077	0077	0077
0078	0078	0078
0079	0079	0079
0080	0080	0080
0081	0081	0081
0082	0082	0082
0083	0083	0083
0084	0084	0084
0085	0085	0085
0086	0086	0086
0087	0087	0087
0088	0088	0088
0089	0089	0089
0090	0090	0090
0091	0091	0091
0092	0092	0092
0093	0093	0093
0094	0094	0094
0095	0095	0095
0096	0096	0096
0097	0097	0097
0098	0098	0098
0099	0099	0099

Figure A-1 X1120 and X11780 Addresses

Table A-1 Data Transfer Function Codes

Function Code (Go Bit Included)	Name	Description
51	WRITE CK FWD	Write Check Forward - Tape subsystem reads and records in a forward direction. Data is checked in RH controller.
52	WRITE CK REV	Write Check Reverse - Tape subsystem reads and records in a reverse direction. Data is checked in RH controller.
61	WRITE PE*	Write phase encoded records
63	WRITE GCR†	Write group-coded records
71	READ FWD	Read records forward
73	EXSNS	Read extended sense error log
77	READ REV	Read records reverse

*The recording density format is ignored unless the tape is pre-toned at a lead point. At lead point, the write command specifies the recording format of the entire tape.

DATA TRANSFER INTERRUPT REGISTER



755-327

Figure A-4 Data Transfer Interrupt Register





Figure A-4 Tape Control Register

EXCEPTION INTERRUPT CODE REGISTER



40-2047

Figure A-7 Exception Interrupt Code Register

12	11	10	09	08	07	06	05	04	03	02	01	00	
CONCRETE CURB													
						C	VST F4.0						
						0	00						

```
NO:DATA=KANSAS
NAME=...
TOTAL=60000
REFER=...

```

2004 2005 2006 2007 2008 2009 2010 2011 2012 2013 2014 2015 2016 2017 2018 2019 2020 2021 2022 2023 2024 2025 2026 2027 2028 2029 2030 2031 2032 2033 2034 2035 2036 2037 2038 2039 2040 2041 2042 2043 2044 2045 2046 2047 2048 2049 2050 2051 2052 2053 2054 2055 2056 2057 2058 2059 2060 2061 2062 2063 2064 2065 2066 2067 2068 2069 2070 2071 2072 2073 2074 2075 2076 2077 2078 2079 2080 2081 2082 2083 2084 2085 2086 2087 2088 2089 2090 2091 2092 2093 2094 2095 2096 2097 2098 2099 2100 2101 2102 2103 2104 2105 2106 2107 2108 2109 2110 2111 2112 2113 2114 2115 2116 2117 2118 2119 2120 2121 2122 2123 2124 2125 2126 2127 2128 2129 2130 2131 2132 2133 2134 2135 2136 2137 2138 2139 2140 2141 2142 2143 2144 2145 2146 2147 2148 2149 2150 2151 2152 2153 2154 2155 2156 2157 2158 2159 2160 2161 2162 2163 2164 2165 2166 2167 2168 2169 2170 2171 2172 2173 2174 2175 2176 2177 2178 2179 2180 2181 2182 2183 2184 2185 2186 2187 2188 2189 2190 2191 2192 2193 2194 2195 2196 2197 2198 2199 2200 2201 2202 2203 2204 2205 2206 2207 2208 2209 2210 2211 2212 2213 2214 2215 2216 2217 2218 2219 2220 2221 2222 2223 2224 2225 2226 2227 2228 2229 2230 2231 2232 2233 2234 2235 2236 2237 2238 2239 2240 2241 2242 2243 2244 2245 2246 2247 2248 2249 2250 2251 2252 2253 2254 2255 2256 2257 2258 2259 2260 2261 2262 2263 2264 2265 2266 2267 2268 2269 2270 2271 2272 2273 2274 2275 2276 2277 2278 2279 2280 2281 2282 2283 2284 2285 2286 2287 2288 2289 2290 2291 2292 2293 2294 2295 2296 2297 2298 2299 2300 2301 2302 2303 2304 2305 2306 2307 2308 2309 2310 2311 2312 2313 2314 2315 2316 2317 2318 2319 2320 2321 2322 2323 2324 2325 2326 2327 2328 2329 2330 2331 2332 2333 2334 2335 2336 2337 2338 2339 2340 2341 2342 2343 2344 2345 2346 2347 2348 2349 2350 2351 2352 2353 2354 2355 2356 2357 2358 2359 2360 2361 2362 2363 2364 2365 2366 2367 2368 2369 2370 2371 2372 2373 2374 2375 2376 2377 2378 2379 2380 2381 2382 2383 2384 2385 2386 2387 2388 2389 2390 2391 2392 2393 2394 2395 2396 2397 2398 2399 2400 2401 2402 2403 2404 2405 2406 2407 2408 2409 2410 2411 2412 2413 2414 2415 2416 2417 2418 2419 2420 2421 2422 2423 2424 2425 2426 2427 2428 2429 2430 2431 2432 2433 2434 2435 2436 2437 2438 2439 2440 2441 2442 2443 2444 2445 2446 2447 2448 2449 2450 2451 2452 2453 2454 2455 2456 2457 2458 2459 2460 2461 2462 2463 2464 2465 2466 2467 2468 2469 2470 2471 2472 2473 2474 2475 2476 2477 2478 2479 2480 2481 2482 2483 2484 2485 2486 2487 2488 2489 2490 2491 2492 2493 2494 2495 2496 2497 2498 2499 2500 2501 2502 2503 2504 2505 2506 2507 2508 2509 2510 2511 2512 2513 2514 2515 2516 2517 2518 2519 2520 2521 2522 2523 2524 2525 2526 2527 2528 2529 2530 2531 2532 2533 2534 2535 2536 2537 2538 2539 2540 2541 2542 2543 2544 2545 2546 2547 2548 2549 2550 2551 2552 2553 2554 2555 2556 2557 2558 2559 2560 2561 2562 2563 2564 2565 2566 2567 2568 2569 2570 2571 2572 2573 2574 2575 2576 2577 2578 2579 2580 2581 2582 2583 2584 2585 2586 2587 2588 2589 2590 2591 2592 2593 2594 2595 2596 2597 2598 2599 2600 2601 2602 2603 2604 2605 2606 2607 2608 2609 2610 2611 2612 2613 2614 2615 2616 2617 2618 2619 2620 2621 2622 2623 2624 2625 2626 2627 2628 2629 2630 2631 2632 2633 2634 2635 2636 2637 2638 2639 2640 2641 2642 2643 2644 2645 2646 2647 2648 2649 2650 2651 2652 2653 2654 2655 2656 2657 2658 2659 2660 2661 2662 2663 2664 2665 2666 2667 2668 2669 2670 2671 2672 2673 2674 2675 2676 2677 2678 2679 2680 2681 2682 2683 2684 2685 2686 2687 2688 2689 2690 2691 2692 2693 2694 2695 2696 2697 2698 2699 2700 2701 2702 2703 2704 2705 2706 2707 2708 2709 2710 2711 2712 2713 2714 2715 2716 2717 2718 2719 2720 2721 2722 2723 2724 2725 2726 2727 2728 2729 2730 2731 2732 2733 2734 2735 2736 2737 2738 2739 2740 2741 2742 2743 2744 2745 2746 2747 2748 2749 2750 2751 2752 2753 2754 2755 2756 2757 2758 2759 2760 2761 2762 2763 2764 2765 2766 2767 2768 2769 2770 2771 2772 2773 2774 2775 2776 2777 2778 2779 2780 2781 2782 2783 2784 2785 2786 2787 2788 2789 2790 2791 2792 2793 2794 2795 2796 2797 2798 2799 2800 2801 2802 2803 2804 2805 2806 2807 2808 2809 2810 2811 2812 2813 2814 2815 2816 2817 2818 2819 2820 2821 2822

三、

Table A-2. Nondata Transfer Parameter Codes

Function Code (Go Bit Included)	Name	Description
05	NO OP	Operates as unique NO OP parameter code
06	Unload ¹	Unloads tape and interrupts immediately
07	Rewind ¹	Rewinds tape and interrupts when done
1	Status ²	Data status information into CAS
13	Data Security Erase†	Erases remainder of tape and rewinds
15	WTM PE $\frac{1}{2}$	Writes phase encoded tape mark
17	WTM OCR $\frac{1}{2}$	Writes OCR tape mark
21	SP FWD REC	Spaces forward record, stops if tape mark
23	SP REV REC	Spaces reverse record, stops if tape mark or BOT
25	SP FWD FILE	Spaces forward file (to tape mark)
27	SP REV FILE	Spaces reverse file (to tape mark)
31	SP FWD EITHER	Spaces forward either record or file
33	SP REV EITHER	Spaces reverse either record or file
35	PRG PE $\frac{1}{2}$	Erases three inches of tape, sets PE

Table A-2 Nondata Transfer Function Codes (Cont.)

Function Code (to Bit 1 introduced)	Name	Description
37	ERG GCR §	Erases three inches of tape, sets GCR
41	Close File PE §	Writes two tape marks, spaces reverse and, sets PE
43	Close File GCR §	Writes two tape marks, spaces reverse and, sets GCR
45	SPACE LEFT	Spaces forward until two tape marks, spaces reverse one
47	SPACE FWD FWD/LEFT 1	Spaces forward to tape mark, steps if two successive tape marks (logical end of tape)

§ Sometimes interrupts when record starts; always interrupts after tape motion has stopped.

§ Sense registers are valid as long as the ATTN bit is set.

‡ Erases at least 3.03 in (10 1/4) beyond the BOT marker.

§ Recording format is ignored except when tape is at start of reel (BOT). It is specified by bit 1.

|| Do not use after any reverse operation; the FMTX may skip over an LBCT located where direction was reversed.

HARDWARE CONTROL REGISTER




Figure A-8 Hardware Control Register




Figure A-10 Configuration/Status Register




Figure A-1. Context Register




Figure A-12 Status Register



Figure A-13 Virtual Address Register




Figure A-14 H2 Counter Register




FIGURE A-15 Diagnostic Review




Figure A-5 Map Register

APPENDIX B

EXTENDED SENSE BYTES

Byte	Description
1	Command code being executed on last error
2	Interrupt code from last error
3	Failure code last error
4	Hardware register 0; read path write fail bits
5	Hardware register 1; read path diagnostic bits
6	Hardware register 2; read path status (Refer to Figure B-1)
7	Hardware register 3; read path control loop (Refer to Figure B-1)
8	Hardware register 20; AMTTS (CH 7:0) loaded the status of the AMTTS lines from the tape drive. This is a 48-min read of the M950 done bits by the M953 read path microcontroller
9	Hardware register 21; RC TRONT (CH 7:0). This bit will be false if the associated M950 has completed its assigned task
10	Hardware register 22; OCH illegal S-1, PE code error such as no bit time phase (read) or

use #6 (RSTAT)



READ PATH MICROCONTROLLER
STATUS CODES ARE RETURNED IN
THIS BYTE. TABLE B-10 DEFINES
EACH CODE AND ITS MEANING.

00000000

Figure B-1 Read Path Status Byte

Table B-1 Read Microcontroller Status Codes

Status	Meaning
Status resulting from an ECC self-test command	
101	ECC sequencer passed self-test
102	ECC sequencer failed self-test
Status resulting from an M8950 self-test	
103	Read path passed self-test
104	Read path failed self-test
Status resulting from an M8950 self-test command	
105	Read channel tests all passed
Status resulting from a channel test command for velocity control of drive by channel	
201	First test pulse Last test pulse (eleventh bit (last space))
Status resulting from a sample density command	
210	NOT CAPABLE found
211	GCR ID found
212	PB ID found
Status resulting from a write test of TRC, PB ID, GCR ID, AKA ID, or ARA found	
220	Bad status write test
Status resulting from a tape mark test sequence	
312	Good tape mark found on tape 221.2
Status resulting from a NON-BOT command (read or write FWD or REV, GCR, or PB)	
210	AKA ID found first record or TMI
231	Tape mark found
234	Possible end not found
235	Read path fault 1, too many M8950s have been failed in sequencing record processing

Table B-1 Read Microcontroller Status Codes (Cont)

Status	Meaning
235	Read path fault 2: 5 or more M8950 BLOADS found illegal 3 to 4 translations.
247	Unexpected IDG in data; probably created tape (7 or more AMTIES added)
261	Postamble long
262	Postamble short
377	OK




Figure B-7 Read Microcontroller Command Byte

Byte	Description
11	Hardware register 23; mask 2 (CH 7 0-RMK2)
12	Hardware register 24; end mask (CH 7 0-RENT) for read channels location; M8950s
13	Hardware register 25; RC PAR'ms (CH P) (Refer to Figure B-3)

Table B-2 Read Microcontroller Command Codes

Command	Description
00	NOP
01	Header block read
02	Test PE (ID) burst
03	Test CR (ID) burst
04	Test ARA (ID) burst
05	Test tape mark
06	Test ARA burst
07	Normal NON-BOT read
08	Run BMC self-test
09	Test link down ID burst
10	Run read channel micro's test
11	Diagnostic read channel read
12	Run read channel self-test
13	Run clear all BMC test program
14	Run ECC self-test program
15	Find gap




Figure B-3 Parity Read Channel Status Byte

Byte	Description
14	Hardware register 26; read channel PE postamble detect register (CH 70); location = M8950
15	Hardware register 27; data (CH 70) Data output from M8950 to ECC-M8951
16	Hardware register 30; CRC word (CRC checker output bits = location 8952)




Figure B-4 ECC Status Byte

Byte	Description
17	Hardware register 31: ECCOK. Corrected data (CH 7-0). Corrected data output from M8951 to M8952
18	Hardware register 32: ECC status - 8951 (Refer to Figure B-4)
19	Hardware register 40: channel 0 TIE bus (Refer to Figure B-5)
20	Hardware register 41: channel 1 TIE bus (Refer to Figure B-5)
21	Hardware register 42: channel 2 TIE bus (Refer to Figure B-5)
22	Hardware register 43: channel 3 TIE bus (Refer to Figure B-5)
23	Hardware register 44: channel 4 TIE bus (Refer to Figure B-5)
24	Hardware register 45: channel 5 TIE bus (Refer to Figure B-5)
25	Hardware register 46: channel 6 TIE bus (Refer to Figure B-5)
26	Hardware register 47: channel 7 TIE bus (Refer to Figure B-5)
27	Hardware register 50: channel P TIE bus (Refer to Figure B-5)

FSB PIN 27 (CONT'D)




Figure 8-5 Channel (N) Link to Error Data




Figure B-7 CAS Port (IN) Status Byte




Figure B-8 MASSBUS C-Rx Status Byte

- | Byte | Description |
|------|--|
| 40 | Hardware register 323: BYCNT1 <15:8>. Write byte count in word |
| 41 | Hardware register 324: PADCNT1 <7:0>. Write microbyte assembly pad character counter in word |
| 42 | Hardware register 325: PADCNT2 <7:0>. Write microbyte assembly pad character counter in word |
| 43 | Hardware register 326: ERRCNT <7:0>. In word bits 8–15. Write microbyte assembly error code |




Figure B-9 MASSBUS Data Bus Status Byte




Figure B-10 Write Microcontroller Error Byte

Byte	Description
44	Hardware register 326: CURRENT mode <15%> word bits 0-17. Refer to Appendix E in maintenance manual for bit codes
45	Hardware register 320: DDR A diagnostic data register A used to test bus between M8956 and M8959
46	Hardware register 321: DDR B. Diagnostic data register B used to test bus between M8956 and M8959
47	Hardware register 330 WMCERR (Refer to Figure B-10)




Figure D.1. Internet Usage Data

Figure H-17 U.S. Status Base

Byte	Description
48	Hardware register 340: INTSTA (Refer to Figure 5-11) Interrupt status byte on M4960
49	M4A register 0: ITR0 status (Refer to Figure 5-12)

Byte	Description
50	MIA register 1; MIA status A (Refer to Figure B-14)
51	MIA register 2; MIA status B (Refer to Figure B-14)
52	MIA register 3; SNTHL Serial number - thousands and hundreds digits (BCD)
53	MIA register 4; SNTHL serial number - tens and units digits (BCD)
54	MIA register 5; diag (Refer to Figure B-15)
55	Retry counter (RETCNT) - This byte is the count of retry interrupt requests given for the tape unit. When this count is zero, the tape unit is not in a retry sequence.
56	Retry control bits (RETCNT1) - This byte is used by the commands to control error recovery. It is read only when the retry counter (byte 55) is not zero. (Refer to Figure B-16)
57	TU software status (LUT) - This byte contains information about the tape drive. (Refer to Figure B-17)
58	Transfer control word (XFRCTL4) - This byte contains control information used by data transfer commands. (Refer to Figure B-18)
59	Retry suppress and format control (XFRTRY). This byte contains the contents of the left half of the MASSBUS register (CAS register 2), which contains the SERISuppress, Lock and Error Reporting and bit format, and strip count.
60	Keypad enable flag (ENON) - This byte is not zero when the keypad is enabled.




Figure B-15 MFA TL Diagnostic Byte




Figure B-1.5 Key Control Kyles




Figure B-17 Hardware Status





Figure B-18 Transfer Control Data



TUBE Schematic Data Block Diagram

