

.REM @

IDENTIFICATION

PRODUCT CODE: AC-E779D-MC
PRODUCT NAME: CZDRLDO DR11 GEN NPR INTFC
DATE RELEASED: OCTOBER, 1981
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: DAN P. MILLEVILLE

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1977, 1982 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	

34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52

HISTORY

REV

DATE

NOTE

A 1977
B 1980
C 1980
D 1981(ALL REV 'D' FIXES ARE
HIGHLIGHTED BY ';DPM001'
IN THE COMMENT FIELD)INITIAL RELEASE
CORRECTION OF CODING ERRORS
11/05 PROBLEM AND ENDLESS LOOP PROBLEM FIXED
> 11/10 PROBLEM - FAILS TEST 4 MISTAKENLY
> CORRECTION OF CODING PROBLEMS WHEN RUN
ON 11/34'S.
> ADDITION OF CODE TO CHECK THE POWER
MONITOR BIT OF THE CPU ERROR REGISTER,
IF ONE EXISTS.
> CHANGED AUTOSIZE ROUTINE TO PROMPT USER
FOR DEVICE ADDRESS IF NON-OPTION MANU-
FACTURING ENVIRONMENT (IF OPTION MANF.,
SIZING OCCURS AS BEFORE), AND (IF MODULE
FAILS TO INTERRUPT) ITS VECTOR AND
PRIORITY.

TABLE OF CONTENTS

53		
54		
55		
56	1.0	ABSTRACT
57		
58	2.0	REQUIREMENTS
59		
60		2.1 EQUIPMENT
61		2.2 HARDWARE SWITCH SETTINGS
62		2.3 STORAGE
63		
64	3.0	TESTING MODES
65		3.1 DEFINITION
66		3.2 IMPLEMENTATION
67		
68	4.0	LOAD AND START PROCEDURE
69		
70	5.0	SWITCH REGISTER
71		
72		5.1 OPTIONS
73		5.2 SOFTWARE SWITCH REGISTER
74		5.3 LOADING OF THE SOFTWARE SWITCH REGISTER
75		5.4 PROGRAM AND/OR OPERATOR ACTION
76		
77	6.0	ERROR REPORTING
78		
79	7.0	OPERATING MODES
80		
81		7.1 MANUAL MODE
82		7.1.1 EDIT FUNCTION
83		7.1.2 LIST FUNCTION
84		7.1.3 BURST CALIBRATION FUNCTION
85		7.1.4 RUN FUNCTION
86		
87		7.2 AUTO MODE
88		7.3 RESTART AFTER PREVIOUS RUN
89		7.4 TESTING UNDER APT
90		
91		
92	8.0	MISCELLANEOUS
93		
94		8.1 POWER FAIL
95		8.2 END-OF-PASS MESSAGE SPECIAL FEATURE
96		
97	9.0	EXECUTION TIMES

10.0 SUBROUTINE DESCRIPTIONS

10.1 READ
10.2 ERCAPT
10.3 FIXTBL
10.4 LODBUF
10.5 CHKBFF
10.6 INTA
10.7 DATCHK
10.8 CLENUP
10.9 CHKCAB
10.10 DATOCK
10.11 ERRCHK
10.12 BPINIT
10.13 DRGET
10.14 TYP CNF
10.15 ASIZE
10.16 CATCH
10.17 PSTATE
10.18 PNTPRI
10.19 SETUP
10.20 TSTMM

11.0 DATA STACKS

11.1 PATRNS
11.2 EXPATO
11.3 EXPAT1

126
127
128
129
130
131
132
133
134
135
136

1.0 ABSTRACT

THIS DIAGNOSTIC PROGRAM IS CAPABLE OF TESTING THE DR11-W
NPR GENERAL INTERFACE IN DR11-W OR DR11-B MODE.

IT HAS THE FOLLOWING FEATURES:

1. APT11/XXDP COMPATIBLE
2. MULTIPLE BOARD TESTING USING TABLE CREATED BY USER
3. BURST DATA LATE CALIBRATION
4. INDEPENDENT 'LOGIC WRAP-AROUND' AND 'CABLE WRAP-AROUND' TESTING

2.0 REQUIREMENTS

2.1 EQUIPMENT

1. PDP11 STANDARD COMPUTER
2. I/O TYPE TERMINAL
3. 1-16 DR11-W MODULE(S)
4. LOOP BACK CABLE (NEEDED TO FULLY CHECK THE MODULE WITH THIS DIAGNOSTIC)

2.2 HARDWARE SWITCH SETTINGS

THE ADDRESS SELECTION SWITCH, E120, IS SET UP AS BELOW:

	1	2	3	4	5	6	7	8	9	10
ADDRESS BITS:	12	11	10	9	8	7	6	5	4	3

EXAMPLE: DEVICE ADDRESS 172410, SWITCHES 1, 3, 5 & 10 SHOULD BE OFF, AND ALL OTHERS SHOULD BE ON.

THE E105 SWITCHPACK: THIS SWITCHPACK MUST BE IN THE FOLLOWING POSITIONS TO RUN THIS DIAGNOSTIC:

- 1 - OFF
- 2 - ON
- 3 - OFF
- 4 - OFF
- 5 - ON FOR -W MODE, OFF FOR -B MODE

SINGLE SWITCH NEAR THE E105 SWITCHPACK:

- 2 CYCLE MODE - SWITCH HANDLE TOWARDS PACK E105
- N CYCLE MODE - SWITCH HANDLE TOWARDS E94

THE VECTOR SELECTION SWITCH, E15, IS SET UP AS BELOW:

	1	2	3	4	5	6	7	8
VECTOR BITS:	1	2	3	4	5	6	7	8

EXAMPLE: VECTOR ADDRESS 300, SWITCHES 6 & 7 SHOULD BE OFF, AND ALL OTHERS SHOULD BE ON.

2.3 STORAGE

THE PROGRAM USES APPROX. 56000 WORDS OF MEMORY

3.0 TESTING MODE

3.1 DEFINITION

THE DR11-W DIAGNOSTIC ACCOMPLISHES DEVICE REGISTER BIT TESTS, INTERNAL "LOGIC" WRAP-AROUND TESTS, AND WITH THE BC06-R WRAP-AROUND CABLE IN J1 AND J2, PROVIDES EXTERNAL "CABLE" WRAP-AROUND TESTS. IN ORDER TO FULLY CHECK THE MODULE, THE DIAGNOSTIC MUST BE RUN WITH AND WITHOUT THE WRAPAROUND CABLE IN PLACE, RESTARTING AT ADDRESS 200 EACH TIME, OR EDITING TO CHANGE THE CABLE MODE (SEE SECT. 7.1.1)

THERE ARE ONLY TWO LEGAL MODES OF OPERATION OF THIS DIAGNOSTIC:

1. DR11 WITH NO CABLE(S) IN USER SLOTS.
2. DR11 WITH WRAP-AROUND CABLE FROM J1 TO J2.

THIS DIAGNOSTIC IS NOT MEANT TO BE RUN IN THE FOLLOWING MODES:

1. DR11 CONNECTED TO ANOTHER DR11.
2. DR11 CONNECTED TO A USER DEVICE.

3.2 IMPLEMENTATION

DEVICE REGISTER BIT TESTS AND INTERNAL LOGIC WRAP-AROUND TESTS ARE EXECUTED UNCONDITIONALLY. CABLE WRAP-AROUND TESTS ARE EXECUTED ONLY IF THE BC06-R CABLE IS IN PLACE BETWEEN THE J1 AND J2 CONNECTORS ON THE DR11-W UNDER TEST. THE PRESENCE OF THIS CABLE IS "SIZED" FOR AUTOMATICALLY FOR EACH BOARD WHEN THE DIAGNOSTIC IS STARTED AT ADDRESS 200. THE USER *MUST* VERIFY THAT THE "SIZING" OCCURRED CORRECTLY BY OBSERVING THE OUTPUT OF THE PROGRAM WHEN STARTING AT 200. (REFER TO SECTION 5.1 FOR EXAMPLE)

IN MANUAL MODE (STARTING ADDRESS = 204), THE USER CAN FORCE UNIFORM TESTING PARAMETERS FOR ALL MODULES THROUGH USE OF THE EDIT FUNCTION (REFER TO SECTION 7.1.1).

223
224
225
226
227
228
229

4.0 LOAD AND START PROCEDURE

1. LOAD PROGRAM INTO MEMORY.
2. LOAD STARTING ADDRESS 200, 204 OR 210. (SEE SECTS. 7.1, 7.2, 7.3
RESPECTIVELY)
3. PRESS START.

230 5.0 SWITCH REGISTER
231
232 5.1 OPTIONS
233
234 SWITCH OCTAL FUNCTION
235
236 SW15=1 100000 HALT ON ERROR
237
238 THIS WILL CAUSE THE PROCESSOR TO HALT AT THE
239 NEXT ERROR.
240
241 SW14=1 040000 LOOP ON TEST
242
243 THIS WILL CAUSE THE PROCESSOR TO LOOP ON THE
244 TEST IT IS THEN EXECUTING.
245
246 SW13=1 020000 INHIBIT ERROR TYPEOUTS
247
248 THIS WILL CAUSE ERROR TYPEOUTS TO BE INHIBITED.
249
250 SW12=1 01000

284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326

SW08=1

000400

LOOP ON TEST IN SWR<6:0>

THIS FUNCTION CAUSES THE CPU TO JUMP TO THE TEST IN BITS <6:0> AND EXECUTE THAT TEST UNCONDITIONALLY. CHANGE THE SWITCH REGISTER TO EXIT. TO CREATE A TIGHTER LOOP ON THAT PARTICULAR TEST, SET LOOP-ON-TEST (40000) IN THE SWR ONCE THE TEST IS EXECUTING.

SW07=1

000200

INHIBIT MULTIPLE ERROR TYPEOUTS

ON ERROR CALLS IN LOOPS WHERE MULTIPLE ERRORS ARE POSSIBLE, THIS FUNCTION INHIBITS ANY ADDITIONAL DATA THAT MAY PRINT IN THAT LOOP.
EXAMPLE:

MULTIPLE TYPEOUTS ENABLED:

[ERROR MESSAGE]

[DATA HEADER]

XXXXXX XXXXXX XXXXXX XXXXXX
XXXXXX XXXXXX XXXXXX XXXXXX
XXXXXX XXXXXX XXXXXX XXXXXX
XXXXXX XXXXXX XXXXXX XXXXXX
XXXXXX XXXXXX XXXXXX XXXXXX

>>>>>NOTE<<<<<<

A MAXIMUM OF 17 (OCTAL) DATA LINES WILL PRINT. IF THERE ARE MORE, A MESSAGE WILL PRINT AS FOLLOWS:

THERE ARE STILL MORE ERRORS, BUT WILL NOT BE PRINTED.
ERRORS WILL STILL BE COUNTED AND PRINTED AT THE EOP.

MULTIPLE TYPEOUTS DISABLED:

[ERROR MESSAGE]

[DATA HEADER]

XXXXXX XXXXXX XXXXXX XXXXXX

(NO MORE DATA WILL PRINT) THE TOTAL NUMBER OF ERRORS WILL STILL BE TOTALED AND PRINTED AT THE EOP OR EOD.

5.2 SOFTWARE SWITCH REGISTER

IF THE HARDWARE SWITCH REGISTER DOES NOT EXIST, OR IF ONE DOES AND IT CONTAINS '-1' (177777) THEN THE SOFTWARE SWITCH REGISTER (LOCATION 176) IS USED, WHICH ALLOWS THE USER THE SAME SWITCH OPTIONS AS THE HARDWARE SWITCH REGISTER.

5.3 LOADING THE SOFTWARE SWITCH REGISTER

THIS PROGRAM SUPPORTS THE DYNAMIC LOADING OF THE SOFTWARE SWITCH REGISTER (LOCATION 176) FROM THE TTY. THIS IS ACCOMPLISHED AS FOLLOWS:

375
376
377
378
379
380
381
382

6.0 ERROR REPORTING

EACH TEST WILL CALL AN ERROR CONTAINING THE TEST NUMBER, ERROR PC AND DATA THAT IS SIGNIFICANT TO THE PROBLEM THAT CAUSED THE ERROR.

IN THE CASE OF MULTIPLE BOARD TESTING, THE FAILING MODULE IS IDENTIFIED BY THE DEVICE REGISTER ADDRESS, AND THE END-OF-DEVICE-TEST MESSAGE FOLLOWING ALL ERRORS FOR THAT PARTICULAR MODULE.

7.0 OPERATING MODE

7.1 MANUAL MODE (STARTING ADDRESS = 204)

DEFINED AS NON-AUTOMATIC USE OF THE DIAGNOSTIC.

THIS MODE IS INTENDED FOR USE IN MANUFACTURING WHEN APT IS NOT AVAILABLE.

IN MANUAL MODE, ALL DR11-W HARDWARE

429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467

486
487
488
489
490
491
492
493
494
495
496
497
498
499
500

7.1.2 WHEN [L] IS ENTERED, THE PROGRAM ENTERS THE LIST FUNCTION
THE DIAGNOSTIC THEN PRINTS THE FOLLOWING:

# OF BOARDS	START REGADR	VECADR	W-B	P-LEV	2-N CYCLE	CABLE TESTS
XX	XXXXXX	XXX	X	X	X	X

AS PREVIOUSLY MENTIONED, ALL BOARDS MUST BE SPACED 10 ADDRESS LOCATIONS APART STARTING WITH THE 'REGADR' VALUE ABOVE, AND VECTORS SPACED 10 ADDRESS LOCATIONS APART STARTING WITH THE 'VECADR' VALUE ABOVE. THE EXPECTED W-B, PRIORITY LEVEL, 2-N CYCLE AND CABLE TEST STATES WILL BE THE SAME FOR ALL MODULES.

501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539

7.2 AUTO-SIZE MODE (STARTING ADDRESS = 200)

THIS MODE IS THE NORMAL FIELD SERVICE MODE. IT SUPPORTS STANDALONE OPERATION AS WELL AS SCRIPT OPERATION UNDER ACT11 OR XXDP (CHAIN).

THE DR11 DIAGNOSTIC HAS THE FOLLOWING RUN CHARACTERISTICS WHEN OPERATING IN AUTO MODE:

- A. THE

585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620

B. THE FOLLOWING WILL NOT BE OFFERED TO THE USER IN AUTOSIZE
MODE:

621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636

THE CONTROL X (^X) FEATURE BYPASSES THE SECTIONS THAT PRINT THE END-OF-PASS AND END-OF-DEVICE MESSAGES. THIS IS TO IMPROVE THE NUMBER OF PASSES EXECUTED OVER ANY PERIOD OF TIME, AS WELL AS MAKE OVERNIGHT OR WEEKEND RUNS USE NO PAPER (IF NO ERRORS). ERROR TYPEOUTS ARE NOT DISABLED IN THIS MODE. WHEN AN ERROR OCCURS, THE END-OF-PASS (EOP

637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672

THE CONTROL Y (^Y) FUNCTION CALLS FOR A SUMMARY OF DEVICE(S) AND PASS

673
674
675
676
677
678
679
680
681
682
683
684
685

7.3 RESTARTING PROGRAM IN MEMORY (STARTING ADDRESS = 210)

WHENEVER THE PROGRAM IS HALTED, ALL HISTORY OF PREVIOUS TESTING IS SAVED. IT WILL REMAIN INTACT UNTIL:

- 1

7.4 TESTING UNDER APT (AUTOMATED PRODUCT TESTING)

TO SET UP FOR MULTIPLE BOARDS FOR TESTING UNDER APT CONTROL,
THE APT SYSTEM MANAGER SHOULD ANSWER THE APT QUERIES TO THE
FOLLOWING ITEMS AS INDICATED BELOW:

SOFTWARE ENVIRONMENT: 000 - DUMP MODE
001 - SCRIPT MODE (APT MONITORS
DIAGNOSTIC)

ENVIRONMENT MODE (\$ENVM):

742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758

8.0 MISCELLANEOUS

8.1 POWER FAIL

IF A POWER FAILURE OCCURS AND BATTERY BACKUP MAINTAINS
THE PROGRAM IN MEMORY, OR A NON-VOLATILE MEMORY EXISTS,
THE PROGRAM WILL

759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781

8.2 END-OF-PASS MESSAGE

THE EOP WILL PRINT ONCE EVERY 20 SECONDS, APPROXIMATELY (17 SECONDS ON AN 11/44), AS FOLLOWS WITH NO ERRORS ON THAT PASS:

782
783
784
785
786

9.0 EXECUTION TIME

ON A PDP11/44:

IN ALL MODES: APPROXIMATELY 64 DEVICE PASSES IN 17 SECONDS, ALL MODES.

10.0 SUBROUTINE ABSTRACT

10.1 READ

THE READ SUBROUTINE IS USED IN THE EDIT ROUTINE TO INPUT UP TO 6 DIGITS IN OCTAL, 2 DIGITS IN DECIMAL, OR A SINGLE NON-NUMERIC CHARACTER. R4 IS USED AS THE LOCATION TO HOLD THE NUMBER IN OCTAL, AND IS CLEARED FOR THAT PURPOSE AT THE START OF THE SUBROUTINE. R3 IS TO BE PRELOADED WITH THE NUMBER OF DIGITS EXPECTED, SINCE A <CRLF

886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920

10.11 ERRCHK
THIS ROUTINE CLEARS IE AND UPDATES THE PC FOR RETURN AFTER THE ERROR IN THE TEST IF ERROR IS CLEAR. IF SET, RETURN IS EXEC

921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956

10.16

957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976

11.0 DATA STACK

11.1 PATRNS

THIS SET OF 7 DATA WORDS IS USED TO CHECK ANY LOCATION FOR STUCK

977
978

^a.NLIST MC,MD,CND

3032

```
.TITLE CZDRLDO-DR11 GEN NPR INTFC
;*COPYRIGHT (C) 1981
;*DIGITAL EQUIPMENT CORP.
;*MAYNARD, MASS. 01754
;*
;*PROGRAM BY DAN MILLEVILLE
;*
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-DZQAC-C5), JAN, 1981.
;*
```

3034

.SBTTL OPERATIONAL SWITCH SETTINGS

```

: *
: *      SWITCH      USE
: *      -----
: *      15          HALT ON ERROR
: *      14          LOOP ON TEST
: *      13          INHIBIT ERROR TYPE
```


3053			.SBTTL	DEFINITIONS OF THE CSR BITS
3054		..*****~*****		
3055	000001	GO	=1	:GO
3056				

```
3078 .SBTTL CSR BIT COMPLIMENT DEFINITIONS
3079 *****
3080 CGO      =177776 ;COMPLIMENT OF GO
3081 CF1      =177775 ;COMPLIMENT OF FNCT1
3082 CF2      =177773 ;COMPLIMENT OF FNCT2
3083 CF3      =177767 ;COMPLIMENT OF FNCT3
3084 CFNC     =177761 ;COMPLIMENT OF FNCT1 & FNCT2 & FNCT3
3085 CX6      =177757 ;COMPL
```

3102			.SBTTL COMPLEMENTS OF BIT DEFINITIONS
3103		*****	
3104	177776	CBIT0	=1

```
3121                                     .SBTTL PRIORITY LEVELS AND OTHER DEFINITIONS
3122                                     ;*****
3123                                000140      LEVEL3  =140
3124                                000200      LEVEL4  =200
3125                                000240      LEVEL5  =240
3126                                000300      LEVEL6  =300
3127                                000340      LEVEL7  =340
3128                                000033      ESC    =33
3129                                000003      CNTLC   =3
3130                                0
```


3175

001000
000046 000046
026324
000052 000052
000000
001000

3176

001000
000024

3437

3438 002264 052233

3439 002266 054527

3440 002270 055660

3441

3498

3499 002404 051352
3500 002406 053274
3501 002410 055404
3502 002412 000000

:ITEM 212

.WORD EM46
.WORD DM17
.WORD DT17
.


```
3590                                     .SBTTL  DEVICE DESCRIPTOR WORD BIT DESCRIPTION
3591                                     ;*****
3592                                     ; DESCRIPTION OF BITS IN THE DDW (DEVICE DESCRIPTOR WORD):
3593                                     ;
3594                                     ;      BIT 0   DR11-W=0, DR11-B=1
3595                                     ;      BIT 1   2 CYCLE=0, N CYCLE=1
3596                                     ;      BIT 2   CABLE DOESN'T EXIST=0, CABLE DOES EXIST=1
3597                                     ;      BIT 5   \
359
```


3706				.SBTTL SUBROUTINE TO LOAD INBUF WITH AN INCREMENTING PATTERN
3707				*****
3708				THIS SUBROUTINE CLEARS THE FIRST LOCATION OF THE BUFFER AND LOADS
3709				


```

3821                                     .SBTTL SUBROUTINE TO CHECK FOR CABLE MODE AND ALTER EXPECTED DATA
3822                                     :*****
3823                                     :
3824                                     :   THIS SUBROUTINE CHECKS THE DDW (DEVICE DESCRIPTOR WORD) FOR THE CABLE
3825                                     :   BEING IN OR OUT AND SETS BITS 12, 10, 8 AND 6 IN THE EXPECTED DATA
3826                                     :   LOCATION IF THE CABLE IS OUT.
3827                                     :
3828                                     :*****
3829 003670 032737 000004 002720 CHK CAB: BIT    #BIT2,DD
```


