MAINDEC: -08-DIRXA-C-D

TITLE: -RX8/RX01 DIAGNOSTIC PROGRAM

AUTHOR: -MIKE STURAK
-HANK POULTER
-DON RICE

DATE: -JULY, 1976

MAINTAINER: -DIAGNOSTIC ENGINEERING

COPYRIGHT (C) 1975, 1976
DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.

THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DEC.

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORTATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

1. ABSTRACT

2. REQUIREMENTS

    2.1 EQUIPMENT
    2.2 STORAGE
    2.3 PRELIMINARY DIAGNOSTIC PROGRAMS

3. LOADING PRODEEDURE

4. STARTING PROCEDURE

    4.1 STARTING ADDRESS LOCATIONS
    4.2 OPERATOR ACTION
    4.3 PROGRAM ACTION
    4.4 TEST PARAMATER SELECTIONS

        4.4.1 RESTRICTIONS

5. OPERATING PROCEDURE

6. ERROR DETECTION

    6.1 PROGRAM DEFINITIONS OF:

        6.1.1 WRITE ERROR
        6.1.2 READ ERROR (CRC)
        6.1.3 CRC AND DATA ERROR
        6.1.4 NO CRC BUT DATA ERROR
        6.1.5 CRC BUT NO DATA ERROR

            6.1.5.1 SUMCHECK ERROR

        6.1.6 SEEK ERROR
        6.1.7 PARITY ERROR

    6.2 DIFINITIVE ERROR CODES

    6.3 UNEXPECTED OR MISSING ERROR CONDITIONS:

        6.3.1 MISSING D.D. MARK
        6.3.2 UNEXPECTED D.D. MARK
        6.3.3 MISSING ERROR FLAG
        6.3.4 UNEXPECTED RXØ1 IRQ
        6.3.5 DEVICE TEST HUNG

    6.4 SYSTEM FAILURES: (UNKNOWN IRQ)

7. ERROR REPORTING

7.1 EXAMPLES

7.1.1 EXAMPLES OF INTERFACE / CONTROL RELATED ERRORS
7.1.2 EXAMPLES OF DRIVE / DATA RELATED ERRORS

7.1.2.1 SEEK ERROR
7.1.2.2 WRITE-CRC AND DATA ERROR
7.1.2.3 READ-CRC AND DATA ERROR
7.1.2.4 WRITE-CRC BUT NO DATA ERROR

7.2 ERROR RECOVERY
7.3 FATAL ERROR RECOVERY

8. MANUAL INTERVENTION

8.1 FIELD ENGINEERING TROUBLE SHOOTING AIDS

9. DIAGNOSTIC TEST STRATEGY

10. CONSOLE PACKAGE ADDENDUM

11. APT-8 INTERFACES

12. PROGRAM LISTING

1. ABSTRACT

THIS PROGRAM IS DESIGNED TO TEST THE RX01 FLEXIBLE DISKETTE SUBSYSTEM CONFIGURED AS A COMPLETE SUBSYSTEM, (RX8 INTERFACE, RX01 CONTROL, AND DISKETTE DRIVES), OR AS A PARTIAL SUBSYSTEM (INTERFACE, AND/OR CONTROL). OBVIOUSLY THE MAXIMUM RESOLUTION POSSIBLE IS ACHIEVED BY TESTING THE RX01 DISKETTE SUBSYSTEM CONFIGURED AS A COMPLETE SUBSYSTEM.

***
REVISION C

THE ADDITION OF THE CONSOLE PACKAGE.
THE REMOVAL OF TEST THREE (3).
SEE LISTING LOCATION FOR EXPLINATION
THE REMOVAL OF DECIMAL CONVERSION ROUTINES.
THE ADDITION OF APT-8 INTERFACES.

***

2. REQUIREMENTS

2.1 EQUIPMENT

A PDP-8/E TYPE GENERATION COMPUTER WITH 4K OF CORE, CONSOLE SWITCHES, TELETYPE, AND AN RX01 DISKETTE SUBSYSTEM.

THE DIAGNOSTIC CAN RUN WITHOUT HARDWARE SWITCH IF THE CONSOLE PACKAGE IS USED. IF THE CONSOLE PACKAGE IS ACTIVE 8K OF CORE IS NEEDED.

2.2 STORAGE

THIS PROGRAM IS DESIGNED TO BE RUN STAND ALONE AND MUST OCCUPY PROGRAM LOCATIONS 0 THRU 7577 OF FIELD 0.

THE CONSOLE PACKAGE OCCUPIES FIELD 1 LOCATIONS 200 TO 2000.

FIELD 1 IS NEEDED ONLY IF THE CONSOLE PACKAGE IS BEING USED.

2.3 PRELIMINARY DIAGNOSTIC PROGRAMS

THIS PROGRAM ASSUMES THAT THE HOST PDP IS FUNCTIONING CORRECTLY.

3. LOADING PROCEDURE

THIS PROGRAM IS IN BINARY FORMAT. TO LOAD THIS PROGRAM INTO CORE, FOLLOW THE INSTRUCTIONS PUBLISHED FOR THE PARTICULAR BINARY FORMAT LOADER BEING USED.

4. STARTING PROCEDURE

4.1 STARTING ADDRESS LOCATIONS

THIS PROGRAM HAS 2 STARTING ADDRESS LOCATIONS:

200 * DIAGNOSTIC PROGRAM *

STARTING THIS PROGRAM AT PROGRAM LOCATION 200, AND SUCCESSFULLY SUPPLYING THE NECESSARY TEST PARAMATERS REQUESTED, DIRECTS THIS PROGRAM TO BEGIN TESTING THE RX01 SUBSYSTEM AS A SUBSYSTEM OR PARTIAL SUBSYSTEM.
THE ADDRESS THAT THE CONSOLE PACKAGE WILL START THE DIAGNOSTIC AT IS LOCATION 200.

201 * RESTART OF DIAGNOSTIC PROGRAM *

STARTING THIS PROGRAM AT PROGRAM LOCATION 201 DIRECTS THE PROGRAM TO CONTINUE TESTING THE RX01 SUBSYSTEM AS A SUBSYSTEM OR PARTIAL SUBSYSTEM USING THE PARAMATERS SUPPLIED AT STARTING ADDRESS 200.

4.2 OPERATOR ACTION

CONFIGURE THE ACCUMULATOR SWITCHES TO REPRESENT THE OCTAL PROGRAM STARTING ADDRESS LOCATION DESIRED, PRESS " LOAD ADDRESS ", PRESS " CLEAR ", AND FINALLY PRESS " CONT " INUE. IF THE CONSOLE PACKAGE IS ACTIVE THEN ISSUEING THE R DIRXA COMMAND WILL LOAD THE PROGRAM FROM A DISKETTE.

4.3 PROGRAM ACTION

THE PROGRAM HAS PRINTED ON THE TELEPRINTER THE PRESENT " MAINDEC " REVISION, AND, IF THE PROGRAM STARTING ADDRESS PROGRAM LOCATION IS:

* 200 *

AND THE CONSOLE PACKAGE IS ACTIVE THE DIAGNOSTIC WILL PRINT "REMOVE DIAGNOSTIC DISKETTE" AND WAIT FOR A *** CONTROL E ***
THE PROGRAM WILL CONTINUE RUNNING AFTER THE OPERATOR REMOVES THE DIAGNOSTIC DISKETTE AND REPLACES IT WITH A SCRATCH DISKETTE.
TO CONTINUE TYPE CONTROL E.

THE PROGRAM IS REQUESTING TEST PARAMATER INFORMATION TO BE SUPPLIED BY BY THE OPERATOR VIA THE PDP SWITCHES.

* 201 *

THE PROGRAM HAS RECONFIRMED PREVIOUS TEST PARAMATER SELECTIONS BY PRINTING APPROPRIATE MESSAGES ON THE TELEPRINTER, AND HAS RESUMED TESTING.

4.4 TEST PARAMETER SELECTIONS

AFTER STARTING THIS PROGRAM AT STARTING ADDRESS 200, THE PROGRAM WILL PRINT " SELECT PARAMATERS (INCLUDING DEVICE CODE) " AND HALT OR PRINT THE SWITCH REGISTER QUESTION IF THE CONSOLE PACKAGE IS ACTIVE.

THE OPERATOR WILL THEN CONFIGURE CONSOLE SWITCHES 0, AND 1 TO REPRESENT DISKETTE DRIVE SELECTION, CONSOLE SWITCH 2 TO REPRESENT RX01 MICROCONTOLLER CABLE CONNECTION TO RX8 INTERFACE, CONSOLE SEITCHES 3, 4, AND 5 TO REPRESENT RX8 INTERFACE IOT DEVICE CODE, AND FINALLY CONSOLE SWITHCHES 7 THRU 11 TO REPRESENT THE [STARTING] TEST , AND THEN PRESS " CONT " INUE.(SEE RESTRICTIONS)

C O N S O L E
S W I T C H E S

```
0  1  2  3  4  5  6  7  8  9 10 11

U  U  C  X  X  X  -  T  T  T  T  T
                      (STARTING TEST)
```

0 = 0 - DISKETTE DRIVE(S) IS READY
1 = 0 - (POWER APPLIED / DOOR CLOSED)

2 = 0 - RX01 MICROCONTROL CABLED TO RX8 INTERFACE

3 = - FOR STANDARD DEVICE CODE
4 = - POSITION CONSOLE SWITCHES
5 = - 3-4-5 = 0

7 = - TO EXECUTE ALL TESTS
8 = - CONFIGURE CONSOLE SWITCHES
9 = - 7 THRU 11
10= - EQUIVALENT TO ZERO
11= - (THIS IS THE STARTING TEST)

THE PROGRAM WILL PRINT A CONFIRMATION MESSAGE, THEN BEGIN TESTING THE RX01 SUBSYSTEM AS A SUBSYSTEM OR PARTIAL SUBSYSTEM WITH THE FIRST TEST CONFIGURED WITHIN CONSOLE SWITCHES 7 THRU 11.

TO TEST THE RX01 DISKETTE SUBSYSTEM AS A COMPLETE SUBSYSTEM, CONFIGURE CONSOLE SWITCHES 0, 1, AND 2 TO REPRESENT ZERO. THE PROGRAM WILL ASSUME ALL DRIVE(S) ARE READY (POWER APPLIED / DOOR CLOSED).

NOTE, HOWEVER, THAT TESTING THE RX01 DISKETTE SUBSYSTEM AS A PARTIAL SUBSYSTEM IS MORE THAM MERELY CONFIGURING CONSOLE SWITCHES 0, 1, AND 2 TO REPRESENT VALUES OTHER THAN ZERO.

IF ONLY THE CONTROL / INTERFACE PARTIAL SUBSYSTEM (NO DRIVES) IS THE THE UNIT UNDER TEST (UUT), THEN THE DISKETTE DRIVE(S) CABLE (IF ANY) MUST BE PHYSICALLY REMOVED FROM THE RX01 CONTROLLER, OR, THE DRIVES MUST BE RENDERED " NOT READY " (DOOR OPEN), THEN THE CONSOLE SWITCHES 0, AND 1 EACH MUST BE CONFIGURED TO REPRESENT A " 1 ".

IF ONLY THE INTERFACE PARTIAL SUBSYSTEM (NO DRIVES AND CONTROL) IS THE UUT THEN THE BC05-L CABLE FROM THE INTERFACE TO THE CONTROL MUST BE PHYSICALLY

MOVED, ONLY THEN MAY CONSOLE SEITCHES 0, 1, AND 2 BE CONFIGURED TO RE-PRESENT A " 1 ".

4.4.1 RESTRICTIONS
////////////////////

A SELECT GROUP OF TESTS ARE DESIGNED TO CONFIRM THE RESULTS OF PREVIOUS TESTS. THE FOLLOWING IS AN OVERVIEW OF THOSE TESTS WHICH REQUIRE A PREVIOUS TESTS TO HAVE EXECUTED CORRECTLY.

...FOR THIS TEST TO FUNCTION CORRECTLY...		...THIS TEST MUST HAVE PREVIOUSLY EXECUTED CORRECTLY...
T14, T15	/	T13

TEST 14, AND TEST 15 EMPTY THE SECTOR BUFFER IN 12-BIT MODE COMPARING THE CONTENTS TO THE EXPECTED DATA PATTERN FILLED BY TEST 13.

T17, T20	/	T16

TEST 17, AND TEST 20 EMPTY THE SECTOR BUFFER IN 8-BIT MODE COMPARING THE CONTENTS TO THE EXPECTED DATA PATTERN FILLED WITHIN TEST 16.

T24, T25, T26	/	T22

THE SECTOR BUFFER SHOULD REMAIN UNCHANGED AND CONTAIN THE DATA PATTERN FILLED WITHIN TEST 22 AFTER THE RX01 CONTROL ATTEMPTS TO SEEK SECTOR 0.

T27	/	T22

THE CONTENTS OF THE SECTOR BUFFER SHOULD REMAIN UNCHANGED AND CONTAIN THE DATA PATTERN FILLED WITHIN TEST 22 AFTER THE RX01 CONTROLLER ATTEMPTS TO SEEK AN ILLEGAL TRACK GREATER THAN 114.

T32	/	T31

TEST 32 ISSUES AN INITIALIZE WHICH PERFORMS AN " IMPLIED READ " OF TRACK 1 / SECTOR 1. THE PROGRAM COMPARES THE DATA FROM THE SECTOR BUFFER WHICH SHOULD BE EQUIVALENT TO THE DATA WRITTEN WITHIN TEST 31 (FIRST WRITE EVER).

T33 / T31

TEST 33 ISSUES THE FIRST READ EVER OF THE TRACK / SECTOR WRITTEN WITHIN TEST 31 AND COMPARES THE DATA EXPECTING THE DATA PATTERN OF TEST 31.

5. OPERATING PROCEDURE
////////////////////////

THE OPERATOR MAY CONTROL THE DYMANIC ACTION OF THE PROGRAM BY APPROPRIATELY CONFIGURING THE ACCUMULATOR SWITCHES AS DESCRIBED BELOW.

IF THE CONSOLE PACKAGE IS ACTIVE THEN THE SETTING OF THE SWITCH REGISTER UNDER DYMANIC CONDITIONS IS POSSIBLE BY TYPING CONTROL D THIS WILL PRINT THE SWITCH REGISTER QUESTION AND ALLOW CHANGES TO IT THEN CONTINUE RUNNING.

```
Ø = 1 - HALT AT DETECTION OF AN ERROR
1 = 1 - HALT AT THE END OF A TEST PASS
2 = 1 - (LONG) DATA COMPARISON ERROR PRINTOUT
3 = 1 - INHIBIT ERROR PRINTOUTS
4 = 1 - LOCK SCOPE LOOP ON ERROR
5 = 1 - LOCK SCOPE LOOP ON TEST (OK OR NOT)
6 = 1 - INHIBIT THE ISSUING OF [INIT] AT ERROR
11= 1 - DISABLE THE RINGING OF THE BELL AT AN ERROR
```

6. ERROR DETECTION

6.1 PROGRAM DEFINITIONS

THIS PROGRAM HAS DEFINED THE FOLLOWING AS ERRORS:

6.1.1 WRITE ERROR
//////////////////

A WRITE ERROR IS A READ ERROR IF THE DATA BEING READ IS OF UNKNOWN QUALITY (THE DATA BEING READ IS BEING READ FOR THE FIRST TIME AFTER ITS WRITING) .

6.1.2 READ (CRC) ERROR - (TRANSFER REGISTER STATUS BIT 11 = 1)
//////////////////////

A READ ERROR IS A READ ERROR WHERE THE QUALITY OF THE DATA BEING READ IS KNOWN (THE DATA BEING READ HAD BEEN READ SUCCESSFULLY SOME TIME PREVIOUSLY).

6.1.3 CRC AND DATA ERROR
////////////////////////

6.1.4 NO CRC BUT DATA ERROR
////////////////////////////

6.1.5 CRC BUT NO DATA ERROR
////////////////////////////

THESE DATA ERRORS ARE DETECTED WHEN THE PROGRAM IS VERIFYING THE DATA THAT " SHOULD HAVE BEEN READ " WITH THE DATA THAT " ACTUALLY WAS READ " BY COMPARING THE " BAD " COLUMN TO THE " GOOD " COLUMN.

WORD#	GOOD	BAD
1	(TRACK IDENTIFICATION BITS 5-11)	
2	(SECTOR IDENTIFICATION BITS 8-11)	

WORDS 3 THRU 62 (IF 12-BIT MODE), OR
BYTES 3 THRU 126 (IF 8-BIT MODE) CONTAIN
THE OPERATORS PPP SELECTION.

63 (OR BYTE 127) - THE SUM OF ALL WORDS 1 THRU 62
OR BYTES 1 THRU 127.

64 OR (BYTE 128) - THE NEGATIVE OF 2 TIMES
THE VALUE OF WORD # 63 OR BYTE # 127.

6.1.5.1 SUMCHECK ERROR
//////////////////////

THE PROGRAM DETECTS A " SUM-CHECK " ERROR BY SUMMING ALL THE ACTUAL (BAD) DATA COLUMN AND COMPARING THAT SUM TO 0.

THE REASON FOR THE FIRST 2 WORDS/BYTES CONTAINING TRACK / SECTOR IDENTIFICATION CODES IS TO DETECT ADDRESSING ERRORS.

THE REASON FOR THE LAST 2 WORDS/BYTES CONTAINING CHECKSUM INFORMATION IS TO DISTINGUISH BETWEEN WHAT MIGHT RESEMBLE AN ADDRESSING ERROR (IF THE PROGRAM DETECTED AN ERROR WHEN COMPARING THE FIRST 2 WORDS/BYTES) AND A CRC ERROR.

6.1.6 SEEK ERROR - (NO ALLOCATED TRANSFER REGISTER STATUS BIT)
////////////////

A SEEK ERROR HAS BEEN DEFINED AS " NOT A CRC ", AND " NOT A PARITY " ERROR.

6.1.7 PARITY ERROR - (TRANSFER REGISTER STATUS BIT 10 = 1)
//////////////////

A PARITY ERROR IS AN ERROR WHICH RESULTS FROM AN INCORRECT TRANSFER OF THE COMMAND WORD FORM THE RX8 INTERFACE TO THE RX01 MICROPROCESSOR CONTROL.

6.2 DEFINITIVE ERROR CODES
//////////////////////////

THE RX01 MICROCONTROLLER HAS DEFINED ERROR CODES AND MEANINGS WHICH ARE AVAILABLE TO THE PROGRAM BY ISSUING COMMAND #7 TO " READ THE B-CODE ".

A DEFINITIVE ERROR CODE REPRESENTS [WHERE] WITHIN A MICRO-FUNCTION THE ERROR WAS DETECTED.

THE FOLLOWING ARE THE DEFINITIVE ERROR CODES AND MEANINGS:

0	-	NO ERROR
10	-	DRIVE 0 FAILED TO SEE HOME FROM INITIALIZE
20	-	DRIVE 1 FAILED TO SEE HOME FROM INITIZLIAE
30	-	HOME FOUND WHEN STEPPING OUT 10 TRACKS FROM INIT
40	-	TRIED TO ACCESS A TRACK GREATER THAN 77(DECIMAL)
50	-	HOME WAS FOUND BEFORE DESIRED TRACK
60	-	SELF DIAGNOSTIC ERROR
70	-	DESIRED SECTOR NOT FOUND AFTER SAMPLING 52 HEADERS
100	-	WRITE PROTECT ERROR
110	-	MORE THAN 40US AND NO SEP CLOCK DETECTED
120	-	A PREAMBLE COULD NOT BE FOUND
130	-	PREAMBLE FOUND BUT NO ID MARD FOUND IN TIME
140	-	CRC ERROR ON SUPPOSIDLY GOOD HEADER
150	-	GOOD HEADER(NO CRC ERROR) BUT TRACK COMPARE ERROR
160	-	IDAM NOT FOUND IN TOME
170	-	DATA AM NOT FOUND IN TIME
200	-	DATA CRC ERROR
210	-	ALL PARITY ERRORS

6.3 UNEXPECTED OR MISSING ERROR CONDITIONS

6.3.1 MISSING DD MARK

THIS ERROR MAY OCCUR WHEN THE PROGRAM EXPECTED A DELETED DATA MARK BUT NONE OCCURED.

6.3.2 UNEXPECTED DD MARK

THIS ERROR MAY OCCUR WHEN THE PROGRAM HAD NOT EXPECTED A DELETED DATA MARK BUT ONE OCCURED.

6.3.3 MISSING ERROR FLAG

THIS ERROR MAY OCCUR WHEN THE CONTENTS OF THE TRANSFER REGISTER AT DONE TIME ARE NOT 0, AND THE ERROR FLAG IS CLEARED.

6.3.4 UNEXPECTED RX01 IRQ

THIS ERROR MAY OCCUR WHEN THE PROGRAM HAS NOT YET ENABLED THE RX8 INTERRUPT ENABLE FLIP-FLOP BUT AN INTERRUPT OCCURED.

6.3.5 DEVICE TEST HUNG

THIS ERROR MAY OCCUR WHEN THE PROGRAM EXPECTS BUT FAILED TO RECIEVE A PROGRAM INTERRUPT REQUEST FROM THE RX01 SUBSYSTEM WITHIN AN ALLOTTED PERIOD OF TIME (APPROXIMATELY 4 SECONDS).

6.4 UNKNOWN IRQ

THIS ERROR MAY OCCUR WHEN THE PROGRAM HAS FAILED TO IDENTIFY THE DEVICE ISSUING A PROGRAM INTERRUPT REQUEST.

7. ERROR REPORTING
////////////////////

ALL ERRORS DETECTED WILL BE REPORTED IF AC SW 3 = 0. THE PROGRAM HAS TWO ERROR REPORTING SCHEMES.

7.1.1 EXAMPLES IF INTERFACE / CONTROL RELATED ERRORS

THE FOLLOWING INFORMATION IS PRINTED FOR ALL INTERFACE / CONTROL RELATED ERRORS.

```
ERR     FAT     FAST    -       EAC     GOOD    PASS
```

```
ERR     - PROGRAM ADDRESS OF THE ERROR
FAT     - FIRST ADDRESS OF THE TEST IN ERROR
FAST    - FIRST ADDRESS OF THE SUBTEST WITHIN THE TEST
-       - SEE ASSEMBLY LISTING FOR MAP
EAC     - ERROR AC (ACTUAL) RESULT OF TEST
GOOD    - EXPECTED RESULT OF TEST
PASS    - PASS # AT ERROR
```

7.1.2 EXAMPLES OF DRIVE / DATA RELATED ERRORS

THE FOLLOWING INFORMATION IS PRINTED FOR ALL DRIVE / DATA RELATED ERRORS.

```
CMND    XDR    CODE    RSTA    START      TARGET    PASS
```

```
CMND    - COMMAND TO THE RX01 MICROCONTROLLER
XDR     - CONTENTS OF THE TRANSFER REGISTER AT ERROR/DONE
CODE    - DEFINITIVE ERROR CODE (VIA COMMAND #7)
RSTA    - STATUS (VIA COMMAND #5)
START   - STARTING TRACK/SECTOR ACTUATOR POSITION
TARGET  - TARGET TRACK/SECTOR ACTUATOR POSITION
PASS    - PASS # AT ERROR (TO 16777215 DECIMAL)
```

7.1.2.1 SEEK ERROR

```
CMND    XDR     CODE    RSTA    START   TARGET  PASS
0014    0100    0120    0300    [HOME]  1    1
INIT    0       0120    0200    [HOME]  [HOME]
```

A SEEK ERROR OCCURED WHILE TRYING TO " WRITE DELETED DATA " (CMND #14) ONTO TRACK 1 SECTOR 1.

```
COMD    - WRITE DELETED DATA
XDR     - DELETED DATA MARK
CODE    - A PREAMBLE COULD NOT BE FOUND
RSTA    - DRIVE READY + DELETED DATA
START   - HOME POSITION
TARGET  - TRACK 1, SECTOR 1
```

THEN THE PROGRAM ISSUED AN INITIALIZE AT AN ATTEMPT TO RECOVER FROM THE " SEEK " ERROR.

```
CMND    - MEANS IOT 67X7 [INIT] WAS ISSUED
XDR     - MUST BE SEEK (NOT CRC OR PARITY)
CODE    - A PREAMBLE COULD NOT BE FOUND
RSTA    - DRIVE READY
START   - HOME POSITION
TARGET  - HOME POSITION
```

7.1.2.2 WRITE-CRC AND DATA ERROR

```
CMND    XDR     CODE    RSTA    START   TARGET  PASS
0026    0001    3200    0201    100,30  100,1
WRITE-CRC AND DATA ERROR
WORD    GOOD    BAD
4       5435    5473
5       6617    5437
6       6303    4606
SUMCHECK IS 1253
TOTAL BAD=60
```

WHILE READING SECTOR 7 OF TRACK 100 THE PROGRAM DETECTED A CRC ERROR.

THE PROGRAM EXPANDS THE STANDARD ERROR FORMAT TO INCLUDE DATA COMPARISON INFORMATION IF THE TEST IS A DATA COMPARISON TEST.

IF AC SWITCH 2 =1 THEN A [LONG] DATA COMPARISON PRINTOUT WOULD HAVE OCCURRED OF [ALL] THE WORDS/BYTES IN ERROR.

THE WORD " WRITE " WITHIN THE EXPANSION MEANS THAT THE DATA OF SECTOR 7 HAD NEVER BEEN READ BEFORE, THEREFORE THE PROGRAM ASSUMED IT WAS WRITTEN INCORRECTLY.

7.1.2.3 READ-CRC AND DATA ERROR

```
CMND    XDR     CODE    RSTA    START   TARGET  PASS
0026    0001    0200    0201    100,30  100,1
READ-CRC AND DATA ERROR
WORD    GOOD    BAD
4       5435    5477
5       6617    5437
6       6303    5406
SUM-CHECK IN 1257
TOTAL BAD=60
```

WHILE SEEKING SECTOR 1 OF TRACK 100 THE PROGRAM DETECTED A CRC ERROR.

THE PROGRAM EXPANDS THE STANDARD ERROR FORMAT TO INCLUDE DATA COMPARISON INFORMATION IF THE TEST IS A DATA COMPARISON TEST.

IF AC SWITCH 2 = 1 THEN A [LONG] DATA COMPARISON ERROR PRINTOUT WOULD HAVE OCCURRED OF [ALL] THE WORDS/BYTES IN ERROR.

THE WORD " READ " WITHIN THE EXPANSION MEANS THAT THE DATA OF SECTOR 7 HAD BEEN READ SOME TIME PREVIOUSLY, THEREFORE THE PROGRAM ASSUMES THAT THE DATA WAS WRITTEN CORRECTLY BUT READ INCORRECTLY.

7.1.2.4 WRITE-CRC BUT NO DATA ERROR

CMND	XDR	CODE	RSTA	START	TARGET	PASS
0026	0001	0200	0201	100,30	100,1	

WRITE - CRC BUT NO DATA ERROR

A CRC ERROR WAS DETECTED AFTER READING SECTOR 1 OF TRACK 100.

THE WORD " WRITE " WITHIN THE DATA EXPANSION MEANS THAT THE DATA OF SECTOR 1 TRACK 100 HAD NEVER BEEN READ BEFORE THEREFORE THE PROGRAM ASSUMED IT WAS WRITTEN INCORRECTLY, AND BECAUSE THE PROGRAM DID NOT DETECT A DATA COMPARISON ERROR, IT ASSUMED THAT THE 2 CRC CHARACTERS WERE WRITTEN INCORRECTLY.

7.2 ERROR RECOVERY
//////////////////////

THE PROGRAM WILL ATTEMPT TO RETRY ALL ERRORING FUNCTIONS 10 TIMES. A RECOVERABLE ERROR (SOFT) IS ONE WHICH DISAPPEARS WITHIN 10 PROGRAM RETRYS. AN UNRECOVERABLE ERROR (HARD) IS ONE WHICH REMAINS AFTER 10 PROGRAM RETRYS.

THE PROGRAM WILL ISSUE IOT 67X7 [INIT] FOR ALL ERRORS BUT DEFINITIVE ERROR CODES 140, 200, AND 210.

140 - CRC ERROR ON SUPPOSIDELY GOOD HEADER
200 - DATA CRC ERROR
210 - PARITY ERROR

THESE ERRORS ARE [NOT] SEEK TYPE ACTUATOR RELATED ERRORS.

IF A HARD WRITE ERROR IS DETECTED THE PROGRAM ABORTS FURTHER TESTING THIS PASS OF THAT TRACK/SECTOR BUT CONTINUES TESTING TRACKS. ON THE REMAINING

A SYMPATHETIC HARD READ ERROR MAY OCCUR (PATTERN DEPENDENT) IF THE HARD WRITE ERROR HAD OCCURRED WITHIN A TEST WHICH WOULD EVENTUALLY READ THAT SECTOR AND A SYMPATHETIC HARD DATA COMPARISON ERROR MAY OCCUR IF THAT TEST WAS TO VERIFY THE DATA TO A KNOWN PATTERN.

7.3 FATAL ERROR RECOVERY

IF THE PROGRAM DETECTS ANY OF THE SUCCEDING FATAL ERROR CONDITIONS, THE PROGRAMS RECOVERY WILL BE THAT OF EXITING THE PRESENT TEST.

(A) HARD PARITY ERROR
(B) A SELECTED DRIVE BECOMING NOT READY
(C) NO EXPECTED RX01 INTERRUPT REQUEST
(D) MISSING ERROR FLAG
(E) LOG OVERFLOW
(F) DEVICE TEST HUNG.

8. MANUAL INTERVENTION

8.1 FIELD ENGINEERING TROUBLE SHOOTING AIDS

THE FIELD ENGINEER, BY ALTERING THE CONTENTS OF SPECIFIC PROGRAM MAINTENANCE LOCATIONS, IS ABLE TO DIRECT THE PROGRAM TO PERFORM TESTING UPON A PARTICULAR AREA [WINDOW] OF THE DISKETTE INSTEAD OF THE ENTIRE SURFACE. THESE PROGRAM LOCATIONS ARE LABLED "OD" "ID", "FIRST, AND "LAST".

"OD" (OUTSIDE DIAMETER), PROGRAM LOCATION 30, IS THE INITIAL OUTER-MOST TRACK THE PROGRAM WILL ACCESS.

"ID" (INSIDE DIAMETER), PROGRAM LOCATION 31, IS THE FINAL INNERMOST INNERMOST TRACK THE PROGRAM WILL ACCESS.

"FIRST", PROGRAM LOCATION 32, IS THE FIRST SECTOR TO BE ACCESSED OF A TRACK.

"LAST", PROGRAM LOCATION 33, IS THE LAST SECTOR TO BE ACCESSED OF A TRACK.

THE STANDARD ASSEMBLED CONTENTS OF THESE FIELD ENGINEERING MAINTENANCE LOCATIONS ARE:

```
        *30

OD,     52      /INITIAL TRACK TO TEST
ID,     53      /FINAL TRACK TO TEST
FIRST,  1       /FIRST SECTOR OF A TRACK
LAST,   32      /LAST SECTOR OF A TRACK
```

THESE ARE THE ONLY FIELD ENGINEERING MAINTENANCE PROGRAM LOCATIONS DESIGNED TO BE EXTERNALLY ALTERED.

THE PROGRAM WILL PRINT A MAINTENANCE VERIFICATION MESSAGE IF THE CONTENTS OF THE MAINTENANCE LOCATIONS ARE NOT THE ASSEMBLED STANDARDS.

THE OCTAL CONTENTS OF THESE MAINTENANCE LOCATIONS MUST BE WITHIN THE RESTRICTED LIMITS WHICH ARE:

```
0 <= OD <= ID
0 <= ID <= 114
1 <= FIRST <= LAST
1 <= LAST <= 32
```

THE PROGRAM VERIFIES THE CONTENTS OF EACH MAINTENANCE LOCATION. THE PROGRAM WILL SET INTO THE MAINTENANCE LOCATION THE STANDARD VALUE IF THE DESIRED CONTENTS WERE NOT WITHIN THE REQUIRED SPECIFIED LIMITS.

NOTE, THAT TRACK 0 IS NOT INCLUDED WITHIN THE STANDARD [WINDOW] OF TESTABLE TRACKS. THE REASONE FOR THIS IS NOT TO INADVERENTLY DESTROY THE FORMATTED CONTENTS OF TRACK 0.

TO EXPAND THE WINDOW OF TESTABLE TRACKS INCLUDING TRACK 0, THE CONTENTS OF PROGRAM LOCATIONS " OD " MUST BE ZERO.

IN SUMMARY, IF THE CONTENTS OF PROGRAM LOCATIONS OD, ID, FIRST, AND LAST WERE 30, 30, 1, 1, RESPECTIVELY, THE PROGRAM WOULD PERFORM SELECTED TESTING ONLY UPON TRACK 30, SECTOR 1.

9. DIAGNOSTIC TEST STRATEGY

THE PDP-8 DIAGNOSTIC PACKAGE, WHICH CONTAINS THE RX8/RX01 DIAGNOSTIC PROGRAM, MAINDEC-08-DIRXA-, AND THE RX8/RX01 DATA RELIABILITY/EXERCISER PROGRAM, MAINDEC-08-DIRXB-, IS DESIGNED TO COMPLETELY TEST THE RX8/RX01 SUBSYSTEM WHEN EACH PROGRAM IS RUN TO ITS NATURAL COMPLETION COMMENCING WITH THE RX8/RX01 DIAGNOSTIC PROGRAM.

THE RX8 DIAGNOSTIC PROGRAM CONTAINS EFFICIENT MAINTENANCE SCOPING LOOPS, WHILE THE RX8/RX01 DATA RELIABILITY/EXERCISER PROGRAM CONTAINS DISKETTE COMPATABILITY VERIFICATION.

10. CONSOLE PACKAGE

TABLE OF CONTENTS

10.1. ABSTRACT

10.2. REQUIREMENTS

10.3. RESTRICTIONS

10.4. STANDARD OPERATING PROCEDURE
10.4.1 INITIALIZATION
10.4.2 CONTROL CHARACTERS
10.4.3 WAITING MESSAGE
10.4.4 SWITCH REGISTER MESSAGE
10.4.5 END OF PASS MESSAGE

10.5. ERRORS
10.5.1 ERROR HALTS

10.6. SWITCH REGISTER SETTINGS
10.6.1 OPERATING SWITCHES
10.6.2 ERROR SWITCHES

10.7. LOCATION CHANGES

10.8. PROGRAM DESCRIPTION

10.9. DIALOGUE FOR CONSOLE PACKAGE

10.10. LISTING

10.1. ABSTRACT

THE CONSOLE PACKAGE HAS BEEN ADDED TO THIS DIAGNOSTIC TO ALLOW THE PROGRAM TO RUN WITH NO HARDWARE SWITCH REGISTER AND TO HAVE COMMUNICATIONS WITH THE DIAGNOSTIC VIA A TERMINAL.

THE DIAGNOSTIC CAN BE RUN IN TWO MODES WITH THE CONSOLE PACKAGE . 1) RUNNING WITH THE CONSOLE PACKAGE ACTIVE - THIS ALLOWS THE OPERATOR CONTROL OF THE DIAGNOSTIC THROUGH THE TERMINAL. THE DIAGNOSTIC WILL ASK FOR THE VALUE OF THE PSEUDO SWITCH REGISTER,BEFORE COTINUING WITH EXECUTION OF THE DIAGNOSTIC ALL ERROR WILL BE PRINTED ON THE TERMINAL AND THE NUMBER OF PASSES WILL BE PRINTED. THERE WILL BE NO HALTS EXECUTIED .

2) CONSOLE PACKAGE NOT ACTIVE-THIS WILL RESULT IN THE USE OF HALTS FOR ERROR, HALTS AT END OF PASS IF SELECTED,USE OF THE HARDWARE SWITCH REGISTER ,NOT ASKING THE SWITCH QUESTION.

10.2. REQUIREMENTS

10.3. RESTRICTIONS

1) RUNNING THE CONSOLE PACKAGE REQUIRES THAT THE PSEUDO SWITCH REGISTER BE USED.

2) ONCE RUNNING THE CONSOLE PACKAGE NONACTIVE AND NOW DESIRE TO RUN IT ACTIVE. ONE MUST RELOAD THE DIAGNOSTIC AND INITILIZE FOR A ACTIVE CONSOLE PACKAGE.

3.) THE CONSOLE PACKAGE IS LOCATED IN FIELD 1 THERE MUST BE 8K OF CORE TO RUN THE CONSOLE PACKAGE.

10.4. STANDARD OPERATION PROCEDURE

10.4.1 INITIALIZATION

FOR A ACTIVE CONSOLE PACKAGE

1.) LOAD ADDRESS 0021

2.) SET TO 0000 INDICATOR FOR USING THE PSEUDO SWITCH REGISTER

3.) LOAD ADDRESS 0022

4.) SET SR3=1 (400) INDICATOR FOR USING A ACTIVE CONSOLE PACKAGE

5.) LOAD STARTING ADDRESS OF PROGRAM AND BEGIN

FOR A NON ACTIVE CONSOLE PACKAGE

1.) LOAD ADDRESS 0021

2.) SET SR0=1 (4000) TO INDICATE A HARDWARE SWITCH REGISTER

3.) LOAD ADDRESS 0022

4.) SET TO 0000 TO INDICATE A DEACTIVE CONSOLE PACKAGE

5.) LOAD STARTING ADDRESS OF PROGRAM AND BEGIN

10.4.2 CONTROL CHARACTERS

CONTROL CHARACTERS ARE USED TO GIVE THE OPERATOR THE ABILITY TO PERFORM THE FOLLOWING FUNCTIONS.
NOTE: THE PROGRAM WILL RESPOND TO THE CONTROL CHARACTER IN FIVE (5) SECONDS OR LESS.

CONTROL C
: THIS WILL START THE LOADER THAT IS IN LOCATION 7600.

CONTROL R
: THIS WILL RESTART THE PROGRAM AND REASK THE SWITCH REGISTER QUESTION.

CONTROL E
: THIS WILL CONTINUE THE PROGRAM FROM A ERROR IF ALLOWED BY THE DIAGNOSTIC OR FROM A WAITING STATEMENT.

CONTROL S
: THIS WILL STOP PROGRAM EXECTUION AND WAIT FOR A CONTROL Q BEFORE PRINTING . THIS IS A NONPRINTING CHARACTER.

CONTROL Q
: THIS IS TO CONTINUE A PROGRAM AFTER A CONTROL Q IS TYPED.THIS IS A NONPRINTING CHARACTER.

10.4.3 WAITING MESSAGE

THE WAITING MESSAGE IS USED TO ALLOW THE OPERATOR TIME
TO MAKE A DECISION AS TO WHAT CONTROL CHARACTER
TO TYPE. THIS MESSAGE MAY APPEAR AT THE END
OF PASS MESSAGE IF THE HALT ON ERROR BIT IS SET.THE CONTROL
CHARACTERS MAY NOW BE USED TO PERFORM THE NEEDED FUNCTION.
THE WAITING MESSAGE MAY BE PRINTED AFTER A ERROR MESSAGE
IF THE HALT ON ERROR BIT IS SET.HERE AGAIN THE CONTROL
CHARACTERS MAY BE USED.
THE WAITING MESSAGE MAY BE PRINTED IF OPERATOR INTERVENTION
IS REQUIRED..

10.4.4
SWITCH REGISTER MESSAGE

THIS MESSAGE IS USED TO SETUP THE PSEUDO SWITCH REGISTER
BEFORE PROGRAM EXECUTION TAKES PLACE.THE SWITCH REGISTER
IS SETUP WHEN THE FOURTH CHARACTER IS ENTERED OR A CARRIAGE
RETURN IS TYPED

```
**************************************************************
SR=0000 4000
        ----
```

UNDER SCORING INDICATES OPERATOR RESPONCE

10.4.5
END OF PASS

A INDICATION WILL BE GIVEN WHEN THE DIAGNOSTIC HAS MADE A
SUCESSFULL PASS. THE PRINT OUT WILL INDICATE THE DIAGNOSTIC
MAINDEC NUMBER THE WORD PASS AND A FOUR DIGIT PASS NUMBER.
A PASS WILL BE A TIME PERIOD RATHER THAN A PROGRAM PASS
OF THE DIAGNOSTIC. THE TIME PERIOD WILL BE IN THE RANGE OF
ONE (1) TO FIVE (5) MINUTES. IF THE DIAGNOSTIC MAKES A PROGRAM
PASS IN THE 1 TO 5 MINUTE RANGE THEN THE PASS COUNT WILL BE THE
SAME AS THE NUMBER OF PROGRAM PASSES.IF THE PROGRAM MAKES A
PROGRAM PASS IN LESS THEN ONE MINUTE THEN THE PASS COUNT WILL
NOT BE THE SAME AS THE PASS COUNTER THE PASS COUNTER WILL
REFLECT MORE THEN ON PROGRAM PASS.
THE NUMBER OF PROGRAM PASSES REQUIRED FOR "A PASS MESSAGE
CAN BE FOUND IN LOCATION CALLED "CNTVAL".
IF HALT AT END OF PASS IS SET THEN THE PASS MESSAGE WILL BE
PRINTED AND A WAITING STATEMENT WILL ALSO BE PRINTED.
A CONTROL CHARACTER IS NEEDED TO CONTINUE FROM THIS MESSAGE.
THE FORMAT OF THE END OF PASS MESSAGE IS

```
NAME PASS 0001 ( - OR I OR C OR D )
                - AN ERROR OCCURED DURING I,C,D
                I INTERFACE TEST OK RX8
                C RX8 AND RX01 TESTED OK
                D RX8 AND RX01 AND DRIVE TESTED OK
**************************************************************
```

10.5. ERRORS

UPON DETECTION OF A ERROR THE DIAGNOSTIC WILL DO ONE OF
THE FOLLOWING OPERATIONS:
1.) PRINT THE ERROR MESSAGE FOR THE ERROR CONDITION
    CHECK THE SWITCH REGISTER TO SEE IF THE PROGRAM SHOULD HALT
    IF HALT ON ERROR IS SELECTED THEN WAITING WILL BE PRINTED
    TO GO ON FROM THE ERROR TYPE CONTROL E
REFERE TO THE LISTING AT THE LOCATION PRINTED IN THE ERROR
PC FOR THE CAUSE OF THE ERROR.

10.5.1 ERROR HALTS

CONSOLE PACKAGE DEACTIVE WILL CAUSE NO ERROR MESSAGE
TO BE PRINTED.A HALT WILL REPLACE THE ERROR CALL IN THE
CODE AND THE DIAGNOSTIC WILL THEN GO TO THAT HALT.
REFER TO THE LISTING FOR THE CAUSE OF THE ERROR,THE ERROR
LOCATION WILL BE THE SAME IF THE CONSOLE PACKAGE WAS ACTIVE.

10.6. SWITCH REGISTER SETTINGS

THE FOLLOWING SWITCH REGISTER SETTINGS ARE USED BY THE CONSOLE
PACKAGE. THESE SWITCH REGISTER SETTINGS ARE VALID WHEN USING
THE HARDWARE SWITCH REGISTER AND THE PSEUDO SWITCH REGISTER.

10.6.1 OPERATING SWITCHES

THE CONSOLE PACKAGE USES THE LOCATIONS 20 21 22 FOR THE
FOLLOWING PURPOSES.

LOCATION 20
PSEUDO SWITCH REGISTER

LOCATION 21
HARDWARE IDENTIFIER 1

LOCATION 22
HARDWARE IDENTIFIER 2

LOCATION 0022

BIT	OCTAL VALUE	FUNCTION WHEN 0	FUNCTION WHEN 1
0	4000	NOT ON ACT8A LINE	ON ACT 8A LINE
1	2000	NOT ON ACT 8E LINE	ON ACT 8E LINE
2	1000	NOT YET DEFINED	
3	400	DEACTIVE CONSOLE PACKAGE	ACTIVE CONSOLE PACKAGE

6.2 ERROR RELATED SWITCHES

THESE ARE THE SWITCH REGISTER SETING THAT THE CONSOLE PACKAGE WILL RECOGNISE.

BIT	OCTAL VALUE	FUNCTION WHEN 0	FUNCTION WHEN 1
0	4000	CONTINUE AFTER ERROR	STOP AFTER ERROR
1	2000	CONTINUE AFTER END OF PASS	STOP AFTER END OF PASS
2	1000	SHORT ERROR PRINTOUT	LONG DATA COMPARISON ERROR PRINTOUT
3	400	PRINT ERROR MESSAGES	DO NOT PRINT ERRORS
4	200	NO SCOPE LOOP ON ERROR	LOCK SCOPE LOOP ON ERROR
5	100	NO SCOPE LOOP ON TEST	LOCK SCOPE LOOP ON TEST(OK OR NOT)
6	40	ISSUE[INIT]AT ERROR	DO NOT ISSUE [INIT] AT ERROR
11	1	RING BELL ON ERROR	NO BELL RINGING

10.7. LOCATION CHANGES

THE FOLLOWING LOCATIONS CAN BE CHANGED TO MEET THE SPECIFIC NEED FOR MODIFICATION OF THE DIAGNOSTIC.

CNTVAL — IS THE LOCATION FOR THE VALUE OF THE NUMBER OF PROGRAM PASSES NEED TO PRINT THE END OF PASS MESSAGE.

FILLER — IS THE LOCATION SET FOR THE NUMBER OF FILLER CHARACTERS AFTER A CRLF SET TO FOUR (4)

10.8. PROGRAM DESCRIPTION

```
PARAMETER SELECTIONS:
BITS 0-1
SELECT DRIVES:  0000 =SELECT DRIVES 0 AND 1
                4000 =SELECT DRIVE 1
                2000 =SELECT DRIVE 0

BIT2
DRIVE/CONTROLLER TESTS
0000 =DO DRIVE AND CONTROLLER
1000 =DO CONTROLLER ONLY


BITS 3-5
DEVICE CODE SELECTION
PUT ONE DIGITE DEVICE CODE IN HERE
THE PROGRAM ASSUMES THE FIRST DIGIT TO BE 7

EXAMPLE :IF DEVICE CODE IS 75 ENTER A 500
BITS 7-11

TEST SELECTION
PUT IN TEST YOU WISH TO RUN
A 00 TEST SELECTION IS ALL TESTS
```

10.9. DIALOGUE FOR CONSOLE PACKAGE

THE DIALOGUE FOR THIS DIAGNOSTIC IS:

```
R DIRXA (CR)

MAINDEC-08-DIRXA-B                  /THE -B IS THE REVISION LEVEL

REMOVE DIAGNOSTIC DISKETTE          /THE PROGRAM WILL WAIT FOR
                                    /A CONTROL E BEFORE CONTINUING

SELECT PARAMATERS(INCLUDING DEVICE CODES)
SR=0500                             /DEVICE CODE SELECTED IS 75
                                    /0500=DRIVES 0 AND 1 DEVICE CODE 75
                                    /4500=DRIVE 1 DEVICE CODE 75
                                    /2500=DRIVE 0 DEVICE CODE 75

TEST PARAMATERS: 0500               /VERIFICATION FOR PARAMETERS

OD=0001 ID=0114 FIRST= 0001 LAST= 0032  /DISKETTE RANGE SELECTED

SR=0500 6000                        /6000= SWITCH SETTING STOP ON ERROR AND
                                    /AT END OF PASS
```

11. APT-8 INTERFACES

11.1 DESCRIPTION

TWO INTERFACES HAVE BEEN PROVIDED WHICH WILL ALLOW THIS DIAGNOSTIC TO RUN UNDER THE STANDARD APT-8 SYSTEM. THESE INTERFACES ARE:

1. TIMING INTERFACE

2. ERROR INTERFACE

EACH WILL BE EXPLAINED IN MORE DETAIL.

11.2 SETUP

IN ORDER TO RUN UNDER APT-8, ADDRESSES 20 AND 22 MUST BE ESTABLISHED PRIOR TO RUNNING THE PROGRAM UNDER APT-8 CONTROL. THE FOLLOWING INFORMATION MUST BE INDICATED:

1. DEVICE CODE OF RX01 CONTROLLER UNDER TEST.

2. RX01 CONTROLLER CABLED TO INTERFACE.

3. DRIVE OR DRIVES TO BE TESTED.

4. DIAGNOSTIC RUNNING UNDER THE APT-8 SYSTEM.

5. STARTING TEST NUMBER IF OTHER THEAN THAT FOR ACCEPTANCE.

ADDRESS 20

ADDRESS 20 IS USED TO ESTABLISH ALL BUT ITEM 4.
THE SET UP IS THE SAME FOR THAT OF THE STANDARD SWITCH REGISTER FUNCTION.

```
        0  1  2  3  4  5  6  7  8  9 10 11

        U  U  C  X  X  X  -  T  T  T  T  T
                             (STARTING TEST)

                0 = 0   - DISKETTE DRIVE(S) IS READY
                1 = 0   - (POWER APPLIED / DOOR CLOSED)

                2 = 0   - RX01 MICROCONTROL CABLED TO
                          RX8 INTERFACE

                3 =     - FOR STANDARD DEVICE CODE
                4 =     - POSITION CONSOLE SWITCHES
                5 =     - 3-4-5 = 0

                7 =     - TO EXECUTE ALL TESTS
                8 =     - CONFIGURE CONSOLE SWITCHES
                9 =     - 7 THRU 11
                10=     - EQUIVALENT TO ZERO
                11=     - (THIS IS THE STARTING TEST)
```

NOTE: IF MORE THAN ONE DEVICE CODE IS AVAILABLE ON THE SYSTEM THE DIAGNOSTIC WILL HAVE TO RELOADED AND THE PROPER DEVICE CODE SELECTED.

ADDRESS 22

THIS ADDRESS IS USED TO INDICATE THAT THE PROGRAM IS RUNNING ON APT-8, THE NUMBER OF DRIVES TO BE DONE, AND IF SINGLE DRIVE TESTING.

BIT ZERO MUST BE A ONE (1) TO INDICATE THAT THE DIAGNOSTIC IS RUNNING ON APT-8.

CAUTION:

WHILE UNDER APT-8 CONTROL THE HARDWARE SWITCH REGISTER IS FUNCTIONAL, IT IS RECOMMENDED THAT THE SWITCH REGISTER BE SET TO ZERO PRIOR TO START-UP.

11.3 APT-8 INTERFACES.

11.3.1 TIMING

APT-8 IS NOTIFIED OF PROGRAM RUN BETWEEN .2 SECONDS AND 2.0 SECONDS. THIS WILL ALLOW THE DIAGNOSTIC TO RUN UNDER THE MUCH SLOWER MOS MEMORY WITHOUT CAUSING APT-8 TO GIVE A TIMEOUT ERROR.

11.3.2 ERRORS

ONLY THE ERROR PC IS REPORTED TO APT-8. THE TYPE OF ERROR CAN BE DETERMINED FROM THE CORRESPONDING ADDRESS IN THE PROGRAM LISTING. THERE IS A POSSIBILITY THAT A TIMEOUT ERROR MAY OCCUR. THIS IS CAUSED BY THE ERROR "HUNG DEVICE". THE PROGRAM WILL HAVE TO BE RERUN IN DUMP MODE IF THIS SHOULD HAPPEN.

11.4 LOADING PRECAUTIONS

THIS PROGRAM SHOULD BE LOADED IN SRCIPT MODE INDICATING TO APT-8 THAT CORE SUMCHECKS ARE TO BE IGNORED.

12. PROGRAM LISTING

```
                        /RX8 RX01 DIAGNOSTIC DIRXA-C
                0001            FIELD 1
                        /CONSOL SRC-V1R4-  CONSOL PACKAGE



                        /SET UP A LAS TO BE EQUALL TO THE CALL C8CKSW

                        /PROGRAM SHOULD CHECK FOR A CONTPOL CHARACTER FROM THE CONSOL
                        /EVERY FIVE SECONDS OR LESS



                        /SETUP CNTVAL FOR A RANGE OF 1 TO 4 MINUTES FOR C8PASS TO PRINT PASS
                        /SETUP OF CNTVAL WILL BE FOUND IN C8PASS
                        /THIS VALUE SHOULD BE A POSITIVE NUMBER.


                        /SET UP XDOSW AS THE VALUE NEEDED FOR A RETURN FOR CONTROL R
                        /RETURN TO ASK THE SWITCH REGISTER QUESTION.

                        /CHANGE 1 AND 2 APRIL 16 1975

                        /CHANGE 3 APRIL 18,1975

                        /CHANGE 4 APRIL 22 1975

                        /CHANGE 5 APRIL 23 1975


                        /CHANGE 6 APRIL 24,1975


                        /CHANGE 7 APRIL 25,1975



                        /THE CALL TABLE IS A CONDITIONAL ASSEMBLY.
                        / TO ASSEMBLE THE CALL REMOVE THE / BEFORE CONSOL  =0.
                        /IN COMBINING THE CONSOL PACKAGE TO A DIAGNOSTIC.
                        / THE CALL TABLE IS TO BE AT THE BEGINNING OF A PROGRAM.
                        /CONSOL=0
                6661            PSKF=   6661
                6662            PCLF=   6662
                6663            PSKE=   6663
                6664            PSTB=   6664
                6665            PSIE=   6665
                6004            GTF=    6004
                7701            ACL=    7701
                6007            CAF=    6007
                7421            MQL=    7421
                4461            HLT=    HALT
                        /#6
                7501            MQA=    7501
                        /#6
```



```
                0200            *200
                        /**********************************************************************
                        /C8PASS
                        /THIS IS CALLED AT THE END OF EACH PROGRAM COMPLETION
                        /THE VALUE OF** CNTVAL** WILL BE DETERMINED BY THE TIME IT TAKES
                        /THE PROGRAM TO COMPLEATE THIS MANY C8PASS TO BE IN THE 1 TO 4 MINUTE
                        /RANGE
                        /       C8PASS=JMS      XC8PAS
                        /EX.            C8PASS
                        /               HLT                     /HALT IF NON CONSOL PACKAGE
                        /               JMP     START1          /CONTINUE RUNNING THIS PROGRAM
                        /RETURN TO LOCATION CALL PLUS ONE WITH THE AC=0 IF NON CONSOL PACKAGE AND HLT
                        /IF CONTINUE TO RUN THEN RETURN TO CALL PLUS2 AC=0

0200  0000    XC8PAS, 0
0201  4777'            JMS     C8CK22          /CHECK IF CONSOL IS ACTIVE
0202  5210            JMP     DOPACK          /IS CLASSIC
0203  4267            JMS     XC8SW                   /CHECK SR SETTING
0204  0376            AND     (400            /FOR HALT ON END OF C8PASS
0205  7640            SZA CLA                 /1= HALT 0 CONTINUE
0206  5234            JMP     C8EXT1          /DO ONE EXIT
0207  5233            JMP     C8BY1           /CONTINUE ON RUNNING PROGRAM
0210  4236    DOPACK, JMS     CKCOUT          /CLASS CHECK C8PASS COUNT
0211  5233            JMP     C8BY1           /C8PASS COUNT NOT DONE REDO PROGRAM
0212  2255            ISZ     PASCNT          /C8PASS COUNT DONE SET C8PASS COUNT
                        /#2
0213  4775'            JMS     XC8CRL
                        /#2
0214  4317            JMS     XC8PNT                  /C8PRNT BUFFER
0215  0260            MESPAS                  /
0216  1255            TAD     PASCNT          /GET NUMBER
0217  4774'            JMS     XC80CT                  /CONVERT IT TO ASCII
0220  6201            CDF 0
0221  1653            TAD I   XMX             /GET THE CHAR TO PRINT
0222  6211            CDF 10
0223  3236            DCA     CKCOUT          /STORE FOR PRINTING
0224  4317            JMS     XC8PNT          /PRINT IT
0225  0236            CKCOUT
0226  4775'            JMS     XC8CRL                  /DO A CARRIAGE RETURN
0227  4267            JMS     XC8SW                   /CHECK A HALT AT END OF C8PASS
0230  0376            AND     (400            /MASK BIT
0231  7640            SZA CLA                 /HALT =1 NO SKIP CONTINUE =0
0232  4773'            JMS     XC8INQU                 /STOP PROGRAM EXECUTION-LOOK FOR INPUT
0233  2200    C8BY1,  ISZ     XC8PAS          /BUMP RETURN
0234  6203    C8EXT1, CDF CIF 00
0235  5600            JMP I   XC8PAS
0236  0000    CKCOUT, 0
0237  1256            TAD     DOSET           /CHECK IF SET UP NEEDED
0240  7640            SZA CLA                 /0=SET UP C8PASS COUNT VALUE
                                              /1=C8PASS COUNT VALUE OK
0241  5246            JMP     NOSET           /C8PASS COUNT VALUE ON
0242  1257            TAD     CNTVAL          /GET COUNT VALUE FOR THIS PROG
0243  7040            CMA                     /SET TO NEGATIVE
0244  3254            DCA     DOCNT           /STORE IN HERE
```

```
                                ISZ     DOSET           /INDICATE VALUE SET UP
                        /#2
0246  2254      NOSET,  ISZ     DOCNT           /COUNT THE NUMBER OF PASSES
                        /#2
0247  5233             JMP     C8BY1           /EXIT FOR ANOTHER PASS
0250  3256             DCA     DOSET           /SET TO C8PRNT C8PASS
0251  2236             ISZ     CKCOUT          /BUMP RETURN FOR
0252  5636             JMP I   CKCOUT          /C8PASS C8TYPE OUT
0253  0556      XMX,    MX              /LOCATION OF CHAR TO PRINT AT PASS FROM FLD 0
0254  0000      DOCNT,  0
0255  0000      PASCNT, 0                       /
0256  0000      DOSET,  0
0257  0000      CNTVAL, 0
0260  0411      MESPAS, TEXT    "DIRXA-C PASS "
0261  2230
0262  0155
0263  0340
0264  2001
0265  2323
0266  4000

                        /*********************************************************************

                        /C8CKSW
                        /ROUTINE THAT WILL CHECK WHERE TO READ THE
                        /C8 SWITCHES FROM IE, FROM PANEL OR PSEUDO C8SWIT REGISTER
                        /       C8CKSW= JMS XC8SW
                        /EX     C8CKSW          /READ THE C8SWIT REGISTER
                                                /RETURN WITH THE CONTENTS OF SWITCH REGISTER

                        /RETURN TO NEXT LOCATION FOLLOWING CALL WITH THE AC= TO VALUE OF C8SWIT SETTING


0267  0000      XC8SW,  0
                        /#1
0270  7200              CLA                     /CLEAR AC
0271  4772'             JMS     XC8CKP                  /GO CHECK THE IF ANY CONTRL
                        /#2
0272  7000              NOP
                        /#2
                        /#1
0273  6201              CDF 00
0274  1771              TAD I   (21             /GET WD FOR INDICATOR
0275  6211              CDF 10
0276  7710              SPA CLA                 /CHECK IF FROM PANEL 4000
0277  7614              7614                    /DO LAS AND SKIPGET FROM PANEL WITH LAS
0300  5302              JMP     C8GET1          /GET CONTENTS OF LOC 20 FLD 00
0301  5305              JMP     C8EXT2          /EXIT COMMON
0302  6201      C8GET1, CDF 00
0303  1770              TAD I   (20             /PSEUDO SW
0304  6211              CDF 10
0305  5667      C8EXT2, JMP I   XC8SW           /EXIT WITH STATUS BIT IN AC.
```



```
                        /*********************************************************************

                        /C8TTYI
                        /THIS ROUTINE WILL LOOK FOR A INPUT FROM THE CONSOL
                        /       C8TTYI= JMS XC8TTY
                        /EX.    C8TTYI          /READ CHAR FROM THE CONSOL DEVICE
                        /                       /RETURN TO CALL PLUS ONE AC CONTAINS THE CHAR

                        /
                        /
0306  0000      XC8TTY, 0
0307  6031              KSF                     /LOOK FOR KEYBOARD FLAG
0310  5307              JMP     .-1
0311  6036              KRB                     /GET CHAR
0312  0367              AND     (177            /MASK FOR 7 BITS
0313  1366              TAD     (200            /ADD THE EIGTH BIT
0314  3765'             DCA     CHAR            /STORE IT
0315  1765'             TAD     CHAR
0316  5706              JMP I   XC8TTY          /EXIT


                        /*********************************************************************

                        /C8PRNT

                        /THIS ROUTINE WILL TYPE THE CONTENTS OF THE C8 PRINT BUFFER. THE LOCATION
                        /OF THE BUFFER WILL BE IN THE ADDRS FOLLOWING THE CALL.  C8 PRINTING OF THE BUFFER
                        /WILL STOP WHEN A 00 CHAR IS DETECTED. CHARACTERS ARE PACKED 2 PER WORD.

                        /       C8PRNT= JMS XC8PNT


                        /EX.    C8PRNT                  /C8PRNT THE CONTENTS OF THE FOLLOWING BUFFER
                        /       MESS77                  /LOCATION OF C8PRNT BUFFER
                        /C8PRNT WILL USE THE LOCATION FOLLOWING THE CALL AS THE POINTER FOR THE
                        /C8PRNT ROUTINE,RETURN TO CALL PLUS TWO WITH AC= 0



0317  0000      XC8PNT, 0
0320  7300              CLA CLL
0321  1717              TAD I   XC8PNT          /GET C8PRNT BUFFERS STARTING LOCATION
0322  3352              DCA     PTSTOR          /STORE IN PTSTOR
0323  2317              ISZ     XC8PNT          /BUMP RETURN
0324  1752      C8DO1,  TAD I   PTSTOR          /GET DATA WORD
0325  0364              AND     (7700           /MASK FOR LEFT BYTE
0326  7450              SNA                     /CHECK IF 00 TERMINATE
0327  5717              JMP I   XC8PNT          /EXIT
0330  7500              SMA                     /IS AC MINUS
0331  7020              CML                     /MAKE CHAR A 300 AFTER ROTATE
0332  7001              IAC                     /MAKE CHAR A 200 AFTER ROTATE
0333  7012              RTR
0334  7012              RTR
0335  7012              RTR                     /PUT CHAR IN BITS 4-11 MAKE IT 8 BIT ASCII
```

```
0336  4763'          JMS     XC8TYP          /C8PRNT IT ON CONSOLE
0337  1752           TAD I   PTSTOR          /GET DATA WORD
0340  0362           AND     (0077           /MASK FOR RIGHT BYTE
0341  7450           SNA                     /CHECK IF 00 TERMINATOR
0342  5717           JMP I   XC8PNT          //EXIT
0343  1361           TAD     (3740           /ADD FUDGE FACTOR TO DETERMINE IF 200
0344  7500           SMA                     /OR 300 IS TO BE ADD TO CHAR
0345  1360           TAD     (100            /ADD 100
0346  1357           TAD     (240            /ADD 200
0347  4763'          JMS     XC8TYPE                 /C8TYPE ONLY BITS 4-11
0350  2352           ISZ     PTSTOR          /BUMP POINTER FOR NEXT WORD
0351  5324           JMP     C8DO1           /DO AGAIN
0352  0000  PTSTOR, 0                       /STOR FOR C8PRNT BUFFER
0353  0000  STOPNT, 0                       /0000 C8PRNT 7777=DO NOT C8PRNT

                     /**************************************************************************

0357  0240
0360  0100
0361  3740
0362  0077
0363  1106
0364  7700
0365  1104
0366  0200
0367  0177
0370  0020
0371  0021
0372  1050
0373  0635
0374  1007
0375  1032
0376  0400
0377  1330
      0400           PAGE
                     /**************************************************************************

                     /C8CNTR
                     /THIS ROUTINE WILL CHECK FOR THE PRESENCE OF CONTROL CHARACTERS
                     /IT WILL CHECK FOR THE FOLLOWING CHAR C-R-Q-O-L-S
                     /       C8CNTR= JMS XC8CNT

                     /EX,    C8CNTP                  /CHECK FOR CONTROL CHARACTER
                     /       JMP     ANYTHING        /LOC FOLLOWING CALL IS FOR CONTINUING THE PROGRAM
                     /       JMP     ANYTHING        /LOC. IS FOR RETURN IF INMODE SET AND NOT CNTRL CHAR
                     /

                     /RETURN IS TO CALL PLUS ONE IFCONTINUE
                     /RETURN IS TO CALL PLUS TWO IF INMOD SET AND NOT CONTROL CHAR
                     /
                     /RETURN IS TO CALL PLUS TWO IF INMODE IS NOT SET AND NO
                     /CONTROL CHAR ..THIS WILL PRINT THE CHARACTER AND A ?
                     /CLEAR THE AC AND RETURN CALL+2.
```



```
0400  0000  XC8CNT, 0
0401  3777'          DCA     ACSAVE          /SAVE THE AC
0402  4776'          JMS     C8CK22          /CHECK IF CONSOL ACTIVE
0403  5206           JMP     .+3             /ON ACTIVE CONSOLE
0404  1777'          TAD     ACSAVE          /GET AC FOR RETURN
0405  5600           JMP I   XC8CNT          /EXIT NOT ON ACTIVE CONSOLE
0406  6004           GTF
0407  3775'          DCA     FLSAVE
                     /#6
0410  7501           MQA
                     /#6
0411  3774'          DCA     MQSAVE          /SAVE THE MQ
0412  3255           DCA     INDEXA          /SET DISPLACEMENT INTO TABLE B
0413  1257           TAD     XTABLA          /GET ADDRS OF TABLE A
0414  3256           DCA     GETDAT          /CONTAINS POINTER TO CONTROL CHAR
0415  1656  REDOA,   TAD I   GETDAT          /GET CONTROL CHAR FROM TABLE
0416  7450           SNA                     /CHECK FOR A 0 END OF TABLE
0417  5226           JMP     DONEA           /END OF TABLE NO CONTROL CHAR
0420  1773'          TAD     CHAR            /COMPARE CHAR TO CONTROL CHAR
0421  7650           SNA CLA                 /0 IF MATCH
0422  5243           JMP     GOITA           /MATCH
0423  2255           ISZ     INDEXA          /NO MATCH NOT END OF TABLE REDO
0424  2256           ISZ     GETDAT          /BUMP INDEX FOR EXIT WHEN CONTROL FOUND
0425  5215           JMP     REDOA           /BUMP GETDAT FOR COMPARE OF NEXT CNTRL CHAR.
0426  1772'  DONEA,  TAD     INMODE          /CHECK IF PROGRAM EXPECTS CHAR
0427  7640           SZA CLA                 /1=CHAR EXPECTED  0= NO CHAR EXPECTED
0430  5240           JMP     EXITA           /CHAR EXPECTED
0431  1773'          TAD     CHAR            /GET CHAR - NOT CONTROL + NOT EXPECTED
0432  4771'          JMS     XC8TYP                  /C8PRNT CHAR
0433  1370           TAD     (277            /GET CODE FOR "?"
0434  4771'          JMS     XC8TYP
0435  4767'          JMS     XC8CRL
                     /#1
0436  2200           ISZ     XC8CNT          /BUMP RETURN
                     /#2
0437  5600           JMP I   XC8CNT          /EXIT CALL+2
                     /#2
                     /#1
0440  2200  EXITA,   ISZ     XC8CNT          /BUMP RETURN FOR MAIN PROGRAM CHECK OF CHAR
0441  1773'          TAD     CHAR            /PUT CHAR IN AC.
0442  5600           JMP I   XC8CNT          /EXIT
0443  1773'  GOITA,   TAD     CHAR            /GET THE CONTENTS OF CHAR
0444  1366           TAD     (100            /ADD 100 TO FORM A GOOD ASCII CHARACTER
0445  3773'          DCA     CHAR            /RESTORE COFFECT CHAR
0446  1260           TAD     XTABLB          /GET START OF TABLE B
0447  1255           TAD     INDEXA          /GET NOW FAR INTO TABLE
0450  3254           DCA     GOTOA           /STORE IT
0451  1654           TAD I   GOTOA           /GET THE ROUTINE STARTTING ADDRESS
0452  3254           DCA     GOTOA           /STORE IT IN HERE
0453  5654           JMP I   GOTOA           /GOTO CONTROL CHAR ROUTINE
0454  0000  GOTOA,   0000                    /ADD OF CNTRL ROUTINE TO EXECUTE
0455  0000  INDEXA,  0000                    /DISPLACEMENT INTO CNTRL TABLE
0456  0000  GETDAT,  0000                    /LOCATION OF ADDRS OF CONTROL CHAR.
0457  0461  XTABLA,  TABLA                   /ADDRS OF TABLEA
```

```
0460  0470    XTABLB, TABLB                   /ADDRS OF TABLEB
0461  7575    TABLA,  7575                    /CNTRL C BACK TO MONITOR 203
0462  7557            7557                    /CNTRL Q START DISPLAYING CHAR, AGAIN 221
0463  7556            7556                    /CNTRL R BACK TO BEGINNING OF PROGRAM 222
0464  7555            7555                    /CNTRL S STOP SENDING CHAR TO DISPLAY WAIT FOR CNTRL Q 223
0465  7573            7573                    /CNTRL E CONTINUE WITH PROGRAM 205
0466  7574            7574                    /CONTROL D CHANGE SWITCH REGISTER ON FLY
0467  0000            0000
0470  0476    TABLB,  CNTRLC
0471  0503            CNTRLQ
0472  0514            CNTRLR
0473  0524            CNTRLS
0474  0542            CNTRLE
0475  0600            CNTRLD

                      /RETURN TO MONITOR
                      /#7
0476  3765'  CNTRLC, DCA     TTYLPT          /CLEAR THE LPT FLAG TO PRINT ON DISPLAY
                      /#7
0477  4764'           JMS     UPAROW          /C8PRNT A^ AND LETTER IN CHAR
0500  6203            CDF CIF                 /GO TO 0 FLD
0501  6007            CAF                     /CLEAR THE WORLD
0502  5763            JMP I   (7600           /GO TO DIAGNOSTIC MONITOR
                      /
                      /START SENDING CHAR, TO THE DISPLAY
                      /THIS WILL RETURN CONTROL TO CALL THAT WAS SET BY
                      /THE CALL FOR CONTROL S.
                      /
                      /#7
0503  3772'  CNTRLQ, DCA     INMODE          /CLEAR THE SOFT IN FLAG
0504  1340            TAD C8SETS              /GET THE SOFT FLAG
0505  7640            SZA CLA
0506  4311            JMS     BYRETR          /FIRST ENTRY TO CNTRL Q WITH NO CNTRL S
0507  4762'           JMS     C8GET
0510  5600            JMP I   XC8CNTR         /RETURN VIA CONTROL
0511  3340    BYRETR, DCA     C8SETS          /CLEAR THE FLAG FOR CONTROL S
0512  4762'           JMS     C8GET           /RESTOR
0513  5741            JMP I   C8RETR          /GO TO CALL SAVED BY CNTRL S

                      /
                      /
                      /GO TO THE QUESTION C8SWIT
                      /
                      /
0514  3765'  CNTRLR, DCA     TTYLPT          /SET FLAG TO TTY
0515  3340            DCA     C8SETS          /CLEAR SOFT FLAG FOR CNTRL S
0516  3772'           DCA     INMODE
0517  4764'           JMS     UPAROW          /PRINT CHAR
0520  3761'  C8BY4,   DCA     C8SWST          /CLEAR FLAG FOR CNTRL D OR P
                      /#3
0521  6203            CDF CIF 00
0522  5723            JMP I   XDOSW           /GO TO ADDRS OF C8SWIT
                      /#1
0523  0200  XDOSW,   C8STRT                   /DOSW IS LABEL FOR C8SWIT QUESTION
                      /#1
```



```
                      /
                      /
                      /STOP SENDING CHAR, TO DISPLAY UNTIL A ^Q IS RECEIVED
                      /
                      /
                      /#7
0524  1340    CNTRLS, TAD     C8SETS          /IF1 DO NOT STORE IN C8RETR
                      /#7
0525  7640            SZA CLA
0526  5332            JMP     C8DO7           /DONT SET UP C8RETR
                      /#5
0527  7001            IAC                     /MAKE RETURN CALL PLUS 2
                      /#5
0530  1200            TAD     XC8CNT          /GET RETURN FOR THIS CALL
0531  3341            DCA     C8RETR          /STORE IT HERE FOR USE BE CNTROL Q
                      /#2
0532  2340    C8DO7,  ISZ     C8SETS          /SET FLAG TO SAVE CALL
                      /#4
0533  4760'           JMS     XC8TTY                  /LOOK FOR THE INPUT
                      /#5
0534  4762'           JMS     C8GET           /GET REGISTERS
                      /#5
0535  4200            JMS     XC8CNTR                 /CHECK FOR THE CONTROL CHAR
                      /#4
0536  7200            CLA
                      /#7
0537  5324            JMP     CNTRLS          /IF NOT A CNTRL Q R C REASK
                      /#7
                      /#2
0540  0000    C8SETS, 0
0541  0000    C8RETR, 0
                      /
                      /SWITCH OUTPUT FROM ONE OUTPUT DEVICE TO ANOTHER - THE TWO OUTPUTS ARE THE
                      /CONSOLE AND THE PRINTER WITH DEVICE CODE 66.
                      /
                      /


                      /
                      /
                      /CONTROL E
                      /CONTINUE RUNNING FROM A INQUIRE OR ERROR
                      /
                      /
0542  4764'  CNTRLE, JMS     UPAROW          /PRINT THE CONTROL CHAR
0543  4762'           JMS     C8GET           /GET THE REGISTERS
0544  5600            JMP I   XC8CNT          /RETURN TO CALL PLUS ONE
                      /
                      /
                      /
0560  0306
0561  0745
0562  0624
0563  7600
```

```
0564  0615
0565  1132
0566  0100
0567  1032
0570  0277
0571  1106
0572  1105
0573  1104
0574  1315
0575  1316
0576  1330
0577  1314
      0600    PAGE
              /
                      /CONTROL D
                      /CHANGE THE SWITCH REGISTER ANYTIME CNTRL D AND RETURN TO
                      /THE PROGRAM RUNNING.


0600  4215  CNTRLD, JMS     UPAROW
0601  1213          TAD     C8SETD          /CHECK IF THE RETURN ADDRS IS SAFE
0602  7640          SZA CLA
0603  5207          JMP     C8D011          /DO NOT CHANGE THE RETURN ADDRS
0604  1777'         TAD     XC8CNT          /GET THE RETURN ADDRS AND SAVE IT
0605  3214          DCA     C8RETD          /SAVE THE RETURN HERE
0606  2213          ISZ     C8SETD          /INDICATE RETURN SAVED DONT DISTROY
0607  4251  C8D011, JMS     XC8PSW                  /GO CHANGE THE SWITCH REGISTER
0610  3213          DCA     C8SETD          /CLEAR THE FLAG
              /#3
0611  4224          JMS     C8GET           /RESTORE THE AC MQ LINK ETC
              /#3
0612  5614          JMP I   C8RETD          /RETURN TO THE PROGRAM
              /
0613  0000  C8SETD, 0
0614  0000  C8RETD, 0
              /


0615  0000  UPAROW, 0                       /PRINT THE "^" AND THE CHAR TYPED IN
0616  1376          TAD     (336            /CODE FOR ^
0617  4775'         JMS     XC8TYP
0620  1774'         TAD     CHAR            /C8TYPE THE CHAR
0621  4775'         JMS     XC8TYP
0622  4773'         JMS     XC8CRLF
0623  5615          JMP I   UPAROW          /EXIT


              /**********************************************************************
0624  0000  C8GET,  0
              /#6
0625  7200          CLA
              /#6
0626  1772'         TAD     MQSAVE
```



```
0627  7421          MQL                     /RESTORE MQ
0630  1771'         TAD     FLSAVE
0631  7004          RAL                     /RESTORE THE LINK
              /#1
0632  7200          CLA
              /#1
0633  1770'         TAD     ACSAVE          /RESTORE THE AC
0634  5624          JMP I   C8GET           /GET THE REGISTERS


              /**********************************************************************

              /C8INQU
              /C8INQU ROUTINE WILL PRINT A WAITING
              /AND THE PROGRAM IS EXPECTING A CONTROL CHAR INPUT
              /IF CONTINUE FROM CONTROL CHAR RETURN IS CALL PLUS ONE
              /IF NO CONTROL CHAR ENTERED THEN WAITING IS REPRINTED
              /AND PROGRAM WAITS FOR A CONTROL CHAR AGAIN
              //

              /       C8INQU= JMS XC8INQ

              /EX     C8INQU                  /C6 WILL PRINT A WAITINGAND WAIT FOR INPUT
              /       DO ANYTHING             /RETURN IS CALL PLUS ONE AC =0 CONTINUE

0635  0000  XC8INQ, 0
0636  4767'         JMS     C8CK22          /CHECK IF CONSOLE
0637  7410          SKP                     /SKIP FOR ACTIVE
0640  5635          JMP I   XC8INQ          /NOT CONSOLE LEAVE
              /#1
0641  4773'         JMS     XC8CRLF
0642  4766'         JMS     XC8PNT
0643  1307          WAITMES                 /INQUIR WAITTING
0644  4765'         JMS     XC8TTY                  /GET CHARACTER
              /#5
0645  4224          JMS     C8GET
              /#5
0646  4777'         JMS     XC8CNTR                 /CHECK IF CONTROL CHARACTER
              /#1
0647  5635          JMP I   XC8INQ          /EXIT AND CONTINUE
0650  5236          JMP     XC8INQ+1        /REASK


              /**********************************************************************


              /C8SWIT
              /ROUTINE WILL CHECK IF CONSOL IS ACTIVE IF IT IS ACTIVE DISPLAY
              /SW QUESTION, IN NOT ACTIVE IT WILL NOT PRINT THE SW QUESTIONBUT
              /RETURN TO CALL PLUS ONE AC=0.
              /C8SWIT WILL SET UP THE PSEUDO C8SWIT
              /REGISTER WITH THE NEW DATA ENTERED
              /THE TAG  C8DOR AT THE START OF THE CALL IS FOR THE RETURN OF CONTROL R
              /CHAR, THIS MAY BE CHANGED IF THIS IS NOT WHERE A GOOD RESTART
              /OF PROGRAM IS.
```

```
                        /
                        /       C8SWIT= JMS XC8PSW
                        /
                        /EX.    C8DOK,  C8SWIT          /SET UP PSEUDO C8SWIT REGISTER IF
                                                        /ON THE CONSOL PACKAGE. RETURN IS CALL PLUS ONE AC = 0
                        /
                        /
                        /
                        /
0651  0000    XC8PSW, 0
0652  4767'             JMS     C8CK22          /CHECK IF ON ACTIVE CONSOLE
0653  7410              SKP
0654  5651              JMP I   XC8PSW          /RETURN WITHOUT ASKING PSEUDO SWITCH
0655  1345              TAD     C8SWST          /IS THE SOFT FLAG SET FOR SWITCH?
0656  7640              SZA CLA                 /SKIP IF ONE ENTRY AT ATIME OK
0657  5764'             JMP     C8BY4           /SECOND ENTRY WITH OUT A EXIT GO TO SW QUESTION
0660  2345              ISZ     C8SWST          /FIRST ENTRY SET FLAG
                        /*3
0661  4773'    REDO1,  JMS     XC8CRLF
0662  4766'             JMS     XC8PNT                  /C8PRNT SR=XXX
0663  1004              MESA
0664  6201              CDF 00
0665  1763              TAD I   (20             /GET CONTENTS OF SW
0666  6211              CDF 10
0667  4762'             JMS     XC8OCTA                 /CONVERT IT TO ASCII
0670  1361              TAD     (40             /GET SPACE
0671  4775'             JMS     XC8TYPE
0672  2760'             ISZ     INMODE          /SET FLAG FOR CHAR EXECTED
0673  4757'             JMS     XC8ECHO                 /LOOK FOR INPUT
0674  4321              JMS     TSTCHA          /NOT CONTROL TEST IT IS LEGAL
0675  1774'             TAD     CHAR            /STORE NEW CHAR IN SW REG
0676  6201              CDF 00
0677  3763              DCA I   (20
0700  6211              CDF 10
0701  1356              TAD     (-3             /GET A MINUS 3
0702  3346              DCA     TMPCNT          /STORE IN TEMP COUNT
0703  4757'    GETCH1, JMS     XC8ECHO                 /GET NEXT CHAR
0704  4321              JMS     TSTCHA          /CHECK IF CR + GOOD CHAR
0705  6201              CDF 00
0706  1763              TAD I   (20             /GET C8SWIT REGISTER
0707  6211              CDF 10
0710  7106              RTL CLL                 /ROTATE IT LEFT 3 PLACES
0711  7004              RAL
0712  1774'             TAD     CHAR            /GET CHAR + ADD IT TO PREVIOUS CONTENTS
0713  6201              CDF 00
0714  3763              DCA I   (20             /SAVE NEW CONTENTS
0715  6211              CDF 10
0716  2346              ISZ     TMPCNT          /BUMP COUNT
0717  5303              JMP     GETCH1          /JMP BACK + GET NEXT CHAR
0720  5342              JMP     ENDIT           /END 4 CHAR C8TYPED IN
0721  0000    TSTCHA, 0
0722  7041              CIA                     /CMPL CHAR IN AC
0723  1355              TAD     (215            /TEST IF IT IS A CARRIAGE RETURN
0724  7650              SNA CLA                 /SKIP IN NOT CR.
0725  5342              JMP     ENDIT           /WAS CARRIAGE RETURN
```



```
0726  1774'             TAD     CHAR            /NOT CR. GET CHAR
0727  1351              TAD     (-260           /CHECK IF IT IS IN RANGE
0730  7710              SPA CLA                 /IF NOT POSITIVE C8ERR CHAR SMALLER THEN 260
0731  5753'             JMP     ERR1            /C8ERR - CHAR TOO SMALL
0732  1774'             TAD     CHAR            /GET CHAR
0733  1352              TAD     (-270           /GET A -270 + CHECK IF IT IS LARGER THEN 7
0734  7700              SMA CLA                 /SKIP IF LESS THEN 7
0735  5753'             JMP     ERR1            /C8ERR ON CHAR NOT IN RANGE
0736  1774'             TAD     CHAR            /GET CHAR
0737  0351              AND     (7              /MASK FOR RIGHT BYTE
0740  3774'             DCA     CHAR            /STORE IN CHAR
                                                /GET CHAR IN AC
0741  5721              JMP I   TSTCHA          /EXIT
0742  4773'    ENDIT,  JMS     XC8CRLF
0743  3345              DCA     C8SWST          /CLEAR THE PSW ENTRY FLAG
0744  5651              JMP I   XC8PSW          /EXIT PSW
0745  0000    C8SWST, 0
0746  0000    TMPCNT, 0
0751  0007
0752  7510
0753  1000
0754  7520
0755  0215
0756  7775
0757  1072
0760  1105
0761  0040
0762  1007
0763  0020
0764  0520
0765  0306
0766  0317
0767  1330
0770  1314
0771  1316
0772  1315
0773  1032
0774  1104
0775  1106
0776  0336
0777  0400
      1000              PAGE
1000  1377    ERR1,   TAD     (277            /C8PRNT
1001  4306              JMS     XC8TYPE                 /?
1002  4232              JMS     XC8CRLF                 /
1003  5776'             JMP     REDO1           /EXIT + ASK AGAIN
1004  2322    MESA,   TEXT    "SR= "
1005  7540
1006  0000

                        /*********************************************************************
                        /C8OCTA
                        /OCTAL TO ASCII CONVERSION
                        /THIS ROUTINE WILL TAKE THE OCTAL NUMBER IN THE AC AND CONVERT IT TO ASCII
                        /THE RESULT WILL BE PRINTED ON THE CONSOL DISPLAY
```

```
                /       C8OCTA= JMS XC8OCT
                /
                /EX.    C8OCTA          /AC CONTAINS NUMBER TO BE CHANGE
                /
1007  0000    XC8OCT, 0
1010  7130            CLL RTL
1011  7006            RTL                     /POSITION THE FIRST CHAR FOR PRINTING
1012  3230            DCA     C8TMP1          /SAVE CORRECT POSITIONED WORD HERE
1013  1375            TAD     (-4
1014  3231            DCA     C8CKP           /STORE COUNTER IN HERE
1015  1230    C8D04,  TAD     C8TMP1          /GET FIRST NUMBER
1016  0374            AND     (0007           /MASK
1017  1373            TAD     (260            /ADD THE PRINT CONSTANT
1020  4306            JMS     XC8TYPE         /TYPE THE NUMBER
1021  1230            TAD     C8TMP1          /
1022  7006            RTL
1023  7004            RAL                     /PUT NEXT NUMBER IN POSITION
1024  3230            DCA     C8TMP1          /STORE IT
1025  2231            ISZ     C8CKP           /DONE YET WITH FOUR NUMBERS
1026  5215            JMP     C8D04           /NOT YET DO MORE
1027  5607            JMP I   XC8OCT          /DONE WITH FOUR
1030  0000    C8TMP1, 0
1031  0000    C8CKP,  0

                /*****************************************************************

                /C8CRLF
                /TYPE CR AND LF WITH FILLERS FOLLOWING EACH LF AND CR
                /
                /       C8CRLF= JMS XC8CRL
                /
                /EX.    C8CRLF          /C8PRNT A CR AND LF WITH FILL
                /                       /RETURN TO CALL PLUS ONE AC =0

1032  0000    XC8CRL, 0
1033  7300            CLA CLL
1034  1372            TAD     (215            /GET CODE FOR CR
1035  4306            JMS     XC8TYPE
1036  1246            TAD     C8FILLER
1037  7040            CMA
1040  3247            DCA     FILCNT          /STORE FILLER IN HERE
1041  1371            TAD     (212            /GET CODE FOR LF
1042  4306    C8D02,  JMS     XC8TYPE
1043  2247            ISZ     FILCNT          /CHECK ON FILLER CHAR
1044  5242            JMP     C8D02           /TYPE A NON PRINTING CHAR
1045  5632            JMP I   XC8CRL          /EXIT
                /#1/#2
1046  0004    C8FILLER,       0004            /FILLER SET FOR 4 CHAR
                /#1/#2
1047  0000    FILCNT, 0                       /COUNTER FOR FILL


                //*************************************************************
```



```
                /#1
                /C8CKPA
                /THIS ROUTINE WILL CHECK IF A CHARACTER WAS ENTERED FROM THE
                /TERMINAL. IFTHE FLAG IS SET AND THE CONSOLE PACKAGE IS
                /ACTIVE A CHECK IS MADE TO DETERMIND IF IT IS A CONTROL CHAR.
                /IF IT WAS A CONTROL CHAR THEN ITS CONTROL FUNCTION IS PERFORMED.
                /IF NOT A CONTROL CHARACTER OR A CONTROL E-D-L-O- IT WILL DO
                /THE CONTROL FUNCTION AND RETURN TO CALL PLUS 2.
                /A NON CONTROL CHARACTER WILL BE PRINTEDAND A "?" IT WILL RETURN TO
                /CALL PLUS 2.
                /IF NO FLAG IS SET OR THE CONSOL IS NOT ACTIVE THE RETURN IS TO
                /CALL PLUS 1.


                /       C8CKPA= JMS     XC9CKP


                /EX.    C8CKPA                  /CALL TO CHECK IF CONTROL CHAR SET
                /       ANYTHING(SKIP)          /RETURN IF NOT FLAG OR NOT CONSOLE ACTIVE
                /       ANYTHING(JMP EXIT SKIP CHAIN)   /RETURN IF NOT CONTROL OR CONTINUE CONTROL


1050  0000    XC8CKP, 0
1051  3770'            DCA     ACSAVE          /SAVE THE AC
1052  6004            GTF                     /SAVE THE FLAGS
1053  3767'            DCA     FLSAVE          /SAVE THE FLAGS
                /#2
                /#6
1054  7501            MQA                     /PUT MQ IN AC
                /#6
1055  3766'            DCA     MQSAVE          /SACE THE MQ
                /#2
1056  6031            KSF                     /CHECK THE KEYBOARD FLAG
1057  5270            JMP     C8BY3           /EXIT TO CALL PLUS 1
1060  4765'            JMS     C8CK22          /CHECK IF ON CONSOLE
1061  7410            SKP
1062  5270            JMP     C8BY3           /EXIT TO CALL PLUS 1
1063  4764'            JMS     XC8TTY                  /GET THE CHAR
                /#2
1064  4763'            JMS     C8GET           /GET THE FLAGS
1065  4762'            JMS     XC8CNTR                 /CHECK IF CONTROL  CHAR.
                /#2
1066  7000            NOP                     /RETURN IF A CONTINUE CHAR.
1067  2250            ISZ     XC8CKP          /BUMP RETURN FOR CALL PLUS 2
1070  4763'    C8BY3,  JMS     C8GET           /GET REGISTERS
1071  5650            JMP I   XC8CKP          /SAY GOOD BY
                /#1


                //*************************************************************

                /C8ECHO
                /THIS ROUTINE WILL LOOK FOR A CHAR FROM THE KEYBOARD.  STORE IT IN LOCATION CHAR
                /CHECK IF IT WAS A C8CNTR CHARACTER - SET INMODE - C8PRNT CHARACTER
                /       C8ECHO= JMS XC8ECH
                /EX.    C8ECHO          /LOOK FOR CONSOL CHAR C8PRNT IT
```

```
                                        /RETURN CALL PLUS ONE AC = CHAR C8TYPED IN


                        /
1072  0000    XC8ECH, 0
1073  4764'             JMS     XC8TTY                  /WAIT FOR CHAR FROM KEYBOARD
                        /#1
                        /#1
1074  4763'             JMS     C8GET
1075  2305              ISZ     INMODE          /SET INMODE IDENTIFING THIS AS A EXPECTED CHAR
1076  4762'             JMS     XC8CNTR                 /GO CHECK IF IT IS A CONTROL CHAR
1077  5672              JMP I   XC8ECH          /WAS A CONTROL CHAR - CONTINUE RUNNING
1100  4306              JMS     XC8TYPE                 /NOT A CONTROL CHAR C8PRNT IT
1101  3305              DCA     INMODE          /CLEAR FLAG THAT CHAR EXPECTED
1102  1304              TAD     CHAR            /GET CHAR IN AC
1103  5672              JMP I   XC8ECH          /EXIT
1104  0000    CHAR,   0
1105  0000    INMODE, 0

                        /*********************************************************************

                        /C8TYPE
                        /THIS ROUTINE WILL C8PRNT ON THE CONSOLE OR THE LPT WITH DEVICE CODE 66.
                        /
                        /       C8TYPE= JMS XC8TYP

                        /EX.    C8TYPE          /C8PRNT THE CHAR IN THE AC.
                        /                       /RETURN CALL PLUS ONE AC =0000
                                                /DO NOT CLEAR THE LINK IN THIS ROUTINE NEEDED BYC8OCT


1106  0000    XC8TYP, 0
1107  3331              DCA     PNTBUF          /STORE CHAR
1110  1332              TAD     TTYLPT          /CHECK 0=TTY 7777=LPT
1111  7640              SZA CLA
1112  5321              JMP     XDOLPT          /DO OUT PUT ON LPT
1113  1331              TAD     PNTBUF
1114  6046              TLS
1115  6041              TSF
1116  5315              JMP     .-1
1117  6042              TCF
1120  5327              JMP     C8BY5
1121  1331    XDOLPT, TAD     PNTBUF          /GET CHAR
1122  6666              PSTB    PCLF            /C8PRNT IT
                        /#6
1123  4333              JMS     C8HANG          /CHECK KEYBOARD IF HUNG
                        /#6
1124  6661              PSKF
1125  5323              JMP     .-2             /WAIT UNTIL DONE
1126  6662              PCLF
1127  7200    C8BY5,  CLA                     /CLEAR THE AC
1130  5706              JMP I   XC8TYP          /EXIT
1131  0000    PNTBUF, 0
1132  0000    TTYLPT, 0
```



```
                        /#6
1133  0000    C8HANG, 0               /WILL CHECK KEYBOARD FOR CNTRL CHAR
                                      /WILL NEED IF LPT HANGS TO GET OUT
1134  4250              JMS     XC8CKPA                 /SEE IF KEYBOARD INPUT
1135  7000              NOP
1136  5733              JMP I   C8HANG          /IF HUNG IN LPT SKIP FLAG NOT SET
                                              /ONLY WAY OUT IS CNTRL R - C !!!
                        /#6


1162  0400
1163  0624
1164  0306
1165  1330
1166  1315
1167  1316
1170  1314
1171  0212
1172  0215
1173  0260
1174  0007
1175  7774
1176  0661
1177  0277
      1200      PAGE
                /*********************************************************************

                /C8ERR
                /THIS ROUTINE WILL DETERMINE WHAT TO DO WHEN A C8ERR IS ENCOUNTERED
                /WILL CHECK IF CLASSIC SYSTEM, WILL CHECK C8SWIT REGISTERS.
                /       C8ERR=  JMS XC8ERR
                /EX.    C8ERR           /GO TO C8ERR CALL IF N0LT/0/
                /                       /RETURN IS CALL PLUS ONE AC =0000


1200  0000    XC8ERR, 0
1201  6002              IOF
1202  3314              DCA     ACSAVE          /SAVE AC
1203  6004              GTF
1204  3316              DCA     FLSAVE          /SAVE THE FLAGS
1205  7501              MQA
1206  3315              DCA     MQSAVE          /SAVE THE MQ
1207  7340              CLA CLL CMA             /SUBTRACT A 1 FOR TRUE LOCATION
1210  1200              TAD     XC8ERR          /GET RETTURN LOCATION
1211  3313              DCA     PCSAVE          /SAVE ADD OF C8ERR CALL
1212  1022              TAD     22              /GET LOCATION 22
1213  0377              AND     (400            /MASK FOR CLASSIC SYSTEM
1214  7650              SNA CLA                 /SKIP IF CLASSIC BIT IN LOC 22 SET
1215  5252              JMP     NTCLAS          /NOT CLASSIC SYSTEM
1216  1776'             TAD     STOPNT          /NO ERROR PRINTING
1217  7640              SZA CLA
1220  5245              JMP     C8DO10          /DO NOT PRINT
                        /#2
1221  4775'             JMS     XC8CRLF
```

```
                        /#2
                        JMS     XC8PNT
                        ERRMES                  /PRINT THE ERROR MESSAGE
                        JMS     XC8PNT
                        MESPC                   /PRINT THE PC STSTEMENT
                        TAD     PCSAVE
                        JMS     XC8OCTA                 /CONVERT 4 DIGIT PC TO ASCII
                        JMS     XC8PNT
                        MESAC                   /PRINT THE AC MESS
                        TAD     ACSAVE
                        JMS     XC8OCTA
                        JMS     XC8PNT
                        MESMQ                   /PRINT MQ
                        TAD     MQSAVE
                        JMS     XC8OCTA
                        JMS     XC8PNT
                        MESFL                   /PRINT FL
                        TAD     FLSAVE
                        JMS     XC8OCTA
                        JMS     XC8CRLF
C8DO10, JMS     XC8SW                   /CHECK SWITCH REGISTER
                        /#1
                        SPA CLA                 /SKIP IF BIT 0 SET
                        /#1
                        JMP     C8BY2           /LEAVE
                        JMS     XC8INQU                 /GO TO THE INQUIRE ROUTINE
                        JMP     C8BY2           /LEAVE
NTCLAS, JMS     XC8SW                   /CHECK PSEUDO SWITCH REGISTER
                                                /CHECK THE C8SWIT REGISTER
                        /#1
                        SPA CLA                 /SKIP IF HALT
                        /#1
                        JMP 1   XC8ERR          /NO HALT CONTINUE
                        TAD     (7402           /CODE FOP HLT
                        DCA I   PCSAVE          /PUT IT IN CALL LOC.
                        /#5
                        JMS     C8GET
                        /#5
                        JMP I   PCSAVE          /EXIT  TO CALL AND HALT
C8BY2,  JMS     C8GET           /GET THE REGISTERS
                        /#3
                        /#3
                        JMP I   XC8ERR
ERRMES, TEXT    "DIRXAC  FAILED "
                1230
                0103
                4040
                0601
                1114
                0504
                4000
MESPC,  TEXT    "  PC:"
                2003
                7200
MESAC,  TEXT    "  AC:"
```



```
                0103
                7200
MESMQ,  TEXT    "  MQ:"
                1521
                7200
MESFL,  TEXT    "  FL:"
                0614
                7200
WATMES, TEXT"WAITING"           /TEXT FOR INQU ROUTINE NEED SPACE
                1124
                1116
                0700
PCSAVE, 7777
ACSAVE, 7777
MQSAVE, 7777
FLSAVE, 7777


                /C8PAUS
                /THIS ROUTINE WILL CHECK IF THE CONSOL PACKAGE IS ACTIVE,IF ACTIVE
                /IT WILL RETURN TO CALL PLUS ONE AC= 0, AND DO THAT INSTRUCTION.
                /IF THE CONSOL PACKAGE IS NOT ACTIVE THE CALL WILL BE REPLACED
                /WITH A7402 HALT AND THEN RETURN TO THE HALT.

                /       C8PAUS= JMS XC8PAU
                /
                /
                /EX.            C8PAUS          /CHECK IF ON ACTIVE CONSOL IF NOT HALT HERE
                /               ANYTHING        /RETURN HERE IF ON ACTIVE CONSOL
                /
                /


XC8PAU, 0
                JMS     C8CK22          /CHECK IF CONSOLE
                JMP     C8DO3           /GO DO CONSOL PART RETURN CALL +1
                CMA                     /PUT HLT IN CALL
                TAD     XC8PAU          /GET CORRECT RETURN ADDRS
                DCA     XC8PAU          /SET UP RETURN
                TAD     HLT             /GET CODE FOR HLT
                DCA I   XC8PAU          /PUT HALT IN CALL LOCATION
C8DO3,  JMP I   XC8PAU          /GO TO HALT OR RETURN TO NEXT LOCATION
                /***********************************
                        /CHECK LOCATION 22 FIELD 0


C8CK22, 0
                CLA
                CDF 00
                TAD I   (22             /GET LOC 22 FIELD 0
                CDF 10
                SNA CLA
                ISZ     C8CK22
                JMP I   C8CK22          /EXIT
```

```
                        /*********************************
                        /THIS IS FIELD 0 CALL FOR CHECKING FOR A CONTROL CHAR.
1340  0000  XXC8CNTR,    0
1341  4777' JMS   XC8CNTR       /CHECK CHAR STILL IN BUFFER FOR ANY CONTROL FUNCTION
1342  7000  NOP
1343  6203  CDF CIF 00
1344  5740  JMP I   XXC8CNTR    /RETURN TO FIELD 0


                        /***************
                        /CALL FROM FIELD 0 FOR WAITING MESSAGE WITH RETURN TO FLD 0


1345  0000  XXC8INQU,    0
1346  4771' JMS   XC8INQU       /PRINT WAITING RETURN TO FLD 00
1347  6203  CDF CIF 00
1350  5745  JMP I   XXC8INQU    /EXIT TO FIELD 00


                        /***************************
                        /CALL FROM FIELD 0 FOR PRINT SWIT RG QUESTION FETURN TO FLD 0
1351  0000  XXC8PSW,    0
1352  4764' JMS   XC8PSW        /PRINT PSEUDO SW REG
1353  6203  CDF CIF 00          /RETURN TO FIELD 00
1354  5751  JMP I   XXC8PSW     /EXIT TO FIELD 00


                        /*****************
                        /CHECK THE PSEUDO OR HARDWRE SWITCHES
1355  0000  XXC8SW, 0
1356  4772' JMS   XC8SW         /CHECK THE SWITCHES
1357  6203  CDF CIF 00          /RETURN TO FIELD 00
1360  5755  JMP I   XXC8SW      /TO FIELD 00


                        /
                        /LOOK IS RIUTINE TO WAIT FOR A TTY CHAR CHECK IT FOR CONTROL VALUE


1364  0651
1365  0022
1366  4461
1367  0624
1370  7402
1371  0635
1372  0267
1373  1007
1374  0317
1375  1032
1376  0353
1377  0400
      1400        PAGE

1400  0000  XC8LOOK,    0
1401  4777' JMS   XC8TTY        /GET THE CHAR
1402  4776' JMS   XC8CNTR       /CHECK FOR CONTROL
```



```
1403  7410  SKP                 /IS A CONTINUE CHAR
1404  5207  JMP   REASK1        /NOT A CONTROL CHAR
1405  6203  EXTLOOK,  CDF CIF 00          /EXIT LOOK TO FIELD 0
1406  5600  JMP I   XC8LOOK     /EXIT LOOK
1407  4775' REASK1, JMS   XC8INQU
1410  5205  JMP   EXTLOOK      /GOT CONTINUE CHAR


1575  0635
1576  0400
1577  0306
      0000  FIELD 0
```

```
0000
0100

0200  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
0300  11111111  11111111  11111111  11111111  11111111  11110001  11111111  11111111

0400  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
0500  11111111  11111111  11111111  11111111  11111000  00000000  11111111  11111111

0600  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
0700  11111111  11111111  11111111  11111111  11111110  01111111  11111111  11111111


1000  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
1100  11111111  11111111  11111111  11111110  00000000  00000000  00111111  11111111

1200  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
1300  11111111  11111111  11111111  11111111  11111111  11111111  10001111  11111111

1400  11111111  10000000  00000000  00000000  00000000  00000000  00000000  00000000
1500  00000000  00000000  00000000  00000000  00000000  00000000  00000000  00000111

1600
1700


2000
2100

2200
2300

2400
2500

2600
2700


3000
3100

3200
3300

3400
3500

3600
3700
```



```
4000
4100

4200
4300

4400
4500

4600
4700


5000
5100

5200
5300

5400
5500

5600
5700


6000
6100

6200
6300

6400
6500

6600
6700


7000
7100

7200
7300

7400
7500

7600
7700
```

```
1026
1027
1028
1029
1030                    / RX8/RX01 DIAGNOSTIC * MAINDEC-08-DIRXA-C
1031                    /
1032                    /STARTING ADDRESS 200 - (AC) = STARTUP SWITCHES
1033                    /
1034                    /STARTING ADDRESS 201 - RESTART (PARAMATERS ALREADY SELECTED AT START 200)
1035                    /
1036                    /STARING ADDRESS 202 - CHANGE DEVICE CODES.
1037                    /
1038                    /START-UP AC SWITCH DEFINITIONS (WHEN THE STARTING ADDRESS IS 200)
1039                    /
1040                    /  AC 0 - (0) TEST DISKETTE DRIVE 0
1041                    /  AC 1 - (0) TEST DISKETTE DRIVE 1
1042                    /  AC 2 - (0) RX01 CONTROL CABLED TO RX8
1043                    /  AC 3 -
1044                    /  AC 4 -
1045                    /  AC 5 -
1046                    /  AC 6 -
1047                    /  AC 7 - T
1048                    /  AC 8 - T     (FOR NORMAL PROGRAM)
1049                    /  AC 9 - T     (OPERATION, POSITION)
1050                    /  AC 10- T     (AC SWITCHES 7 THRU 11 = 0)
1051                    /  AC 11- T
1052                    /
1053                    /THE PRETEST IS NOT SWITCH SELECTABLE - THIS PRETEST IS ALWAYS
1054                    /EXECUTED PRIOR TO THE FIRST TTTTT SELECTION
1055                    /
1056                    /PRETEST - VERIFICATION OF INIT (KEY)
1057                    /
1058                    /    (PRETEST)  IB      - INIT PART I (KEY) / FLAG DETECTION PART I
1059                    /
1060                    /INTERFACE / CONTROL TESTS
1061                    /
1062                    /NOTE: * THE KEYBOARD IS " ALIVE " DURING TESTS 6, 7, 10, AND 11, AND 12
1063                    /IF A CHARACTER IS STRUCK AN ERROR MAY OCCUR
1064                    /
1065                    /     TTTTT
1066                    /
1067                    /       0       I       - FLAG DETECTION PART II / " C " LINES PART I
1068                    /       1       IB      - DIRECTION OF IOT XDR PART I / IOT DECODING PART I
1069                    /                       - " C " LINES PART II
1070                    /       2       IB      - FLAG DETECTION PART II / " C " LINES PART III
1071                    /       3       IB      - IOT DEVICE CODE VERIFICATION
1072                    /       4       IB      - DIRECTION OF IOT XDR PART II / " C " LINES PART IV
1073                    /       5       I       - IOT DECODING PATR II
1074                    /    *  6       IB/I    - INTERRUPT TESTING PART I / IOT DECODING PART III
1075                    /    *  7       IB      - INTERRUPT TESTING PART II
1076                    /    *  10      IB      - INTERRUPT TESTING PART III
1077                    /    *  11      I       - INTERRUPT TESTING PART IV
1078                    /    *  12      IB/1    - INIT PART II (PROGRAMMED) / INTERRUPT TEST PART V
1079                    /RX01 CONTROL TESTS
1080                    /
```



```
1081                    /       13      C       - FILL BUFFER 12-BIT MODE
1082                    /       14      C       - EMPTY BUFFER 12-BIT MODE
1083                    /       15      C       - VERIFICATION OF PREVIOUS TEST
1084                    /       16      C       - FILL BUFFER 8-BIT MODE
1085                    /       17      C       - EMPTY BUFFER 8-BIT MODE
1086                    /       20      C       - VERIFICATION OF PREVIOUS TEST
1087                    /       21      C       - FILL BUFFER 8-BIT MODE (ALL 0'S)
1088                    /       22      C       - FILL BUFFER 8-BIT MODE (ALL 1'S)
1089                    /
1090                    /DISKETTE DRIVE TESTS
1091                    /
1092                    /       23      D       - STATUS BIT "DRIVE READY"
1093                    /       24      D       - B-CODE VERIFICATION (70) PART I
1094                    /       25      D       - B-CODE VERIFICATION (70) PART II
1095                    /       26      D       - B-CODE VERIFICATION (70) PART III
1096                    /       27      D       - B-CODE VERIFICATION (40) PART IV
1097                    /       30      D       - SEEK AND CRC VERIFICATION
1098                    /       31      D       - WRITE TEST
1099                    /       32      D       - INIT PART III (PROGRAMMED) IMPLIED READ TRACK 1 SECTOR 1
1100                    /       33      D       - READ TEST
1101                    /       34      D       - WRITE-READ-PROGRAM VERIFY 12 BIT MODE
1102                    /       35      D       - WRITE-READ-PROGRAM VERIFY  8 BIT MODE
1103                    /       36      D       - WRITE-READ-PROGRAM VERIFY 12 BIT MODE WITH DELETED DATA
1104                    /       37      D       - WRITE-READ-PROGRAM VERIFY  8 BIT MODE WITH DELETED DATA
1105                    /
1106                    /       I - MEANS RX8 INTERFACE TEST
1107                    /       B - MEANS RX01 MAY BE CABLED TO RX8
1108                    /       C - MEANS AN RX01 MUST BE CABLED TO THE RX8
1109                    /       D - MEANS A DRIVE MUST BE READY
1110                    /
1111                    /OPERATIONAL AC SWITCH DEFINITIONS
1112                    /
1113                    /  AC 0 - (1) HALT ON DETECTION OF ERROR
1114                    /  AC 1 - (1) HALT AT END OF PASS
1115                    /  AC 2 -
1116                    /  AC 3 - PRINT AN ERROR MESSAGE
1117                    /  AC 4 - (1) LOCK SCOPE LOOP ON ERROR
1118                    /  AC 5 - (1) LOCK SCOPE LOOP ON TEST
1119                    /  AC 6 - (1) DISABLE THE ISSUING OF (INIT)
1120                    /  AC 7 - (1) HALT AT END OF A TEST
1121                    /  AC 8 -
1122                    /  AC 9 -
1123                    /  AC 10-
1124                    /  AC 11- (1) DISABLE RINGING OF BELL AT ERROR
1125                    /THE FOLLOWING MAP IS A SUMMARY OF ALL ERRORS.
1126                    /
1127                    /
1128                    /       ERA     TEST    BLANK   EAC     GOOD    COMMENT:
1129                    /
1130                    /
1131    1600  0410              E0PRE / PRETEST -       -       -       UNEXPECTED TRANSFER REQUEST FLAG
1132    1601  0413              E2PRE /         -       -       -       UNEXPECTED ERROR FLAG
1133    1602  0423              E3PRE /         -       -       -       MISSING DONE FLAG
1134    1603  0443              E1PRE /         STATUS  STATUS
1135                    /                       FROM    MINUS   4,      STATUS NOT = INIT DONE, OR
```

```
1136                    /                       TR      DEL     204     DRIVE READY + INIT DONE
1137                    /                               DATA
1138    1604  0446              E4PPE /         -       -       -       UNEXPECTED DONE FLAG
1139                    /
1140                    /
1141    1605  0620              E0 /    T0      -       X       0       IOT 67X1 DIDN'T CLEAR AC
1142    1606  0624              E1 /            -       -       -       UNEXPECTED TRANSFER REQUEST FLAG
1143    1607  0630              E2 /            -       -       -       UNEXPECTED ERROR FLAG
1144    1610  0634              E3 /            -       -       -       UNEXPECTED DONE FLAG
1145                    /
1146                    /
1147                    /       E11 /   T1      -       X       0       IOT 67X1 FAILED TO CLEAR AC
1148    1611  0660              E10 /           -       X       200     TR NOT = 200 (DRIVE READY)
1149                    /
1150                    /
1151                    /       E20 /   T2      -       -       -       MISSING DONE FLAG
1152    1612  0671              E21 /           -       -       -       MISSING TR FLAG
1153    1613  0674              E22 /           -       -       -       MISSING ERROR FLAG
1154    1614  0677              E23 /           -       -       -       MISSING DONE FLAG
1155    1615  0702              E24 /           -       -       -       MISSING TR FLAG
1156    1616  0705              E25 /           -       -       -       MISSING ERROR FLAG
1157    1617  0715              E26 /           -       X       7777    IOT 67X6 CLEARED AC
1158    1620  0723              E27 /           -       X       7777    IOT 67X3 CLEARED AC
1159    1621  0731              E28 /           -       X       7777    IOT 67X4 CLEARED AC
1160                    /
1161                    /
1162                    /
1163    1622  0755              E30 /   T3      -       X       67X5    (EAC) = ILLEGAL DEVICE CODE
1164                    /
1165                    /
1166                    /
1167    1623  1021              E42 /   T4      7776    X       200     IOT 67X1 CLEARED AC
1168                    /
1169                    /
1170    1624  1044              E40 /           TO              376
1171                    /                                       375     DATA TO TR NOT =
1172                    /                                       373     DATA FROM TR
1173    1625  1056              E41 /           7677            367     OR,
1174                    /                                       357     DATA FROM TR NOT =
1175                    /                                       337     DATA FROM TR PREVIOUSLY
1176                    /                                       7677
1177    1626  1076              E56 /   T5      -       X       0       (TR) NOT = 0
1178    1627  1101              E50 /           -       -       -       MISSING DONE FLAG
1179    1630  1105              E53 /           -       -       -       UNEXPECTED DONE FLAG
1180    1631  1110              E51 /           -       -       -       MISSING TR FLAG
1181    1632  1114              E54 /           -       -       -       UNEXPECTED TR FLAG
1182    1633  1117              E52 /           -       -       -       MISSING ERROR FLAG
1183    1634  1123              E55 /           -       -       -       UNEXPECTED ERROR FLAG
1184                    /
1185                    /
1186                    /
1187    1635  1137              E60 /   T6      -       -       -       UNEXPECTED RX01 IRQ
1188    1636  1147              E61 /           -       -       -       MISSING DONE FLAG
1189    1637  1152              E62 /           -       -       -       MISSING TR FLAG
1190    1640  1155              E63 /           -       -       -       MISSING ERROR FLAG
```



```
1191                    /
1192                    /
1193                    /
1194    1641  1213              E70 /   T7      -       -       -       MISSING RX01 IRQ
1195                    /
1196                    /
1197                    /
1198    1642  1227              E100 /  T10     -       -       -       UNEXPECTED RX01 IRQD
1199                    /
1200                    /
1201                    /
1202    1643  1253              E110 /  T11     -       -       -       UNXPECTED RX01 IRQ
1203                    /
1204                    /
1205                    /
1206    1644  1276              E124 /  T12     -       -       -       UNEXPECTED RX01 IRQ
1207    1645  1310              E120 /          -       -       -       UNEXPECTED DONE FLAG
1208    1646  1314              E121 /          -       -       -       UNEXPECTED TR FLAG
1209    1647  1320              E122 /          -       -       -       UNEXPECTED ERROR FLAG
1210    1650  1325              E123 /          -       X       0       (TR) NOT = 0
1211    1651  1411              EA120 / ALT 12  -       -       -       UNEXPECTED TR FLAG
1212    1652  1415              EA121 /         -       -       -       UNEXPECTED DONE FLAJG
1213    1653  1437              EA122 /         ACTUAL  ACTUAL  4 OR
1214                    /                       STATUS  MINUS   204     STATUS NOT = 4, OR 204
1215                    /                               DEL DAT
1216    1654  1450              EA123 /         -       X       0       THE B-CODE NOT = 0
1217                    /THE " XRSTB " SUBROUTINE WHICH READS THE B-CODE STATUS BY ISSUING
1218                    /COMMAND # 7 IS ENTERED FROM TESTS:   ***   ALT12, (T24, T25, T26), AND T27
1219                    /
1220                    /THE CONTENTS OF " BLANK " = THE CONTENTS OF GOOD FROM TEST: ALT12
1221                    /
1222    1655  2405              E7000 /         4/204   -       -       UNEXPECTED TR FLAG
1223    1656  2416              E7001 /         4/204   STATUS  -       UNEXPECTED ERROR FLAG
1224    1657  2430              E7002 /         4/204   X       7000    SHIFT REGISTER NOT SHIFTING
1225                    /
1226                    /
1227                    /
1228                    /THE " XRST " SUBROUTINE TO READ THE STATUS REGISTER BY ISSUING COMMAND # 5
1229                    /IS ENTERED FROM TESTS:   ***   ALT12, AND T23
1230                    /
1231    1660  2444              E7003 /         4/204   -       -       UNEXPECTED TR FLAG
1232    1661  2455              E7004 /         4/204   STATUS  -       UNEXPECTED ERROR FLAG
1233    1662  2467              E7006 /         4/204   STATUS  5000    SHIFT REGISTER NOT SHIFTING
1234    1663  2505              E7005 /         4/204   STATUS  0/200
1235                    /
1236                    /
1237                    /
1238                    /SUBROUTINE " FBEB " TO FILL AND EMPTY THE BUFFER IS ENTERED FROM TESTS:
1239                    / T13, T16 (FILL THE BUFFER) / T14, T17 (EMPTY THE BUFFER)
1240                    /
1241    1664  1512              E130 /          COMMAND -       -       UNEXPECTED ERROR FLAG
1242    1665  1525              E131 /          COMMAND ACTUAL  EXPECT  # OF TR FLAGS NOT OK
1243                    /                                               (EAC) = # OF FLAGS
1244                    /                                               NEG. # MEANS NOT ENOUGH
1245                    /                                               >0 MEANS TO MANY
```

```
                        /
                        /
                        /
                        /ERROR # 140 MAY OCCUR WITHIN TESTS T14, T17, T15, AND T20
                        /
                        /THE CONTENTS OF " BLANK " IS EQUIVALENT TO THE WORD/BYTE COUNT AT THE ERROR
                        /
                        /THE CONTENTS OF THE " EAC " IS EQUIVALENT TO THE ACTUAL DATA FROM THE SECTOR
                        /BUFFER (8 OR 12-BIT MODE)
                        /
                        /THE CONTENTS OF " GOOD " IS EQUIVALENT TO THE EXPECTED CONTENTS OF THE
                        /SECTOR BUFFER
                        /
1666  1661              E140 /  *       #       ACTUAL  EXPECT  DATA COMPARISON ERROR
                        / " FB128BYTES " IS A SUBROUTINE WHICH FILLS THE SECTOR BUFFER WITH 128 BYTES
                        /OF DATA (ALL 1'S OR ALL 0'S) AND IS ENTERED FROM TESTS T21, AND T22
                        /
1667  4557              E210 /  *       -       -       -       UNEXPECTED ERROR FLAG
                        /
                        /
                        /SUBROUTINE " TX " EMPTIES THE SECTOR BUFFER AND COMPARES THE DATA TO AN
                        /EXPECTED PATTERN
                        /
                        /THIS SUBROUTINE IS ENTERED FROM TESTS: *** T21, T22, (T24, T25, T26), AND T27
                        /
1670  2320              E211 /          #       ACAUAL  EXPECT  DATA COMPARISON ERROR
1671  2332              E212 /          -       -       -       UNEXPECTED ERROR FLAG
                        /
                        /
                        /
                        /ERRORS E240, E245, E241, AND E242 MAY OCCUR WITHIN TESTS: T24, T25, T26
                        /
                        /
                        /
1672  2030              E240 /  *       CMND    X       2       # OF TR FLAGS NOT OK
1673  2033              E245 /          CMND    -       -       MISSING ERROR FLAG
1674  2067              E241 /          ACTUAL  X       T24/200,300
                        /                                       T25/200
                        /                                       T26/300
1675  2100              E242 /          -       X       70      B=CODE NOT = 70
                        /
                        /
                        /
1676  2134              E270 /  T27     115     # OF    2       # OF TR FLAGS NOT OK
                        /                       XFERS
1677  7137              E271 /          -       -       -       MISSING ERROR FLAG
1700  2150              E272 /          -       X       40      B=CODE NOT = 40
      0000              *0
0000  0303              303             / C  IS THE REVESION
      0001              *1
0001  5402              JMP I IP1
                        /
                        /PROGRAM LOCATION 2 CONTAINS THE INTERRUPT RETURN ADDRESS
                        /
                        /PROGRAM LOCATION 2 IS MODIFIED WITHIN CERTAIN TESTS
```



```
                        /
0002  5405              IPI,    PI
                        /
      0005              *5
                        /***********
                        /CONSOLE
                        /***********

      4405              C8LOOK= JMS I   .
0005  1400              XC8LOOK                 /WAIT FOR TTY INPUT AND THEN RETURN

                        /*************
                        /
                        /AUTO INDEX REGISTER DEFINITION.
                        /
      0010              *10
0010  0000              A10,    0
0011  0000              A11,    0
0012  0000              A12,    0
0013  0000              A13,    0                       /TEST Q
      0020              *20
                        /
                        /THE FOLLOWING PROGRAM LOCATIONS (20, 21, AND 22, 23) ARE RESERVED FOR ACT8/A
                        /
0020  0500              0500            /SET FOR DRIVES 0 AND 1 DEVICE CODE 75
0021  4000              4000            /0000=PSEUDO SWITCH REGISTER IF ON ACTIVE CONSOLE
                                        /4000=USE HARDWARE SWITCH REGISTER


0022  0000              0000            /0000=NOT ACTIVE CONSOLE PACKAGE
                                        /0400= ACTIVE CONSOLE PACKAGE
      0024              *24

                        /*****************************************************************

                        /THE FOLLOWING CALLS ARE USED FOR THE CONSOLE PACKAGE

      4424  CHECKC8=          JMS I   .
0024  4516              XCHECK                  /USED TO CHECK IF THE CONSOLE IS ACTIVE

      4425  C8PASS=           JMS I   .
0025  0200              XC8PASS                 /END OF PASS FOR CONSOL

      4426  C8SWIT=           JMS I   .
0026  1351              XXC8PSW                 /ASK THE PSEUDO SWITCH QUESTION

      4427  C8INQU=           JMS I   .
0027  1345              XXC8INQU                /PRINT WAITING

      4430  C8CKSW=           JMS I   .
0030  1355              XXC8SW                  /CHECK IF USING HARDWARE SWIT REG
                        /*****************************************************************
                        /
                        /THE FOLLOWING PROGRAM LOCATIONS "OD", "ID", "FIRST", AND "LAST" MAY BE
                        /CHANGED BY THE OPERATOR MANUALLY HOWEVER FOLLOWING THESE RESTRICTIONS.
```

```
1356                    /
1357                    /               1.  THE CONTENTS OF " OD " (MIN VAL 0) MUST BE <= THE
1358                    /                   CONTENTS OF " ID " (MAX VAL 114).
1359                    /
1360                    /               2.  THE CONTENTS OF "FIRST" (MIN VAL 1) MUST BE <= THE
1361                    /                   CONTENTS OF "LAST" (MAX VAL 32)
1362                    /
1363                    /THE PROGRAM INITIALLY SETS THESE VALUES AT PROGRAM LOAD TIME
1364                    /
1365                    / (OD) = 52, AND (ID) = 53
1366                    /
1367                    /BECAUSE TRACK 53 IS THE TRACK AT WHICH THE RX01 MICROCONTROLLER WILL
1368                    /DECREASE THE WRITE CURRENT IN HALF
1369                    /
1370    0031  0001      OD,     1                       /OUTSIDE DIAMETER (MIN VALUE 0)
1371    0032  0114      ID,     114                     /INSIDE DIAMETER (MAX VALUE 114)
1372    0033  0001      FIRST,  1                       /FIRST SECTOR TO ACCESS (MIN VAL 1)
1373    0034  0032      LAST,   32                      /LAST SECTOR TO ACCESS (MAX VAL 32)
1374                    /
1375                    /PDP-8/E AUGMENTED INSTRUCTIONS
1376                    /
1377          4435      BSW=JMS I .
1378    0035  2612              XBSW            /BYTE SWAP
1379          6001      ION=6001
1380          6002      IOF=6002
1381          4570      LAS=CKSWIT
1382          7501      MQA=7501                        / "OR" (MQ) WITH (AC)
1383          7421      MQL=7421                        /MQ=AC (THEN CLEAR AC)
1384                    /
1385                    /DISKETTE IOT SUBROUTINES
1386                    /
1387          4436      TY8OCT=JMS I .
1388    0036  5200              XTY8OC1                         /TYPE EIGHT OCTAL DIGITS.
1389          4437      LCD=JMS I .
1390    0037  6200              XLCD
1391          4440      LCDA=JMS I .
1392    0040  6205              XLCDA
1393          4441      LCDB=JMS I .
1394    0041  6232              XLCDB
1395          4442      XDRIN=JMS I .
1396    0042  6400              XXDRIN
1397          4443      XDROUT=JMS I .
1398    0043  6403              XXDROUT
1399          4444      STR=JMS I .
1400    0044  6407              XSTR
1401          4445      SER=JMS I .
1402    0045  6414              XSER
1403          4446      SDN=JMS I .
1404    0046  6421              XSDN
1405          4447      INTR=JMS I .
1406    0047  6426              XINTR
1407          4450      INIT=JMS I .
1408    0050  6434              XINIT
1409          4451      INITB=JMS I .
1410    0051  6447              XINITB
```



```
1411                    /OPERATING SYSTEM SUBROUTINES
1412                    /
1413          4452      ERROR=JMS I .
1414    0052  2637              XERROR
1415          5453      EXIT=JMP I .
1416    0053  0450              MORETESTS               /EXIT FROM A TEST (IF RX8 ONLY )
1417          4454      DONE=JMS I .
1418    0054  4243              XDONE           /               FORM: "DONE; NO; YES"
1419          4455      GETAPATTERN=JMS I .
1420    0055  3035              XGETAPATTERN
1421          4456      GETASECTOR=JMS I .
1422    0056  4607              XGETASECTOR
1423          4457      GETATRACK=JMS I .
1424    0057  4261              XGETATRACK      /GET A TRACK FOR IOT LCD-B (TRACK #)
1425          4460      GETUNIT=JMS I .
1426    0060  4200              XGETUNIT        /SELECT A DISKETTE DRIVE
1427          4461      HLT=HALT
1428          4461      HALT=JMS I .
1429    0061  4115              XHALT
1430          4462      INITSECTORS=JMS I .
1431    0062  4600              XINITSECTORS
1432          4463      INITTRACKS=JMS I .
1433    0063  4250              XINITTRACKS
1434          4464      LOCKUP=JMS I .
1435    0064  2600              XLOCKUP
1436          5453      NOTEST=EXIT
1437          4465      OK=JMS I .
1438    0065  6123              XOK                             /SKIP IF NOT ON APT.
1439          4466      TICK=JMS I .
1440    0066  4127              XTICK
1441          4467      AERROR=JMS I .
1442    0067  4346              XAERRO
1443          4470      APT8=JMS I .
1444    0070  1546              XAPT8
1445          4471      WAIT=JMS I .
1446    0071  1722              XWAIT
1447          4472      CHEK22=JMS I .
1448    0072  2541              XCHK22                          /CHECK FOR APT SYSTEM.
1449          4473      PRINT=JMS I .
1450    0073  5244              XPRINT          /PRINT A MESSAGE; FORM: "PRINT; MESSAGE"
1451          4474      READ=JMS I .
1452    0074  3414              XREAD
1453          4475      READCOMPARE=JMS I .
1454    0075  3410              XREADCOMPARE
1455          4476      RST=JMS I .
1456    0076  2437              XRST            /STATUS AFTER "RST" COMMAND (12)  /  5 TIMES 2
1457          4477      RSTB=JMS I .
1458    0077  2400              XRSTB           /STATUS AFTER READ B-CODES COMMAND (16)  7 X 2
1459          4500      SETUP=JMS I .
1460    0100  4077              XSETUP
1461          4501      SPECIALTYPE=JMS I .
1462    0101  5351              XSPECIALTYPE
1463          4502      SCOPE=JMS I .
1464    0102  1332              XSCOPE
1465          4503      SUBSCOPE=JMS I .
```

```
1466    0103  1342            XSSCOPE
1467          4504    TAB=JMS I .
1468    0104  5215            XTAB            /              FORM: " TAB; N "
1469          4505    TY4OCT=JMS I .
1470    0105  5000            XTY4OCT                 /TYPE (4) OCTAL ; FORM: " TY4OCT; OCTAL "
1471          4506    TYPEIT=JMS I .
1472    0106  5305            XTYPEIT                 /TYPE 1 8 BIT ASCII,AC =ASCII,
1473          4507    WAITTY=JMS I .
1474    0107  5400            XWAITTY
1475          4510    WRITE=JMS I .
1476    0110  3200            XWRITE
1477                  /
1478                  /ACCUMULATION SWITCH REGISTER DEFINITIONS
1479                  /
1480          4000    SW0=4000
1481          2000    SW1=2000
1482          1000    SW2=1000
1483          0400    SW3=400
1484          0200    SW4=200
1485          0100    SW5=100
1486          0040    SW6=40
1487          0020    SW7=20
1488          0010    SW8=10
1489          0004    SW9=4
1490          0002    SW10=2
1491          0001    SW11=1
1492                  /OPERATING SYSTEM ALLOCATED STORAGE REFERENCES
1493                  /
1494    0111  0000    BUSY,           0               / = 1 = PROCESSING AN RX01 PROGRAM INTERRUPT
1495    0112  0000    COMMAND,        0               /DISKETTE COMMAND ; (AC) AT LCD
1496    0113  0000    COMPRERROR,     0               /PROGRAM DATA COMPARE ERRORS
1497    0114  0000    DTESTP,         0               /DIAGNOSTIC TEST PARAMATERS (SELECTED AT L/S )
1498    0115  7777    FIRSTERROR,     7777            / (7777) IF 1ST ERROR ; (0) IF NOT
1499    0116  0000    HANGER,         0               /COUNTER TO DETECT DEVICE TEST HUNG
1500    0117  7777    K7777,          -1              /
1501    0120  0000    RDC,            0               / = 0 IF A RDC TEST, = 7777 IF NOT
1502    0121  7765    KRETRY,         -13             / 1 ORIGINAL TRY + 10 RETRYS
1503    0122  7746    SECTORS,        -32             /NEGATIVE # OF SECTORS PER TRACK (1=32 OCTAL)
1504    0123  0000    SSTART,         0               /SECTOR LAST ACCESSED ( 0 = "HOME" )
1505    0124  0000    STARGET,        0               /TARGET SECTOR OF (UNITX)
1506    0125  0000    START,          0               /TRACK LAST ACCESSED
1507    0126  0000    ASTATUS,        0               /DISKETTE STATUS AT ERROR OR DONE
1508    0127  0000    BSTATUS,        0               /RX01 DEFINITIVE ERROR CODE REGISTER
1509    0130  0000    CSTATUS,        0               /STATUS FROM THE "READ STATUS" COMMAND
1510    0131  0000    TARGET,         0               /TARGET TRACK OF (UNITX)
1511    0132  0000    TESTP,          0               /TEST PARAMATERS (DYNAMIC BY PROGRAM)
1512    0133  0000    XA10,           0
1513    0134  0000    XA11,           0
1514                  /
1515                  /PROGRAM LOCATION XXX IS A TEMPORARY STORAGE REGISTER FOR DATA
1516                  /OR ADDRESSES OF DATA WHICH ARE CALLED WITHIN SUBROUTINES WHICH
1517                  /DO NOT CALL SUBROUTINES WHICH CALL THESE STORAGE REGISTERS
1518                  /
1519                  /XXX IS CALLED WITHIN THE FOLLOWING SUBROUTINES
1520                  /
```



```
1521                  /D,D/RX-ERROR (2)
1522                  /COMPARE (2)
1523                  /XGETAPATTERN (6)
1524                  /RDORWR (2)
1525                  /
1526    0135  0000    XXX,            0
1527                  /
1528    0136  7765    R1RETRY,        -13     /WERRORS        /WRITE ERROR RECOVERY
1529    0137  7765    R2RETRY,        -13     /RERRORS        /READ ERROR RECOVERY
1530    0140  0000    DWSLOG,         0       /DATAERRORS     /DATA ERROR WITH CRC STATUS ERROR
1531    0141  0000    DNSLOG,         0       /DNSERROKS      /DATA ERROR BUT NO CRC STATUS ERROR
1532    0142  0000    SNDLOG,         0       /SNDERROKS      /CRC STATUS ERROR BUT NO DATA ERROR
1533    0143  7765    SRETRY,         -13     /SERRORS        /SEEK ERROR RECOVERY
1534    0144  7765    PRETRY,         -13     /PERRORS        /PARITY ERROR RECOVERY
1535                  / (TRACKS) ARE SET TO THE NEGATIVE DIFFERENCE BETWEEN (OD), AND (ID)
1536                  / IN THE SUBOROUTNE "INITTRACKS "
1537                  /
1538    0145  7663    TRACKS,         -115            / -# OF TRACKS PER DISKETTE (-115 TO -1 DYNAMIC DECREMENT)
1539    0146  0115    TTRACKS,        115             / # OF TRACKS PER DISKETTE (115 TO 1 STATIC)
1540    0147  0000    XTARGET,        0               / ; (AC) = TRACK+SECTOR AT IOT LCD-B ; DESTINATION
1541    0150  0000    ECOMMAND,       0
1542    0151  0000    H1,             0
1543    0152  0000    GOBIT,          0               / > 0 MEANS EXPECTING AN RX01 PI, <= 0 MEANS NOT EXPECTING
1544
1545                  /
1546                  / (PAT-SUMCHECK) IS A NUMBER GENERATED WITHIN SUBROUTINE " XGETAPATTERN"
1547                  /EQUIVALENT TO SUMCHECK OF 60/124  [ 12/8 BIT MODE] DATA WORDS
1548                  /
1549    0153  0000    PATSUMCHECK,    0
1550                  /
1551                  / (WORDX) IS AN ADDRESS WHOSE CONTENTS = : (PAT-SUMCHECK) + (WBUFFER) + (WBUFFER+1)
1552                  /
1553                  / (WORDY) IS AN ADDRESS FOR WHICH THE CONTENTS REPRESENT THE NEGATIVE-1
1554                  /OF 2 TIMES THE CONTENTS OF THE ADDRESS WITHIN PROGRAM LOCATION " WORDX "
1555                  /
1556                  /THE CONTENTS OF BOTH WORDX AND WORDY ARE GENERATED WITHIN SUBROUTINE " XGETASECTOR "
1557                  /
1558    0154  0000    WORDX,          0
1559    0155  0000    WORDY,          0
1560    0156  0000    LSB,            0
1561    0157  0000    MSB,            0
1562    0160  0000    TTYBUSY,        0
1563    0161  0000    PASS,           0
1564    0162  0000            0               /PASS COUNT TO A MAGNITUDE OF 16777215(10)
1565    0163  0000    RXHERE,         0               / = 1000 IF AN RX01 IS CABLED TO THE RX8
1566    0164  0000    GOOD,           0               /EXPECTED RESULT
1567    0165  0000    EAC,            0               / (AC) AT ERROR "BAD" (ACTUAL RESULT)
1568    0166  0000    BLANK,          0
1569    0167  0611    TEST,           T0              /ADDRESS OF STARTING ADDRESS OF TEST
1570                  /*****************************************************************
1571                  /ADDITIONAL CALL FOR CONSOLE PACKAGE
1572
1573
1574          4570    CKSWIT=         JMS I   .
1575    0170  3400            XCKSWIT                 /CHECK IF LAS TO USE LOC 22 OR HARDWARE
```

```
1576          4571    C8CNTR= JMS I   .
1577    0171  1340            XXC8CNTR                /CHECK FOR CONSOLE CONTROL CHAR.
1578    0172  7000    K7000,  7000
1579    0173  0007    K0007,  0007
1580    0174  7777    XCNT,   -1
1581          4575    FORCE=JMS I .
1582    0175  5513            XXFORCE
1583                  /STARTING ADDRESS 200 - (AC) = STARTUP SWITCHES
1584                  /
1585                  /STARTING ADDRESS 201 - RESTART (PARAMATERS ALREADY SELECTED AT START 200)
1586                  /
1587                  /
1588          0200    *200
1589                  /
1590                          /*************
1591                          /CONSOLE
1592                          /*************
1593    0200  5202    C8STRT, JMP     .+2                             /NORMAL PROGRAM ACTIVITY.
1594    0201  5203            JMP     .+2                             /RESTART WITH SAME PARAMETERS.
1595                  /THIS SECTION IS NORMAL PROGRAM ACTIVITY.
1596                  /DEVICE  CODE 75 IS  ASSUMED. ANY OTHER WILL CAUSE ERRORS.
1597    0202  7240            STA
1598    0203  3010            DCA     A10
1599    0204  3160            DCA TTYBUSY
1600    0205  3111            DCA BUSY
1601    0206  3152            DCA GOBIT
1602    0207  3161            DCA PASS
1603    0210  3162            DCA PASS+1
1604    0211  1377            TAD (-40)
1605    0212  3116            DCA HANGER
1606    0213  3123            DCA SSTART
1607    0214  3131            DCA TARGET
1608    0215  1010            TAD     A10
1609    0216  7650            SNA CLA
1610    0217  5230            JMP     AROUND                  /USE EXISTING PARAMETERS.
1611
1612                          /************************
1613    0220  4776'           JMS     PNTID           /PRINT ID AND REMOVE DIAGNOSTIC
1614                          /************************
1615    0221  4424            CHECKC8                 /CONSOLE ACTIVE
1616    0222  4426            C8SWIT                  /ASK SR QUESTION.
1617    0223  5225            JMP     .+2
1618    0224  4461            HLT
1619    0225  4570            LAS                             /GET PARAMETERS.
1620    0226  3114            DCA     DTESTP
1621    0227  4775'           JMS     CHNDEV                          /CHANGE DEVICE  CODES.
1622    0230  1374    AROUND, TAD (1000)
1623    0231  0114            AND DTESTP
1624    0232  3163            DCA RXHERE/ = 0 IF RX01 CABLED TO RX8
1625    0233  1114            TAD DTESTP
1626    0234  7040            CMA
1627    0235  0373            AND (SW0+SW1)
1628    0236  3772'           DCA UNITS       / = UNITS TO TEST
1629    0237  4473            PRINT
1630    0240  6532            MDTESTP                 /TEST PARAMATER CONFIRMATION MESSAGE
```



```
1631    0241  4505            TY4OCT
1632    0242  0114            DTESTP
1633                  /THE PROGRAM WILL VERIFY THAT THE CONTENTS OF PROGRAM LOCATIONS:
1634                  /
1635                  /               OD, ID, FIRST, AND LAST
1636                  /
1637                  /WHICH ARE VARIABLE BY THE USER ARE WITHIN SELECTABLE LIMITS
1638                  /
1639                  / 0 <= OD <= 114
1640                  /
1641    0243  1031            TAD OD
1642    0244  7700            SMA CLA
1643    0245  5250            JMP .+3
1644    0246  1371            TAD (52)
1645    0247  3031            DCA OD
1646    0250  1370            TAD (-114)
1647    0251  1031            TAD OD
1648    0252  7740            SMA SZA CLA
1649    0253  5246            JMP .-5
1650    0254  4473            PRINT
1651    0255  6673            MOD
1652    0256  4505            TY4OCT
1653    0257  0031            OD
1654                  / 0 <= ID <= OD
1655                  /
1656    0260  1032            TAD ID
1657    0261  7700            SMA CLA
1658    0262  5265            JMP .+3
1659    0263  1367            TAD (53)
1660    0264  3032            DCA ID
1661    0265  1032            TAD ID
1662    0266  7041            CIA
1663    0267  1031            TAD OD
1664    0270  7740            SMA SZA CLA
1665    0271  5263            JMP .-6
1666    0272  4473            PRINT
1667    0273  6677            MID
1668    0274  4505            TY4OCT
1669    0275  0032            ID
1670                  / 0 < (FIRST) <= 32
1671                  /
1672    0276  1033            TAD FIRST
1673    0277  7740            SMA SZA CLA
1674    0300  5303            JMP .+3
1675    0301  7301            CLL CLA IAC
1676    0302  3033            DCA FIRST
1677    0303  1033            TAD FIRST
1678    0304  1366            TAD (-32)
1679    0305  7740            SMA SZA CLA
1680    0306  5301            JMP .-5
1681    0307  4473            PRINT
1682    0310  6703            MFIRST
1683    0311  4505            TY4OCT
1684    0312  0033            FIRST
1685    0313  5765'           JMP TADLAST
```

```
                        /IF THE TELEPRINTER IS BUSY (TTYBUSY = X), AND
                        /
                        /IF A KEYBOARD FLAG HAS OCCURED,
                        /
                        /THEN STOP TELEPRINTER OUTPUTS (IF A KRB = <CTRL>S ), OR
                        /
                        /THEN RESUME TELEPRINTER OUTPUTS (IF A KRB = <CTRL>Q
                        /AND A PREVIOUS <CTRL> Q HAD OCCURED)
                        /
0314  6036  XKCC,       KRB                             /READ THE KEYBOARD BUFFER STATIC
0315  0364              AND     (177
0316  1363              TAD     (200                    /MAKE IT 8 BIT CODE
0317  6211              CDF 10
0320  3751              DCA I   XC8CHAR                 /STORE IN FIELD ONE CHAR
0321  1751              TAD I   XC8CHAR                 /GET THE CHAR
0322  6201              CDF 0
0323  0364              AND (177)
0324  1362              TAD (-21)                       / <CTRL>Q
0325  7440              SZA
0326  5335              JMP NOTQ                        /  ?? <CTRL>S
                        /
                        /THE KEYBOARD BUFFER STATIC IS <CTRL>Q
                        /
                        /RESUME TELEPRINTER OUTPUTS
                        /
                        / (IF A PREVIOUS <CTRL>S HAD OCCURED)
                        /
0327  1160              TAD TTYBUSY                     / = 4000 IF A PREVIOUS <CTRL>S
0330  7700              SMA CLA
0331  5761'             JMP PIEXIT                      /NO PREVIOUS <CTRL>S
0332  7301              CLL CLA IAC
0333  3160              DCA TTYBUSY                     /  1
0334  5760'             JMP XTCF                        /RESUME TELEPRINTER OUTPUTS
                        /
                        /THE KEYBOARD BUFFER STATIC IS NOT A <CTRL>Q
                        /
                        /IF IT IS A <CTRL>S THEN SUSPEND TELEPRINTER OUTPUTS
                        /
0335  1357  NOTQ,       TAD (-2)
0336  7640              SZA CLA
0337  5343              JMP C8TEST                      /NOT A <CTRL>S EITHER
0340  7330              STL CLA RAR
0341  3160              DCA TTYBUSY                     /  4000
0342  5761'             JMP PIEXIT
                        /********
                        /CONSOLE
                        /!*******
0343  4424  C8TEST,     CHECKC8                 /CONSOLE ACTIVE.
0344  4571              C8CNTR                  /CHECK CONSOLE CONTROL CHARACTERS
0345  7000              NOP
0346  7200              CLA
0347  3160              DCA     TTYBUSY         /CLEAR FLAG
0350  5761'             JMP     PIEXIT          /EXIT
0351  1104  XC8CHAR,     CHAR                    /LOC IN FIELD 1
```



```
                        /********
                        /CONSOLE
                        /********
0357  7776
0360  5343
0361  5476
0362  7757
0363  0200
0364  0177
0365  3273
0366  7746
0367  0053
0370  7664
0371  0052
0372  4235
0373  6000
0374  1000
0375  5067
0376  1530
0377  7740
      0400              PAGE
                        /PRETEST - INITIALIZE (KEY) PART I / FLAG DETECTION PART I
                        /
                        / (A)   IF AN RX01 MICROCONTROLLER IS (NOT) CABLED TO THE RX8 INTERFACE,
                        /       THEN ALL FLAGS (DONE, TRANSFER REQUEST, AND ERROR) , AND THE RX8
                        /       INTERFACE TRANSFER TEGISTER SHOULD HAVE BEEN CLEARED BY "KEY"
                        /       INITIALIZE (IF THEY WERE EVER SET).
                        /
                        / (B)   IF AN RX01 MICROCONTROLLER (IS) CABLED TO THE RX8 INTERFACE,
                        /       THEN "KEY" INITIALIZE SHOULD HAVE (SET) THE DONE FLAG BECAUSE
                        /       ANY (INIT) OF THE RX01 MICROCONTROLLER IS AN IMPLIED (READ SECTOR)
                        /       OF TRACK 0 SECTOR 1 (FOR SYSTEMS PROGRAMMING BOOTSTRAP APPLICATIONS).
                        /
                        /       THEREFORE, ANY ERROR (EXCEPT PARITY) THAT MAY OCCUR FROM A NORMAL
                        /       "READ SECTOR" COMMAND MAY OCCUR HERE CAUSEING THE ERROR FLAG TO SET, AND
                        /       DISPLAYING THE ERROR STATUS WITHIN THE TRANSFER REGISTER AT "DONE".
                        /
                        /       THE TRANSFER REQUEST FLAG SHOULD BE CLEARED.
                        /
                        /NOTE:
                        /
                        /SCOPE LOOPING IS NOT OFFERED BECAUSE THE "INIT" FUNCTION
                        /
0400  7240  PRETEST,     STA
0401  3115              DCA FIRSTERROR          /FOR FIRST ERROR EVER THIS PASS
0402  3777'             DCA ERRORS                      /CLEAR "ERRORS" FOR FIRST "SCOPE" EVER
0403  4502              SCOPE                           /THIS "SCOPE" TO REFRESH "FAT" IF ERROR
0404  1776'             TAD PCSCOPE
0405  3167              DCA TEST                /TO REFRESH "FAT" FOR "ERROR"
0406  4444              STR
0407  4465              OK
0410  4452  E0PRE,      ERROR                           /UNEXPECTED TRANSFER REQUEST FLAG
0411  4445              SER
0412  4465              OK
```

```
1795    0413  4452    E2PRE,  ERROR                           /UNEXPECTED ERROR FLAG
1796                  /
1797                  /*****************************************************************************
1798                  /*****************************************************************************
1799                  /
1800                  /IF AN RX01 MICROCONTROLLER [IS] CABLED TO THE RX8 INTERFACE
1801                  /THEN THE DONE FLAG SHOULD BE SET
1802                  /
1803    0414  1163            TAD RXHERE
1804    0415  7640            SZA CLA
1805    0416  5227            JMP NORX01                      /
1806    0417  4471            WAIT
1807    0420  4446            SDN
1808    0421  5217            JMP     .-2                     /WAIT FOR DONE FLAG
1809    0422  7410            SKP
1810    0423  4452    E3PRE,  ERROR                           /MISSING DONE FLAG
1811                  /
1812                  /*****************************************************************************
1813                  /*****************************************************************************
1814                  /THE ENTIRE STATUS WORD IS DISPLAYED IN THE TRANSFER REGISTER AT ERROR/DONE TIME.
1815                  /
1816                  /IF AN RX01 CONTROLLER IS CABLED TO THE RX8 INTERFACE
1817                  / (AND DRIVE 0 IS READY THEN THE STATUS SHOULD INDICATE " SEL DRV RDY" ), ALSO
1818                  /DELETED DATA [MAY] = 1 IF TRACK 0/SECTOR 1 WAS WRITTEN WITH DELETED DATA
1819                  /AND "INIT DONE" SHOULD BE SET.
1820                  /
1821    0424  5775'           JMP     TSTUNT                          /OFF PAGE BECAUSE OF ROOM.
1822                  /
1823                  /
1824    0425  1374            TAD (40                 /PROGRAM EXPECTS DRIVE 0 TO BE READY
1825                  /
1826                  /
1827                  ////////////////////////////////////////////////////////////////////////////
1828                  /
1829                  /       4       5       -       -       8       9       10      11              /
1830                  /
1831                  /       SEL                             WRITE   INIT    PAR                     /
1832                  /       DRIVE   DD                      PROTECT [DONE]          CRC             /
1833                  /       RDY                                     (N/A)                           /
1834                  /
1835                  ////////////////////////////////////////////////////////////////////////////
1836                  /
1837                  /
1838    0426  7107            CLL IAC RTL                     / 4  [INIT] DONE OR 204
1839    0427  3164    NORX01, DCA GOOD
1840    0430  4442            XDRIN
1841    0431  3166            DCA BLANK                       /ACTUAL STATUS FROM [INIT]
1842    0432  1166            TAD BLANK
1843    0433  0773'           AND     COMP
1844    0434  3165            DCA EAC                         /STATUS MINUS DELETED DATA (BIT 5)
1845    0435  1165            TAD EAC
1846    0436  7041            CIA
1847    0437  1164            TAD GOOD                        /EXPECTED
1848    0440  7650            SNA CLA
1849    0441  5244            JMP .+3                         /OK
```



```
1850    0442  1165            TAD EAC
1851    0443  4452    E1PRE,  ERROR                           / [INIT] STATUS NOT = EXPECTED
1852                  /
1853                  /IF AN RX01 MICROCONTROLLER (IS) CABLED TO THE RX8 INTERFACE
1854                  /THEN THE PREVIOUS "SDN" SHOULD HAVE CLEARED THE DONE FLAG, BUT
1855                  /
1856                  /IF AN RX01 MICROCONTROLLER IS (NOT) CABLED TO THE RX8 INTERFACE
1857                  /THEN "KEY" INITIALIZE SHOULD HAVE CLEARED THE DONE FLAG
1858                  /
1859                  /TECHNICAL NOTE:
1860                  /
1861                  /IF THE DONE FLAG IS SET, AND IF THE INTERRUPT ENABLE FLIP-FLOP IS SET ILLEGALLY,
1862                  /THEN AN "UNEXPECTED RX01 INTERRUPT" WILL OCCUR IN T0 (IF AN RX01 CONTROLLER
1863                  / [IS] CABLED TO THE RX8 INTERFACE) OR IN T1 WHEN THE MAINTENANCE FLIP-
1864                  /FLOP "SETS ALL FLAGS"
1865                  /
1866    0444  4446            SDN
1867    0445  4465            OK
1868    0446  4452    E4PRE,  ERROR                           /UNEXPECTED DONE FLAG
1869                  /
1870                  /END OF PRE-TEST                        /END OF PRETEST
1871                  /
1872    0447  5345            JMP REBEGIN
1873                  /
1874    0450  4404    MORETESTS, LOCKUP
1875    0451  3777'   FIRSTTEST, DCA ERRORS
1876    0452  1413            TAD I A13
1877    0453  3167            DCA TEST                / FAT (FIRST ADDRESS OF TEST)
1878    0454  1167            TAD TEST
1879    0455  3776'           DCA PCSCOPE             / EQUIVALENT TO " SCOPE "
1880    0456  3772'           DCA WUNITS                      /FOR FIRST ENTRY INTO XGETUNIT THIS TEST
1881    0457  5567            JMP I TEST
1882                  /
1883                  /TESTS
1884                  /
1885    0460  0611    TESTS,  T0
1886    0461  0637            T1
1887    0462  0663            T2
1888    0463  0734            T3
1889    0464  1000            T4
1890    0465  1065            T5
1891    0466  1126            T6
1892    0467  1200            T7
1893    0470  1216            T10
1894    0471  1232            T11
1895    0472  1261            T12
1896    0473  1455            T13
1897    0474  1603            T14
1898    0475  1601            T15
1899    0476  1454            T16
1900    0477  1602            T17
1901    0500  1600            T20
1902    0501  1675            T21
1903    0502  1674            T22
1904    0503  2265            T23
```

```
1905  0504  1714          T24
1906  0505  1716          T25
1907  0506  1720          T26
1908  0507  2106          T27
1909  0510  2200          T30
1910  0511  2202          T31
1911  0512  2223          T32
1912  0513  2241          T33
1913  0514  2300          T34
1914  0515  2276          T35
1915  0516  2277          T36
1916  0517  2275          T37
1917  0520  0521          NOMORE-1
1918                /THERE ARE NO MORE TESTS
1919                /
1920                /PRINT AN END OF PASS INDICATOR
1921                /
1922                /           A = INTERFACE TEST OK (ONLY RX8 TO TEST)
1923                /           C = RX8 AND RX01 TEST OK
1924                /           D = RX8 AND RX01 AND DRIVE TESTING OK
1925                /
1926                /           - = AN ERROR OCCURED (DURING A, B, OR D)
1927                /
1928        0400    XD=0400
1929  0521  1371          TAD (XD)
1930  0522  3356    NOMORETESTS, DCA MX                 / (XI), (XC), (XD), OR 0
1931                /
1932                /NOTE:IF THE CONTENTS OF PROGRAM LOCATION FIRSTERROR = 0
1933                /THEN AN ERROR HAS OCCURED FOR THIS PASS
1934                /
1935  0523  1115          TAD FIRSTERROR
1936  0524  7640          SZA CLA
1937  0525  5330          JMP .+3
1938  0526  1370          TAD (5500)
1939  0527  3356          DCA MX          /  -
1940                      /*************
1941                      /CONSOLE
1942                      /*******
1943  0530  4424          CHECKC8
1944  0531  4430          C8CKSW
1945  0532  5767'         JMP C8RET2      /IF ACTIVE CONSOL DO C8RET2
1946                      /*************
1947  0533  4473          PRINT
1948  0534  0556          MX
1949  0535  2161          ISZ PASS
1950  0536  5341          JMP .+3
1951  0537  2162          ISZ PASS+1
1952  0540  7000          NOP
1953  0541  4570          LAS
1954  0542  0366          AND (SW1)
1955  0543  7640          SZA CLA
1956  0544  4461          HLT
1957  0545  1114    REBEGIN, TAD DTESTP
1958  0546  0365          AND (37)
1959  0547  1364          TAD (TESTS-1)
```



```
1960  0550  3013          DCA A13
1961  0551  7240          STA
1962  0552  3115          DCA FIRSTERROR          /FIRST ERROR SWITCH FOR EACH PASS
1963  0553  7340          CLL CLA CMA
1964  0554  3763'         DCA     CLKCNT                  /FOR APT TIMING
1965  0555  5251          JMP FIRSTTEST
1966                /
1967  0556  1100    MX,     TEXT "I"                        / I, C, OR D
1968  0563  4145
1969  0564  0457
1970  0565  0037
1971  0566  2000
1972  0567  0600
1973  0570  5500
1974  0571  0400
1975  0572  4236
1976  0573  2756
1977  0574  0040
1978  0575  2744
1979  0576  1364
1980  0577  1363
            0600          PAGE
1981                      /*****************************************
1982                      /ROUTINE FOR CONSOLE PASS
1983                      /
1984
1985  0600  4424    C8RET2,CHECKC8
1986  0601  4425          C8PASS
1987  0602  4461          HLT
1988  0603  6001          ION     /CONSOLE PASS
1989  0604  2161          ISZ PASS
1990  0605  5210          JMP .+3
1991  0606  2162          ISZ PASS+1
1992
1993  0607  7000          NOP
1994  0610  5777'         JMP REBEGIN             /CONTINUE WITH PROGRAM RETURN
1995                      /*****************************************
1996                /TEST 0 - FLAG DETECTION PART II / " C " LINES VERIFICATION PART I
1997                /
1998                /*****************************************************************************
1999                /*****************************************************************************
2000                /
2001                /IF AN RX01 MICROCONTROLLER IS CABLED TO THE RX8 INTERFACE
2002                /THEN DON'T EXECUTE THIS TEST
2003                /BECAUSE ISSUING THE IOT LCD WITH THE AC = 177
2004                /RESEMBLED A COMMAND TO THE RX01
2005                /
2006  0611  1163    T0,     TAD RXHERE
2007  0612  7650          SNA CLA
2008  0613  5453          NOTEST
2009  0614  3164          DCA GOOD
2010                /*****************************************************************************
2011                /*****************************************************************************
2012                /
2013                /THE PURPOSE OF THIS TEST IS TO VERIFY THAT THE LCD (LOAD COMMAND REGISTER)
```

```
                        /IOT 67X1 DOES [NOT] SET THE MAINTENANCE FLIP-FLOP WHEN THE CONTENTS
                        /OF THE AC = 177 AT THE TIME THE LCD IOT IS ISSUED.
                        /
                        /
                        /TECHNICAL NOTE:
                        /
                        /IF AN ERROP OCCURS, THEN IT IS ASSUMED [KEY] INIT FAILED TO CLEAR THE
                        /MAINTENANCE FLIP-FLOP, OR, THAT THE ISSUING OF THE LCD IOT REALLY
                        / [SET] THE MAINTENANCE FLIP-FLOP INSTEAD OF [CLEARING] .
                        /
                        / " C " LINES VERIFICATION PART I
                        /
0615  1376                      TAD (177)
0616  4437                      LCD                       /MAINTENANCE MODE <OFF>
                        /THE (AC) SHOULD = 0 BECAUSE IOT LCD 67X1 SHOULD CLEAR THE AC
                        /
0617  7440                      SZA
0620  4452              E0,     ERROR                             / IOT 67X1 DID NOT CLEAR THE AC
0621  4503                      SUBSCOPE
                        /
                        /FLAG DETECTION PART II
                        /
                        /THE PURPOSE OF THIS TEST IS TO VERIFY THAT ISSUING IOT LCD 67X1 WITH
                        /THE AC = 177 DOES NOT SET THE MAINTENANCE FLIP-FLOP
                        /WHICH IN TURN WOULD SET ALL FLAGS
                        /
                        /THEREFORE ALL FLAGS SHOULD BE CLEARED
                        /
0622  4444                      STR
0623  4465                      OK
0624  4452              E1,     ERROR                             /UNEXPECTED TRANSFER REQUEST FLAG
0625  4503                      SUBSCOPE
0626  4445                      SER
0627  4465                      OK
0630  4452              E2,     ERROR                             /UNEXPECTED ERROR FLAG
0631  4503                      SUBSCOPE
0632  4446                      SDN
0633  4465                      OK
0634  4452              E3,     ERROR                             /UNEXPECTED DONE FLAG
0635  4502                      SCOPE
0636  5453                      EXIT                              / END OF TEST 0
                        /
                        /TEST 1 - DIRECTION OF IOT XDR (67X2) PART I / IOT DECODING PART I
                        /
                        /       - " C " LINES VERIFICATON PART II
                        /
                        /THE PURPOSE OF THIS TEST IS TO VERIFY THAT
                        /ISSUING THE IOT XDR (TRANSFER DATA REGISTER) 67X2 DOES [NOT] CLEAR
                        /THE MAINTENANCE FLIP-FLOP
                        /
                        /TECHNICAL NOTE:
                        /
                        /THE IOT'S SDN (67X5), AND SER (67X4) ARE NOT TESTED HERE
                        /BECAUSE IF AN RX01 MICROCONTROLLER IS CABLED TO THE RX8 INTERFACE
                        /AND IF THE IOT LCD IS ISSUED WITH THE AC = 200
```



```
                        /REALLY CLEARS THE MAINTENANCE FLIP-FLOP
                        /THEN THE DONE FLAG, AND THE ERROR FLAG SHOULD BE CLEARED, AND
                        /TRANSFER REQUEST MAY BE SET
                        /BECAUSE THE CLEARING OF THE MAINTENANCE FLIP-FLOP WOULD HAVE
                        /RESEMBLED A COMMAND TO THE RX01 MICROCONTROLLER
                        /
                        /TECHNICAL NOTE:
                        /
                        /IF THE CONTENTS OF THE TRANSFER REGISTER IS NOT = 200, THEN IS MUST
                        /BE ASSUMED THAT THE SECOND LCD IOT CLEARED THE MAINTENANCE FLIP-FLOP
                        /OR THAT IOT XDR CLEARED THE MAINTENANCE FLIP-FLOP
                        /
0637  3164              T1,     DCA GOOD
0640  1375                      TAD (200)
0641  4437                      LCD     / MAINTENANCE MODE <ON>
                        /THE (AC) SHOULD = 0 AFTER ISSUING IOT LCD 67X1
                        /
0642  7440                      SZA
0643  4452              E11,    ERROR                             / IOT LCD 67X1 FAILED TO CLEAR AC
0644  4503                      SUBSCOPE
                        /
0645  1375                      TAD (200)
0646  4437                      LCD                       / MAINTENANCE MODE <ON>, AGAIN
0647  4442                      XDRIN                             /CONTENTS OF TRANSFER REGISTER
0650  3165                      DCA EAC                           /SAVE
0651  1165                      TAD EAC
0652  1374                      TAD (-200)                        /COMPARE WITH "EXPECTED"
0653  7650                      SNA CLA
0654  5261                      JMP .+5                           / OK
0655  1375                      TAD (200)
0656  3164                      DCA GOOD                          / "EXPECTED" RESULT
0657  1165                      TAD EAC                           / "ACTUAL" RESULT
0660  4452              E10,    ERROR                             /TRANSFER REGISTER NOT =200
0661  4502                      SCOPE
0662  5453                      EXIT                              / END OF TEST 1
                        /TEST 2 - FLAG DETECTION PART III / " C " LINES VERIFICATION PART III
                        /
                        / (A)   THE SETTING OF THE MAINTENANCE FLIP-FLOP SHOULD "DIRECT SET" ALL
                        /       FLAGS (DONE, TRANSFER REQUEST, AND ERROR).
                        /
                        / (B)   IF AN RX01 MICROCONTROLLER [IS] CABLED TO THE RX8 INTERFACE,
                        /       THEN THE SETTING OF THE MAINTENANCE FLIP-FLOP WILL ASSERT THE "RUN"
                        /       LINE (RESEMBLING A FILL BUFFER COMMAND) THUS CAUSING THE RX01
                        /       CONTROLLER TO SETUP FOR A "FILL BUFFER", BUT, HOWEVER, BECAUSE THE
                        /       MAINTENANCE FLIP-FLOP [IS] SET, THE RX8 INTERFACE RECIEVERS
                        /       SHOULD BE DISABLED AND NOT REACTIVE TO THE RX01 MICROCONTROLLER.
                        /
                        /WITH ALL FLAGS SET, THE RX8 INTERFACE IOT'S:
                        /
                        / SDN - "SKIP ON DONE" (67X5), AND
                        / SER - "SKIP ON ERROR" (67X4), AND
                        / STR - "SKIP ON TRANSFER REQUEST" (67X3) SHOULD SKIP
                        /
                        /TECHNICAL NOTE:
                        /
```

```
                        /IF FLAGS ARE "MISSING", IS THE MAINTENANCE MODE FLIP-FLOP REALLY SET ?
                        /
0663  1375    T2,       TAD (200)
0664  4437              LCD                         / MAINTENANCE <ON>
0665  4446              SDN
0666  4452    E20,      ERROR                               /MISSING DONE FLAG
0667  4503              SUBSCOPE
0670  4444              STR
0671  4452    E21,      ERROR                               /MISSING TRANSFER REQUEST FLAG
0672  4503              SUBSCOPE
0673  4445              SER
0674  4452    E22,      ERROR                               /MISSING ERROR FLAG
0675  4503              SUBSCOPE
                        /
                        /ALL FLAGS SHOULD REMAIN " DIRECT SET "
                        /BECAUSE THE MAINTENANCE FLIP-FLOP SHOULD STILL BE SET
                        /
                        /TECHNICAL NOTE:
                        /
                        /IF THE FLAGS ARE "MISSING" THEN IT IS ASSUMED THAT THE PREVIOUS
                        /FLAG TESTING ACTUALLY [CLEARED] THE FLAGS.
                        /
0676  4446              SDN
0677  4452    E23,      ERROR                               /MISSING DONE FLAG
0700  4503              SUBSCOPE
0701  4444              STR
0702  4452    E24,      ERROR                               /MISSING TRANSFER REQUEST FLAG
0703  4503              SUBSCOPE
0704  4445              SER
0705  4452    E25,      ERROR                               /MISSING ERROR FLAG
0706  4503              SUBSCOPE
                        / " C " LINES VERIFICATION PART III
                        /
                        /THE FOLLOWING RX8 INTERFACE IOT'S SHOULD NOT CLEAR THE AC:
                        /
                        /IOT'S: SDN(67X5), SER(67X4), OR STR(67X3)
                        /
0707  7240              STA
0710  3164              DCA GOOD
0711  1164              TAD GOOD
0712  6755    K67X5B,   6755
0713  7000              NOP
0714  7650              SNA CLA
0715  4452    E26,      ERROR                               / IOT SDN (67X5) CLEARED THE AC
0716  4503              SUBSCOPE
0717  1164              TAD GOOD
0720  6753    K67X3B,   6753
0721  7000              NOP
0722  7650              SNA CLA
0723  4452    E27,      ERROR                               / IOT STR (67X3) CLEARED THE AC
0724  4503              SUBSCOPE
0725  1164              TAD GOOD
0726  6754    K67X4B,   6754
0727  7000              NOP
0730  7650              SNA CLA
```



```
0731  4452    E28,      ERROR                               / IOT SER (67X4) CLEARED THE AC
0732  4502              SCOPE
0733  5453              EXIT                                / END OF TEST 2
                        /TEST 3
                        /
                        /RX8 IOT DEVICE CODE VERIFICATION
                        /
                        /THE PURPOSE OF THIS TEST IS TO VERIFY THAT ONLY THE DEVICE CODE SELECTED
                        /BY THE OPERATOR (AC SWITCHES 3-4-5 AT THE START OF THIS PROGRAM) IS ACTIVE.
                        /
                        /FIRST SET THE MAINTENANCE FLIP-FLOP, WHICH HAS PREVIOUSLY BEEN VERIFIED TO
                        /DIRECT SET ALL FLAGS, THEN SEQUENCE THROUGH ALL DEVICE CODES (EXPECT THE
                        /DEVICE CODE SELECTED AT THE START OF THIS PROGRAM) BY ISSUING IOT SDN 67X5
                        / (SKIP ON DONE FLAG), WHICH HAS ALSO PREVIUOSLY BEEN VERIFIED TO "SKIP AND
                        /CLEAR " SUCCESSFULLY.
                        /
                        /NOTE:
                        /
                        /THE PROGRAM DOES NOT ISSUE THE DEVICE CODE 67X5 WHERE X = POSITION OF AC
                        /SWITCHES 3-4-5 AT THE START 200 OF THIS PROGRAM.
                        /*****************************************************************
                        /*****************************************************************
                        /THIS TEST HAS BEEN REMOVED
                        /THIS TEST IS NOT NEEDED IN A SYSTEM ENVIRERMENT.
                        /TO REPLACE TEST T3 CHANGE LOCATIONS:
                        /       LOCATION  FROM    TO
                        /       ---------  ----    --
                        /       734       5464    1367
                        /
                        /       767         XXXX    0200
                        /REMOVED MAY 16,1975
                        ///
                        /
0734  5453    T3,       EXIT
0735  4437              LCD                         / MAINTENANCE <ON>
0736  1773*             TAD K67X5A
0737  3164              DCA GOOD
0740  1372              TAD (-7)
0741  3010              DCA A10
0742  1371              TAD (6705)
0743  3352    DCACTIVE, DCA ACTIVE
0744  4502              SCOPE                               /REFRESH PROGRAM LOCATION PCSCOPE
0745  1164              TAD GOOD
0746  7041              CIA
0747  1352              TAD ACTIVE
0750  7650              SNA CLA
0751  5357              JMP NEXTACTIVE
0752  6775    ACTIVE,   6775
0753  5357              JMP NEXTACTIVE
0754  1352              TAD ACTIVE
0755  4452    E30,      ERROR
0756  4502              SCOPE                         / (AC) = ILLEGAL DEVICE CODE
0757  1370    NEXTACTIVE, TAD (10)
0760  1352              TAD ACTIVE
0761  2010              ISZ A10
```

```
2234    0762  5343            JMP LCACTIVE
2235    0763  5453            EXIT                            / END OF TEST 3
2236    0770  0010
2237    0771  6705
2238    0772  7771
2239    0773  6422
2240    0774  7600
2241    0775  0200
2242    0776  0177
2243    0777  0545
              1000            PAGE
2244                  /TEST 4 - TRANSFER REGISTER DIRECTION TESTING (PART II)
2245                  /
2246                  /       - " C " LINES VERIFICATION PART IV
2247                  /
2248                  /WITH THE MAINTENANCE FLIP-FLOP SET THE PROGRAM WILL VERIFY THE DIRECTION
2249                  /AND TRANSFER MODE (8-BIT MODE INCLUSIVE "OR", AND 12-BIT MODE "JAM")
2250                  /TRANSFERS INTO THE ACCUMULATOR FROM THE RX8 TRANSFER REGISTER BY ISSUING
2251                  /IOT "XDR" (TRANSFER DATA REGISTER) 67X2 AFTER PREVIOUSLY [LOADING] THE
2252                  /THE TRANSFER REGISTER WITH THE CONTENTS OF THE ACCUMULATOR REPRESENT-
2253                  /ATIVE OF THE FLOLLOWING PATTERNS WHEN THE "LCD" IOT 67X1 IS ISSUED.
2254                  /
2255                  /               (1)     200     - MAINTENANCE MODE <ON>
2256                  /               (2)     376     -
2257                  /               (3)     375     -
2258                  /               (4)     373     - (BYTES 2 THRU 7)
2259                  /               (5)     367     - (INCLUSIVE "OR" )
2260                  /               (6)     357     -
2261                  /               (7)     337     -
2262                  /               (8)    7677     - (WORD 8 - "JAM " )
2263                  /
2264                  /THE LCD IOT WILL BE ISSUED A TOTAL OF 8 TIMES.
2265                  /
2266                  /THE 1ST LCD IOT WILL BE ISSUED WITH THE AC = 200 WHICH INITIALLY SETS THE
2267                  /MAINTENANCE FLIP-FLOP THEREBY GUARANTEEING THE CONTENTS OF THE TRANSFER
2268                  /REGISTER [AFTER] EACH SUCCEEDING LCD IOT.
2269                  /
2270                  /LCD IOT'S 2 THUR 8 ARE ISSUED WITH THE ACCUMULATOR CONTAINING THE PATTERNS
2271                  /DESCRIBED ABOVE.
2272                  /
2273                  /ALL PATTERNS EXCEPT WORD 8 (7677) TEST THE INCLUSIVE "OR" TRANSFER OF
2274                  /THE RX8 INTERFACE TRANSFER REGISTER.  WORD 8 TESTS THE 12-BIT "JAM" TRANSFER.
2275                  /
2276    1000  1377    T4,     TAD (200)
2277    1001  4437            LCD                     /MAINTENANCE MODE <ON>
2278    1002  7350            CLL STA RAR                     / 3777
2279    1003  3166            DCA BLANK
2280    1004  1166    T4B,    TAD BLANK
2281    1005  7120            STL
2282    1006  7500            SMA
2283    1007  7100            CLL
2284    1010  7004            RAL
2285    1011  3166            DCA BLANK
2286    1012  4502            SCOPE                           / REFRESH PROGRAM LOCATION PCSCOPE
2287    1013  1166            TAD BLANK                       / (BLANK) = (AC) BEFORE LCD IOT 67X1
```



```
2288    1014  4437            LCD                             /  TO
2289                  /
2290                  / " C " LINES VERIFICATION PART IV
2291                  /
2292                  /THE PURPOSE OF THIS TEST IS TO VERIFY THAT SUCCEEDING LCD IOT'S(67X1)
2293                  /TRANSFER THE (AC) INTO THE DATA REGISTER CLEARING THE ACCUMULATOR
2294                  /
2295    1015  3165            DCA EAC                         / (AC) AFTER ISSUING IOT LCD (67X1)
2296    1016  3164            DCA GOOD                        / PROGRAM EXPECTS AC = 0
2297    1017  1165            TAD EAC
2298    1020  7440            SZA
2299    1021  4452    E42,    ERROR                           / IOT LCD (67X1) DIDN'T CLEAR THE AC
2300    1022  4503            SUBSCOPE
2301                  /
2302                  /TRANSFER DIRECTION PART II
2303                  /
2304    1023  4442            XDRIN                           /  FROM
2305    1024  3165            DCA EAC
2306    1025  1376            TAD (100)
2307    1026  0166            AND BLANK
2308    1027  7106            CLL RTL
2309    1030  7006            RTL                             / LINK = 1 FOR 8-BIT MODE
2310    1031  7006            RTL
2311    1032  1166            TAD BLANK
2312    1033  7430            SZL
2313    1034  0375            AND (377)                       / 8-BIT BYTE "GOOD" MASK
2314    1035  3164            DCA GOOD
2315    1036  1164            TAD GOOD                        /EXPECTED RESULT
2316    1037  7041            CIA
2317    1040  1165            TAD EAC                         /ACTUAL RESULT
2318    1041  7650            SNA CLA
2319    1042  5245            JMP .+3                         /COMPARED OK
2320    1043  1165            TAD EAC
2321    1044  4452    E40,    ERROR                           / TRANSFER REGISTER NOT = "GOOD"
2322    1045  4503            SUBSCOPE
2323                  /
2324                  /THE TRANSFER REGISTER SHOULD REMAIN UNCHANGED
2325                  /FROM THE PREVIUS XDR IOT
2326                  /
2327    1046  4442            XDRIN                           /  FROM
2328    1047  3165            DCA EAC
2329    1050  1165            TAD EAC                         /ACTUAL
2330    1051  7041            CIA
2331    1052  1164            TAD GOOD                        /EXPECTED
2332    1053  7650            SNA CLA
2333    1054  5257            JMP .+3                         /COMPARED OK
2334    1055  1165            TAD EAC
2335    1056  4452    E41,    ERROR                           / TRANSFER REGISTER NOT = "GOOD"
2336    1057  4502            SCOPE
2337    1060  1166            TAD BLANK
2338    1061  0376            AND (100)
2339    1062  7640            SZA CLA
2340    1063  5204            JMP T4B                         /UNTIL (BLANK) = 7677
2341    1064  5453            EXIT                            / END OF TEST 4
2342                  /TEST 5
```

```
                        /
                        /RX8 IOT DECODING VERIFICATION PART II
                        /
                        /*****************************************************************************
                        /*****************************************************************************
                        /
                        /IF AN RX01 CONTROL IS CABLED TO THE RX8 INTERFACE
                        /THEN DON'T EXECUTE THIS TEST
                        /BECAUSE THE CLEARING OF THE MAINTENANCE F/F
                        /RESEMBLES A FILL BUFFER COMMAND
                        /
1065  1163      T5,     TAD RXHERE
1066  7650              SNA CLA
1067  5453              NOTEST
1070  3164              DCA GOOD
                        /*****************************************************************************
                        /*****************************************************************************
                        /
                        /THE MAINTENANCE FLIP-FLOP HAS PREVIOUSLY BEEN VERIFIED TO SET AND CLEAR.
                        /THE IOT UNDER TEST SHOULD "SKIP AND CLEAR" [ONLY] ITS RESPECTIVE FLAG.
                        /ALL OTHER FLAGS SHOULD REMAIN UNCHANGED
                        /
                        / (I.E. THE SDN IOT 67X5 SHOULD SKIP AND CLEAR ONLY THE DONE FLAG, ALL
                        /OTHER FLAGS SHOULD REMAIN SET)
                        /
1071  1377              TAD (200)
1072  4437              LCD
1073  4437              LCD             / MAINTENANCE <ON> / <OFF>
1074  4442              XDRIN
1075  7440              SZA
1076  4452      E56,    ERROR                           /TRANSFER REGISTER NOT = 0
1077  4503              SUBSCOPE
1100  4446              SDN
1101  4452      E50,    ERROR                           /DONE FLAG WASN'T SET, OR
1102  4503              SUBSCOPE                        /IOT LCD OR XDR CLEARED THE DONE FLAG
1103  4446              SDN
1104  4465              OK
1105  4452      E53,    ERROR
1106  4503              SUBSCOPE                        /IOT SDN DIDN'T "SKIP AND CLEAR"
1107  4444              STR
1110  4452      E51,    ERROR                           /TRANSFER REQUEST FLAG WASN'T EVER SET, OR
1111  4503              SUBSCOPE                        /IOT LCD, OR SDN OR XDR CLEARED THE TR FLAG
1112  4444              STR
1113  4465              OK
1114  4452      E54,    ERROR
1115  4503              SUBSCOPE                        /IOT STR DIDN'T "SKIP AND CLEAR"
1116  4445              SER
1117  4452      E52,    ERROR                           /ERROR FLAG WASN'T EVER SET, OR
1120  4503              SUBSCOPE                        /IOTS LCD OR SDN OR XDR OR STR CLEARED THE ERROR FLAG
1121  4445              SER
1122  4465              OK
1123  4452      E55,    ERROR
1124  4502              SCOPE                           /IOT SER DIDN'T "SKIP AND CLEAR"
1125  5453              EXIT                            / END OF TEST 5
                        /TEST 6 - INTERRUPT TEST PART I / IOT DECODING VERIFICATION PART III
```



```
                        /
                        /INTERRUPT TEST PART I
                        /
                        /THE MAINTENANCE FLIP-FLOP HAS PREVIOUSLY BEEN VERIFIED TO DIRECT
                        / [SET] ALL FLAGS AND THE INTERFACE IOT -SKIP ON DONE- "SDN" 67X5 WAS
                        /FOUND TO "SKIP AND CLEAR" SUCCESSFULLY,
                        /
                        /FIRST SET THE MAINTENANCE FLIP-FLOP WHICH IN TURN SETS ALL FLAGS.
                        /
                        /THEN ISSUE IOT INTP 67X6 WITH THE AC = 0 [CLEARING] THE RX8 INTERRUPT ENABLE
                        /NO INTERRUPTS SHOULD OCCUR
                        /
1126  4507      T6,     WAITIY
1127  1374              TAD (E60)
1130  3002              DCA IPI
1131  1377              TAD (200)
1132  4437              LCD
1133  4447              INTR                            /INTERRUPT ENABLE FLIP-FLOP <OFF>
1134  7000              NOP                             /...WAIT
1135  7000              NOP                             /...PLENTY
1136  7410              SKP                             /...OF TIME
1137  4452      E60,    ERROR                           /UNEXPECTED INTERRUPT
1140  4503              SUBSCOPE
                        /
                        /*****************************************************************************
                        /*****************************************************************************
                        /
                        /IF AN RX01 MICRO-CONTROLLER IS CABLED TO THE RX8 INTERFACE
                        /THEN DON'T EXECUTE THE REMAINING PORTION OF THIS TEST
                        /BECAUSE THE CLEARING OF THE MAINTENANCE FLIP-FLOP RESEMBLES A FILL BUFFER COMMAND
                        /TO THE RX01 MICROCONTROLLER
                        /
1141  1163              TAD RXHERE
1142  7650              SNA CLA
1143  5453              NOTEST
                        /
                        /*****************************************************************************
                        /*****************************************************************************
                        /
                        /IOT DECODING PART III- IOT INTR 67X6 DECODING VERIFICATION
                        /
                        /TECHNICAL NOTE:
                        /
                        /ALL FLAGS SHOULD REMAIN SET
                        /IF ANY FLAG IS MISSING,
                        /THEN IT IS ASSUMED THAT IOT "INTR" 67X6 CLEARED THE FLAG(S)
                        /
1144  4437              LCD                             /MAINTENANCE MODE <OFF>
1145  4447              INTR                            /DISABLE THE INTERRUPT ENABLE F/F
1146  4446              SDN
1147  4452      E61,    ERROR                           /MISSING DONE FLAG
1150  4503              SUBSCOPE
1151  4444              STR
1152  4452      E62,    ERROR                           /MISSING TRANSFER REQUEST FLAG
1153  4503              SUBSCOPE
```

```
2453    1154  4445          SER
2454    1155  4452    E63,  ERROR                         /MISSING ERROR FLAG
2455    1156  4502          SCOPE
2456    1157  5453          EXIT                          / END OF TEST 6
2457    1174  1137
2458    1175  0377
2459    1176  0100
2460    1177  0200
              1200          PAGE
2461                /
2462                /TEST 7 - INTERRUPT TEST PART II
2463                /
2464                /INTERRUPT TEST PART II
2465                /
2466                /THE MAINTENANCE FLIP-FLOP HAS PREVIOUSLY BEEN VERIFIED TO DIRECT
2467                / [SET] ALL FLAGS AND THE INTERFACE IOT -SKIP ON DONE- "SDN" 67X5 WAS
2468                /FOUND TO "SKIP AND CLEAR" SUCCESSFULLY,
2469                /
2470                /FIRST SET THE MAINTENANCE FLIP-FLOP
2471                /WHICH SHOULD DIRECT SET THE DONE FLAG,
2472                /THEN BY SETTING THE RX01 INTERRUPT ENABLE
2473                /BY ISSUING THE IOT "INTR" 67X6 WITH THE AC = 1.
2474                /
2475                /AN INTERRUPT REQUEST SHOULD BE ASSERTED.
2476                /
2477                /THE PROGRAM IS EXPECTING AN INTERPUPT.
2478                /
2479                /TECHNICAL NOTE:
2480                /
2481                /IF AN INTERRUPT DOES NOT OCCUR, THEN IT IS ASSUMED THAT ISSUING THE IOT
2482                / "INTR" 67X6 DID NOT SET THE RX8 INTERRUPT ENABLE, OR INTERRUPT REQUEST
2483                /
2484    1200  4507    T7,   WAITTY
2485    1201  1377          TAD (200)
2486    1202  4437          LCD                           /MAINTENANCE <ON>
2487    1203  1376          TAD (T70K)
2488    1204  3002          DCA IPI
2489    1205  6001          ION     /*SEE FOOTNOTE NEXT PAGE
2490    1206  7201          CLA IAC
2491    1207  4447          INTR                          /RX01 INTERRUPT ENABLE <ON>
2492    1210  7000          NOP
2493    1211  7000          NOP
2494                /PROGRAM NOTE:
2495                /
2496                /CLEAR PROGRAM LOCATION "GOBIT" BECAUSE THE TIME FOR THE INTERRUPT
2497                /TO OCCUR HAS EXPIRED (IF IT WAS EVER GOING TO OCCUR THAT IS)
2498                /
2499    1212  3152          DCA GOBIT
2500    1213  4452    E70,  ERROR                         /MISSING INTERRUPT
2501    1214  4502    T70K, SCOPE
2502    1215  5453          EXIT                          / END OF TEST 7
2503                /TEST 10
2504                /
2505                /INTERRUPT TEST (PART III)
2506                /
```



```
2507                /IOT INTR 67X6 SHOULD CLEAR THE INTERRUPT ENABLE FLIP-FLOP, THEN
2508                /
2509                /WITH ALL FLAGS SET, NO INTERRUPTS SHOULD OCCUR
2510                /
2511                /TECHNICAL NOTE:
2512                /
2513                /IF AN UNEXPECTED PROGRAM INTERRUPT OCCURS FROM APPROXIMATELY THIS PC
2514                /THEN THE RX PROGRAM INTERRUPT REQUEST TOOK TO LONG TO SET
2515                /FROM THE PREVIOUS TEST.
2516                /
2517                / * FOOTNOTE:
2518                /
2519                /THIS IOT "ION" IS ISSUED HERE BECAUSE - IF AN UNEXPECTED PROGRAM
2520                /INTERRUPT HAD OCCUPED IN THE PREVIOUS TEST AND AC SW3 = 1 DIRECTING
2521                /THE PROGRAM NOT TO PRINT AN ERROR - THEN THE PDP'S INTERRUPT FACILITY
2522                /WOULD BE <OFF> - THEREFORE NEVER EXECUTING THIS TEST PROPERLY
2523                /
2524    1216  4507    T10,  WAITTY
2525    1217  4447          INTR                          /DISABLE RX8 INTERRUPT ENABLE
2526    1220  1375          TAD (E100)
2527    1221  3002          DCA IPI
2528    1222  6001          ION     / *SEE FOOTNOTE ABOVE
2529    1223  1377          TAD (200)
2530    1224  4437          LCD
2531    1225  7000          NOP
2532    1226  7410          SKP
2533    1227  4452    E100, ERROR                         /UNEXPECTED INTERRUPT
2534    1230  4502          SCOPE
2535    1231  5453          EXIT                          / END OF TEST 10
2536                /TEST 11
2537                /
2538                /INTERRUPT TEST (PART IV)
2539                /
2540                /*************************************************************************
2541                /*************************************************************************
2542                /
2543                /IF AN RX01 CONTROL IS CABLED TO THE RX8 INTERFACE
2544                /THEN DON'T EXECUTE THIS TEST
2545                /BECAUSE THE CLEARING OF THE MAINTENANCE F/F
2546                /RESEMBLES A FILL BUFFER COMMAND
2547                /
2548    1232  1163    T11,  TAD RXHERE
2549    1233  7650          SNA CLA
2550    1234  5453          NOTEST
2551                /*************************************************************************
2552                /*************************************************************************
2553                /
2554                /TOGGLING THE MAINTENANCE MODE <ON> / <OFF> SETS ALL FLAGS AND
2555                /
2556                /PERMITS IOT SDN TO CLEAR THE DONE FLAG
2557                /
2558                /THEREFORE NO INTERRUPTS SHOULD OCCUR (ONLY DONE FLAG RAISES AN INTERRUPT REQUEST)
2559                /
2560                / (EVEN THOUGH THE RX01 INTERRUPT ENABLE IS 1 )
2561                /
```

```
2562    1235  4507            WAITTY
2563                  /
2564    1236  1377            TAD (200)
2565    1237  4437            LCD
2566    1240  4437            LCD             /MAINTENANCE <ON> / <OFF>
2567    1241  4446            SDN
2568    1242  7000            NOP
2569    1243  7000            NOP                     /CLEAR THE DONE FLAG
2570    1244  1374            TAD (E110)
2571    1245  3002            DCA IPI
2572    1246  7201            CLA IAC
2573    1247  4447            INTR                    /RX01 INTERRUPT ENABLE <ON>
2574    1250  7000            NOP
2575    1251  7000            NOP
2576    1252  7330            STL CLA RAR
2577    1253  4447    E110,   INTR                            /RX01 INTERRUPT ENABLE <OFF>
2578    1254  1152            TAD GOBIT
2579    1255  7700            SMA CLA
2580    1256  4452            ERROR                           /UNEXPECTED INTERRUPT
2581    1257  4502            SCOPE
2582    1260  5453            EXIT                            / END OF TEST 11
2583                  /TEST 12 - INITIALIZE TEST PART II (PROGRAMMED) / INTERRUPT TEST PART V
2584                  /
2585                  /*************************************************************************
2586                  /*************************************************************************
2587                  /
2588                  /IF AN RX01 IS CABLED TO THE RX8 THEN DON'T EXECUTE T12
2589                  /
2590                  /BUT EXECUTE ALT12 (THE ALTERNATIVE TEST)
2591                  /
2592    1261  1163    T12,    TAD RXHERE
2593    1262  7650            SNA CLA
2594    1263  5773'           JMP ALT12
2595                  /*************************************************************************
2596                  /*************************************************************************
2597                  /
2598                  /INTERRUPT TEST PART V / INITIALIZE TEST PART II (PROGRAMMED)
2599                  /
2600                  /THE PURPOSE OF THIS TEST IS TO VERIFY THAT IOT INIT CLEARS THE INTERRUPT
2601                  /ENABLE FLIP-FLOP WHEN SET
2602                  /
2603    1264  1372            TAD (E124)
2604    1265  3002            DCA IPI
2605    1266  7201            CLA IAC
2606    1267  4447            INTR                    / SET THE RX8 INTERRUPT ENABLE F/F
2607    1270  4451            INITB
2608    1271  3152            DCA GOBIT               / ISSUE INIT IOT 67X7
2609                  /...BUT AN INTERRUPT SHOULD NOT OCCUR
2610                  /
2611                  /IF AN INTERRUPT OCCURS THEN IOT INIT FAILED TO CLEAR
2612                  /
2613                  /THE RX8 INTERRUPT ENABLE FLIP-FLOP
2614                  /
2615    1272  1377            TAD (200)
2616    1273  4437            LCD
```



```
2617    1274  4437            LCD             / MAINTENANCE MODE <ON> / <OFF>
2618                  /
2619                  /THE DONE FLAG SHOULD BE SET, BUT NO INTERUPTS SHOULD OCCUR
2620                  /
2621    1275  7330            STL CLA RAR
2622                  /
2623                  /RETURN TO HERE IF AN INTERRUPT OCCURED
2624                  /
2625    1276  4447    E124,   INTR                            / RX8 INTERRUPT ENABLE <OFF>
2626    1277  1152            TAD GOBIT
2627    1300  7700            SMA CLA
2628    1301  4452            ERROR                           / IOT INIT 67X7 DID NOT CLEAR THE IE F/F
2629    1302  4503            SUBSCOPE
2630                  /
2631                  /IOT "INIT" 67X7 SHOULD CLEAR THE RX8 INTERFACE TRANSFER REGISTER, THE
2632                  /MAINTENANCE FLIP-FLOP, AND ALL FLAGS (DONE, TRANSFER REQUEST, AND ERROR).
2633                  /
2634    1303  7240            STA
2635    1304  4437            LCD                     /ALL 1'S TO TRANSFER REGISTER
2636    1305  4451            INITB                           / IOT 67X7
2637    1306  4446            SDN
2638    1307  4465            OK
2639    1310  4452    E120,   ERROR                           /UNEXPECTED DONE FLAG
2640    1311  4503            SUBSCOPE
2641    1312  4444            STR
2642    1313  4465            OK
2643    1314  4452    E121,   ERROR                           /UNEXPECTED TRANSFER REQUEST FLAG
2644    1315  4503            SUBSCOPE
2645    1316  4445            SER
2646    1317  4465            OK
2647    1320  4452    E122,   ERROR                           /UNEXPECTED ERROR FLAG
2648    1321  4503            SUBSCOPE
2649    1322  3164            DCA GOOD                        / PROGRAM EXPECTS TRANSFER REGISTER = 0
2650    1323  4442            XDRIN
2651    1324  7440            SZA
2652    1325  4452    E123,   ERROR                           /TRANSFER REGISTER NOT = 0
2653    1326  4502            SCOPE
2654                  /
2655                  /*************************************************************************
2656                  /*************************************************************************
2657                  /
2658                  /NO MORE RX8 INTERFACE TESTS EXIST
2659                  /
2660                  /IF AN RX01 CONTROL IS CABLED TO THE RX8 INTERFACE
2661                  /
2662                  /THEN CONTINUE WITH THE NORMAL FLOW OF TESTING
2663                  /
2664          1100    XI=1100
2665                  /
2666                  / END OF PASS " I "
2667                  /
2668    1327  4464            LOCKUP
2669    1330  1371            TAD (XI)
2670    1331  5770'           JMP NOMORETESTS
2671                  /*************************************************************************
```

```
                        /*****************************************************************************
1332  1332              XSCOPE, .
1333  1363                      TAD ERRORS
1334  7640                      SZA CLA
1335  5355                      JMP SCOPING
                        /NO ERROR HAS BEEN DETECTED HERE
                        /
                        /JUST SET (PCSCOPE)=THE FIRST ADDRESS OF THE SCOPE LOOP
                        /
                        / (IN CASE ANY ERRORS ARE EVER DETECTED LATER)
                        /
1336  3363              NOSCOPE, DCA ERRORS
1337  1332                      TAD XSCOPE
1340  3364                      DCA PCSCOPE
1341  5732                      JMP I XSCOPE
                        /  " SUBSCOPE "
                        /
1342  1342              XSSCOPE, .
1343  1342                      TAD XSSCOPE
1344  3332                      DCA XSCOPE
1345  1363                      TAD ERRORS
1346  7650                      SNA CLA
1347  5732                      JMP I XSCOPE
                        /ERRORS DO EXIST
                        /
                        /IF THIS ERROR IS THE SAME AS THE ADDRESS WITHIN THE PROGRAM LOCATION
                        /PCSSCOPE, THEN THIS IS A SCOPE LOOP
                        /
                        /IF NOT, THEN EXIT
                        /
1350  1332                      TAD XSCOPE
1351  7041                      CIA
1352  1362                      TAD EPCSCOPE
1353  7640                      SZA CLA
1354  5732                      JMP I XSCOPE
                        /THIS IS A SCOPEING LOOP
                        /
1355  4570              SCOPING, LAS
1356  0377                      AND (SW4)
1357  7650                      SNA CLA
1360  5336                      JMP NOSCOPE
1361  5764                      JMP I PCSCOPE
1362  0000              EPCSCOPE,       0               /ADDRESS +1 OF  "SCOPE" OR "SUBSCOPE"
1363  0000              ERRORS,         0               / > 0 IF AN ERROR HAS BEEN DETECTED (FOR THIS TEST)
1364  0000              PCSCOPE,        0               / FIRST ADDRESS OF SCOPE LOOP
1370  0522
1371  1100
1372  1276
1373  1400
1374  1253
1375  1227
1376  1214
1377  0200
      1400                      PAGE
                        /ALTERNATE TEST 12 - VERIFICATION OF [INIT]
```



```
                        /
                        /INITIALIZE TEST PART II
                        /
                        /THIS TEST IS EXECUTED IN PLACE OF T12
                        /
                        /BECAUSE AN RX01 CONTROLLER IS CABLED TO THE RX8 INTERFACE
                        /
                        /IOT "INIT" 67X7 WILL PERFORM AN IMPLIED READ OF TRACK 0 SECTOR 1
                        /
                        / (IF DRIVE 0 IS READY)
                        /
                        /THEREFORE THE DONE FLAG SHOULD SET AT THE END OF THAT IMPLIED READ.
                        /
                        /TECHNICAL NOTE:
                        /
                        /IF AN ERROR FLAG IS SET (AND DRIVE 0 IS READY) THEN THE ERROR MAY HAVE
                        /BEEN THE RESULT FROM THE [IMPLIED READ SECTOR 0]
                        /
1400  4502              ALT12,  SCOPE
1401  4451                      INITB
1402  4444              ALT12LOOP, STR
1403  7410                      SKP
1404  5211                      JMP EA120               /UNEXPECTED TRANSFER REQUEST FLAG
1405  4446                      SDN
1406  5202                      JMP ALT12LOOP           /WAIT FOR THE DONE FLAG
1407  4444                      STR
1410  4465                      OK
1411  4452              EA120,  ERROR                           /UNEXPECTED TRANSFER REQUEST
1412  4503                      SUBSCOPE
1413  4445                      SER
1414  4465                      OK
1415  4452              EA121,  ERROR                           /UNEXPECTED ERROR FLAG
1416  4503                      SUBSCOPE
1417  1777*                     TAD UNITS                       /UNITS SELECTED BY OPERATOR
1420  7710                      SPA CLA
1421  1376                      TAD (40                 /PROGRAM EXPECTS DRIVE 0 TO BE READY
                        /
                        /
                        ////////////////////////////////////////////////////////////////////////////
                        /
                        /       4       5       -       -       8       9       10      11      /
                        /
                        /       SEL                             WRITE   INIT    PAR             /
                        /       DRIVE   DD                      PROTECT [DONE]          CRC     /
                        /       RDY                                             (N/A)           /
                        /
                        ////////////////////////////////////////////////////////////////////////////
                        /
                        /
1422  7107                      CLL IAC RTL                     /  4 [INIT] DONE, OR 204
1423  3164                      DCA GOOD
1424  4442                      XDRIN                           / "ACTUAL" STATUS AT DONE
1425  3166                      DCA BLANK
1426  1166                      TAD BLANK
1427  0375                      AND (-100-1)
```

```
2781  1430  3165          DCA EAC                         / "ACTUAL" MINUS DELETED DATA (IF ANY)
2782  1431  1165          TAD EAC
2783  1432  7041          CIA
2784  1433  1164          TAD GOOD                        /EXPECTED STATUS
2785  1434  7650          SNA CLA
2786  1435  5240          JMP .+3                         /COMPARED OK
2787  1436  1165          TAD EAC
2788  1437  4452  EA122,  ERROR                           /TRANSFER REGISTER NOT = "GOOD"
2789  1440  4503          SUBSCOPE
2790                      /
2791                      /READ THE B-CODE STATUS AND EXPECT = 0
2792                      /
2793                      /PROGRAMMING NOTE:
2794                      /
2795                      /THE PROGRAM SAVES THE CONTENTS OF "GOOD" FOR REFERENCES WITHIN SUBROUTINE "XRST"
2796                      /
2797                      /BECAUSE "GOOD" IS REFRESHED WITHIN PROGRAM SUBROUTINE "XRSTB"
2798                      /
2799  1441  1164          TAD GOOD
2800  1442  3166          DCA BLANK
2801  1443  4477          RSTB
2802  1444  7650          SNA CLA
2803  1445  5251          JMP .+4
2804  1446  3164          DCA GOOD                        /PROGRAM EXPECTS 0
2805  1447  1165          TAD EAC
2806  1450  4452  EA123,  ERROR                           /B-CODE NOT = 0
2807  1451  4503          SUBSCOPE
2808                      /
2809                      /READ THE CONTENTS OF THE RX01 STATUS REGISTER USING THE COMMAND # 5
2810                      /
2811                      /THIS STATUS SHOULD = THE STATUS IN THE TRANSFER REGISTER AT ERROR/DONE
2812                      /
2813  1452  4476          RST                             / "READ STATUS" (COMMAND # 5)
2814                      /
2815  1453  5453          EXIT                            / END OF TEST ALT12 (TEST 12)
2816                      /THE PURPOSE OF THESE TESTS IS TO VERIFY THE TRANSFER LENGTH OF THE FUNCTION
2817                      / "FILL BUFFER" AND "EMPTY BUFFER" OF THE RX01 MICROCONTROLLER
2818                      /
2819                      /64 TRANSRERS SHOULD OCCUR FOR 12-BIT MODE, AND
2820                      /128 TRANSFERS SHOULD OCCUR FOR 8-BIT MODE
2821                      /
2822                      /THE SECTOR BUFFER IS FILLED WITH A COUNT PATTERN
2823                      /
2824                      /               WORD/BYTE 0 = 0
2825                      /
2826                      /               WORD 2 = 0202
2827                      /               BYTE 2 = 2
2828                      /
2829                      /               WORD 77 = 7777
2830                      /               BYTE 177 = 177
2831                      /
2832                      /FILL BUFFER 8-BIT MODE
2833                      /
2834  1454  1374  T16,    TAD (100)
2835                      /
```



```
2836                      /FILL BUFFER 12-BIT MODE
2837                      /
2838  1455  4437  T13,    LCD                             /ISSUE THE COMMAND
2839  1456  1374          TAD (100)
2840  1457  0112          AND COMMAND
2841  1460  7640          SZA CLA
2842  1461  7307          CLL CLA IAC RTL         /  4
2843  1462  1373          TAD (6000)
2844  1463  3132          DCA TESTP
2845  1464  4455          GETAPATTERN
2846  1465  1372          TAD (WBUFFER-1)
2847  1466  3010          DCA A10           /PROGRAMS "WRITE" BUFFER
2848  1467  1371          TAD (-WBUFFER+1)
2849  1470  3133          DCA XA10                / -STARTING ADDRESS OF WRITE BUFFER
2850  1471  4276  FB,     JMS FBEB
2851  1472  5453          EXIT                            / ** END OF TESTS 13, OR 16
2852  1473  1410          TAD I A10
2853  1474  4443          XDROUT
2854  1475  5271          JMP FB            / AND "FILL THE BUFFER"
2855                      / FILL / EMPTY BUFFER SUBROUTINE FOR TESTS:     ***     13, 16 / 14, 17 ***
2856                      /
2857  1476  1476  FBEB,   .
2858  1477  4444          STR
2859  1500  5303          JMP .+3                         /WAIT FOR TRANSFER REQUEST FLAG
2860  1501  2276          ISZ FBEB
2861  1502  5676          JMP I FBEB
2862  1503  4446          SDN
2863  1504  5277          JMP FBEB+1                      /WAIT FOR THE DONE FLAG
2864  1505  3006          DCA     6                       /FIRST TIME  FOR WAIT.
2865  1506  1112          TAD COMMAND
2866  1507  3166          DCA BLANK
2867  1510  4445          SER
2868  1511  4465          OK
2869  1512  4452  E130,   ERROR                           /UNEXPECTED ERROR FLAG
2870  1513  4503          SUBSCOPE
2871                      /
2872                      / 64 OR 128 BYTES SHOULD HAVE BEEN TRANSFERRED IN OR OUT
2873                      /
2874  1514  1374          TAD (100)
2875  1515  0112          AND COMMAND                     / 200 FOR 8-BIT MODE
2876  1516  1374          TAD (100)
2877  1517  3164          DCA GOOD
2878  1520  1164          TAD GOOD
2879  1521  7041          CIA                             / 100 FOR 12-BIT MODE
2880  1522  1010          TAD A10
2881  1523  1133          TAD XA10
2882  1524  7440          SZA                             /SKIP IF TRANSFERS OK
2883  1525  4452  E131,   ERROR                           / (AC) = - # MEANS NOT ENOUGH TRANSFERS
2884  1526  4502          SCOPE                           / (AC) > 0 MEANS TO MANY TRANSFERS
2885  1527  5676          JMP I   FBEB                    /RETURN IS TO EXIT
2886
2887
2888                      /******************
2889                      /CONSOLE PACKAGE
2890                      /******************
```

```
2891                            /************
2892                            /CONSOL
2893                            /************
2894
2895    1530  0000    PNTID, 0                                /PRINT BEGIN MESSAGES
2896    1531  6007            CAF                             /TO REPLACE A CLEAR SWITCH
2897    1532  4470            APT8                            /TEST FOR APT SYSTEM.
2898    1533  4473            PRINT
2899    1534  6471            MIDENTIFICATION         /ID MESSAGE
2900    1535  4473            PRINT
2901    1536  6452            REMOVE                  /REMOVE DIAGNOSTIC DISKETTE
2902    1537  4424            CHECKC8
2903    1540  4405            C8LOOK                          /WAIT FOR CONTROL E TO CONTINUE
2904    1541  7000            NOP                             /REQUIRED.
2905    1542  4473            PRINT
2906    1543  6504            MSELECT                 /SELECT PARAMETERS
2907    1544  7200            CLA
2908    1545  5730            JMP I   PNTID                   /EXIT PNTID
2909                            /************************************
2910                    /
2911                    /
2912                    /
2913                    /
2914                    /
2915                    /ROUTINE TO DETERMINE IF ON APT-8. IF APT-8 IS SELECTED
2916                    /THEN CONSOLE AND TEST PARAMETER SELECTION FUNCTIONS ARE NOP.
2917                    /IF NOT ROUTINE IS NOP.
2918                    /
2919    1546  0000    XAPT8,  0
2920    1547  7300            CLA CLL
2921    1550  4472            CHEK22
2922    1551  7410            SKP                             /ON APT-8
2923    1552  5746            JMP I   XAPT8
2924    1553  1022            TAD     22
2925    1554  0362            AND     K7377                   /NOP CONSOLE PACKAGE
2926    1555  3022            DCA     22                      /RESTORE 22
2927    1556  1172            TAD     K7000
2928    1557  3763            DCA I   HLTNOP
2929    1560  1020            TAD     20                      /GET TEST PARAMETERS.
2930    1561  5770'           JMP     AROUND-2                /MAIN FLOWOF PROGRAM.
2931    1562  7377    K7377,  7377
2932    1563  3316    HLTNOP, C8RET4-1
2933    1570  0226
2934    1571  0666
2935    1572  7112
2936    1573  6000
2937    1574  0100
2938    1575  7677
2939    1576  0040
2940    1577  4235
              1600              PAGE
2941                    /SECTOR BUFFER ADDRESSING VERIFICATION TESTS
2942                    /
2943                    /OPERATIONAL NOTE:
2944                    /
```



```
2945                    / (1).  FOR TEST 14 TO EMPTY THE BUFFER IN 12-BIT MODE SUCCESSFULLY, TEST 13
2946                    /       MUST HAVE FILLED THE BUFFER IN 12-BIT MODE SUCCESSFULLY.
2947                    /
2948                    / (2).  FOR TEST 17 TO EMPTY THE BUFFER IN 8-BIT MODE SUCCESSFULLY, TEST 16
2949                    /       MUST HAVE FILLED THE BUFFER IN 8-BIT MODE SUCCESSFULLY
2950                    /
2951                    /THE PURPOSE OF THESE TESTS IS TO VERIFY THAT THE CONTENTS OF THE SECTOR
2952                    /BUFFER REMAIN UNCHANGED AFTER THE PREVIOUS EMPTY BUFFER 8-BIT MODE TEST, AND
2953                    /AFTER THE PREVIOUS EMPTY BUFFER 12-BIT MODE TEST
2954                    /
2955    1600  7410    T20,    SKP                                     /VERIFY EMPTY BUFFER 8-BIT MODE
2956                    /
2957    1601  7410    T15,    SKP                                     /VERIFY EMPTY BUFFER 12-BIT MODE
2958                    /
2959                    /THE PURPOSE OF THESE TESTS IS TO VERIFY THE CONTENTS OF THE SECTOR BUFFER AFTER
2960                    /THE PREVIOUS FILL BUFFER 8-BIT MODE TEST, AND THE PREVIOUS FILL BUFFER
2961                    /12-BIT MODE TEST.
2962                    /
2963                    /EMPTY BUFFER 8-BIT MODE
2964                    /
2965    1602  1377    T17,    TAD (40
2966                    /
2967                    /EMPTY BUFFER 12-BIT MODE
2968                    /
2969    1603  7105    T14,    CLL IAC RAL
2970    1604  4437            LCD                             /ISSUE THE COMMAND 2 OR 102
2971    1605  1376            TAD (100)
2972    1606  0112            AND COMMAND
2973    1607  7640            SZA CLA
2974    1610  7307            CLL CLA IAC RTL
2975    1611  1375            TAD (6000)
2976    1612  3132            DCA TESTP
2977    1613  4455            GETAPATTERN     / COUNT PATTERN ( PATTERN #6)
2978    1614  1374            TAD (RBUFFER-1)
2979    1615  3010            DCA A10         /PROGRAMS "READ" BUFFER
2980    1616  1373            TAD (-RBUFFER+1)
2981    1617  3133            DCA XA10                / -STARTING ADDRESS OF READ BUFFER
2982    1620  1010            TAD A10
2983    1621  3011            DCA A11                 /
2984    1622  4772'   EB,     JMS F8EB
2985    1623  5230            JMP EBCOMPARE
2986    1624  3410            DCA I A10
2987    1625  4442            XDRIN
2988    1626  3411            DCA I A11               / AND "EMPTY THE BUFFER"
2989    1627  5222            JMP EB                          /
2990                    /COMPARE THE CONTENTS OF THE SECTOR BUFFER
2991                    /
2992                    /WITH THE GOOD DATA IN "WBUFFER"
2993                    /
2994    1630  1371    EBCOMPARE, TAD (WBUFFER-1)
2995    1631  3133            DCA XA10                /EXPECTED
2996    1632  1374            TAD (RBUFFER-1)
2997    1633  3134            DCA XA11                /ACTUAL
2998    1634  3113            DCA COMPRERROR                  / = 1 IF COMPARE ERROR
2999                    /
```

```
3000    1635  2133    EBLOOP, ISZ XA10
3001    1636  2134            ISZ XA11
3002    1637  7100            CLL
3003    1640  1376            TAD (100)
3004    1641  0112            AND COMMAND
3005    1642  7640            SZA CLA
3006    1643  7120            STL                             /SET LINK IF 8-BIT MODE
3007    1644  1533            TAD I XA10
3008    1645  7430            SZL
3009    1646  0370            AND (377)
3010    1647  3164            DCA GOOD
3011    1650  1164            TAD GOOD
3012    1651  7041            CIA
3013    1652  1534            TAD I XA11
3014    1653  7650            SNA CLA
3015    1654  5263            JMP EBOK
3016                  /A COMPARE ERROR HAS OCCURED
3017                  /
3018                  /INCORRECT DATA WAS TRANSFERRED FROM THE RX01 CONTROL SECTOR BUFFER
3019                  /TO THE RX8 INTERFACE AND SAVED WITHIN PROGRAM LOCATIONS BEGINNING WITH "RBUFFER"
3020                  /
3021                  /THAT DATA, HOWEVER, MAY HAVE BEEN TRANSFERRED INCORRECTLY  *TO*
3022                  /THE RX01 CONTROL FROM THE RX8 INTERFACE PREVIOUSLY WITHIN T12, OR T15
3023                  /
3024    1655  1367            TAD (-WBUFFER)
3025    1656  1133            TAD XA10
3026    1657  3166            DCA BLANK
3027    1660  1534            TAD I XA11                      /ACTUAL WORD/BYTE FROM SECTOR BUFFER
3028    1661  4452    E140,   ERROR                           /IS NOT = EXPECTED
3029    1662  4502            SCOPE
3030    1663  1376    EBOK,   TAD (100)
3031    1664  0112            AND COMMAND
3032    1665  1376            TAD (100)
3033    1666  7041            CIA
3034    1667  1133            TAD XA10
3035    1670  1366            TAD (-WBUFFER+1)
3036    1671  7640            SZA CLA
3037    1672  5235            JMP EBLOOP
3038                  /END OF TESTS 14, 15, 17, OR 20
3039                  /
3040                  /...ALSO
3041                  /
3042                  /END OF TESTS 31, 32, OR 33
3043                  /
3044    1673  5453            EXIT
3045                  /
3046                  /SECTOR BUFFER DATA TESTING
3047                  /
3048                  /THE PURPOSE OF THESE TESTS IS TO VERIFY THAT ALL 1'S AND ALL 0'S CAN BE
3049                  /SET INTO THE SECTOR BUFFER
3050                  /
3051                  /SECTOR BUFFER DATA TESTING
3052                  /
3053                  /FILL THE SECTOR BUFFER WITH ALL 1'S
3054                  /
```



```
3055    1674  1370    T22,    TAD (377)                       / " GOOD " = ALL 1'S
3056                  /
3057                  /FILL THE SECTOR BUFFER WITH ALL 0'S
3058                  /
3059                  /FILL THE SECTOR BUFFER WITH 128 BYTES OF "GOOD"
3060                  /
3061    1675  4765'   T21,    JMS FB128BYTES
3062    1676  4764'           JMS TX                  / "GOOD " = ALL 0'S
3063                  /*****************************************************************************
3064                  /*****************************************************************************
3065                  /
3066                  /IF THIS IS TEST #22
3067                  /
3068                  /THEN TEST FOR A DRIVE SELECTION
3069                  /
3070                  /IF NO DRIVES ARE ENABLED WITHIN PROGRAM LOCATION " DTESTP "
3071                  /
3072                  /THEN THERE ARE NO MORE RX01 CONTROL TESTS TO EXECUTE
3073                  /
3074    1677  1167            TAD TEST
3075    1700  1363            TAD (-T22)
3076    1701  7640            SZA CLA
3077    1702  5453            EXIT    / END OF TEST 21
3078    1703  1762'           TAD UNITS
3079    1704  7640            SZA CLA
3080    1705  5453            EXIT            / END OF TEST 22
3081          0300    XC=0300
3082                  /
3083                  / END OF PASS " C "
3084                  /
3085    1706  7340            CLL CLA CMA
3086    1707  3761'           DCA     COUNT                   /INIT TIMING FOR APT IF ONLY
3087                                                          /INTERFACE IS TO BE TESTED.
3088    1710  4760'           JMS     XTICK
3089    1711  4464            LOCKUP
3090    1712  1357            TAD (XC)
3091    1713  5756'           JMP NOMORETESTS
3092                  /*****************************************************************************
3093                  /*****************************************************************************
3094    1714  7327    T24,    CLA STL IAC RTL
3095    1715  5755'           JMP IRDWR       /  6  (READ)
3096    1716  7307    T25,    CLL CLA IAC RTL
3097    1717  5755'           JMP IRDWR       /  4  (WRITE)
3098    1720  1354    T26,    TAD (14)
3099    1721  5755'           JMP IRDWR               / 14  (WRITE DELETED DATA)
3100                  /
3101                  /THE PURPOSE OF THESE TESTS IS TO VERIFY
3102                  /THE RX01 CONTROL CLOCK SET OF THE ERROR FLAG
3103                  /
3104                  /BY FORCING A SEEK ERROR TO OCCUR
3105                  / (ATTEMPTING TO PERFORM A FUNCTION ON A NON-EXISTANT SECTOR #0 )
3106                  /
3107                  /NOTE;THE CONTENTS OF THE SECTOR BUFFER SHOULD REMAIN UNCHANGED AND CONTAIN
3108                  /     THE PATTERN OF ALL 1'S AS FILLED WITHIN TEST 22 BECAUSE THE READ SHOULD
3109                  /     HAVE NEVER OCCURED.
```

```
                        /
                        /  1.  THE STATUS WITHIN THE TRANSFER REGISTER AT ERROR SHOULD = 0
                        /  2.  THE R-CODE STATUS SHOULD = 70 (UNABLE TO FIND SECTOR)
                        /  3.  THE STATUS FROM THE RST COMMAND (12) SHOULD = DRIVE READY (200)
                        /
                        /THE LENGTH ( # OF TRANSFERS TO THE RX01 CONTROL) SHOULD BE TWO
                        / (ONE EACH FOR THE SECTOR AND FOR THE TRACK)
                        /
                        /GET ONE UNIT ONLY (UNIT 1 IF UNIT 0 IS NOT READY)
                        /
                        /ROUTINE TO WAIT FOR SKIP ON AN IOT. IF SKIP DOES NOT OCCUR
                        /THE ROUTINE WILL PRINT PC POINT IN ERROR AND GO BACK ABOUT ITS
                        /BUSINESS.
                        /
1722  0000      XWAIT,  0
1723  1006              TAD     6
1724  7650              SNA CLA
1725  5330              JMP     .+3
1726  7240              STA
1727  3006              DCA     6
1730  2151              ISZ     H1
1731  5722              JMP I   XWAIT
1732  2116              ISZ     HANGER
1733  5722              JMP I   XWAIT
1734  1322              TAD     XWAIT                   /GET ERROR PC
1735  1353              TAD     (-E3PRE
1736  7710              SPA CLA                         /DID CALL COME FROM PRETEST.
1737  5752'             JMP     E3PRE                   /YES. REPORT ERROR.
1740  1322              TAD     XWAIT                   /GET BACK ERROR
1741  5751'             JMP     HUNGUP
                        /
1751  3341
1752  0423
1753  7355
1754  0014
1755  2000
1756  0522
1757  0300
1760  4127
1761  4146
1762  4235
1763  6104
1764  2303
1765  4541
1766  0666
1767  0665
1770  0377
1771  7112
1772  1476
1773  0466
1774  7312
1775  6000
1776  0100
1777  0040
      2000              PAGE
```



```
2000  3112    IRDWR,  DCA COMMAND
2001  3777'           DCA WUNITS
2002  4460            GETUNIT
2003  1112            TAD COMMAND
2004  1776'           TAD UNIT
2005  3166            DCA BLANK
2006  1166            TAD BLANK
2007  4437            LCD                     /  6,  4,  OR  14
2010  3165            DCA EAC
2011  5214            JMP .+3
2012  2165            ISZ EAC
2013  4443            XDROUT
2014  4444            STR
2015  7410            SKP
2016  5212            JMP .-4                 /SECTOR 0 - TRACK 0
2017  4446            SDN
2020  5214            JMP .-4                 /WAIT FOR DONE FLAG
2021  7344            CLL STA RAL
2022  1165            TAD EAC
2023  7650            SNA CLA
2024  5231            JMP .+5
2025  7305            CLL CLA IAC RAL
2026  3164            DCA GOOD                / 2 TRANSFERS WERE EXPECTED
2027  1165            TAD EAC
2030  4452    E240,   ERROR                   / # OF TRANSFER REQUEST FLAGS NOT OK
2031  4503            SUBSCOPE                / (AC) = # OF TRANSFERS OCCURED
                      /
                      /THE ERROR FLAG SHOULD = 1
                      /
2032  4445            SER
2033  4452    E245,   ERROR                   / MISSING ERROR FLAG
2034  4503            SUBSCOPE
                      /IF THIS IS T24, THEN DELETED DATA (MAY) BE SET (BUT THAT'S OK FOR NOW),
                      /THE STATUS AT ERROR SHOULD = X (100 MAYBE DELETED DATA)+200 DRIVE READY
                      /
                      /IF THIS IS T25, THEN DELETED DATA (SHOULD NOT) BE SET, THEREFORE
                      /THE CONTENTS OF THE TRANSFER REGISTER (THE STATUS AT THE ERROR) SHOULD = 200
                      /
                      /IF THIS IS T26, THEN DELETED DATA (MUST) BE SET, THEREFORE
                      /THE STATUS SHOULD = 300 (200 DRIVE READY)+(100 (DELETED DATA)
                      /
2035  1167            TAD TEST                /FOR T #
2036  1375            TAD (-T25)
2037  7650            SNA CLA
2040  5245            JMP .+5                 / T25 THEN " JMP .+5 "
2041  1167            TAD TEST
2042  1374            TAD (-T26)
2043  7650            SNA CLA
2044  1373            TAD (100)               / T26 MEANS EXPECT DELETED DATA
2045  3164            DCA GOOD                / T24
2046  4442            XDRIN                   /ACTUAL STATUS
2047  3166            DCA BLANK
2050  1166            TAD BLANK
2051  3165            DCA EAC
                      /
```

```
                        /IF THIS IS T24, THEN DELETED DATA (MAY) BE SET, (BUT THAT'S OK FOR NOW)
                        /
2052  1167              TAD TEST                        / FOR T #
2053  1372              TAD (-T24)
2054  7640              SZA CLA                         / T24 ?
2055  5261              JMP .+4
2056  1371              TAD (-100-1)                    / YES
2057  0166              AND BLANK                       /ACTUAL STATUS MINUS DELETED DATA
2060  3165              DCA EAC
2061  1165              TAD EAC
2062  7041              CIA
2063  1164              TAD GOOD                        /EXPECTED
2064  7650              SNA CLA
2065  5270              JMP .+3
2066  1165              TAD EAC
2067  4452  E241,       ERROR                           /STATUS NOT = "GOOD"
2070  4503              SUBSCOPE
                        /
                        /THE B-CODE SHOULD = 70 (UNABLE TO FIND SECTOR)
                        /
2071  4477              RSTB                            /RETURN WITH AC = CODE
2072  1370              TAD (-70)
2073  7650              SNA CLA
2074  5301              JMP .+5
2075  1367              TAD (70)
2076  3164              DCA GOOD
2077  1165              TAD EAC
2100  4452  E242,       ERROR                           /B-CODE STATUS NOT = CODE # 70
2101  4502              SCOPE
                        /THE CONTENTS TO THE SECTOR BUFFER SHOULD REMAIN UNCHANGED
                        /
                        /THE CONTENTS OF THE SECTOR BUFFER SHOULD = ALL BYTES OF 1'S
                        /
2102  1366              TAD (377)
2103  3164              DCA GOOD                /EXPECT ALL 1'S
2104  4765*             JMS TX                          /VERIFY SECTOR BUFFER SUBROUTINE
2105  5453              EXIT                            / END OF TEST 24, 25, 26
                        /
                        / TEST 27 - SEEK AND CRC VERIFICATION (FIRST PROGRAMMED HEAD MOVEMENT)
                        /
                        /THE PURPOSE OF THIS TEST IS TO VERIFY THAT SUPPLYING THE RX01 WITH A TRACK
                        /WHOSE VALUE IS GREATER THAN 114 (OCTAL) EXPECTS A B-CODE ERROR OF 40
                        /
2106  1364  T27,       TAD (115)
2107  3166              DCA BLANK
2110  7327              STL CLA IAC RTL
2111  4437              LCD             / ISSUE READ COMMAND
2112  3165              DCA EAC
2113  7410              SKP
2114  2165              ISZ EAC                         / + TO TRANSFER COUNT
2115  1166              TAD BLANK                       / SECTOR TRACK
2116  4443              XDROUT                          /TO RX01 CONTROL
2117  4444              STR                             / WAIT FOR TRANSFER REQUEST FLAG
2120  7410              SKP
2121  5314              JMP .-5
```



```
2122  4446              SDN                             / WAIT FOR DONE FLAG
2123  5317              JMP .-4
2124  3006              DCA    6                        /WAIT POINTER
2125  7344              CLL STA RAL                     / ONLY 2 TRANSFER REQUESTS WERE EXPECTED
2126  1165              TAD EAC                         / ACTUAL # OF TRANSFER REQUEST OCCURED
2127  7650              SNA CLA
2130  5335              JMP .+5
2131  7305              CLL CLA IAC RAL
2132  3164              DCA GOOD
2133  1165              TAD EAC
2134  4452  E270,       ERROR                           / # OF TRANSFER REQUEST FLAGS NOT OK
2135  4503              SUBSCOPE                        / (AC) CONTAINS THE # OF REQUEST OCCURED
                        /
                        /THE ERROR FLAG SHOULD = 1
                        /
2136  4445              SER
2137  4452  E271,       ERROR                           / MISSING ERROR FLAG
2140  4503              SUBSCOPE
                        /THE B-CODE SHOULD = 40
                        /
2141  4477              RSTB
2142  1363              TAD (-40)
2143  7650              SNA CLA
2144  5351              JMP .+5
2145  1362              TAD (40
2146  3164              DCA GOOD
2147  1165              TAD EAC
2150  4452  E272,       ERROR                           / B-CODE NOT = 40
2151  4502              SCOPE
                        /
                        /THE CONTENTS OF THE SECTOR BUFFER SHOULD REMAIN UNCHANGED
                        /
2152  1366              TAD (377)
2153  3164              DCA GOOD                / EXPECT ALL 1'S
2154  4765*             JMS TX
                        /
2155  5453              EXIT                            / END OF TEST 27
2162  0040
2163  7740
2164  0115
2165  2303
2166  0377
2167  0070
2170  7710
2171  7677
2172  6064
2173  0100
2174  6060
2175  6062
2176  4242
2177  4236
      2200              PAGE
                        /TEST 30 - SEEK AND CRC VERIFICATION
                        /
                        /READ ALL SECTORS OF ALL TRACKS
```

```
                        /
                        /IF THE DATA IS OF KNOWN QUALITY THEN MONITOR FOR CRC ERRORS
                        /
2200  3132    T30,      DCA TESTP
2201  5777'             JMP TEST4
                        /TEST 31 - FIRST WRITE EVER
                        /
                        /WRITING TO THE DISK SHOULD NOT DESTROY THE CONTENTS OF THE SECTOR BUFFER
                        /
                        /TECHNICAL NOTE:
                        /
                        /THIS TEST WRITES ON ONE UNIT ONLY - UNIT 0, BUT IF UNIT 0 WAS
                        /NOT SELECTED BY THE OPERATOR AT THE START OF THIS PROGRAM
                        /THEN THIS TEST WRITES ON UNIT 1
                        /
                        /PROGRAMMING NOTE:
                        /
                        /THIS "DCA WUNITS" IS NECESSARY IF THIS TEST IS LOCKED WITH SW5
                        /
2202  3776'   T31,      DCA WUNITS
                        /
2203  7307              CLL CLA IAC RTL                 / 4 (WRITE 8-BIT MODE)
2204  1375              TAD (6000)
2205  3132              DCA TESTP               /COUNT PATTERN 6
2206  7240              STA
2207  312w              DCA RDC
                        / "GETATRACK"
                        /
221w  1031              TAD OD
2211  3131              DCA TARGET              / TRACK = (OD)
                        / "GETASECTOR"
                        /
2212  1033              TAD FIRST
2213  3124              DCA STARGET             / SECTOR = (FIRST)
                        /GET UNIT 0 (OR UNIT 1 IF UNIT 0 NOT SELECTED)
                        /
2214  4460              GETUNIT
                        /
                        / "INITSECTOR"
                        /
2215  7240              STA
2216  3122              DCA SECTORS             / 1 SECTOR (FIRST) TO WRITE
2217  1374              TAD (.+3)
2220  3773'             DCA XWRITE              / RETURN ADDRESS FROM WRITE SUBROUTINE
2221  5772'             JMP REWRITE+1                   / JMP TO WRITE SUBROUTINE
                        /
                        /RETURN HERE FROM SUBROUTINE " XWRITE "
                        /
                        / JMP  TO T17 TO VERIFY THE CONTENTS OF THE SECTOR BUFFER
                        /
2222  5771'             JMP T17
                        /TEST 32 - INIT (PROGRAMMED) PART III / IMPLIED READ OF TRACK 1 SECTOR 1
                        /
                        /*****************************************************************************
                        /*****************************************************************************
```



```
                        /
                        /IF THE CONTENTS OF PROGRAM LOCATIONS:
                        /
                        /  " OD " = 1, AND
                        / " FIRST " = 1,
                        /
                        /AND IF UNIT 0 WAS SELECTED BY THE OPERATOR AT THE START OF THIS PROGRAM
                        /
                        /THEN EXECUTE THIS TEST
                        /
2223  1033    T32,      TAD FIRST
2224  7110              CLL RAR
2225  7640              SZA CLA
2226  5453              NOTEST
2227  1031              TAD OD
2230  7110              CLL RAR
2231  7640              SZA CLA
2232  5453              NOTEST
2233  177w'             TAD UNITS
2234  7700              SMA CLA
2235  5453              NOTEST
                        /*****************************************************************************
                        /*****************************************************************************
                        /
                        /
                        /THE PURPOSE OF THIS TEST IS TO VERIFY THE "IMPLIED READ" OF TRACK 1 SECTOR 1
                        /AS PART OF THE INITIALIZE FUNCTION
                        /
                        /FIRST FILL THE SECTOR BUFFER WITH ALL 0'S, THEN ISSUE IOT INIT 67X7
                        /
                        /INIT SHOULD READ THE CONTENTS OF TRACK 1 SECTOR 1 OF UNIT 0
                        /
                        /INTO THE SECTOR BUFFER
                        /
2236  4767'             JMS FB128BYTES                  / FILL THE SECTOR BUFFER
2237  4450              INIT                            /OF UNIT 0
                        /
                        /JMP TO TEST 17 TO VERIFY THE CONTENTS OF THE SECTOR BUFFER
                        /
2240  5771'             JMP T17                         / TO TEST 17
                        /TEST 33 - FIRST READ (PROGRAMMED) EVER
                        /
                        /FIRST FILL THE SECTOR BUFFER WITH ALL 0'S
                        /
                        /THEN READ FROM THE DISK TRACK # (OD), SECTOR # (FIRST)
                        /
                        /THE CONTENTS OF THE SECTOR BUFFER SHOULD BE THAT OF THE PREVIOUS TEST
                        /
                        /PROGRAMMING NOTE:
                        /
                        /THIS "DCA WUNITS" INPERATIVE IF T27 WAS EXECUTED PREVIOUSLY THIS PASS
                        /
2241  3776'   T33,      DCA WUNITS
2242  4767'             JMS FB128BYTES                  / FILL THE SECTOR BUFFER
2243  7307              CLL CLA IAC RTL
```

```
3438    2244  3132            DCA TESTP       / 4 (READ 8-BIT MODE)
3439                  /PROGRAMMING NOTE:
3440                  /
3441                  /THE FOLLOWING CODE TO " JMP T17 " IS IMPERATIVE HOUSEKEEPING PRIMING THE
3442                  / " READ " SUBROUTINE
3443                  /
3444    2245  7240            STA
3445    2246  3120            DCA RDC
3446                  / "GETATRACK"
3447                  /
3448    2247  1031            TAD OD
3449    2250  3131            DCA TARGET
3450                  / "GETASECTOR"
3451                  /
3452    2251  1033            TAD FIRST
3453    2252  3124            DCA STARGET
3454                  /GET ONE UNIT ONLY (UNIT 1 IF UNIT 0 IS NOT READY)
3455                  /
3456    2253  4460            GETUNIT                         / SELECT A UNIT
3457    2254  7240            STA
3458    2255  3136            DCA R1RETRY             /SO NO "REWRITES" OCCUR
3459                  / "INITSECTOR"
3460                  /
3461    2256  7240            STA
3462    2257  3122            DCA SECTORS             / 1 SECTOR TO READ (#FIRST)
3463    2260  1366            TAD (.+4)
3464    2261  3765'           DCA XREAD               /RETURN ADDRESS FROM " READ " SUBROUTINE
3465    2262  5764'           JMP READRETRY                   / JMP TO READ SUBROUTINE
3466                  /THIS "WRITE" IS IMPERATIVE FOR REFERENCES WITHIN "XREAD"
3467                  /
3468    2263  4510            WRITE                           / "WRITE" FOR PROGRAM REFERENCES ONLY
3469                  /
3470                  /RETURN HERE FROM SUBROUTINE " XREAD "
3471                  /
3472                  /
3473                  /JMP TO TEST 17 TO VERIFY THE CONTENTS OF THE SECTOR BUFFER
3474                  /
3475    2264  5771'           JMP T17                         / TO TEST 17
3476                  /TEST 23 - DRIVE READY SELECTION (ALL UNITS SELECTED BY OPERATOR)
3477                  /
3478                  /THE PURPOSE OF THIS TEST IS TO VERIFY THE "SEL DRV RDY" STATUS BIT 4
3479                  /
3480    2265  1363    T23,    TAD (200)
3481    2266  3166            DCA BLANK
3482    2267  4460            GETUNIT
3483    2270  1762'           TAD UNIT
3484    2271  4476            RST
3485    2272  4454            DONE
3486    2273  5265            JMP T23
3487    2274  5453            EXIT                            / END OF TEST 27
3488                  /
3489                  /THE PURPOSE OF THESE TESTS IS TO WRITE-READ-AND PROGRAM VERIFY THE DATA
3490                  /ON ALL TRACKS FROM (OD) TO (ID), AND ALL SECTORS FROM (FIRST) TO (LAST),
3491                  /EXERCISING 8-BIT MODE, 12-BIT MODE, AND DELETED DATA
3492                  /
```



```
3493                  /A PATTERN OF ALL 1'S ARE WRITTEN ON THE DISK
3494                  /
3495                  /               WORD/BYTE 1 IS THE TRACK ID (BITS 5 THRU 11)
3496                  /               WORD/BYTE 2 IS THE SECTOR ID (BITS 7 THRU 11)
3497                  /
3498                  /               WORDS 3 THRU 62 IS THE ALL 1'S DATA
3499                  /
3500                  /               BYTES 3 THRU 126 IS THE ALL 1'S DATA
3501                  /
3502                  /               WORDS 63, AND 64 ARE SPECIAL SUMCHECK WORDS
3503                  /
3504                  /               BYTES 127, AND 128 ARE SPECIAL SUMCHECK WORDS
3505                  /
3506                  /TEST 37 - 8 BIT MODE WITH DELETED DATA
3507                  /
3508    2275  7305    T37,    CLL CLA IAC RAL                 / 6 (DELETED DATA - 8/BIT MODE)
3509                  /
3510                  /TEST 35 - 8 BIT MODE
3511                  /
3512    2276  1361    T35,    TAD (2)                         / 4 (8/BIT MODE)
3513                  /
3514                  /TEST 36 - 12 BIT MODE WITH DELETED DATA
3515                  /
3516    2277  1361    T36,    TAD (2)                         / 2 (DELETED DATA - 12/BIT MODE)
3517                  /
3518                  /TEST 34 - 12 BIT MODE
3519                  /
3520    2300  1360    T34,    TAD (1000)                      /ALL 1'S PATTERN
3521    2301  3132            DCA TESTP                       /  (12/BIT MODE)
3522    2302  5757'           JMP THETEST
3523                  /THIS SUBPOUTINE IS ENTERED FROM TESTS:   ***   T21, T22, (T24, T25, T26), T27
3524                  /
3525                  /EMPTY THE BUFFER TO VERIFY THE CONTENTS = ALL 1'S OR ALL 0'S
3526                  /
3527    2303  2303    TX,     .
3528    2304  3166            DCA BLANK                               / BYTE # 1 TO 128
3529    2305  1356            TAD (102)
3530    2306  4437            LCD                             /EMPTY BUFFER 8-BIT MODE
3531    2307  5322            JMP T20STR-1
3532    2310  4442    T20XDRIN, XDRIN
3533    2311  3165            DCA EAC                 /DATA FROM SECTOR BUFFER
3534    2312  1165            TAD EAC
3535    2313  7041            CIA
3536    2314  1164            TAD GOOD                        /COMPARED WITH EXPECTED DATA
3537    2315  7650            SNA CLA
3538    2316  5321            JMP .+3
3539    2317  1165            TAD EAC
3540    2320  4452    E211,   ERROR                                   /DATA "TO" NOT = DATA "FROM"
3541    2321  4503            SUBSCOPE
3542    2322  2166            ISZ BLANK                               / 1 TO 128
3543    2323  4444    T20STR, STR
3544    2324  7410            SKP
3545    2325  5310            JMP T20XDRIN
3546    2326  4446            SDN
3547    2327  5323            JMP T20STP
```

```
3548    2330  4445            SER
3549    2331  4465            OK
3550    2332  4452    E212,   ERROR                           /UNEXPECTED ERROR FLAG
3551    2333  4502            SCOPE
3552    2334  5703            JMP I TX
3553                    /
3554                    /
3555                    /
3556                    /
3557    2356  0102
3558    2357  3000
3559    2360  1000
3560    2361  0002
3561    2362  4242
3562    2363  0200
3563    2364  3423
3564    2365  3414
3565    2366  2264
3566    2367  4541
3567    2370  4235
3568    2371  1602
3569    2372  3207
3570    2373  3204
3571    2374  2222
3572    2375  6004
3573    2376  4236
3574    2377  2510
              2400      PAGE
3575                    /READ THE B-CODE STATUS
3576                    /
3577                    /THIS SUBROUTINE IS ENTERED FROM TESTS:  ***  ALT12, (T24, T25, T26), T27
3578                    /
3579    2400  2400      XRSTB,  .
3580    2401  1377            TAD (16)
3581    2402  4437            LCD             /ISSUE COMMAND # 7
3582    2403  4444            STR
3583    2404  4465            OK
3584    2405  4452    E7000,  ERROR                           /UNEXPECTED TRANSFER REQUEST FLAG
3585    2406  4503            SUBSCOPE
3586    2407  4446            SDN
3587    2410  5203            JMP .-5
3588    2411  4442            XDRIN
3589    2412  3165            DCA EAC                         /ACTUAL STATUS
3590    2413  4145            SER
3591    2414  5217            JMP .+3
3592    2415  1165            TAD EAC
3593    2416  4452    E7001,  ERROR                           /UNEXPECTED ERROR FLAG
3594    2417  4503            SUBSCOPE
3595    2420  1165            TAD EAC
3596    2421  0376            AND (7000)                      /BITS 0,1,2 ARE RESIDUAL FROM COMMAND SHIFT
3597    2422  1375            TAD (1000).
3598    2423  7650            SNA CLA
3599    2424  5231            JMP .+5
3600    2425  1376            TAD (7000)
3601    2426  3164            DCA GOOD
```



```
3602    2427  1165            TAD EAC
3603    2430  4452    E7002,  ERROR                           / SHIFT REGISTER NOT SHIFTING OK
3604    2431  4503            SUBSCOPE
3605    2432  1165            TAD EAC
3606    2433  0374            AND (377)
3607    2434  3165            DCA EAC
3608    2435  1165            TAD EAC
3609    2436  5600            JMP I XRSTB
3610                    /
3611                    /READ STATUS SUBROUTINE
3612                    /
3613                    /THE CONTENTS OF THE AC AT ENTRY = BIT 7 (UNIT SELECT)
3614                    /
3615                    /READ THE STATUS AT DONE BY ISSUING COMMAND # 5
3616                    /
3617                    /THIS SUBROUTINE IS ENTERED FROM TESTS:   ***   ALT12, AND T27
3618                    /
3619    2437  2437      XRST,   .
3620    2440  1373            TAD (12)
3621    2441  4437            LCD             / ISSUE COMMAND # 5 (AC AT ENTRY = UNIT)
3622    2442  4444            STR
3623    2443  4465            OK
3624    2444  4452    E7003,  ERROR                           /UNEXPECTED TRANSFER REQUEST FLAG
3625    2445  4503            SUBSCOPE
3626    2446  4446            SDN
3627    2447  5242            JMP .-5                         /WAIT FOR DONE FLAG
3628    2450  4442            XDRIN
3629    2451  3165            DCA EAC                         /ACTUAL STATUS
3630    2452  4445            SER
3631    2453  5256            JMP .+3
3632    2454  1165            TAD EAC
3633    2455  4452    E7004,  ERROR                           /UNEXPECTED ERROR FLAG
3634    2456  4503            SUBSCOPE
3635                    /
3636                    /THE PURPOSE OF THIS SUBTEST IS TO VERIFY THE SHIFTING OF THE RX8 INTERFACE
3637                    /
3638                    /TRANSFER REGISTER BY THE RX01 MICROCONTROLLET
3639                    /
3640                    /BITS 0, 1, AND 2 OF THE RX8 INTERFACE TRANSFER REGISTER SHOULD BE REMNANTS
3641                    /
3642                    /OF THE PREVIOUS COMMAND (COMMAND # 5), THEREFORE BITS 0, 1, AND 2 SHOULD = 101 (BINARY)
3643                    /
3644    2457  1165            TAD EAC
3645    2460  0376            AND (7000)
3646    2461  1372            TAD (3000)
3647    2462  7650            SNA CLA
3648    2463  5270            JMP .+5
3649    2464  1371            TAD (5000)
3650    2465  3164            DCA GOOD
3651    2466  1165            TAD EAC
3652    2467  4452    E7006,  ERROR
3653    2470  4503            SUBSCOPE
3654                    /
3655                    /THE CONTENTS OF THE RST STATUS SHOULD = DRIVE READY (200)
3656                    /
```

```
                        / (IF UNIT-S WERE SELECTED AT L/S 200 OTHERWISE THE STATUS SHOULD = 0 )
                        /
3659    2471  1166              TAD BLANK                       / (GOOD) SAVED PRIOR TO ENTRY INTO " XRST "
3660    2472  0370              AND (-4-1)                      / MINUS " INIT DONE " BIT
3661    2473  3164              DCA GOOD
3662    2474  1165              TAD EAC                         / ACTUAL STATUS MINUS " DELETED DATA "
3663    2475  0367              AND (277)
3664    2476  3166              DCA BLANK
3665    2477  1164              TAD GOOD                        /EXPECTED
3666    2500  7041              CIA
3667    2501  1166              TAD BLANK                       /ACTUAL (MASSAGED)
3668    2502  7650              SNA CLA
3669    2503  5306              JMP .+3
3670    2504  1165              TAD EAC                         / ACTUAL ACTUAL STATUS
3671    2505  4452    E7005,    ERROR                           /EXPECTED STATUS NOT = (GOOD)
3672    2506  4502              SCOPE
3673    2507  5637              JMP I XRST
                        /SUB-TEST SELECTIONS
                        /
                        /
                        /       TEST   0 = " THE TEST "
                        /       TEST 001 = WRITE - READ (PARITY CHECK)
                        /       TEST 010 = WRITE - READ - READ CHECK (PROGRAM VERIFY)
                        /       TEST 011 = READ - READ CHECK (COMPATABILITY)
                        /       TEST 100 = READ (PARITY CHECK)
                        /       TEST   5 = WRITE ONLY
                        /       TEST 110 = EMPTY BUFFER
                        /       TEST 111 =
                        /
                        /
3687    2510  1366    TEST4,    TAD (READ)
3688    2511  7410              SKP
3689    2512  1365    TEST3,    TAD (READCOMPARE)
3690    2513  3333              DCA DOB
3691    2514  1376              TAD (NOP)
3692    2515  5325              JMP DCADOA
3693    2516  1365    TEST2,    TAD (READCOMPARE)
3694    2517  7410              SKP
3695    2520  1366    TEST1,    TAD (READ)
3696    2521  7410              SKP
3697    2522  1376    TEST5,    TAD (NOP)
3698    2523  3333              DCA DOB
3699    2524  1364              TAD (WRITE)
3700    2525  3332    DCADOA,   DCA DOA
3701                    /
3702    2526  4455    TESTX,    GETAPATTERN
3703    2527  4463              INITTRACKS
3704    2530  4460              GETUNIT
3705    2531  4457    TESTXL,   GETATRACK
3706    2532  4510    DOA,      WRITE
3707    2533  4474    DOB,      READ
3708    2534  2145              ISZ TRACKS
3709    2535  5331              JMP TESTXL
3710    2536  4454              DONE
3711    2537  5326              JMP TESTX
```



```
3712    2540  5453              EXIT
3713                    /
3714                    /ROUTINE TO DETERMINE IF ON APT.
3715                    /
3716    2541  0000    XCHK22, 0
3717    2542  1022              TAD     22
3718    2543  0363              AND     (4000
3719    2544  7640              SZA CLA
3720    2545  5741              JMP I   XCHK22
3721    2546  2341              ISZ     XCHK22
3722    2547  5741              JMP I   XCHK22
3723    2563  4000
3724    2564  4510
3725    2565  4475
3726    2566  4474
3727    2567  0277
3728    2570  7773
3729    2571  5000
3730    2572  3000
3731    2573  0012
3732    2574  0377
3733    2575  1000
3734    2576  7000
3735    2577  0016
              2600              PAGE
3736                    /AC SW 6 = 1 TO HALT AT END OF TEST
3737                    /
3738    2600  2600    XLOCKUP, .
3739    2601  4570              LAS
3740    2602  0377              AND (SW7)
3741    2603  7640              SZA CLA
3742    2604  4461              HLT
3743                    /AC SW 5 = 1 TO LOCK SCOPE LOOP ON TEST
3744                    /
3745    2605  4570              LAS
3746    2606  0376              AND (SW5)
3747    2607  7640              SZA CLA
3748    2610  5567              JMP I TEST
3749    2611  5600              JMP I XLOCKUP
3750                    /
3751                    /BYTE SWAP SUBROUTINE
3752                    /
3753                    /THE CONTENTS OF THE AC AT ENTRY WILL BE SWAPPED
3754                    /
3755    2612  2612    XBSW,   .
3756    2613  3235              DCA BSWAC
3757    2614  7010              RAR
3758    2615  3236              DCA BSWLINK
3759    2616  1375              TAD (-6)
3760    2617  3234              DCA BSWRAL
3761    2620  1235              TAD BSWAC
3762    2621  7100              CLL
3763    2622  7510              SPA
3764    2623  7120              STL
3765    2624  7004              RAL
```

```
3766    2625  2234          ISZ BSWRAL
3767    2626  5221          JMP .-5
3768    2627  3235          DCA BSWAC
3769    2630  1236          TAD BSWLINK
3770    2631  7104          CLL RAL
3771    2632  1235          TAD BSWAC
3772    2633  5612          JMP I XBSW
3773    2634  7772    BSWRAL, -6
3774    2635  0000    BSWAC,  0
3775    2636  0000    BSWLINK, 0
3776    2637  2637    XERROR, .
3777    2640  3165          DCA EAC
3778    2641  1165          TAD     EAC                     /GET ERROR PC.
3779    2642  4467          AERROR
3780    2643  2111          ISZ BUSY
3781    2644  1237          TAD XERROR
3782    2645  7001          IAC
3783    2646  3774'         DCA EPCSCOPE    / ERROR RETURN ADDRESS + 1
3784    2647  7301          CLL CLA IAC
3785    2650  3773'         DCA ERRORS
3786                  /IF AC SW 3 = 0 THEN PRINT AN ERROR MESSAGE
3787                  /
3788    2651  4570          LAS
3789    2652  0372          AND (SW3)
3790    2653  7640          SZA CLA
3791    2654  5327          JMP XNOPRINT
3792                  /IF THIS IS THE FIRST ERROR FOR THIS PASS THEN PRINT THE HEADER LINE
3793                  /
3794    2655  2115          ISZ FIRSTERROR
3795    2656  5261          JMP .+3
3796    2657  4473          PRINT
3797    2660  6544          MXEHEADER
3798    2661  4473          PPINT
3799    2662  6601          MCRLF
3800                  /               ERR  FAT  FAST      EAC  GOOD PASS
3801                  /
3802                  / ERR   = ERROR ADDRESS ( E # )
3803                  / FAT   = FIRST ADDRESS OF TEST
3804                  / FAST  = FIRST ADDRESS OF SUB-TEST
3805                  /       =*SEE MAP
3806                  / EAC   = CONTENTS OF THE ACCUMULATOR AT THE ERROR
3807                  / PASS  = PASS IN WHICH ERROR OCCURED
3808                  /
3809    2663  7240          STA
3810    2664  1237          TAD XERROR
3811    2665  3156          DCA LSB
3812    2666  4505          TY4OCT
3813    2667  0156          LSB
3814    2670  4504          TAB
3815    2671  0005          5
3816    2672  1167          TAD TEST
3817    2673  3156          DCA LSB
3818    2674  4505          TY4OCT
3819    2675  0156          LSB
3820    2676  4504          TAB
```



```
3821    2677  0012          12
3822    2700  4505          TY4OCT
3823    2701  1364          PCSCOPE
3824    2702  4504          TAB
3825    2703  0017          17
3826    2704  4505          TY4OCT
3827    2705  0166          BLANK
3828    2706  4504          TAB
3829    2707  0024          24
3830    2710  4505          TY4OCT
3831    2711  0165          EAC
3832    2712  4504          TAB
3833    2713  0031          31
3834    2714  4505          TY4OCT
3835    2715  0164          GOOD
3836    2716  4504          TAB
3837    2717  0036          36
3838    2720  4436          TY8OCT
3839    2721  0161          PASS
3840    2722  4570          LAS
3841    2723  7700          SMA CLA
3842    2724  5327          JMP .+3
3843    2725  4504          TAB
3844    2726  0043          43
3845          0207    BELL=207
3846                  /
3847    2727  4570    XNOPRINT, LAS
3848    2730  0371          AND (SW11)
3849    2731  7640          SZA CLA
3850    2732  5335          JMP .+3
3851    2733  4501          SPECIALTYPEIT
3852    2734  0207          BELL
3853    2735  3115          DCA FIRSTERROR
3854    2736  4570          LAS
3855    2737  7710          SPA CLA
3856    2740  4461          HLT
3857                  /
3858    2741  3111          DCA BUSY
3859    2742  6001          ION
3860    2743  5637          JMP I XERROR
3861                  /
3862                  /
3863                  /ROUTINE TO DETERMINE WHETHER TO TEST DRIVE ZERO
3864                  /OR IF NO DRIVES ARE TO BE TESTED.
3865                  /
3866    2744  1770'   TSTUNT, TAD UNITS                    /UNITS SELECTED BY OPERATOR
3867    2745  0367          AND     (4000                 /ISOLATE DRIVE ZERO.
3868    2746  7640          SZA CLA                       /IS DRIVE ZERO THERE.
3869    2747  5353          JMP     DRVZRO                /YES.
3870    2750  1366          TAD     (-300-1)              /DON'T TEST DRIVE ZERO.
3871    2751  3356          DCA     COMP                  /IT IS NOT ANERROR IF DRIVE
3872                                                      /ZERO IS OPERATIONAL.
3873    2752  5765'         JMP     NORX01-1
3874    2753  1364    DRVZRO, TAD     (-100-1)
3875    2754  3356          DCA     COMP
```

```
3876    2755  5763'           JMP     NORX01-2                        /DRIVE ZERO THERE SO INDICATE IT.
3877                  /
3878    2756  0000    COMP,   0
3879                  /
3880                  /
3881    2763  0425
3882    2764  7677
3883    2765  0426
3884    2766  7477
3885    2767  4000
3886    2770  4235
3887    2771  0001
3888    2772  0400
3889    2773  1363
3890    2774  1362
3891    2775  7772
3892    2776  0100
3893    2777  0020
              3000    PAGE
3894                  /
3895    3000  4455    THETEST, GETAPATTERN
3896    3001  4463             INITTRACKS
3897    3002  4460             GETUNIT
3898                  /
3899                  /FORCE THE ACTUATOR SEQUENCE = 0 (INCREMENTAL 0-114)
3900                  /
3901    3003  1377    THEL,   TAD (XTHEL)
3902    3004  3776'            DCA XGETATRACK
3903    3005  1131             TAD TARGET
3904    3006  3125             DCA START
3905    3007  1146             TAD TTRACKS
3906    3010  1145             TAD TRACKS
3907    3011  7640             SZA CLA
3908    3012  5775'            JMP SEQ000
3909    3013  1031             TAD OD
3910    3014  3131             DCA TARGET
3911    3015  5775'            JMP SEQ000
3912    3016  4510    XTHEL,  WRITE
3913    3017  4475             READCOMPARE
3914    3020  2145             ISZ TRACKS
3915    3021  5203             JMP THEL
3916    3022  4454             DONE
3917    3023  5201             JMP THETEST+1
3918                  /ACTUATOR MOVEMENT IS THAT SELECTED OF BITS 6,7,8 OF (TESTP)
3919                  /
3920    3024  4463    XXTHEL, INITTRACKS
3921    3025  4460             GETUNIT
3922    3026  4457    XYTHEL, GETATRACK
3923    3027  4475             READCOMPARE
3924    3030  2145             ISZ TRACKS
3925    3031  5226             JMP XYTHEL
3926    3032  4454             DONE
3927    3033  5224             JMP XXTHEL
3928    3034  5453             EXIT
3929                  /GET A PATTERN
```



```
3930                  /
3931    3035  3035    XGETAPATTERN, .
3932                  /
3933                  /ONLY GENERATE A PATTERN, HOWEVER, IF THE CONTENTS OF PROGRAM LOCATIONS
3934                  /
3935                  /ERRORS = 0 (MEANS NO ERRORS),
3936                  /
3937                  /AND AC SW5 = 0 (NOT TO LOCK ON TEST OK)
3938                  /
3939                  /AND TEST = T13, T16, T34, T35, T36, T37
3940                  /
3941    3036  4570             LAS
3942    3037  0374             AND (SW5)
3943    3040  1773'            TAD ERRORS
3944    3041  7640             SZA CLA
3945    3042  5635             JMP I XGETAPATTERN
3946    3043  1372             TAD (GENTESTS-1)
3947    3044  3012             DCA A12
3948    3045  1412             TAD I A12
3949    3046  7450             SNA
3950    3047  5635             JMP I XGETAPATTERN
3951    3050  1167             TAD TEST
3952    3051  7640             SZA CLA
3953    3052  5245             JMP .-5
3954    3053  1371             TAD (WBUFFER+1)
3955    3054  3010             DCA A10
3956    3055  3153             DCA PATSUMCHECK
3957    3056  7307             CLL CLA IAC RTL
3958    3057  0132             AND TESTP       / 8/12 MODE MASK
3959    3060  7640             SZA CLA
3960    3061  1370             TAD (-100)              /124 DATA WORDS
3961    3062  1367             TAD (-74)
3962    3063  3011             DCA A11         / 60 DATA WORDS
3963                  /WORD X AND WORD Y CONTAIN THE ADDRESSES OF THE LAST 2 SUMCHECK WORDS
3964                  /
3965    3064  1011             TAD A11
3966    3065  7041             CIA
3967    3066  1366             TAD (WBUFFER+2)
3968    3067  3154             DCA WORDX
3969    3070  7301             CLL CLA IAC
3970    3071  1154             TAD WORDX
3971    3072  3155             DCA WORDY
3972    3073  1365             TAD (7000)
3973    3074  0132             AND TESTP
3974    3075  7106             CLL RTL
3975    3076  7006             RTL
3976    3077  1364             TAD (TAD PATTERNS)
3977    3100  3301             DCA .+1
3978    3101  1315             TAD PATTERNS
3979    3102  3303             DCA XPATTERNS
3980    3103  4763'   XPATTERNS, JMS RANGEN
3981    3104  3135             DCA XXX
3982                  /DEVELOP A 12 BIT SUMCHECK FOR THE 60/124 DATA WORDS
3983                  /
3984                  /NOTE:
```

```
                        /
                        /THE SUMCHECK WRITTEN IS THIS DEVELOPED SUMCHECK WITH THE FIRST 2 ID WORDS, AND
                        /THE LAST 2 OVERALL SUMCHECK WORDS APPENDED WITHIN SUBROUTINE XGETASECTOR
                        /
3105  1153              TAD PATSUMCHECK
3106  1135              TAD XXX
3107  3153              DCA PATSUMCHECK
3110  1135              TAD XXX
3111  3410              DCA I A10
3112  2011              ISZ A11
3113  5303              JMP XPATTERNS
3114  5635              JMP I XGETAPATTERN
                        /THE FOLLOWING ARE THE ALLOCATED PATTERN POINTERS
                        /
3115  4763'   PATTERNS,  JMS RANGEN
3116  7240              STA                     / 1
3117  1325              TAD PAT2
3120  1326              TAD PAT3
3121  1327              TAD PAT4
3122  1330              TAD PAT5
3123  5340              JMP PAT6
3124  7200              CLA
                        /
                        /       12 BIT MODE     8 BIT MODE
                        /
3125  1463    PAT2,     1463            / 63            / 0011  00110011
3126  6314    PAT3,     6314            / 314           / 1100  11001100
3127  5252    PAT4,     5252            / 252           / 1010  10101010
3130  2525    PAT5,     2525            / 125           / 0101  01010101
                        /
3131  6323    GENTESTS, -T13
3132  6324              -T16
3133  5500              -T34
3134  5502              -T35
3135  5501              -T36
3136  5503              -T37; 0
3137  0000
                        /PROGRAMMING NOTE:
                        /
                        /PATTERN 6 IS A COUNT PATTERN FROM 0 TO 7777, OR FROM 0 TO 177
                        /
                        /THIS COUNT PATTERN IS A " PURE " PATTERN
                        /
                        /A CHECKSUM IS NOT GENERATED FOR THIS PATTERN AS FOR ALL OTHER PATTERNS
                        /
                        /               WORD/BYTE 0 = 1
                        /               WORD/BYTE 1 = 1
                        /
                        /               WORD 2 = 0202
                        /               BYTE 2 = 2
                        /
                        /               WORD 77 = 7777
                        /               BYTE 177 = 177
                        /
3140  7307    PAT6,     CLL CLA IAC RTL         / 4
```



```
3141  0132              AND TESTP
3142  7440              SZA
3143  7120              STL                     / LINK = 1 FOR 8-BIT MODE (128 BYTES)
3144  5351              JMP .+5
3145  7001    XPAT6,    IAC
3146  7420              SNL
3147  1374              TAD (100)
3150  1135              TAD XXX
3151  3135              DCA XXX
3152  1135              TAD XXX
3153  3410              DCA I A10
3154  2011              ISZ A11
3155  5345              JMP XPAT6
3156  5635              JMP I XGETAPATTERN
3163  4710
3164  1315
3165  7000
3166  7115
3167  7704
3170  7700
3171  7114
3172  3130
3173  1363
3174  0100
3175  4306
3176  4261
3177  3016
      3200              PAGE
                        /WRITE ONLY
                        /
                        /WRITE ALL SELECTED SECTORS OF THAT TRACK
                        /
3200  3200    XWRITE,   .
3201  7330              STL CLA RAR
3202  3120              DCA RDC         / THIS IS A WRITE (RDC = 4000)
                        /
3203  4462              INITSECTORS
3204  4456    WRITEL,   GETASECTOR
3205  7410              SKP
3206  1377    REWRITE,  TAD (JMP WHICHREAD)
3207  3263              DCA JMPWHICHREAD
                        /THE PROGRAM WILL ISSUE AN INIT FOR ALL SEEK ERRORS
                        /
                        /NOTE:
                        /
                        /THE FUNCTION OF THE INIT IS TO SEEK TRACK 0/SECTOR 1, AND
                        /TRANSFER INTO THE SECTOR BUFFER THE CONTENTS OF SECTOR 1, THEREFORE
                        /TO RECOVER FROM A SEEK ERROR, THE PROGRAM MUST RE-FILL THE SECTOR BUFFER
                        /THEN RE-SEEK
                        /
3210  1121              TAD KRETRY
3211  3143              DCA SRETRY
3212  1121'   WRESEEK, TAD KRETRY
3213  3144              DCA PRETRY              /PARITY RETRY COUNTER
                        /FILL RX01 SECTOR BUFFER
```

```
4093                    /
4094    3214  1376      REFILL, TAD (WBUFFER-1)
4095    3215  3010              DCA A10
4096    3216  4440              LCDA
4097    3217  5237              JMP FILLOK
4098    3220  5226              JMP FILLERROR
4099                    /RETURN TO HERE IS FROM SUBROUTINE XLCDA
4100                    /
4101    3221  4444      FILL,   STR
4102    3222  5221              JMP FILL
4103    3223  1410              TAD I A10
4104    3224  4443              XDROUT
4105    3225  5221              JMP FILL
4106                    /AC SW (4) = 0 ; INHIBIT INTERFACE PARITY RECOVERY
4107                    /
4108    3226  2144      FILLERROR, ISZ PRETRY
4109    3227  7410              SKP
4110    3230  5600              JMP I XWRITE
4111    3231  4570              LAS
4112    3232  0375              AND (SW4)
4113    3233  7640              SZA CLA
4114    3234  5214              JMP REFILL
4115    3235  3144              DCA PRETRY
4116    3236  5600              JMP I XWRITE
4117                    /THE SECTOR BUFFER HAS SUCCESSFULLY BEEN FILLED AND CONTAINS THE
4118                    /PATTERN SELECTED - ALL SOFT PARITY ERRORS HAVE BEEN LOGGED
4119                    /
4120    3237  1121      FILLOK, TAD KRETRY
4121    3240  3144              DCA PRETRY
4122    3241  7305              CLL CLA IAC RAL           /  2
4123    3242  0132              AND TESTP                 /TESTP FOR DELETED DATA SELECTION
4124    3243  7007              IAC RTL                   / 4 IF WRITE OR 14 IF WRITE DELETED DATA
4125    3244  4441              LCDB
4126    3245  5257              JMP WRITEOK
4127                    /RETURN TO HERE IS FROM A PI (IF AN RX01 ERROR FLAG)
4128                    /
4129                    /AC SW (4) = 0 ; INHIBIT WRITE RETRY
4130                    /
4131    3246  2143      WRITERROR, ISZ SRETRY
4132    3247  7410              SKP
4133    3250  5264              JMP WNOTOK
4134    3251  4570              LAS
4135    3252  0375              AND (SW4)
4136    3253  7640              SZA CLA
4137    3254  5212              JMP WRESEEK
4138    3255  3143              DCA SRETRY
4139    3256  5264              JMP WNOTOK
4140                    /NOTE: THE ONLY ERROR EXPECTED HERE EVER IS A "SEEK" ERROR
4141                    /
4142                    /RETURN TO HERE IS FROM A PI (IF ONLY AN RX01 DONE FLAG)
4143                    /
4144    3257  1131      WRITEOK, TAD TARGET
4145    3260  3125              DCA START
4146    3261  1124              TAD STARGET
4147    3262  3123              DCA SSTART
```



```
4148    3263  5267      JMPWHICHREAD, JMP WHICHREAD      /CONTAINS 0 OR MODIFIED TO JMP WHICHREAD
4149                    /
4150    3264  2122      WNOTOK, ISZ SECTORS
4151    3265  5224              JMP WRITEL
4152    3266  5600              JMP I XWRITE
4153                    /IF THIS IS A WRITE AFTER READ, "JMP READRETRY", BUT
4154                    /
4155                    /IF A HARD SEEK ERROR, "JMP NOREAD"
4156                    /
4157    3267  1143      WHICHREAD, TAD SRETRY
4158    3270  7650              SNA CLA
4159    3271  5774'             JMP NOREAD                /HARD SEEK ERROR
4160    3272  5773'             JMP READRETRY             /SOFT
4161                    /
4162                    / 0 < (LAST) => (FIRST)
4163                    /
4164    3273  1034      TADLAST, TAD LAST
4165    3274  7740              SMA SZA CLA
4166    3275  5300              JMP .+3
4167    3276  1372              TAD (32)
4168    3277  3034              DCA LAST
4169    3300  1034              TAD LAST
4170    3301  7041              CIA
4171    3302  1033              TAD FIRST
4172    3303  7740              SMA SZA CLA
4173    3304  5276              JMP .-6
4174    3305  4473              PRINT
4175    3306  6710              MLAST
4176    3307  4505              TY4OCT
4177    3310  0034              LAST
4178    3311  4504              TAB
4179    3312  0005              5                         /TAB TO MOVE TELEPRINTER HEAD
4180                            /**********
4181                            /CONSOLE
4182                            /***********
4183
4184
4185    3313  4421              CHECKC8                   /IS CONSOLE ACTIVE
4186    3314  4426              C8SWIT                    /YES PRINT SWITCH REGISTER QUESTION
4187                                                      /FOR RUNNING SWITCHES
4188    3315  5317              JMP     C8RET4
4189    3316  4461              HLT
4190    3317  5771'             C8RET4,JMP PRETEST
4191                    /ENTRY TO HERE IS FROM RX01 PI ERROR SERVICE ROUTINE
4192                    /
4193                    /CONTROLLER FAILURES
4194                    /
4195    3320  1370      SDNUNEXPECTED, TAD (MSDNUNEXPECTED)
4196    3321  7410              SKP
4197    3322  1367      NOSER,  TAD (MNOSER)
4198    3323  3334              DCA XMESSAGE
4199    3324  4570              LAS
4200    3325  0371              AND (SW3)
4201    3326  7640              SZA CLA
4202    3327  5335              JMP QUIET
```

```
4203    3330  4575            FORCE
4204    3331  1334            TAD     XMESSAGE                /POINTS TO ERROR MESSAGE THAT WOULD HAVE BEEN PRINTED,
4205    3332  4467            AERROR                          /REPORT ERROR TO APT IF REQUIRED,
4206    3333  4473            PRINT
4207    3334  0000            XMESSAGE, 0
4208    3335  4570    QUIET,  LAS
4209    3336  7710            SPA CLA
4210    3337  4461            HLT
4211    3340  5766'           JMP ERETURN
4212                  /
4213                  /ENTRY TO HERE FROM SUBROUTINES XSER, OR XSDN
4214                  /
4215    3341  2111    HUNGUP, ISZ BUSY
4216    3342  3353            DCA HUNGPC
4217    3343  4575            FORCE
4218                  /
4219                  /THE LABLE "XHUNG" MUST RESIDE HERE BECAUSE OF REFERENCES MADE WITHIN "FORCE"
4220                  /
4221    3344  4473    XHUNG,  PRINT
4222    3345  6611            MHUNGPC
4223    3346  4505            TY40CT
4224    3347  3353            HUNGPC
4225    3350  1365            TAD (-40)
4226    3351  3116            DCA HANGER
4227    3352  5453            NOTEST
4228    3353  0000    HUNGPC, 0
4229                  /
4230    3365  7740
4231    3366  5506
4232    3367  7055
4233    3370  7042
4234    3371  0400
4235    3372  0032
4236    3373  3423
4237    3374  3517
4238    3375  0200
4239    3376  7112
4240    3377  5767
              3400    PAGE
4241                  /
4242                  /ROUTINE IS USED INPLACE OF THE LAS INSTRUCTION WILL READ CORRECT SWITCHES
4243                  /
4244                  /
4245    3400  0000    XCKSWIT,        0
4246    3401  7200            CLA
4247    3402  1022            TAD     22              /CHECK STATUS WORD
4248    3403  0377            AND     (400            /1= ACTIVE CONSOLE
4249    3404  7650            SNA CLA
4250    3405  7614            7614                                    /LAS AND SKIP
4251    3406  1020            TAD     20                              /GET PSEUDO SW REG
4252    3407  5600            JMP I   XCKSWIT                         /EXIT XCKSWIT
4253                  /READ VERIFY
4254                  /
4255    3410  3410    XREADCOMPARE, .
4256    3411  1210            TAD XREADCOMPARE
```



```
4257    3412  3214            DCA XREAD
4258    3413  5216            JMP XRDC
4259                  /READ AND READ AFTER WRITE SUBROUTINE
4260                  /
4261                  /*****************************************************************************
4262                  /
4263                  /IF THIS IS A READ AFTER WRITE, THEN 1 PROGRAM LOCATION PRECEEDING
4264                  /THE PROGRAM LOCATION CONTAINING THE "READ" WILL CONTAIN "WRITE"
4265                  /
4266                  /*****************************************************************************
4267                  /
4268                  /IF THIS IS A READ ONLY, THEN THE CONTENTS OF " RDC " WILL = 1
4269                  /
4270                  /IF THIS IS A READ VERIFY, THEN THE CONTENTS OF " RDC " WILL = 0
4271                  /
4272                  /READ ALL SELECTED SECTORS OF THAT TRACK
4273                  /
4274    3414  3414    XREAD,  .
4275    3415  7301            CLL CLA IAC
4276    3416  3120    XRDC,   DCA RDC
4277    3417  4462            INITSECTORS
4278    3420  1121    READL,  TAD KRETRY
4279    3421  3136            DCA R1RETRY
4280    3422  4456            GETASECTOR
4281    3423  1121    READRETPY, TAD KRETRY
4282    3424  3137            DCA R2RETRY
4283                  /REFRESH PROGRAM LOCATION SNDLOG BECAUSE THE CONTENTS MIGHT BE RESIDUAL
4284                  /IF A PREVIOUS SND (STATUS NO DATA) ERROR EVER OCCURED
4285                  /
4286    3425  3142            DCA SNDLOG
4287    3426  3140            DCA DWSLOG
4288    3427  3141            DCA DNSLOG
4289
4290                  /
4291    3430  1121    REREAD, TAD KRETRY
4292    3431  3143            DCA SRETRY
4293    3432  1121    RESEEK, TAD KRETRY
4294    3433  3144            DCA PRETRY
4295    3434  7327            CLA STL IAC RTL
4296    3435  4441            LCDB
4297    3436  5327            JMP READOK
4298                  /RETURN TO HERE IS FROM A PI (IF AN RX01 ERROR FLAG)
4299                  /
4300                  /AN ERROR HAS BEEN DETECTED
4301                  /
4302                  /IF NOT A CRC ERROR THEN ASSUME A SEEK ERROR
4303                  /
4304    3437  7301    READERROR, CLL CLA IAC
4305    3440  0126            AND ASTATUS             /CRC MASK
4306    3441  7640            SZA CLA
4307    3442  5254            JMP CRCERROR
4308    3443  2143            ISZ SRETRY
4309    3444  7410            SKP
4310    3445  5345            JMP RLOGGED
4311    3446  4570            LAS
```

```
4312    3447  0376            AND (SW4)
4313    3450  7640            SZA CLA
4314    3451  5232            JMP RESEEK
4315    3452  3143            DCA SRETRY
4316    3453  5345            JMP RLOGGED
4317                  /
4318                  /PROGRAMMING NOTE:
4319                  /
4320                  /ANY RECOVERABLE SEEK ERRORS ARE NOTED AT PROGRAM LOCATION " DNS "
4321                  /
4322                  /AN ERROR HAS OCCURED
4323                  /
4324          3506    SND=DNS
4325          3506    DWS=SND
4326                  /
4327                  /THE SECTOR BUFFER CONTAINS THE DATA READ
4328                  /
4329                  /ANY PARITY ERRORS WOULD HAVE PREVIOUSLY BEEN DETECTED AND LOGGED
4330                  /
4331                  /THIS ERROR IS NOT A SEEK ERROR, THEREFORE IT IS ASSUMED TO BE A
4332                  /
4333                  /                       CRC ERROR
4334                  /
4335                  /COMPARE THE DATA WITHIN THE SECTOR BUFFER TO DETECT CRC STATUS
4336                  /WITHOUT DATA ERRORS (SND)
4337                  /
4338                  /IF AT THE END OF THE COMPARE, STATUS NO DATA ERRORS HAVE BEEN DETECTED
4339                  /THEN PRINT AN APPROPRIATE MESSAGE
4340                  /
4341    3454  1120    CRCERROR, TAD RDC
4342    3455  7640            SZA CLA
4343    3456  5303            JMP XCRCERROR
4344    3457  4775'           JMS COMPARE
4345    3460  1113            TAD COMPRERROR
4346    3461  7450            SNA
4347    3462  1774'           TAD INSUMCHECK
4348    3463  7640            SZA CLA
4349    3464  5306            JMP DWS
4350    3465  2142            ISZ SNDLOG
4351                  /
4352                  /IF AC SW (3) = 1 THEN DO NOT PRINT THE ERROR INFORMATION
4353                  /
4354    3466  4570            LAS
4355    3467  0377            AND (SW3)
4356    3470  7640            SZA CLA
4357    3471  5303            JMP XCRCERROR
4358    3472  4350            JMS RDORWR
4359    3473  5277            JMP .+4
4360    3474  4473            PRINT
4361    3475  6715            MWRITE
4362    3476  5301            JMP .+3
4363    3477  4473            PRINT
4364    3500  6721            MREAD
4365    3501  4473            PRINT
4366    3502  6737            MSNDERROR
```



```
4367    3503  4570    XCRCEPROR, LAS
4368    3504  7710            SPA CLA
4369    3505  4461    HLT7,   HLT
4370                  /
4371    3506  1121    DNS,    TAD NRETRY
4372    3507  3143            DCA SRETRY
4373    3510  2137            ISZ R2RETRY
4374    3511  7410            SKP
4375    3512  5322            JMP UREAD
4376                  /AC SW (4) = 0 ; INHIBIT READ RETRY
4377                  /
4378    3513  4570            LAS
4379    3514  0376            AND (SW4)
4380    3515  7640            SZA CLA
4381    3516  5230            JMP REREAD
4382                  /A HARD FILL BUFFER PARITY ERROR OR A HARD PARITY ERROR ON THE COMMAND/
4383                  /SECTOR/TRACK WORDS, OR
4384                  /A HARD SEEK ERROR WHICH HAS BEEN LOGGED WITHIN THE WRITE SUBROUTINE, OR
4385                  /A HARD CRC ERROR WHICH OCCURED WHILE WITHIN THE READ SUBROUTINE
4386                  /
4387    3517  3136    NUREAD, DCA R1RETRY
4388    3520  3137            DCA R2RETRY
4389    3521  5345            JMP RLOGGED
4390                  /IF THIS IS A READ AFTER WRITE THEN RE-WRITE THE SECTOR IN ERROR
4391                  /
4392                  /BECAUSE THIS IS A HARD PROGRAM COMPARE DATA ERROR
4393                  /
4394    3522  4350    UREAD,  JMS RDORWR
4395    3523  5317            JMP NUREAD
4396    3524  2136            ISZ R1RETRY
4397    3525  5773'           JMP REWRITE
4398    3526  5345            JMP RLOGGED
4399                  /IF THIS IS A READ COMPARE TEST
4400                  /
4401                  /THEN " JMS COMPARE ", BUT ...
4402                  /
4403                  /IF A STATUS ERROR WITH NO DATA ERROR HAS PREVIOUSLY BEEN DETECTED
4404                  /
4405                  /THEN DO NOT RE- " JMS COMPARE ", AND
4406                  /
4407                  /DO NOT RESET PROGRAM LOCATION " START " WITH " TARGET "
4408                  /
4409                  /PROGRAMMING NOTE:
4410                  /
4411                  /ANY RECOVERABLE SEEK ERRORS WHICH OCCURED PRIOR TO CRC OR DATA ERRORS
4412                  /
4413                  /ARE LOGGED AT PROGRAM LOCATION " DNS "
4414                  /
4415    3527  1142    READOK, TAD SNDLOG
4416    3530  1120            TAD RDC
4417    3531  7640            SZA CLA
4418    3532  5341            JMP ROK
4419    3533  4775'           JMS COMPARE
4420    3534  1113            TAD COMPRERROR
4421    3535  7450            SNA
```

```
4422    3536  1774'           TAD INSUMCHECK
4423    3537  7640            SZA CLA
4424    3540  5306            JMP DNS
4425    3541  1131    ROK,    TAD TARGET
4426    3542  3125            DCA START
4427    3543  1124            TAD STARGET
4428    3544  3123            DCA SSTART
4429    3545  2122    RLOGGED, ISZ SECTORS
4430    3546  5220            JMP READL
4431    3547  5614            JMP I XREAD
4432                  /IF THE PROGRAMMED INSTRUCTION IMMEDIATELY BEFORE " READ "
4433                  /IS A " WRITE " , THEN THIS IS A WRITE DATA ERROR, IF NOT,
4434                  /THEN THIS IS A READ DATA ERROR
4435                  /
4436                  /FORM: JMS RDORWR; (READ RETURN); (WRITE RETURN)
4437                  /
4438    3550  3550    RDORWR, .
4439    3551  7344            CLL STA RAL
4440    3552  1214            TAD XREAD
4441    3553  3135            DCA XXX
4442    3554  1535            TAD I XXX
4443    3555  1372            TAD (-WRITE)
4444    3556  7650            SNA CLA
4445    3557  2350            ISZ RDORWR
4446    3560  5750            JMP I RDORWR
4447    3572  3270
4448    3573  3206
4449    3574  3761
4450    3575  3601
4451    3576  0200
4452    3577  0400
              3600            PAGE
4453    3600  5601    JMPICOMPARE, JMP I COMPARE
4454                  /
4455                  /THE FOLLOWING INFORMATION IS ALWAYS PRINTED IF A PROGRAM COMPARE DATA ERROR
4456                  /
4457                  /                       DATA ERROR
4458                  /                       WORD GOOD BAD
4459                  /
4460                  /WHERE " WORD " IS THE WORD NUMBER (0-127),
4461                  /AND " GOOD " IS THE DATA WORD WRITTEN,
4462                  /AND " BAD " IS THE DATA WORD READ (IN ERROR)
4463                  /
4464                  /WORDS 0 AND 1 ARE HEADER WORDS (8 BIT BYTES)
4465                  /
4466                  / WORD 0 - TRACK # (BITS 5-11)
4467                  / WORD 1 - SECTOR (BITS 7-11)
4468                  /
4469                  /
4470                  /AC SW (4) = 1 ; INHIBIT READ DATA ERROR TYPEOUT
4471                  /
4472                  /
4473    3601  3601    COMPARE, .
4474                  /
4475                  /EMPTY BUFFER
```



```
4476                  /
4477                  /SAVE THE PREVIOUS READ'S A-STATUS REGISTER
4478                  /
4479    3602  7301            CLL CLA IAC
4480    3603  0126            AND ASTATUS
4481    3604  3360            DCA XASTATUS
4482    3605  1121            TAD KRETRY
4483    3606  3144            DCA PRETRY
4484    3607  1377    EMPTYL, TAD (WBUFFER)
4485    3610  3134            DCA XA11
4486    3611  7305            CLL CLA IAC RAL
4487    3612  4440            LCDA
4488    3613  5776'           JMP EMPTYOK
4489    3614  5775'           JMP EMPTYERROR
4490                  /RETURN TO HERE FROM SUBROUTINE XLCDA
4491                  /
4492    3615  3113            DCA COMPREPROR
4493    3616  3361            DCA INSUMCHECK
4494                  /
4495                  /AC SW (3) = 1 ; INHIBIT FURTHER READ DATA ERROR TYPEOUTS
4496                  /
4497                  /...BUT STAY IN THIS LOOP UNTIL THE RX01 SECTOR BUFFER IS EMPTIED
4498                  /
4499    3617  4444    EMPTY,  STR
4500    3620  5217            JMP EMPTY
4501                  /
4502                  /DISABLE THE PX01 INTERRUPT
4503                  /
4504    3621  4447            INTR
4505                  /
4506                  /TRANSFER DATA FROM THE SECTOR BUFFER INTO THE ACCUMULATOR
4507                  /
4508    3622  4442            XDRIN                   / "ACTUAL"  (BAD)  DATA
4509    3623  3133            DCA XA10
4510                  /
4511                  /ASSUME A 12 BIT SUMCHECK EVEN IF 8 BIT MODE FOR NOW
4512                  /
4513                  /NOTE: THE CONTENTS OF PROGRAM LOCATION " INSUMCHECK " SHOULD = 0
4514                  / (AFTER ALL WORDS HAVE COME IN)
4515                  /
4516    3624  1133            TAD XA10
4517    3625  1361            TAD INSUMCHECK
4518    3626  3361            DCA INSUMCHECK
4519    3627  7307            CLL CLA IAC RTL         / 4  (8/12 BIT MODE MASK)
4520    3630  0132            AND TESTP
4521    3631  7112            CLL RTR
4522    3632  7010            RAR
4523    3633  1534            TAD I XA11
4524    3634  7430            SZL                     / 0 = 12 BIT, 1 = 8 BIT
4525    3635  0374            AND (377)
4526    3636  7041            CIA
4527    3637  1133            TAD XA10
4528    3640  7650            SNA CLA
4529    3641  5773'           JMP ENDCOMPARE
4530                  /
```

```
                        /A PROGRAM COMPARE DATA ERROR HAS BEEN DETECTED
                        /
                        /NOTATION:
                        /
                        /THE CONTENTS OF PROGRAM LOCATION XASTATUS REFLECTS THE STATUS OF THE
                        /RX01 AT THE COMPLETION OF THE PREVIOUS " READ SECTOR "
                        /
                        /IF A CRC EPROR EXISTS THEN THIS IS A DATA ERROR WITH STATUS ERROR
                        /
                        /IF A CRC ERROR DOESN'T EXIST THEN THIS IS A DATA ERROR WITH NO ERROR STATUS
                        /
4542    3642  1360              TAD XASTATUS            / A-STATUS OF PREVIOUS READ
4543    3643  7450              SNA
4544    3644  2141              ISZ DNSLOG              /NO CRC STATUS
4545    3645  7640              SZA CLA
4546    3646  2140              ISZ DWSLOG              /CRC STATUS
4547                    /
4548                    /AC SW (3) TO INHIBIT ERROR PRINTOUT
4549                    /
4550                    /IF THIS IS A READ ONLY TEST (NOT READ COMPARE) OR IF AC SW 3 = 1
4551                    /THEN DO NOT PRINT ERROR INFORMATION
4552                    /
4553                    /BUT,
4554                    /
4555                    /IF THIS IS A READ COMPARE TEST AND AC SW 3 = 0
4556                    /THEN PRINT ERROR INFORMATION
4557                    /
4558    3647  4570              LAS
4559    3650  0372              AND (SW3)
4560    3651  1120              TAD RDC
4561    3652  7640              SZA CLA
4562    3653  5356              JMP ISZCOMPRERROR
4563                    /IF THIS IS THE FIRST COMPARE ERROR THEN PRINT HEADER INFORMATION
4564                    /
4565    3654  1113              TAD COMPRERROR
4566    3655  7640              SZA CLA
4567    3656  5317              JMP CNOTFIRST
4568                    /
4569                    /IF A DATA NO CRC STATUS ERROR (DNS) THEN PRINT ENTIRE ERROR INFORMATION
4570                    /
4571    3657  1141              TAD DNSLOG
4572    3660  7640              SZA CLA
4573    3661  4575              FORCE
4574                    /IF THE PROGRAMMED INSTRUCTION IMMEDIATELY BEFORE " READ "
4575                    /IS A " WRITE " , THEN THIS IS A WRITE DATA ERROR, IF NOT,
4576                    /THEN THIS IS A READ DATA ERROR
4577                    /
4578    3662  4771'     XCOMPARE, JMS RDORWR
4579    3663  5267              JMP .+4
4580    3664  4473              PRINT
4581    3665  6715              MWRITE
4582    3666  5271              JMP .+3
4583    3667  4473              PRINT
4584    3670  6721              MREAD
4585                    /NOTATION:
```



```
4586                    /
4587                    /THE CONTENTS OF PROGRAM LOCATION XASTATUS REFLECTS THE STATUS OF THE
4588                    /RX01 AT THE COMPLETION OF THE PREVIOUS " READ SECTOR "
4589                    /
4590                    /IF A CRC ERROR EXISTS THEN THIS IS A DATA ERROR WITH STATUS ERROR
4591                    /
4592                    /IF A CRC ERROR DOESN'T EXIST THEN THIS IS A DATA ERROR WITH NO ERROR STATUS
4593                    /
4594    3671  1360              TAD XASTATUS
4595    3672  7640              SZA CLA
4596    3673  5277              JMP DWESERROR
4597    3674  4473              PRINT
4598    3675  6725              MDNSERROR
4599    3676  5301              JMP .+3
4600    3677  4473    DWESERROR, PRINT
4601    3700  6733              MDWESERROR
4602    3701  4473              PRINT
4603    3702  6752              MDATAERROR
4604                    /PRINT " WORD " IF 12-BIT MODE, OR PRINT " BYTE " IF 8-BIT MODE
4605                    /
4606    3703  1370              TAD (MWORD)
4607    3704  3314              DCA XFLENGTH
4608    3705  7307              CLL CLA IAC RTL
4609    3706  0132              AND TESTP
4610    3707  7650              SNA CLA
4611    3710  5313              JMP .+3
4612    3711  1367              TAD (MBYTE)
4613    3712  3314              DCA XFLENGTH
4614    3713  4473              PRINT
4615    3714  6761    XFLENGTH, MWORD
4616    3715  4473              PRINT
4617    3716  6767              MGB
4618                    / AC 2 = 0 - PRINT ONLY FIRST 3 COMPARE ERRORS
4619                    / AC 2 = 1 - PRINT ALL COMPARE ERRORS
4620                    /
4621    3717  4570    CNOTFIRST, LAS
4622    3720  7106              CLL RTL
4623    3721  7710              SPA CLA
4624    3722  5327              JMP .+5
4625    3723  7346              CLL STA RTL
4626    3724  1113              TAD COMPRERROR
4627    3725  7700              SMA CLA
4628    3726  5356              JMP ISZCOMPRERROR
4629    3727  4473              PRINT
4630    3730  6601              MCRLF
4631    3731  1366              TAD (-WBUFFER)
4632    3732  1134              TAD XA11
4633    3733  3156              DCA LSB
4634    3734  4505              TY4OCT
4635    3735  0156              LSB
4636    3736  4504              TAB
4637    3737  0005              5
4638                    /IF 8-BIT MODE THEN MASK THE 12-BIT "GOOD" WORDS (377)
4639                    /
4640    3740  7307              CLL CLA IAC RTL
```

```
4641    3741  0132            AND TESTP
4642    3742  7112            CLL RTR
4643    3743  7010            RAR
4644    3744  1534            TAD I XA11
4645    3745  7430            SZL
4646    3746  0374            AND (377)
4647    3747  3156            DCA LSB
4648    3750  4505            TY4OCT
4649    3751  0156            LSB
4650    3752  4504            TAB
4651    3753  0012            12
4652    3754  4505            TY4OCT
4653    3755  0133            XA10
4654    3756  2113    ISZCOMPRERROR, ISZ COMPRERROR
4655    3757  5773'           JMP ENDCOMPARE
4656                  /THE CONTENTS OF THE XASTATUS PROGRAM LOCATION REFLECTS THE STATUS AT THE
4657                  /COMPLETION OF THE PREVIOUS READ FUNCTION
4658                  /
4659                  /THE PREVIOUS STATUS IS SAVED BECAUSE A SUCCEEDING ERROR
4660                  / (PARITY ERROR ON THE COMMAND WORD) MAY OCCUR
4661                  /
4662    3760  0000    XASTATUS, 0
4663                  /
4664                  /THE CONTENTS OF " INSUMCHECK " IS THE SUMCHECK DERIVED FROM THE SUM OF ALL
4665                  /DATA WORDS COMING IN (THE SUM OF ALL " BAD " ), AND
4666                  /SHOULD BE EQUIVALENT TO 0 AT THE END OF THE EMPTY BUFFER
4667                  /
4668    3761  0000    INSUMCHECK, 0
4669    3766  0665
4670    3767  6764
4671    3770  6761
4672    3771  3550
4673    3772  0400
4674    3773  4000
4675    3774  0377
4676    3775  4005
4677    3776  4016
4678    3777  7113
              4000            PAGE
4679                  /
4680                  /RE-ENABLE THE RX01 INTERRUPT
4681                  /
4682    4000  7301    ENDCOMPARE, CLL CLA IAC
4683    4001  4447            INTR
4684    4002  2134            ISZ XA11
4685    4003  6001            ION
4686    4004  5777'           JMP EMPTY
4687                  /
4688                  /THIS INTERFACE PARITY ERROR MUST BE ON THE COMMAND WORD TO "EMPTY BUFFER"
4689                  /
4690                  /NOTE: IT CAN'T BE ANY OTHER ERROR
4691                  /
4692    4005  2144    EMPTYERROR, ISZ PRETRY
4693    4006  7410            SKP
4694    4007  5266            JMP XEMPTYOKNOTOK
```



```
4695    4010  4570            LAS
4696    4011  0376            AND (SW4)
4697    4012  7640            SZA CLA
4698    4013  5775'           JMP EMPTYL
4699    4014  3144            DCA PRETRY
4700    4015  5266            JMP XEMPTYOKNOTOK
4701                  /IF AC SW (3) = 0
4702                  /
4703                  /PRINT A VALUE SYMBOLIC OF THE TOTAL # OF COMPARE ERRORS DETECTED
4704                  /
4705                  /IF 8-BIT MODE THEN THE "SUMCHECK" WILL OVERFLOW INTO BITS 0 TO 3
4706                  /
4707                  /THEREFORE MASK THE CONTENTS OF " INSUMCHECK "
4708                  /
4709                  /THE RESULT OF THE SUBTRACTION SHOULD = 0
4710                  /
4711                  /NO MASK IS NEEDED FOR 12-BIT MODE
4712                  /
4713    4016  7307    EMPTYOK, CLL CLA IAC RTL
4714    4017  0132            AND TESTP
4715    4020  7112            CLL RTR
4716    4021  7010            RAR
4717    4022  1774'           TAD INSUMCHECK
4718    4023  7430            SZL
4719    4024  0373            AND (377)
4720    4025  3774'           DCA INSUMCHECK
4721    4026  4570            LAS
4722    4027  0372            AND (SW3)
4723    4030  7640            SZA CLA
4724    4031  5266            JMP XEMPTYOK
4725                  /IF A SUMCHECK ERROR EXISTS WITHOUT A "COMPRERROR" THEN "FORCE" A TYPEOUT
4726                  /
4727    4032  1113            TAD COMPRERROR
4728    4033  7640            SZA CLA
4729    4034  5241            JMP .+5
4730    4035  1774'           TAD INSUMCHECK
4731    4036  7650            SNA CLA
4732    4037  5266            JMP XEMPTYOK
4733    4040  4575            FORCE
4734    4041  4473            PRINT
4735    4042  6774            MSUMCHECK
4736    4043  1774'           TAD INSUMCHECK
4737    4044  7640            SZA CLA
4738    4045  5251            JMP .+4
4739    4046  4473            PRINT
4740    4047  7004            MOK
4741    4050  5254            JMP .+4
4742    4051  4505            TY4OCT
4743    4052  3761            INSUMCHECK
4744    4053  5257            JMP .+4
4745    4054  1113            TAD COMPRERROR
4746    4055  7650            SNA CLA
4747    4056  5266            JMP XEMPTYOK
4748    4057  4473            PRINT
4749    4060  7006            MDESUMMARY
```

```
4750    4061  4505            TY4OCT
4751    4062  0113            COMPRERROR
4752    4063  4504            TAB
4753    4064  0005            5
4754    4065  5266            JMP XEMPTYOK
4755                  /
4756                  /AC SW 0 = 1 ; HALT ON ERROR
4757                  /
4758    4066  1113    XEMPTYOK, TAD COMPRERROR
4759    4067  7450            SNA
4760    4070  1774'           TAD INSUMCHECK
4761    4071  7650            SNA CLA
4762    4072  5771'           JMP JMPICOMPARE
4763    4073  4570            LAS
4764    4074  7710            SPA CLA
4765    4075  4461            HLT6, HLT
4766    4076  5771'           JMP JMPICOMPARE
4767    4077  4077    XSETUP, .
4768    4100  4507            WAITTY
4769    4101  1370            TAD (ANDRETURN)
4770    4102  3767'           DCA XPRINT
4771    4103  1677            TAD I XSETUP
4772    4104  3314            DCA XANDRETURN
4773    4105  2277            ISZ XSETUP
4774    4106  5677            JMP I XSETUP
4775                  /
4776                  /AND RETURN TO HERE WAITING FOR ENTIRE NUMERICAL OUTPUT
4777                  /
4778    4107  4507    ANDRETURN, WAITTY
4779                  /
4780                  /THEN EXIT FROM HERE FOR MAIN LINE CODE
4781                  /
4782    4110  1714    THENEXIT, TAD I XANDRETURN
4783    4111  3314            DCA XANDRETURN
4784    4112  3160            DCA TTYBUSY
4785    4113  5714            JMP I XANDRETURN
4786    4114  4114    XANDRETURN, .
4787                  /
4788    4115  4115    XHALT,  .
4789    4116  4507            WAITTY
4790                          /************
4791                          /CONSOLE
4792                          /************
4793    4117  4424            CHECKC8
4794    4120  4427            C8INQU
4795    4121  5325            JMP C8RET3      /PRINT WAITING IF ON CONSOLE
4796                          /************
4797    4122  7240            STA
4798    4123  1315            TAD XHALT
4799    4124  7402            7402
4800    4125  7200            C8RET3,CLA
4801    4126  5715            JMP 1 XHALT
4802                  /
4803                  /ROUTINE TO NOTIFY OF OF RUNNING IF NEED BE DONE
4804                  /
```



```
4805    4127  0000    XTICK,  0
4806    4130  4472            CHEK22
4807    4131  7410            SKP                             /ON APT.
4808    4132  5727            JMP I   XTICK
4809    4133  2345            ISZ     CLKCNT
4810    4134  5727            JMP I   XTICK
4811    4135  1346            TAD     COUNT
4812    4136  3345            DCA     CLKCNT                  /INIT CLOCK COUNTER
4813    4137  6002            IOF
4814    4140  6201            CDF     00
4815    4141  6272            CIF     70
4816    4142  4744            JMS I   K6500                   /NOTIFY APT-8
4817    4143  5727            JMP I   XTICK                   /EXIT.
4818                  /
4819    4144  6500    K6500,  6500
4820    4145  7777    CLKCNT, -1
4821    4146  7763    COUNT,  -15
4822    4167  5244
4823    4170  4107
4824    4171  3600
4825    4172  0400
4826    4173  0377
4827    4174  3761
4828    4175  3607
4829    4176  0200
4830    4177  3617
              4200            PAGE
4831                  /SEQUENCE TO THE NEXT AVAILABLE DISKETTE
4832                  /
4833    4200  4200    XGETUNIT,       .
4834    4201  3240            DCA UNITZ       /CLEAR FOR A NEW DISKETTE
4835    4202  1236            TAD WUNITS      /WORKING UNIT COUNTER
4836    4203  7450            SNA
4837    4204  1235            TAD UNITS       /EXAUSTED ALL DISKETTES ; RESET
4838    4205  3236            DCA WUNITS
4839    4206  3237            DCA POLL        /CLEAR POLLER
4840    4207  7120            STL             /START
4841    4210  1237    NEXT,   TAD POLL
4842    4211  7010            RAR             /NEXT
4843    4212  3237            DCA POLL
4844    4213  1237            TAD POLL
4845    4214  7430            SZL             /DISKETTE
4846    4215  4461            HLT             /NO UNITS AVAILABLE ; CATASTROPHIC
4847    4216  0236            AND WUNITS
4848    4217  7450            SNA
4849    4220  2240            ISZ UNITZ       /ACTIVE DISKETTE
4850    4221  7450            SNA
4851    4222  5210            JMP NEXT        /TRY AGAIN
4852                  /A DISKETTE IS AVAILABLE AND SELECTED FOR OPERATIONS
4853    4223  3241            DCA UNITX       /A CODED VERSION OF UNIT
4854    4224  1241            TAD UNITX
4855    4225  7040            CMA             /...DELETE FROM
4856    4226  0236            AND WUNITS      /...AVAILABLE UNIT LIST (WUNITS)
4857    4227  3236            DCA WUNITS      /...AND CREATE NEW LIST
4858    4230  1240            TAD UNITZ
```

```
4859    4231  7106          CLL RTL
4860    4232  7006          RTL     /BIT 7 OF COMMAND REGISTER
4861    4233  3242          DCA UNIT        /FOR COMMAND REGISTER LOAD LATER
4862    4234  5600          JMP I XGETUNIT
4863    4235  6000    UNITS,  6000            /AVAILABLE UNIT LIST (MAX SYS CONFIGURATION)
4864    4236  0000    WUNITS, 0               /CODED WORKING UNIT LIST (UNITS YET TO BE EXERCISED)
4865    4237  0000    POLL,   0               /DISKETTE POLL
4866                  /
4867                  /UNITZ ; UNIT 1 LOOKS LIKE 0001
4868                  /UNITX ; UNIT 1 LOOKS LIKE 2000
4869                  /UNIT  ; UNIT 1 LOOKS LIKE 0020 (RX01 COMMAND WORD BIT 7)
4870                  /
4871    4240  0000    UNITZ,  0               /ACTIVE DISKETTE
4872    4241  0000    UNITX,  0               /ACTIVE DISKETTE IN CODED FORM
4873    4242  0000    UNIT,   0               /A CODED VERSION OF UNIT Z (FOR COMMAND REGISTER LOAD)
4874                  /
4875                  /IF (WUNITS) = 0 ; ALL SELECTED DISKETTE DRIVES HAVE SEQUENCED
4876                  /
4877    4243  4243    XDONE,  .
4878    4244  1236          TAD WUNITS
4879    4245  7650          SNA CLA
4880    4246  2243          ISZ XDONE       / DONE ; (WUNITS) = 0
4881    4247  5643          JMP I XDONE
4882                  /INITIALIZE THE NUMBER OF TRACKS ACCESSED VIA THE DIFFERENCE BETWEEN
4883                  /THE CONTENTS OF PROGRAM LOCATIONS " OD " AND " ID ".
4884                  /
4885    4250  4250    XINITTRACKS, .
4886    4251  1032          TAD ID
4887    4252  7040          CMA
4888    4253  1031          TAD OD
4889    4254  3145          DCA TRACKS
4890    4255  1145          TAD TRACKS
4891    4256  7041          CIA
4892    4257  3146          DCA TTRACKS
4893    4260  5650          JMP I XINITTRACKS
4894                  / OD (OUTSIDE DIAMETER) ACTUATOR POSITION INITIALIZED TO (0)
4895                  /
4896                  / ID (INSIDE DIAMETER) ACTUATOR POSITION INITIALIZED TO 114 (76 DECIMAL)
4897                  /
4898                  / " XGETATRACK " WILL GET A TRACK VALUE BETWEEN THE LIMITS OF THE CONTENTS OF
4899                  /PROGRAM LOCATION OD (MIN 0), AND THE CONTENTS OF ID (MAX 114).
4900                  /
4901                  /GET A DISKETTE TRACK TO BE (AC) WITHIN IOT LCD-B
4902                  /
4903                  / IF THIS IS THE " FIRSTMOVE ", (START) IS NOT APPLICABLE HERE, BUT
4904                  / WILL BECOME APPLICABLE WITHIN SUBROUINE " XGETASECTOR ".
4905                  /
4906    4261  4261    XGETATRACK,     .
4907    4262  1131          TAD TARGET      /PRESENT ACTUATOR POSITION (FROM PREVIOUS LCD-B)
4908    4263  3125          DCA START       /BECOMES  STARTING ACTUATOR POSITION
4909    4264  1377          TAD (70)
4910    4265  0132          AND TESTP
4911    4266  7110          CLL RAR
4912    4267  7012          RTR
4913    4270  1376          TAD (TAD SEQ)
```



```
4914    4271  3272          DCA .+1
4915    4272  1276          TAD SEQ
4916    4273  3275          DCA .+2
4917    4274  5675    RESEQUENCE, JMP I .+1
4918    4275  4306          SEQ000
4919                  /TRACK ACCESS SEQUENCE IS SELECTED VIA AC SWITCHES 6,7,8 AT L/S 200
4920                  /
4921                  / 0 = INCREMENTAL (1-114-0)
4922                  / 1 = DECREMENTAL (114-0)
4923                  / 2 = 1-114, 113-0
4924                  / 3 = BOUNCE ID TO OD ONLY
4925                  / 4 = BOUNCE: (114, 0 ; 113, 1 ; 112, 2 ; ...ETC TO 47, 45)
4926                  / 5 =
4927                  / 6 = STROBE: (77, 0 ; 76, 0 ; 75, 0 ; ...ETC TO 1, 0)
4928                  / 7 = RANDOM
4929                  /
4930    4276  4306    SEQ,    SEQ000
4931    4277  4317          SEQ001
4932    4300  4400          SEQ010
4933    4301  4422          SEQ3
4934    4302  4444          SEQ100
4935    4303  5453          NOTEST
4936    4304  4465          SEQ6
4937    4305  4330          SEQ111
4938                  /
4939                  /INCREMENTAL ACTUATOR ACCESS (OD INCREMENTALLY TO ID)
4940                  /
4941    4306  1146    SEQ000, TAD TTRACKS
4942    4307  1145          TAD TRACKS
4943    4310  7640          SZA CLA
4944    4311  5314          JMP .+3
4945    4312  1031          TAD OD
4946    4313  5332          JMP DCATARGET
4947    4314  1131          TAD TARGET
4948    4315  7001          IAC
4949    4316  5332          JMP DCATARGET
4950                  /DECREMENTAL ACTUATOR ACCESS (ID TO OD)
4951                  /
4952    4317  1146    SEQ001, TAD TTRACKS
4953    4320  1145          TAD TRACKS
4954    4321  7640          SZA CLA
4955    4322  5325          JMP .+3
4956    4323  1032          TAD ID
4957    4324  5332          JMP DCATARGET
4958    4325  1131          TAD TARGET
4959    4326  1117          TAD K7777
4960    4327  5332          JMP DCATARGET
4961                  /RANDOM ACTUATOR ACCESS
4962                  /
4963    4330  4775'   SEQ111, JMS RANGEN
4964    4331  0374          AND (177)
4965    4332  3131    DCATARGET, DCA TARGET
4966                  /PREVIOUSLY AT L/S THE FOLLOWING CONDITION WAS TRUE
4967                  /
4968                  /               0 <= (OD) <= (ID) <= 32
```

```
                        /
                        /THEREFORE TEST FOR THE CONDITION
                        /
                        /               (TARGET) <= (ID)
                        /
4333  1032    XSEQ,     TAD ID
4334  7041              CIA
4335  1131              TAD TARGET
4336  7740              SMA SZA CLA
4337  5274              JMP RESEQUENCE
                        /AND TEST FOR THE CONDITION
                        /
                        /               (OD) <= (TARGET)
                        /
4340  1131              TAD TARGET
4341  7041              CIA
4342  1031              TAD OD
4343  7740              SMA SZA CLA
4344  5274              JMP RESEQUENCE
4345  5661              JMP I XGETATRACK
                        /
                        /ERROR REPORTEP FOR APT. INDICATES TEST PC IN ERROR. THE ONLY EXCEPTIONS
                        /ARE FOR AN UNEXPECTED RX01 INTERRUPT,
                        /AND A MISSING ERROR FLAG.
                        /
4346  0000    XAERRO, 0
4347  3135              DCA     XXX                             /STORE ERROR PC.
4350  4472              CHEK22
4351  7410              SKP
4352  5746              JMP I   XAERRO
4353  6002              IOF
4354  1135              TAD     XXX                     /GET BACK ERROR PC.
4355  6201              CDF     00
4356  6272              CIF     70
4357  5761              JMP I   K6520
4360  4461              HLT                             /SOMETHING WENT WRONG ON
                                                        /ON REPORTING ERROR TO APT
4361  6520    K6520,  6520
4374  0177
4375  4710
4376  1276
4377  0070
      4400              PAGE
                        / OD+1 INCREMENTALLY TO ID; ID-1 DECREMENTALLY TO OD
                        /
4400  1146    SEQ010, TAD TTRACKS
4401  1145              TAD TRACKS
4402  7640              SZA CLA
4403  5213              JMP XSEQ2
4404  1145              TAD TRACKS
4405  7104              CLL RAL
4406  1377              TAD (2)
4407  3145              DCA TRACKS      / (TPACKS X 2)-2 = 152(MAX VAL)
4410  1145              TAD TRACKS
4411  7041              CIA
```



```
4412  3146              DCA TTRACKS
                        /INCREMENT IF (TRACKS) < [ (ID)-(OD) ]
                        /DECREMENT IF (TRACKS) => [ (ID)-(OD) ]
4413  1031    XSEQ2,  TAD OD
4414  7041              CIA
4415  1032              TAD ID
4416  1145              TAD TRACKS
4417  7700              SMA CLA
4420  5776'             JMP SEQ001      / ID-1 TO OD
4421  5775'             JMP SEQ000      / OD+1 TO ID
                        /
                        /BOUNCE; ID,OD ONLY
                        /
4422  1146    SEQ3,   TAD TTRACKS
4423  1145              TAD TRACKS
4424  7640              SZA CLA
4425  5233              JMP XSEQ3
4426  7344              CLL STA RAL
4427  3145              DCA TRACKS
4430  1145              TAD TRACKS
4431  7041              CIA
4432  3146              DCA TTRACKS
4433  1131    XSEQ3,  TAD TARGET
4434  7041              CIA
4435  1031              TAD OD
4436  7650              SNA CLA
4437  1032              TAD ID
4440  7450              SNA
4441  1031              TAD OD
4442  3131              DCA TARGET
4443  5774'             JMP XSEQ
                        /BOUNCE ; ID TO OD
                        /
                        /THEREFORE 76 (NOT 77) TRACKS ARE TESTED
                        /
4444  1146    SEQ100, TAD TTRACKS
4445  1145              TAD TRACKS
4446  7640              SZA CLA
4447  5254              JMP Q40D
                        /FIRST ENTRY INTO SEQUENCE # 4
                        /
                        /IF (TRACKS) = [ (ID)-(OD) ] IS A NEGATIVE ODD THEN INCREMENT (TRACKS)
                        /
4450  7201              CLA IAC
4451  0145              AND TRACKS
4452  7640              SZA CLA
4453  2145              ISZ TRACKS
                        /IF (TRACKS) = -ODD ; BOUNCE TO OUTSIDE DIAMETER, BUT
                        /
                        /IF (TRACKS) = -EVEN ; BOUNCE TO INSIDE DIAMETER
                        /
4454  7201    Q40D,   CLA IAC
4455  0145              AND TRACKS
4456  7650              SNA CLA
4457  5305              JMP Q46ID
```

```
5078    4460  7240          STA
5079    4461  1146          TAD TTRACKS
5080    4462  1145          TAD TRACKS
5081    4463  7110          CLL RAR
5082    4464  5313          JMP Q46OD
5083                  // (TRACKS) = -EVEN ; THEREFORE THE BOUNCE IS TO THE INSIDE DIAMETER
5084                  //
5085                  /Q4ID,  TAD TTRACKS; TAD TRACKS; CLL RAR; CIA; TAD ID; DCA TARGET; JMP XSEQ
5086                  /STROBE ID, OD ; ID=1, OD ; ID=2, OD ; ...ETC...
5087                  /
5088    4465  1146    SEQ6,   TAD TTRACKS
5089    4466  1145          TAD TRACKS
5090    4467  7640          SZA CLA
5091    4470  5300          JMP Q60D
5092                  /FIRST ENTRY INTO SEQUENCE # 6
5093                  /
5094    4471  1145          TAD TRACKS
5095    4472  7105          CLL IAC RAL
5096    4473  3145          DCA TRACKS
5097    4474  1145          TAD TRACKS
5098    4475  7041          CIA
5099    4476  3146          DCA TTRACKS
5100    4477  5305          JMP Q46ID
5101                  /
5102                  / IF (TARGET) = (0D), THEN STROBE TO INSIDE DIAMETER
5103                  /
5104    4500  1131    Q60D,   TAD TARGET
5105    4501  7041          CIA
5106    4502  1031          TAD OD
5107    4503  7640          SZA CLA
5108    4504  5313          JMP Q46OD
5109                  /
5110                  /
5111                  /
5112    4505  1146    Q46ID,  TAD TTRACKS
5113    4506  1145          TAD TRACKS
5114    4507  7110          CLL RAR
5115    4510  7041          CIA
5116    4511  1032          TAD ID
5117    4512  7410          SKP
5118    4513  1031    Q46OD,  TAD OD
5119    4514  3131          DCA TARGET
5120    4515  5774*         JMP XSEQ
5121                        /**********
5122                        /CONSOLE
5123                        /***********
5124
5125
5126    4516  0000          XCHECKC8, 0
5127    4517  7200          CLA                     /CHECK IF CONSOL IS ACTIVE
5128    4520  1022          TAD     22
5129    4521  0373          AND     (400
5130    4522  7650          SNA CLA
5131    4523  5337          JMP     NOTCL8          /NOT ON ACTIVE CONSOLE
5132    4524  1716          TAD I   XCHECKC8        /GET CONSOLE CALL
```



```
5133    4525  3331          DCA     PACKDO  /STORE IT IN THIS LOC
5134    4526  4507          WAITTY                  /WAIT FOR PRINTING TO FONISH
5135    4527  6002          IOF                     /KILL INTERRUPT
5136    4530  6213          CDF CIF 10              /TO FIELD ONE
5137    4531  0000          PACKDO, 0000            /DO CONSOLE CALL
5138    4532  7000          NOP
5139    4533  6001          ION                     /RETURN FROM CALL
5140    4534  2316    EXITCK, ISZ     XCHECKC8        /BUMP RETURN
5141    4535  7200          CLA
5142    4536  5716          JMP I   XCHECKC8        /EXIT XCHECK
5143    4537  2316    NOTCL8, ISZ     XCHECKC8        /BUMP FOR NOT CONSOL CALL +2
5144    4540  5334          JMP     EXITCK          /LEAVE BY THIS MEANS
5145
5146
5147                        /***********
5148                        /CONSOLE
5149                        /***********
5150                  /THIS SUBROUTNE IS ENTERED FROM TESTS:  T21, T22, T32, T33
5151                  /
5152                  /THE CONTENTS OF THE AC AT ENTRY IS THE PATTERN TO FILL THE BUFFER WITH
5153                  /
5154    4541  4541    FB128BYTES, .
5155    4542  3164          DCA GOOD                        /THE CONTENTS OF GOOD IS THE PURE PATTERN
5156    4543  1372          TAD (100)
5157    4544  4437          LCD                     /FILL BUFFER (8-BIT MODE)
5158    4545  5350          JMP .+3                 /START BY WAITING FOR TRANSFER REQUEST
5159    4546  1164          TAD GOOD
5160    4547  4443          XDROUT                  /TRANSFER OUT TO SECTOR BUFFER
5161    4550  4444          STR
5162    4551  7410          SKP
5163    4552  5346          JMP .-4                 /WAIT FOR TRANSFER REQUEST FLAG
5164    4553  4446          SDN
5165    4554  5350          JMP .-4                 /WAIT FOR DONE FLAG
5166    4555  4445          SER
5167    4556  4465          OK
5168    4557  4452    E210,   ERROR                   /UNEXPECTED ERROR FLAG
5169    4560  4502          SCOPE
5170    4561  5741          JMP I FB128BYTES
5171    4572  0100
5172    4573  0400
5173    4574  4333
5174    4575  4306
5175    4576  4317
5176    4577  0002
              4600          PAGE
5177                  /INITIALIZE THE NUMBER OF SECTORS AVAILABLE TO ACCESS (PER TRACK) VIA THE
5178                  /DIFFERENCE BETWEEN THE CONTENTS OF PROGRAM LOCATIONS " FIRST " AND " LAST ".
5179                  /
5180    4600  4600    XINITSECTORS, .
5181    4601  1034          TAD LAST
5182    4602  7040          CMA
5183    4603  1033          TAD FIRST
5184    4604  3122          DCA SECTORS
5185    4605  3307          DCA XSTARGET
5186    4606  5600          JMP I XINITSECTORS
```

```
5187                    /
5188                    /GET A SECTOR
5189                    /
5190                    /SECTOR ACCESS 1-32 (OCTAL)
5191                    /
5192    4607  4607      XGETASECTOR, .
5193                    /
5194                    /SET (SSTART)
5195                    /
5196    4610  7301      XXGETASECTOR, CLL CLA IAC       / 1
5197    4611  3306              DCA IF
5198    4612  1120              TAD RDC
5199    4613  7450              SNA
5200    4614  2306              ISZ IF                  / + 1 RDC
5201    4615  7710              SPA CLA
5202    4616  5222              JMP .+4                 / + 1 WRITE
5203    4617  7307              CLL CLA IAC RTL
5204    4620  0132              AND TESTP
5205    4621  7640              SZA CLA
5206    4622  2306              ISZ IF                  / + 1 8-BIT MODE
5207                    /
5208                    / (IF) IS:
5209                    /
5210                    / 1 IF READ
5211                    / 2 IF WRITE
5212                    / 2 IF WRITE 8-BIT MODE
5213                    / 2 IF READ AND PROGRAM VERIFY
5214                    / 3 IF READ AND PROGRAM VERIFY 8-BIT MODE
5215                    / 2 IF READ 8-BIT MODE
5216                    /
5217    4623  1307      NEXTSECTOR, TAD XSTARGET
5218    4624  7440              SZA
5219    4625  1306              TAD IF                  /INTERLEAVE FACTOR 1, 2, 3
5220    4626  7001              IAC                     /NOW INTERLEAVE FACTOR IS 2, 3, 4
5221    4627  3307              DCA XSTARGET
5222    4630  1307              TAD XSTARGET
5223    4631  1377              TAD (-33)
5224    4632  7510              SPA
5225    4633  5241              JMP OKSTARGET           / < 33
5226    4634  7640              SZA CLA                 /SKIP IF = 33
5227    4635  7240              STA
5228    4636  1376              TAD (-31)
5229    4637  1307              TAD XSTARGET
5230    4640  3307              DCA XSTARGET
5231    4641  7200      OKSTARGET, CLA
5232    4642  1307              TAD XSTARGET
5233    4643  3124              DCA STARGET
5234                    /
5235                    /PREVIOUSLY AT L/S THE FOLLOWING CONDITION WAS TRUE
5236                    /
5237                    /               0 < (FIRST) <= (LAST)
5238                    /
5239                    /THEREFORE TEST FOR THE CONDITION
5240                    /
5241                    /               (STARGET) <= (LAST)
```



```
5242                    /
5243    4644  1034              TAD LAST
5244    4645  7041              CIA
5245    4646  1124              TAD STARGET
5246    4647  7740              SMA SZA CLA
5247    4650  5223              JMP NEXTSECTOR
5248                    /
5249                    /AND FOR THE CONDITION
5250                    /
5251                    /               (FIRST) <= (STARGET)
5252                    /
5253    4651  1124              TAD STARGET
5254    4652  7041              CIA
5255    4653  1033              TAD FIRST
5256    4654  7740              SMA SZA CLA
5257    4655  5223              JMP NEXTSECTOR
5258                    /FORMAT (XTARGET) BITS 0-6 TRACK ; AND BITS 7-11 SECTOR
5259                    /
5260    4656  1131              TAD TARGET
5261    4657  7104              CLL RAL
5262    4660  7006              RTL
5263    4661  7006              RTL
5264    4662  1124              TAD STARGET
5265    4663  3147              DCA XTARGET
5266                    /AND SET THE HEADER WORDS 0, AND 1 OF THE WRITE BUFFER FOR RDC I.D.
5267                    /
5268                    /WORD 0 IS THE TRACK
5269                    /WORD 1 IS THE UNIT (BIT 4) AND THE SECTOR (BITS 7-11)
5270                    /
5271    4664  1131              TAD TARGET
5272    4665  3775'             DCA WBUFFER
5273    4666  1774'             TAD UNITZ
5274    4667  7106              CLL RTL
5275    4670  7006              RTL
5276    4671  7006              RTL
5277    4672  7004              RAL
5278    4673  1124              TAD STARGET
5279    4674  3773'             DCA WBUFFER+1
5280                    /WORDS 63 AND 64 OR 127 AND 128 ARE OUT-SUMCHECK WORDS
5281                    /
5282    4675  1153              TAD PATSUMCHECK
5283    4676  1775'             TAD WBUFFER
5284    4677  1773'             TAD WBUFFER+1
5285    4700  3554              DCA I WORDX
5286    4701  1554              TAD I WORDX
5287    4702  1554              TAD I WORDX
5288    4703  7041              CIA
5289    4704  3555              DCA I WORDY
5290    4705  5607              JMP I XGETASECTOR
5291                    /
5292    4706  0000      IF,     0
5293    4707  0000      XSTARGET, 0             / 1 TO 32
5294                    /
5295                    /RANDOM NUMBER GENERATOR
5296                    / (EXIT IS WITH THE RANDOM # IN THE ACCUMULATOR)
```

```
 5297    4710  4710    RANGEN, .
 5298    4711  7301            CLL CLA IAC
 5299    4712  1324            TAD R1
 5300    4713  1325            TAD R2
 5301    4714  7106            CLL RTL
 5302    4715  3324            DCA R1
 5303    4716  1325            TAD R2
 5304    4717  7012            RTR
 5305    4720  1324            TAD R1
 5306    4721  3325            DCA R2
 5307    4722  1325            TAD R2
 5308    4723  5710            JMP I RANGEN
 5309    4724  1234    R1,     1234
 5310    4725  0765    R2,     0765
 5311    4773  7114
 5312    4774  4240
 5313    4775  7113
 5314    4776  7747
 5315    4777  7745
               5000            PAGE
 5316                    /
 5317                    /TYPE 4 OCTAL
 5318                    /
 5319    5000  5002    XTY4OCT, .
 5320    5001  7410            SKP
 5321    5002  3160            DCA     TTYBUSY                 /INITIALIZE TTYBUSY INDICAOR.
 5322    5003  4500            SETUP
 5323    5004  5000            XTY4OCT
 5324    5005  1600            TAD I XTY4OCT
 5325    5006  2200            ISZ XTY4OCT
 5326    5007  3262            DCA XOCTAL      /FOR " OCTAL " ADDRESS
 5327    5010  1662            TAD I XOCTAL
 5328    5011  3262            DCA XOCTAL      /OCTAL
 5329    5012  7346            CLL STA RTL     / -3
 5330    5013  1117            TAD K7777       / -1
 5331    5014  3263            DCA DIGITS
 5332    5015  7346    SHIFT,  CLL STA RTL     / -3
 5333    5016  3265            DCA SHIFTS
 5334    5017  1262            TAD XOCTAL
 5335    5020  7100    XSHIFT, CLL
 5336    5021  7510            SPA
 5337    5022  7020            CML
 5338    5023  7004            RAL
 5339    5024  2265            ISZ SHIFTS
 5340    5025  5220            JMP XSHIFT
 5341    5026  3262            DCA XOCTAL      /NEW
 5342    5027  1262            TAD XOCTAL
 5343    5030  0173            AND K0007                       /OCTAL MASK
 5344    5031  7450            SNA
 5345    5032  5242    JMPDIG, JMP     1SZDIG                  /DO NOT PRINT LEADING ZEROS.
 5346    5033  3264            DCA     XXDMP                   /STORE NUMBER TO BE PRINTED
 5347    5034  1172            TAD     K7000
 5348    5035  3232            DCA     .-3                     /NOP JMP ISZDIG. LEADING ZEROS WILL NOT BE PRINTED
 5349    5036  1264            TAD     XXDMP                   /RETURN VALUE TO BE PRINTED.
 5350    5037  1377            TAD (260)                       /FOR ASCII COMPONENT
```



```
 5351    5040  4506            TYPEIT
 5352    5041  2266            ISZ     CCNT                    /INDICATES A CHARACTER HAS BEEN PRINTED
 5353    5042  2263    1SZDIG, ISZ DIGITS                      /INDEX DIGIT COUNT
 5354    5043  5215            JMP SHIFT
 5355    5044  2174            ISZ     XCNT                    /TY8OCT?
 5356    5045  5202            JMP     XTY4OCT+2               /YES
 5357    5046  1266            TAD     CCNT
 5358    5047  7650            SNA CLA                         /PRINT ONLY A ZERO??
 5359    5050  5257            JMP     ZERO                    /YES
 5360    5051  7340            CLL CLA CMA
 5361    5052  3174            DCA     XCNT                    /INIT COUNTER
 5362    5053  3266            DCA     CCNT
 5363    5054  1376            TAD     (JMP    ISZDIG)         /ESTABLISH FIRST TIME SWITCH.
 5364    5055  3232            DCA     JMPDIG
 5365    5056  5775'           JMP     THENEXIT
 5366    5057  1377    ZERO,   TAD     (260)
 5367    5060  4506            TYPEIT
 5368    5061  5251            JMP     .-10
 5369    5062  0000    XOCTAL, 0               / " OCTAL " FOR TYPEOUT
 5370    5063  7775    DIGITS, -3
 5371    5064  0000    XXDMP,  0
 5372    5065  7775    SHIFTS, -3
 5373    5066  0000    CCNT,   0
 5374                    /THIS ROUTINE WILL DETERMINE DEVICE CODE TO USE IN PLACE
 5375                    /OF THE STANDARD 75 CODE.
 5376                    /
 5377                    /*************************************************************
 5378    5067  0000    CHNDEV, 0
 5379    5070  1114            TAD     DTESTP                  /GET TESTING PARAMETERS.
 5380    5071  0374            AND     (700                    /ISOLATE DEVICE CODE TO USE.
 5381    5072  7450            SNA                             /USE 75??
 5382    5073  5667            JMP I   CHNDEV                  /YES.
 5383    5074  7112            CLL RTR
 5384    5075  7010            RAR                             /MOVE TO BIT POSITION 6-8.
 5385    5076  1373            TAD (6701)
 5386                    /PROPER DEVICE CODE SHOULD  NOW BE ESTABLISHED.
 5387                    /IF THE OPERATOR HAS MADE AN ERROR THE PROGRAM HAS NO WAY
 5388                    /OF KNOWING IT.
 5389                    /
 5390    5077  3010            DCA A10                         /SET DEVICE CODE = 67X-
 5391    5100  1372            TAD (XDEVIC-1)
 5392    5101  3011            DCA A11         /INTO APPLICABLE PROGRAM
 5393    5102  1411            TAD I A11
 5394    5103  7450            SNA
 5395    5104  5312            JMP .+6         /DEVICE CODE LOCATIONS
 5396    5105  3164            DCA GOOD
 5397    5106  1010            TAD A10
 5398    5107  3564            DCA I GOOD      /SPECIFIED AT
 5399    5110  2010            ISZ A10
 5400    5111  5302            JMP .-7         /PROGRAM LOCATION "DEVICE"
 5401    5112  1726            TAD I XK67X2A
 5402    5113  3771'           DCA K67X2B      /DUPLICATE IOT CODE 67X2
 5403    5114  1727            TAD I XK67X3A
 5404    5115  3770'           DCA K67X3B      /DUPLICATE IOT CODE 67X3
 5405    5116  1730            TAD I XK67X4A
```

```
5406    5117  3767'           DCA K67X4B      /DUPLICATE IOT CODE 67X4
5407    5120  1731            TAD I XK67X5A
5408    5121  3766'           DCA K67X5B      /DUPLICATE IOT CODE 67X5
5409    5122  1733            TAD I XK67X7A
5410    5123  3765'           DCA K67X7B      /DUPLICATE IOT CODE 67X7
5411    5124  5667            JMP I   CHNDEV                  /EXIT AND RUN PROGRAM.
5412                  /PROGRAM DEVICE CODE TABLE
5413                  /
5414    5125  6203    XDEVICE,        K67X1
5415    5126  6401    XK67X2A,        K67X2A                  /XDR TRANSFER DATA REGISTER
5416    5127  6410    XK67X3A, K67X3A                         / STR (SKIP ON TRANSFER REQUEST FLAG)
5417    5130  6415    XK67X4A, K67X4A                         / SER (SKIP ON ERROR FLAG)
5418    5131  6422    XK67X5A, K67X5A                         / SDN (SKIP ON DONE FLAG)
5419    5'32  6431            K67X6                           / CLEAR (AC = 0) / SET (AC = 1) INTERRUPT ENABLE
5420    5133  6435    XK67X7A, K67X7A                         / INIT (INITIALIZE / IMPLIED READ TRACK 0 SECTOR 1)
5421    5134  0000            0                               /
5422                  /
5423    5165  6450
5424    5166  0712
5425    5167  0726
5426    5170  0720
5427    5171  6404
5428    5172  5124
5429    5173  6701
5430    5174  0700
5431    5175  4110
5432    5176  5242
5433    5177  0260
              5200      PAGE
5434                  /
5435                  /ROUTINE TO TYPE 8 OCTAL DIGITS.
5436                  /FORMAT TY8OCT; MSB(STARTING ADDRESS OF DOUBLE LOG TO BE PRINTED).
5437                  /
5438    5200  0000    XTY8OCT,        0
5439    5201  1600            TAD I   XTY8OCT                 /GET STARTING ADDRESS
5440    5202  3212            DCA     .+10
5441    5203  1600            TAD I   XTY8OCT
5442    5204  7001            IAC                             /SECOND ADDRESS
5443    5205  3211            DCA     .+4
5444    5206  7344            CLL CLA CMA RAL                 /-2
5445    5207  3174            DCA     XCNT
5446    5210  4505            TY4OCT
5447    5211  7000            NOP                             /REPLACED WITH POINTER TO BE
5448    5212  7000            NOP                             /PRINTED
5449    5213  2200            ISZ     XTY8OCT                 /UPDATE RETURN
5450    5214  5600            JMP I   XTY8OCT                 /EXIT
5451                  /SUBROUTINE ; TAB
5452                  /ENTRY ; TAB; +N
5453                  /COMMENT ; PRINT " N " SPACES WHERE N IS VIA INDEXED XTAB
5454                  /
5455    5215  5215    XTAB,   .
5456    5216  4500            SETUP
5457    5217  5215            XTAB
5458    5220  3243            DCA XXTAB       /FOR COUNT
5459    5221  7200    XTABL,  CLA
```



```
5460    5222  1243            TAD XXTAB
5461    5223  1615            TAD I XTAB      /FOR " N "
5462    5224  3243            DCA XXTAB
5463    5225  1320            TAD CHARLINE    / # OF CHARACTERS ALREADY TYPED ON THIS LINE
5464    5226  1377            TAD (110)       / 72 CHARACTER LINE STANDARD
5465    5227  7041            CIA
5466    5230  1243            TAD XXTAB
5467    5231  7550            SPA SNA
5468    5232  5221            JMP XTABL
5469    5233  7041            CIA
5470    5234  3243            DCA XXTAB
5471    5235  2215            ISZ XTAB
5472    5236  1376            TAD (240)
5473    5237  4506            TYPEIT
5474    5240  2243            ISZ XXTAB
5475    5241  5236            JMP .-3
5476    5242  5775'           JMP THENEXIT
5477    5243  0000    XXTAB,  0
5478                  /
5479                  /SUBROUTINE ; PRINT
5480                  /ENTRY ;
5481                  /COMMENT ; PRINT A " MESSAGE ",  AND A <CR><LF> AT EACH _
5482                  /
5483                  /  CALL SYNTAX FOR PRINT
5484                  /
5485                  /  1.  PRINT; MTEXT
5486                  /
5487    5244  5244    XPRINT, .
5488    5245  4472            CHEK22
5489    5246  5340            JMP     PNTEXT
5490    5247  4507            WAITTY
5491    5250  1644            TAD I XPRINT    / " TEXT"
5492    5251  2244            ISZ     XPRINT
5493    5252  3262            DCA MESSAGE     /ADDRESS
5494    5253  1662    NUWORD, TAD I MESSAGE
5495    5254  4263            OUTPUT          /LEFT BYTE
5496    5255  1662            TAD I MESSAGE
5497    5256  2262            ISZ MESSAGE
5498    5257  4435            BSW
5499    5260  4263            OUTPUT          /RIGHT BYTE
5500    5261  5253            JMP NUWORD
5501    5262  0000    MESSAGE,0
5502          4263    OUTPUT=JMS .
5503    5263  5263    XOUTPUT,.
5504    5264  0374            AND (-100)      /MASK MS BITS 0-5
5505    5265  7440            SZA
5506    5266  5271            JMP .+3
5507    5267  3160            DCA TTYBUSY
5508    5270  5773'           JMP PIEXIT
5509    5271  1372            TAD (4100)
5510    5272  7450            SNA
5511    5273  5302            JMP NULINE      /   _
5512    5274  1371            TAD (-4100+2)   /CODE 200
5513    5275  7500            SMA
5514    5276  7001            IAC             /CODE 300
```

```
5515    5277  4435          BSW
5516    5300  4506          TYPEIT
5517    5301  5663          JMP I XOUTPUT
5518    5302  1263    NULINE, TAD XOUTPUT
5519    5303  3305          DCA XTYPEIT
5520    5304  5311          JMP XNULINE
5521    5305  5305    XTYPEIT,.
5522    5306  4321          JMS TY1ASC
5523    5307  2320          ISZ CHARLINE
5524    5310  5705          JMP I XTYPEIT
5525    5311  1370    XNULINE,TAD (15)        / <CR>
5526    5312  4321          JMS TY1ASC
5527    5313  1367          TAD (12)        / <LF>
5528    5314  4321          JMS TY1ASC
5529    5315  1366          TAD (-110)
5530    5316  3320          DCA CHARLINE    / 72 CHARACTER LINE (NEGATIVE NOTATION)
5531    5317  5705          JMP I XTYPEIT
5532    5320  7670    CHARLINE,       -110    / # CHARACTERS PER LINE ARE COUNTED HERE
5533                  /
5534          0014    A14=14
5535                  /
5536    5321  5321    TY1ASC, .
5537    5322  6002          IOF
5538    5323  3014          DCA A14
5539    5324  4472          CHEK22
5540    5325  5340          JMP     PNTEXT
5541    5326  1014          TAD A14
5542    5327  6046          TLS
5543    5330  7200          CLA
5544    5331  1160          TAD TTYBUSY
5545    5332  7640          SZA CLA
5546    5333  5773'         JMP PIEXIT
5547    5334  2160          ISZ TTYBUSY
5548    5335  1365          TAD (PI)
5549    5336  3002          DCA IPI
5550    5337  7410          SKP
5551    5340  2244    PNTEXT, ISZ     XPRINT                  /UPDATE RETURN.
5552    5341  6001          ION
5553    5342  5644          JMP I XPRINT
5554                  /
5555                  /
5556    5343  6042    XTCF,   TCF
5557    5344  1014          TAD A14
5558    5345  1364          TAD (-207)
5559    5346  7650          SNA CLA
5560    5347  5705          JMP I XTYPEIT
5561    5350  5721          JMP I TY1ASC
5562                  /
5563                  /
5564                  /
5565    5351  5351    XSPECIALTYPEIT, .
5566    5352  4500          SETUP
5567    5353  5351          XSPECIALTYPEIT
5568    5354  1751          TAD I XSPECIALTYPEIT
5569    5355  2351          ISZ XSPECIALTYPEIT
```



```
5570    5356  4506          TYPEIT
5571    5357  5775'         JMP THENEXIT
5572    5364  7571
5573    5365  5405
5574    5366  7670
5575    5367  0012
5576    5370  0015
5577    5371  3702
5578    5372  4100
5579    5373  5476
5580    5374  7700
5581    5375  4110
5582    5376  0240
5583    5377  0110
              5400    PAGE
5584                  /
5585                  /
5586                  /
5587                  /
5588    5400  5400    XWAITTY, .
5589    5401  1160          TAD TTYBUSY
5590    5402  7640          SZA CLA
5591    5403  5201          JMP .-2
5592    5404  5600          JMP I XWAITTY
5593                  /ENTRY TO THIS POINT WAS CAUSED BY A PROGRAM INTERRUPT REQUEST
5594                  /
5595    5405  3303    PI,     DCA XAC
5596    5406  7010          RAR
5597    5407  3304          DCA XLINK       /SAVE (AC) AND (LINK)
5598    5410  6031          KSF
5599    5411  7410          SKP
5600    5412  5777'         JMP XKCC        /IGNORE KEYBOARD IRQ
5601    5413  6041          TSF
5602    5414  5222          JMP PISDN
5603                  /IF THIS TELEPRINTER FLAG IS EXPECTED (TTYBUSY) = 1
5604                  /THEN "JMP XTCF"
5605                  /IF NOT THEN "JMP PIEXIT"
5606                  /
5607    5415  1160          TAD TTYBUSY
5608    5416  7740          SMA SZA CLA
5609    5417  5776'         JMP XTCF
5610    5420  6042          TCF
5611    5421  5276          JMP PIEXIT
5612                  /IF (BUSY) = 1, THEN AN RX01 PI IS ALREADY BEING PROCESSED
5613                  /
5614                  /IF (GOBIT) = 0, THEN THIS DISKETTE IRQ IS UNEXPECTED
5615                  /
5616                  /DISABLE RX01 INTERRUPT
5617                  /
5618                  /READ RX01 STATUS REGISTER
5619                  /
5620    5422  1160    PISDN,  TAD TTYBUSY
5621    5423  1111          TAD BUSY
5622    5424  7640          SZA CLA
5623    5425  5276          JMP PIEXIT
```

```
5624    5426  2111            ISZ BUSY
5625                  /REFRESH PROGRAM LOCATION " FORCE "
5626                  /
5627    5427  3313            DCA XXFORCE
5628                  /
5629    5430  4446            SDN
5630    5431  5273            JMP UNKNOWN
5631    5432  1152            TAD GOBIT
5632    5433  7750            SPA SNA CLA
5633    5434  5775'           JMP SDNUNEXPECTED
5634    5435  4447            INTR
5635    5436  4442            XDRIN
5636    5437  0374            AND (377)
5637    5440  3126            DCA ASTATUS
5638                  /IF THIS IS TEST # 30 THEN IGNORE DELETED DATA MARKS (IF ANY)
5639                  /
5640    5441  1167            TAD TEST
5641    5442  1373            TAD (-T30)
5642    5443  7650            SNA CLA
5643    5444  5263            JMP DDIGNOPE
5644                  /TECHNICAL NOTE:
5645                  /
5646                  /THE COMMANDS "FILL BUFFER" (0), AND "EMPTY BUFFER" (2)
5647                  /NEVER SHOULD ATTRACT THE "DELETED DATA" STATUS (100)
5648                  /
5649    5445  1372            TAD (16)                /COMMAND MASK
5650    5446  0112            AND COMMAND             /FB (0), OR EB (2)
5651    5447  7440            SZA                     /SKIP IF FILL BUFFER COMMAND (0)
5652    5450  7112            CLL RTR
5653    5451  7640            SZA CLA                 /SKIP IF EMPTY BUFFER COMMAND (2)
5654    5452  7305            CLL CLA IAC RAL         /  2
5655    5453  0132            AND TESTP
5656    5454  7112            CLL RTR                 /PUT TO LINK
5657    5455  1371            TAD (100)               / 100
5658    5456  0126            AND ASTATUS             / A STATUS D.D. MASK
5659                  /
5660                  /IF (L) = 0 AND (AC) = 0, O.K. - NO D.D. MARK
5661                  /
5662                  /IF (L) = 0 AND (AC) > 0  (=100), UNEXPECTED D.D.
5663                  /
5664                  /IF (L) = 1 AND (AC) = 0, D.D. MARK EXPECTED DIDN'T OCCUR
5665                  /
5666                  /IF (L) = 1 AND (AC) > 0  (=100), O.K. - D.D. MARK OCCURED
5667                  /
5668    5457  7430            SZL
5669    5460  7640            SZA CLA                 / (L) = 1
5670    5461  7440            SZA                     / (L) = 0, OR (L) = 1 AND (AC) > 0
5671    5462  5325            JMP DDERROR             / (L) = 0 AND (AC) > 0  (=100)  , OR (L) = 1 AND (AC) = 0
5672    5463  4445    DDIGNORE, SEP
5673    5464  5266            JMP VERIFY              /RX01 OK - RETURN TO INLINE CODE
5674    5465  5773'           JMP RXERROR
5675                  /
5676                  /VERIFY THAT THE CONTENTS OF THE A-STATUS REGISTER = 0
5677                  /
5678                  /WHEN NO RX01 ERROR FLAG EXISTS
```



```
5679                  /
5680                  /MASK BITS 4 (DRIVE READY); AND 5 (DELETED DATA)
5681                  /
5682    5466  1126    VERIFY, TAD ASTATUS
5683    5467  0370            AND (73)
5684    5470  7640            SZA CLA
5685    5471  5767'           JMP NOSER
5686    5472  5307            JMP XRETURN
5687                  /
5688                  /AN UNKNOWN PROGRAM INTERRUPT OCCURED
5689                  /
5690    5473  4473    UNKNOWN, PRINT
5691    5474  7067            MUNKNOWN
5692    5475  3111            DCA BUSY
5693                  /
5694    5476  1304    PIEXIT, TAD XLINK
5695    5477  7104            CLL RAL
5696    5500  1303            TAD XAC
5697    5501  6001            ION
5698    5502  5400            JMP I 0
5699    5503  0000    XAC,    0
5700    5504  0000    XLINK,  0
5701                  /THE CONTENTS OF RETURN ARE SETUP WITHIN THE SUBROUTINES "LCD-A" AND "LCD-B"
5702                  /TO REPRESENT THE RETURN ADDRESS OF THE INLINE TESTING
5703                  /
5704    5505  0000    RETURN, 0
5705                  /
5706    5506  2305    ERETURN, ISZ RETURN                     /INCREMENT FOR ERROR RETURN ADDRESS
5707                  /
5708                  /ENTRY TO HERE FROM PI SERVICE
5709                  /
5710                  /NO RX01 ERROR FLAG EXISTS
5711                  /
5712    5507  3111    XRETURN, DCA BUSY
5713    5510  4466            TICK                            /TIMING FOR APT IF NEEDED.
5714    5511  6001            ION
5715    5512  5705            JMP I RETURN
5716                  /...ENTRY TO THIS POINT MAY HAVE BEEN FROM WITHIN THE SUBROUTINE "COMPARE"
5717                  /WHICH DETECTED A DATA NO STATUS ERROR (DNS) , OR
5718                  /...ENTRY TO THIS POINT MAY HAVE BEEN FROM ROUTINES "XHUNGUP" OR "HUNGUP"
5719                  /THEREBY FORCING AN ERROR INFORMATION PRINTOUT
5720                  /
5721    5513  0000    XXFORCE,        0
5722    5514  2111            ISZ BUSY
5723    5515  5773'           JMP RXERROR
5724    5516  7240    XFORCE, STA
5725    5517  1111            TAD BUSY
5726    5520  3111            DCA BUSY
5727    5521  6001            ION
5728    5522  5713            JMP I XXFORCE
5729    5523  7017    DTYPE,  MEDDDIDNOT
5730    5524  7030            MUDDDID
5731                  /A DISKETTE DELETED DATA MALFUNCTION HAS BEEN DETECTED
5732                  /
5733                  / IF (AC) = 0 - EXPECTED D.D. DIDN'T OCCUR
```

```
5734                    / IF (AC) = 100 - UNEXPEDTED D.D. OCCURED
5735                    /
5736    5525  7640      DDERROR,        SZA CLA                 / 0 OR 1
5737    5526  7001              IAC
5738    5527  1366              TAD (DTYPE)
5739    5530  3135              DCA XXX
5740                    /PROGRAMMING NOTE: "SER" TO CLEAR ACCOMPANYING ERROR FLAG (IF ANY)
5741                    /
5742    5531  4445              SER
5743    5532  7000              NOP
5744    5533  1535              TAD I XXX
5745    5534  5773'             JMP RXERROR
5746    5566  5523
5747    5567  3322
5748    5570  0073
5749    5571  0100
5750    5572  0016
5751    5573  5600
5752    5574  0377
5753    5575  3320
5754    5576  5343
5755    5577  0314
              5600              PAGE
5756                    /A DISKETTE ERROR HAS BEEN DETECTED
5757                    /
5758                    / (DMTYPE) NOT = 0 IF A D.D. ERROR EXISTS
5759                    / (DMTYPE) = 0 IF NO D.D. ERROR EXISTS
5760                    /
5761    5600  3777'     RXERROR, DCA DMTYPE
5762                    /
5763    5601  1112              TAD COMMAND
5764    5602  3150              DCA ECOMMAND
5765    5603  1776'             TAD XXFORCE
5766    5604  1375              TAD (-XHUNG)
5767    5605  7650              SNA CLA
5768    5606  5246              JMP EERROR
5769    5607  1776'             TAD XXFORCE
5770    5610  1374              TAD (-XCOMPARE
5771    5611  7650              SNA CLA
5772    5612  5246              JMP EERROR
5773    5613  1373      SAVEBSTATUS, TAD (16)
5774    5614  4437              LCD
5775    5615  4471              WAIT
5776    5616  4446              SDN
5777    5617  5215              JMP     .-2
5778    5620  3006              DCA     6                       /WAIT POINTER
5779    5621  4445              SER
5780    5622  7000              NOP
5781    5623  4442              XDRIN
5782    5624  0372              AND (377)
5783    5625  3127              DCA BSTATUS
5784    5626  1771'     SAVECSTATUS, TAD UNIT
5785    5627  1370              TAD (12)
5786    5630  4437              LCD
5787    5631  4471              WAIT
```



```
5788    5632  4446              SDN
5789    5633  5231              JMP     .-2
5790    5634  3006              DCA     6                       /WAIT POINTER
5791    5635  4445              SER
5792    5636  7000              NOP
5793    5637  4442              XDRIN
5794    5640  0372              AND (377)
5795    5641  3130              DCA CSTATUS
5796                    /PRINT AN ERROR MESSAGE IF AC SW 3 = 0
5797                    /
5798    5642  4570      LASSW3, LAS
5799    5643  0367              AND (SW3)
5800    5644  7640              SZA CLA
5801    5645  5766'             JMP NOPRINT
5802                    /THE FOLLOWING INFORMATION IS PRINTED FOR ALL ERRORS DETECTED
5803                    /
5804                    /THE ERROR HEADER TEXT IS INHIBITED IF THE ERROR IS NOT THE FIRST ERROR EVER
5805                    /
5806                    /
5807                    /
5808                    /       FAT   CMND  XDR   CODE  RST   START     TARGET     XXXX   PASS
5809                    /
5810                    /
5811                    /
5812    5646  1167      EERROR, TAD     TEST                            /GET TEST IN ERROR
5813    5647  4467              AERROR                          /REPORT ERROR TO APT.
5814    5650  2115              ISZ FIRSTERROR
5815    5651  5255              JMP NOHEADER
5816    5652  4473              PRINT
5817    5653  6626              MEHEADER
5818    5654  5271              JMP ONECRLF
5819                    /IF THIS IS -NOT- A FORCED TYPEOUT, AND IF THERE ARE NO DATA COMPARE
5820                    /ERRORS (COMPRERROR=0), THEN PRINT ONLY 1-CRLF
5821                    /BECAUSE
5822                    /
5823                    /THIS ERROR MUST BE AN ERROR AT THE END OF THE EMPTY BUFFER DONE FLAG
5824                    /WHICH WOULD BE ASSOCIATED TO ANY PREVIOUS FORCED TYPEOUT OF DATA ERRORS
5825                    /
5826    5655  1776'     NOHEADER, TAD XXFORCE
5827    5656  7650              SNA CLA
5828    5657  5267              JMP TWOCRLF
5829    5660  1113              TAD COMPRERROR
5830    5661  7640              SZA CLA
5831    5662  5271              JMP ONECRLF
5832                    /IF THIS IS A FORCED TYPEOUT FROM " XXINIT " THEN PRINT 1 CRLF
5833                    /
5834    5663  1776'             TAD XXFORCE
5835    5664  1365              TAD (-XXINIT)
5836    5665  7650              SNA CLA
5837    5666  5271              JMP ONECRLF
5838    5667  4473      TWOCRLF, PRINT
5839    5670  6601              MCRLF
5840    5671  4473      ONECRLF, PRINT
5841    5672  6601              MCRLF
5842    5673  4505              TY4OCT
```

```
5843    5674  0167            TEST
5844    5675  4504            TAB
5845    5676  0005            5
5846    5677  4764'           JMS INITSWITCH
5847    5700  5305            JMP .+5
5848                  /IF AN ERROR FROM THE RECAL THEN PRINT [INIT] FOR THE COMAND
5849                  /
5850    5701  1776'           TAD XXFORCE
5851    5702  1365            TAD (-XXINIT)
5852    5703  7640            SZA CLA
5853    5704  5310            JMP .+4
5854    5705  4473            PRINT
5855    5706  6670            MINIT
5856    5707  5312            JMP TAB12
5857    5710  4505            TY4OCT
5858    5711  0150            ECOMMAND
5859    5712  4504    TAB12,  TAB
5860    5713  0012            12
5861                  /
5862                  /IF THE DEVICE TEST IS HUNG, THEN THE A-, B-, AND C- STATUS IS NOT APPLICABLE
5863                  /
5864    5714  1776'           TAD XXFORCE
5865    5715  1375            TAD (-XHUNG)
5866    5716  7650            SNA CLA
5867    5717  5325            JMP DASHALL
5868                  /IF THIS IS A " FORCED " TYPEOUT THEN THE B- AND C-STATUS REGISTERS
5869                  /ARE NOT APPLICABLE TO THIS TYPEOUT BECAUSE THEY ARE RESIDUAL FROM THE
5870                  /PREVIOUS COMMAND WHICH WOULD HAVE HAD A PREVIOUS ERROR TYPE OUT
5871                  /RELATING TO THE B- AND C-STATUS REGISTERS IF AN ERROR HAD OCCURED
5872                  /
5873                  /A DATA NO ERROR STATUS HAS BEEN DETECTED PRIOR TO THE COMPLETION OF
5874                  /THE EMPTY BUFFER FUNCTION
5875                  /
5876    5720  1776'           TAD XXFORCE
5877    5721  1374            TAD (-XCOMPARE)
5878    5722  7640            SZA CLA
5879    5723  5340            JMP TYASTATUS
5880    5724  5331            JMP DASHBC
5881    5725  4473    DASHALL, PRINT
5882    5726  7016            MDASH
5883    5727  4504            TAB
5884    5730  0017            17
5885    5731  4473    DASHBC, PRINT
5886    5732  7016            MDASH
5887    5733  4504            TAB
5888    5734  0024            24
5889    5735  4473            PRINT
5890    5736  7016            MDASH; JMP TAB31
5891    5737  5763'
5892    5740  4505    TYASTATUS, TY4OCT
5893    5741  0126            ASTATUS
5894    5742  4504            TAB
5895    5743  0017            17
5896    5744  4505            TY4OCT
5897    5745  0127            BSTATUS
```



```
5898    5746  4504            TAB
5899    5747  0024            24
5900    5750  5762'           JMP TYCSTATUS
5901    5762  6000
5902    5763  6002
5903    5764  6115
5904    5765  1333
5905    5766  6061
5906    5767  0400
5907    5770  0012
5908    5771  4242
5909    5772  0377
5910    5773  0016
5911    5774  4116
5912    5775  4434
5913    5776  5513
5914    5777  6060
              6000            PAGE
5915    6000  4505    TYCSTATUS, TY4OCT
5916    6001  0130            CSTATUS
5917    6002  4504    TAB31,  TAB
5918    6003  0031            31
5919    6004  4315            JMS INITSWITCH
5920    6005  5211            JMP .+4
5921                  /IF (SSTART) = 0 THEN PRINT "HOME" BECAUSE A RECAL HAS TAKEN PLACE
5922                  /THEREFORE THE ACTUATOR IS AT TRACK 0 (HOME)
5923                  /
5924    6006  1123            TAD SSTART
5925    6007  7640            SZA CLA
5926    6010  5214            JMP .+4
5927    6011  4473            PRINT
5928    6012  6664            MHOME
5929    6013  5222            JMP TAB43
5930    6014  4505            TY4OCT
5931    6015  0125            START
5932    6016  4504            TAB
5933    6017  0036            36
5934    6020  4505            TY4OCT
5935    6021  0123            SSTART
5936    6022  4504    TAB43,  TAB
5937    6023  0043            43
5938    6024  4315            JMS INITSWITCH
5939    6025  5232            JMP PHOME
5940                  /IF (FORCE) = THE ADDRESS OF "XXINIT" THEN ALSO PRINT [HOME] FOR THE TARGET
5941                  /
5942    6026  1777'           TAD XXFORCE
5943    6027  1376            TAD (-XXINIT)
5944    6030  7640            SZA CLA
5945    6031  5235            JMP .+4
5946    6032  4473    PHOME,  PRINT
5947    6033  6664            MHOME
5948    6034  5243            JMP .+7
5949    6035  4505            TY4OCT
5950    6036  0131            TARGET
5951    6037  4504            TAB
```

```
5952    6040  0050            50
5953    6041  4505            TY4OCT
5954    6042  0124            STARGET
5955    6043  4504            TAB
5956    6044  0055            55
5957    6045  4505            TY4OCT
5958    6046  0132            TFSTP
5959    6047  4504            TAB
5960    6050  0002            2
5961    6051  4436            TY8OCT
5962    6052  0161            PASS
5963    6053  0162            PASS+1
5964    6054  1260            TAD DMTYPE
5965    6055  7650            SNA CLA
5966    6056  5261            JMP .+3
5967    6057  4473            PRINT
5968    6060  0000            DMTYPE, 0
5969                  /
5970                  /AC SW 11 TO INHIBIT RINGING OF BELL AT ERROR
5971                  /
5972    6061  3115    NOPPINT, DCA FIRSTERROR
5973    6062  4570            LAS
5974    6063  0375            AND (SW11)
5975    6064  7640            SZA CLA
5976    6065  5270            JMP .+3
5977    6066  4501            SPECIALTYPEIT
5978    6067  0207            BELL
5979                  /IF ENTPY WAS FROM A "JMS FORCE" THEN EXIT BY A "JMP I FORCE"
5980                  /
5981    6070  1777'           TAD XXFORCE
5982    6071  7640            SZA CLA
5983    6072  5774'           JMP XFORCE
5984                  /
5985                  /DEFINITIVE ERROR CODES AND MEANINGS
5986                  /
5987                  /       0       /NO ERROR
5988                  /       10      /DRIVE 0 FAILED TO SEE HOME ON INITIALIZE
5989                  /       20      /DRIVE 1 FAILED TO SEE HOME ON INITIALIZE
5990                  /       30      /FOUND HOME WHEN STEPPING OUT 10 TRACKS FOR INIT
5991                  /       40      /TRIED TO ACCESS A TRACK GREATER THAN 77
5992                  /       50      /HOME WAS FOUND BEFORE DESIRED TRACK WAS REACHED
5993                  /       60      /SELF DIAGNOSTIC ERROR
5994                  /       70      /DESIRED SECTOR COULD NOT BE FOUND AFTER LOOKING AT 52 HEADERS
5995                  /       100     /WRITE PROTECT ERROR
5996                  /       110     /MORE THAN 40US AND NO SEP CLOCK SEEN
5997                  /       120     /A PREAMBLE COULD NOT BE FOUND
5998                  /       130     /PREAMBLE FOUND BUT NO ID MARD FOUND WITHIN ALLOWABLE TIME
5999                  /       140     /HEADER CRC ERROR
6000                  /       150     /THE HEADER TRACK ADDRESS OF A GOOD HEADER DOES NOT COMPARE
6001                  /               /WITH THE DESIRED TRACK
6002                  /       160     /TO MANY TRIES FOR A IDAM
6003                  /       170     /DATA AM NOT FOUNT WITHIN ALLOTED TIME
6004                  /       200     /DATA CRC ERROR
6005                  /       210     /ALL PARITY ERROKS
6006                  /
```



```
6007                  /RECAL IF DEFINITIVE ERROR CODE IS A SEEK EPROR
6008                  /
6009                  / (NOT CODES 140, 200, OR 210)
6010                  /
6011    6073  4570    RECALIF, LAS
6012    6074  0373            AND (SW6)
6013    6075  7640            SZA CLA
6014    6076  5311            JMP LASSW0
6015    6077  1127            TAD BSTATUS
6016    6100  1372            TAD (-140)
6017    6101  7450            SNA
6018    6102  5311            JMP LASSW0
6019    6103  1371            TAD (-40)
6020    6104  7450            SNA
6021    6105  5311            JMP LASSW0
6022    6106  1370            TAD (-10)
6023    6107  7640            SZA CLA
6024    6110  4450            INIT
6025    6111  4570    LASSW0, LAS
6026    6112  7710            SPA CLA
6027    6113  4461            HLT16, HLT      /AC SW 0 = 1 (HALT ON ERROR)
6028    6114  5767'           JMP ERETURN
6029                  /
6030    6115  6115    INITSWITCH, .
6031    6116  1766'           TAD XWAIT
6032    6117  1365            TAD (-SDNSECOND)
6033    6120  7640            SZA CLA
6034    6121  2315            ISZ INITSWITCH
6035    6122  5715            JMP I INITSWITCH
6036                  /
6037                  /GENERATES TIMING FOR APT IF NEEDED.
6038                  /
6039    6123  0000    XOK,    0
6040    6124  7000            NOP
6041    6125  2323            ISZ     XOK                             /SKIP.
6042    6126  5723            JMP I   XOK
6043                  /
6044    6165  1341
6045    6166  1722
6046    6167  5506
6047    6170  7770
6048    6171  7740
6049    6172  7640
6050    6173  0040
6051    6174  5516
6052    6175  0001
6053    6176  1333
6054    6177  5513
              6200              PAGE
6055                  /THE CONTENTS OF THE AC AT ENTRY ARE THE CONTENTS OF PROGRAM LOCATION "TCOMMAND"
6056                  /
6057    6200  6200    XLCD,   .
6058    6201  3112            DCA COMMAND
6059    6202  1112            TAD COMMAND
6060    6203  6751    K67X1,  6751
```

```
6061    6204  5600            JMP I XLCD
6062                  /LOAD THE COMMAND FOR: FILL BUFFER, AND EMPTY BUFFER
6063                  /WITH THE RX01 INTERRUPT ENABLED
6064                  /
6065                  /FORM: (AC) IS  COMMAND; LCDA; NORMAL RETURN; ERROR RETURN
6066                  /
6067    6205  6205    XLCDA,  .
6068    6206  1777'           TAD UNIT
6069    6207  3112            DCA COMMAND
6070                  /THE CONTENTS OF THE AC WILL = 100 IF 8 BIT MODE
6071                  /
6072    6210  7307            CLL CLA IAC RTL
6073    6211  0132            AND TESTP
6074    6212  7640            SZA CLA
6075    6213  1376            TAD (100)
6076    6214  1112            TAD COMMAND
6077    6215  3112            DCA COMMAND
6078    6216  1112            TAD COMMAND
6079    6217  4437            LCD
6080    6220  1205            TAD XLCDA
6081    6221  3775'           DCA RETURN
6082    6222  2205            ISZ XLCDA
6083    6223  2205            ISZ XLCDA
6084    6224  1374            TAD (PI)
6085    6225  3002            DCA IPI
6086    6226  7201            CLA IAC
6087    6227  4447            INTR
6088    6230  6001            ION
6089    6231  5605            JMP I XLCDA
6090                  /
6091                  /LOAD THE COMMAND AND THE TRACK AND SECTOR ADDRESSES AND GO WITH INTERRUPT ENABLE !
6092                  /
6093                  /FORM: (AC) IS COMMAND; LCDB; NORMAL RETURN; ERROR
6094                  /
6095    6232  6232    XLCDB,  .
6096    6233  1777'           TAD UNIT                        / 0 OR 20
6097    6234  3112            DCA COMMAND                     /TEMPORARY STORAGE
6098                  /
6099                  /WHEN THE CONTENTS OF " GOBIT " ARE = 0 ; NO PROGRAM IRQ IS EXPECTED FROM THE DISK
6100                  /
6101    6235  7307            CLL CLA IAC RTL                 / 4
6102    6236  0132            AND TESTP                       /TESTP FOR 8/12 BIT MODE SELECTION
6103    6237  7640            SZA CLA
6104    6240  1376            TAD (100)                       / 100 FOR 8 BIT MODE SELECTION
6105    6241  1112            TAD COMMAND                     / 4, 14 OR 6
6106    6242  3112            DCA COMMAND
6107    6243  1112    LCDBL,  TAD COMMAND
6108    6244  4437            LCD
6109                  /
6110                  /LOAD THE TRACK AND SECTOR ADDRESSES FOR THE COMMANDS:
6111                  /
6112                  /WRITE, OR WRITE DELETED DATA, OR READ SECTOR
6113                  /
6114    6245  1373            TAD (LCDBRETURN)
6115    6246  3775'           DCA RETURN
```



```
6116    6247  1372            TAD (NOP)
6117    6250  3312            DCA XLCDBPETURN
6118    6251  7201            CLA IAC
6119    6252  4447            INTR                    /ENABLE RX01 INTERRUPT
6120    6253  4444            STR
6121    6254  5253            JMP .-1                 /SKIP ON TRANSFER REQUEST FLAG
6122    6255  1124            TAD STARGET
6123    6256  4443            XDROUT          / SECTOR
6124    6257  4444            STR
6125    6260  5257            JMP .-1                 /SKIP ON TRANSFER REQUEST FLAG
6126    6261  1131            TAD TARGET
6127    6262  4443            XDROUT          / TRACK
6128    6263  1374            TAD (PI)
6129    6264  3002            DCA IPI
6130                  /
6131                  /WAIT FOR A PROGRAM INTERRUPT REQUEST
6132                  /
6133                  / ; BUT WHILE WAITING, DISPLAY IN THE MQ THE CODED INFORMATION
6134                  /AS INDICATED BY ACCUMULATOR SWITCHES 9, 10, AND 11 AT RUN-TIME
6135                  /
6136                  /               0 = TARGET TRACK AND SECTOR
6137                  /               1 = TEST PARAMATERS (SELECTED FROM SA 200)
6138                  /               2 = " A " STATUS
6139                  /               3 = " COMMAND " WORD TO RX01
6140                  /
6141    6265  6001    XPI,    ION
6142    6266  1371            TAD (-40)
6143    6267  3116            DCA HANGER
6144    6270  4570            LAS
6145    6271  0370            AND (SW10+SW11)
6146    6272  1367            TAD (TAD I DISPLAY)
6147    6273  3274            DCA .+1
6148    6274  1705            TAD I DISPLAY
6149    6275  7421            MQL
6150    6276  2151            ISZ H1
6151    6277  5270            JMP XPI+3
6152    6300  2116            ISZ HANGER
6153    6301  5270            JMP XPI+3
6154    6302  7200            CLA
6155    6303  1366            TAD (XPI)
6156    6304  5765'           JMP HUNGUP
6157    6305  0147    DISPLAY, XTARGET
6158    6306  0132            TESTP
6159    6307  0126            ASTATUS
6160    6310  0112            COMMAND
6161                  /RETURN TO HERE IF ANY ERROR OCCURS (OF IF "DONE" FLAG OCCURS)
6162                  /
6163                  /IF A PARITY ERROR OCCURS THEN RETRY TO LOAD THE COMMAND
6164                  /
6165                  /IF NOT A PARITY ERROR THEN THIS MUST BE THAT "DONE" FLAG I MENTIONED
6166                  /
6167    6311  5323    LCDBRETURN, JMP OTHERRORS               / "JMP OTHERRORS" IF RETURN IS OK
6168    6312  7000    XLCDBRETURN, NOP
6169    6313  7305            CLL CLA IAC RAL
6170    6314  0126            AND ASTATUS
```

```
6171    6315  7650            SNA CLA
6172    6316  5323            JMP OTHERRORS
6173                  /PARITY ERROR - RETRY
6174                  /
6175    6317  2144            ISZ PRETRY
6176    6320  5243            JMP LCDBL
6177    6321  4502            SCOPE
6178    6322  5453            EXIT
6179                  /
6180                  /THESE ARE ALL OTHER ERRORS WHICH MAY OCCUR
6181                  /
6182    6323  1364    OTHERRORS, TAD (JMP OTHERRORS)
6183    6324  3312            DCA XLCDBRETURN
6184                  /
6185    6325  1373            TAD (LCDBRETURN)
6186    6326  7041            CIA
6187    6327  1775*           TAD RETURN
6188    6330  1232            TAD XLCDB
6189    6331  3232            DCA XLCDB
6190    6332  5632            JMP I XLCDB
6191    6364  5323
6192    6365  3341
6193    6366  6265
6194    6367  1705
6195    6370  0003
6196    6371  7740
6197    6372  7000
6198    6373  6311
6199    6374  5405
6200    6375  5505
6201    6376  0100
6202    6377  4242
              6400            PAGE
6203                  /TRANSFER DATA REGISTER (FROM) THE RX01 CONTROL
6204                  /
6205    6400  6400    XXDRIN, .
6206    6401  6752    K67X2A, 6752
6207    6402  5600            JMP I XXDRIN
6208                  /TRANSFER DATA REGISTER (TO) THE RX01 CONTROL
6209                  /
6210    6403  6403    XXDROUT, .
6211    6404  6752    K67X2B, 6752
6212    6405  7200            CLA
6213    6406  5603            JMP I XXDROUT
6214                  /SKIP ON TRANSFER REQUEST
6215                  /
6216    6407  6407    XSTR,   .
6217    6410  6753    K67X3A, 6753
6218    6411  5607            JMP I   XSTR
6219    6412  2207            ISZ     XSTR
6220    6413  5607            JMP I   XSTR
6221                  /
6222    6414  6414    XSER,   .
6223    6415  6754    K67X4A, 6754
6224    6416  5614            JMP I   XSER
```



```
6225    6417  2214            ISZ     XSER
6226    6420  5614            JMP I   XSER
6227                  /SKIP ON RX01 DONE FLAG
6228                  /
6229    6421  6421    XSDN,   .
6230    6422  6755    K67X5A, 6755
6231    6423  5621            JMP I   XSDN
6232    6424  2221            ISZ     XSDN
6233    6425  5621            JMP I   XSDN
6234                  /ENABLE / DISABLE RX01 INTERRUPT ENABLE
6235                  /
6236                  /   AC = 1 AT ENTRY TO ENABLE INTERRUPT
6237                  /
6238                  /FORM: (AC = 0, OR 1); INTR
6239                  /
6240                  / (GOBIT) = 0, NO RX01 PI IS EXPECTED
6241                  /
6242                  / (GOBIT) = 1, AN RX01 PI IS EXPECTED
6243                  /
6244    6426  6426    XINTR,  .
6245    6427  3152            DCA GOBIT
6246    6430  1152            TAD GOBIT
6247    6431  6756    K67X6, 6756
6248    6432  7200            CLA
6249    6433  5626            JMP I XINTR
6250                  /INITIALIZE (POWER CLEAR) THE RX01 SUBSYSTEM
6251                  /
6252    6434  6434    XINIT,  .
6253    6435  6757    K67X7A, 6757
6254                  /THE LABLE " SDNSECOND " MUST RESIDE HERE BECAUSE OF REFERENCES WITHIN " ERROR "
6255                  /
6256    6436  4471            WAIT
6257    6437  4446    SDNSECOND, SDN
6258    6440  5236            JMP     .-2
6259    6441  3006            DCA     6                       /WAIT POINTER
6260    6442  4445            SER
6261    6443  5245            JMP XXINIT
6262                  /AN ERROR HAS OCCURED FROM THE "INIT"
6263                  /
6264                  / [HOME] WAS THE TARGET
6265                  /
6266    6444  4575            FORCE
6267    6445  3123    XXINIT, DCA SSTART
6268    6446  5634            JMP I XINIT
6269                  /
6270                  /
6271                  /
6272    6447  6447    XINITB, .
6273    6450  6757    K67X7B, 6757
6274    6451  5647            JMP I XINITB
6275    6452  3737    REMOVE, TEXT    "__REMOVE DIAGNOSTIC DISKETTE"
        6453  2205
        6454  1517
        6455  2605
        6456  4004
```

```
                6457  1101
                6460  0716
                6461  1723
                6462  2411
                6463  0340
                6464  0411
                6465  2313
                6466  0524
                6467  2405
                6470  0000
 6276           6471  3737    MIDENTIFICATION,TEXT    "__MAINDEC-08-DIRXA-C"
                6472  1501
                6473  1116
                6474  0405
                6475  0355
                6476  6070
                6477  5504
                6500  1122
                6501  3001
                6502  5503
                6503  0000
 6277           6504  3737    MSELECT,        TEXT "__SELECT PARAMATERS (INCLUDING DEVICE CODE)"
                6505  2305
                6506  1405
                6507  0324
                6510  4020
                6511  0122
                6512  0115
                6513  0124
                6514  0522
                6515  2340
                6516  5011
                6517  1603
                6520  1425
                6521  0411
                6522  1607
                6523  4004
                6524  0526
                6525  1103
                6526  0540
                6527  0317
                6530  0405
                6531  5100
 6278           6532  3737    MDTESTP,        TEXT  "__TEST PARAMATERS: "
                6533  2405
                6534  2324
                6535  4020
                6536  0122
                6537  0115
                6540  0124
                6541  0522
                6542  2372
                6543  4000
 6279           6544  3737    MXEHEADER,      TEXT "__EPR  FAT  FAST      EAC  GOOD PASS"
                6545  0522
```



```
                6546  2240
                6547  4006
                6550  0124
                6551  4040
                6552  0601
                6553  2324
                6554  4040
                6555  4040
                6556  4040
                6557  0501
                6560  0340
                6561  4007
                6562  1717
                6563  0440
                6564  2001
                6565  2323
                6566  0000
 6280           6567  3727    MX2HEADER,      TEXT "_WORD GOOD BAD"
                6570  1722
                6571  0440
                6572  0717
                6573  1704
                6574  4002
                6575  0104
                6576  0000
 6281           6577  5440    MCOMMA,         TEXT ", "
                6600  0000
 6282           6601  3700    MCRLF,          TEXT "_"
 6283           6602  3705    MEOT,           TEXT "_END OF TEST "
                6603  1604
                6604  4017
                6605  0640
                6606  2405
                6607  2324
                6610  4000
 6284           6611  3704    MHUNGPC,        TEXT "_DEVICE TEST HUNG AT PC "
                6612  0526
                6613  1103
                6614  0540
                6615  2405
                6616  2324
                6617  4010
                6620  2516
                6621  0740
                6622  0124
                6623  4020
                6624  0340
                6625  0000
 6285           6626  3737    MEHEADER,       TEXT "__FAT  CMND XDR  CODE  RSTA  START     TARGET    TEST PASS"
                6627  0601
                6630  2440
                6631  4003
                6632  1516
                6633  0440
                6634  3004
```

```
                6635  2240
                6636  4003
                6637  1704
                6640  0540
                6641  4022
                6642  2324
                6643  0140
                6644  4023
                6645  2401
                6646  2224
                6647  4040
                6650  4010
                6651  4024
                6652  0122
                6653  0705
                6654  2440
                6655  4047
                6656  402
                6657  0523
                6660  2440
                6661  2001
                6662  2323
                6663  0000
  62R6          6664  3310    MHOME,          TEXT "[HOME]"
                6665  1715
                6666  0535
                6667  0000
  6287          6670  1116    MINIT,          TEXT "INIT"
                6671  1124
                6672  0000
  6288          6673  3737    MOD,            TEXT "__OD = "
                6674  1704
                6675  4075
                6676  4000
  6289          6677  4011    MID,            TEXT " ID = "
                6700  0440
                6701  7540
                6702  0000
  6290          6703  4006    MFIRST,         TEXT " FIRST = "
                6704  1122
                6705  2324
                6706  4075
                6707  4000
  6291          6710  4014    MLAST,          TEXT " LAST = "
                6711  0123
                6712  2440
                6713  7540
                6714  0000
  6292          6715  3727    MWRITE,         TEXT "_WRITE-"
                6716  2211
                6717  2405
                6720  5500
  6293          6721  3722    MREAD,          TEXT "_READ-"
                6722  0501
                6723  0455
```



```
                6724  0000
  6294          6725  1617    MDNSERROR,      TEXT "NO CRC BUT"
                6726  4003
                6727  2203
                6730  4002
                6731  2524
                6732  0000
  6295          6733  0322    MDWESERROR,     TEXT "CRC AND"
                6734  0340
                6735  0116
                6736  0400
  6296          6737  0322    MSNDERROR,      TEXT "CRC BUT NO DATA ERROR"
                6740  0340
                6741  0225
                6742  2440
                6743  1617
                6744  4004
                6745  0124
                6746  0140
                6747  0522
                6750  2217
                6751  2200
  6297          6752  4004    MDATAERROR,     TEXT " DATA ERROR_"
                6753  0124
                6754  0140
                6755  0522
                6756  2217
                6757  2237
                6760  0000
  6298          6761  2717    MWORD,          TEXT "WORD"
                6762  2204
                6763  0000
  6299          6764  0231    MBYTE,          TEXT "BYTE"
                6765  2405
                6766  0000
  6300          6767  4007    MGB,            TEXT " GOOD BAD"
                6770  1717
                6771  0440
                6772  0201
                6773  0400
  6301          6774  3723    MSUMCHECK,      TEXT "_SUM-CHECK IS "
                6775  2515
                6776  5503
                6777  1005
                7000  0313
                7001  4011
                7002  2340
                7003  0000
  6302          7004  1713    MOK,            TEXT "OK"
                7005  0000
  6303          7006  3724    MDESUMMARY,     TEXT "_TOTAL BAD = "
                7007  1724
                7010  0114
                7011  4002
                7012  0104
```

```
                7013  4075
                7014  4000
 6304           7015  7200    MCOLON,          TEXT ":"
 6305           7016  5500    MDASH,           TEXT "-"
 6306           7017  3715    MEDDDIDNOT,      TEXT "_MISSING DD MARK"
                7020  1123
                7021  2311
                7022  1607
                7023  4004
                7024  0440
                7025  1501
                7026  2213
                7027  0000
 6307           7030  3725    MUDDDID,         TEXT "_UNEXPECTED DD MARK"
                7031  1605
                7032  3020
                7033  0503
                7034  2405
                7035  0440
                7036  0404
                7037  4015
                7040  0122
                7041  1300
 6308           7042  3725    MSDNUNEXPECTED,  TEXT "_UNEXPECTED RX01 IRQ"
                7043  1605
                7044  3020
                7045  0503
                7046  2405
                7047  0440
                7050  2230
                7051  6061
                7052  4011
                7053  2221
                7054  0000
 6309           7055  3715    MNOSER,          TEXT "_MISSING ERROR FLAG"
                7056  1123
                7057  2311
                7060  1607
                7061  4005
                7062  2222
                7063  1722
                7064  4006
                7065  1401
                7066  0700
 6310           7067  3737    MUNKNOWN,        TEXT "__UNKNOWN IRQ"
                7070  2516
                7071  1316
                7072  1727
                7073  1640
                7074  1122
                7075  2100
 6311           7076  3704    MDEV,    TEXT "_DEVICE CODE TO BE USED  "
                7077  0526
                7100  1103
                7101  0540
```



```
                7102  0317
                7103  0405
                7104  4024
                7105  1740
                7106  0205
                7107  4025
                7110  2305
                7111  0440
                7112  4000
 6312                       /THE FOLLOWING IS THE WRITE BUFFER ALLOCATED STORAGE
 6313                       /
 6314           7113        WBUFFER=.
 6315           7313        RBUFFER=WBUFFER+200
 6316           7513                *RBUFFER+200
 6317
 6318
 6319
 6320
 6321           0200                *200                    /AUTO START BINARY
 6322
 6323                       $$$
```

```
0000  11100100  11110000  11101111  11111111  11111111  11111111  11111111  11111111
0100  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111100

0200  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
0300  11111111  11111111  11111111  11111111  11111111  11000001  11111111  11111111

0400  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
0500  11111111  11111111  11111111  11111111  11111111  11111110  00011111  11111111

0600  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
0700  11111111  11111111  11111111  11111111  11111111  11111111  11110000  11111111


1000  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
1100  11111111  11111111  11111111  11111111  11111111  11111111  00000000  00001111

1200  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
1300  11111111  11111111  11111111  11111111  11111111  11111111  11111000  11111111

1400  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
1500  11111111  11111111  11111111  11111111  11111111  11111111  11110000  11111111

1600  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
1700  11111111  11111111  11111111  11111111  11000000  01111111  11111111  11111111


2000  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
2100  11111111  11111111  11111111  11111111  11111111  11111100  00111111  11111111

2200  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
2300  11111111  11111111  11111111  11111000  00000000  00000011  11111111  11111111

2400  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
2500  11111111  11111111  11111111  11111111  11111111  00000000  00011111  11111111

2600  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
2700  11111111  11111111  11111111  11111111  11111111  11111110  00011111  11111111


3000  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
3100  11111111  11111111  11111111  11111111  11111111  11111110  00011111  11111111

3200  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
3300  11111111  11111111  11111111  11111111  11111111  11110000  00000111  11111111

3400  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
3500  11111111  11111111  11111111  11111111  11111111  11111111  10000000  00111111

3600  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
3700  11111111  11111111  11111111  11111111  11111111  11111111  11000011  11111111
```



```
4000  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
4100  11111111  11111111  11111111  11111111  11111110  00000000  00000001  11111111

4200  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
4300  11111111  11111111  11111111  11111111  11111111  11111111  11000000  00001111

4400  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
4500  11111111  11111111  11111111  11111111  11111111  11111111  11000000  00111111

4600  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
4700  11111111  11111111  11111100  00000000  00000000  00000000  00000000  00011111


5000  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
5100  11111111  11111111  11111111  11111000  00000000  00000000  00000111  11111111

5200  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
5300  11111111  11111111  11111111  11111111  11111111  11111111  00001111  11111111

5400  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
5500  11111111  11111111  11111111  11111000  00000000  00000000  00000011  11111111

5600  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
5700  11111111  11111111  11111111  11111111  11111111  10000000  00111111  11111111


6000  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
6100  11111111  11111111  11111110  00000000  00000000  00000000  00000111  11111111

6200  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
6300  11111111  11111111  11111111  11100000  00000000  00000000  00001111  11111111

6400  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
6500  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111

6600  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
6700  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111


7000  11111111  11111111  11111111  11111111  11111111  11111111  11111111  11111111
7100  11111111  11100000  00000000  00000000  00000000  00000000  00000000  00000000

7200
7300

7400
7500

7600
7700
```

```
A10     0010    C8RETD  0614    DOSET   0256    E51     1110
A11     0011    C8RETR  0541    DRVZRO  2753    E52     1117
A12     0012    C8SETD  0613    DTESTP  0114    E53     1105
A13     0013    C8SETS  0540    DTYPE   5523    E54     1114
A14     0014    C8STRT  0200    DWESER  3677    E55     1123
ACL     7701    C8SWIT  4426    DWS     3506    E56     1076
ACSAVE  1314    C8SWST  0745    DWSLOG  0140    E60     1137
ACTIVE  0752    C8TEST  0343    E0      0620    E61     1147
AERROR  4467    C8TMP1  1030    E0PRE   0410    E62     1152
ALT12   1400    CAF     6007    E1      0624    E63     1155
ALT12L  1402    CCNT    5066    E10     0660    E70     1213
ANDRET  4107    CHAR    1104    E100    1227    E7000   2405
APT8    4470    CHARLI  5320    E11     0643    E7001   2416
AROUND  0230    CHECKC  4424    E110    1253    E7002   2430
ASTATU  0126    CHEK22  4472    E120    1310    E7003   2444
BELL    0237    CHNDEV  5067    E121    1314    E7004   2455
BLANK   0166    CKCOUT  0236    E122    1320    E7005   2505
BSTATU  0127    CKSWIT  4570    E123    1325    E7006   2467
BSW     4435    CLKCNT  4145    E124    1276    EA120   1411
BSWAC   2635    CNOTFI  3717    E130    1512    EA121   1415
BSWLIN  2636    CNTRLC  0476    E131    1525    EA122   1437
BSWRAL  2634    CNTRLD  0600    E140    1661    EA123   1450
BUSY    0111    CNTRLE  0542    E1PRE   0443    EAC     0165
BYRETR  0511    CNTRLQ  0503    E2      0630    EB      1622
C8BY1   0233    CNTRLR  0514    E20     0666    EBCOMP  1630
C8BY2   1261    CNTRLS  0524    E21     0671    EBLOOP  1635
C8BY3   1070    CNTVAL  0257    E210    4557    EBOK    1663
C8BY4   0520    COMMAN  0112    E211    2320    ECOMMA  0150
C8BY5   1127    COMP    2756    E212    2332    EERROR  5646
C8CK22  1330    COMPAR  3601    E22     0674    EMPTY   3617
C8CKP   1031    COMPRE  0113    E23     0677    EMPTYE  4005
C8CKSW  4430    COUNT   4146    E24     0702    EMPTYL  3607
C8CNTR  4571    CRCERR  3454    E240    2030    EMPTYO  4016
C8DO1   0324    CSTATU  0130    E241    2067    ENDCOM  4000
C8DO10  1245    DASHAL  5725    E242    2100    ENDIT   0742
C8DO11  0607    DASHBC  5731    E245    2033    EPCSCO  1362
C8DO2   1042    DCACTI  0743    E25     0705    ERETUR  5506
C8DO3   1327    DCADOA  2525    E26     0715    ERR1    1000
C8DO4   1015    DCATAR  4332    E27     0723    ERRMES  1263
C8DO7   0532    DDERRO  5525    E270    2134    ERROR   4452
C8EXT1  0234    DDIGNO  5463    E271    2137    ERRORS  1363
C8EXT2  0305    DIGITS  5063    E272    2150    EXIT    5453
C8FILL  1046    DISPLA  6305    E28     0731    EXITA   0440
C8GET   0624    DMTYPE  6060    E2PRE   0413    EXITCK  4534
C8GET1  0302    DNS     3506    E3      0634    EXTLOO  1405
C8HANG  1133    DNSLOG  0141    E30     0755    FB      1471
C8INQU  4427    DOA     2532    E3PRE   0423    FB128B  4541
C8LOOK  4405    DOB     2533    E40     1044    FBEB    1476
C8PASS  4425    DOCNT   0254    E41     1056    FILCNT  1047
C8RET2  0600    DONE    4454    E42     1021    FILL    3221
C8RET3  4125    DONEA   0426    E4PRE   0446    FILLER  3226
C8RET4  3317    DOPACK  0210    E50     1101    FILLOK  3237
```



```
FIRST   0033    K67X2B  6404    MINIT   6670    PAT6    3140
FIRSTE  0115    K67X3A  6410    MLAST   6710    PATSUM  0153
FIRSTT  0451    K67X3B  0720    MNOSER  7055    PATTER  3115
FLSAVE  1316    K67X4A  6415    MOD     6673    PCLF    6662
FORCE   4575    K67X4B  0726    MOK     7004    PCSAVE  1313
GENTES  3131    K67X5A  6422    MORETE  0450    PCSCOP  1364
GETAPA  4455    K67X5B  0712    MQA     7501    PHOME   6032
GETASE  4456    K67X6   6431    MQL     7421    PI      5405
GETATR  4457    K67X7A  6435    MQSAVE  1315    PIEXIT  5476
GETCH1  0703    K67X7B  6450    MREAD   6721    PISDN   5422
GETDAT  0456    K7000   0172    MSB     0157    PNTBUF  1131
GETUNI  4460    K7377   1562    MSDNUN  7042    PNTEXT  5340
GOBIT   0152    K7777   0117    MSELEC  6504    PNTID   1530
GOITA   0443    KRETRY  0121    MSNDER  6737    POLL    4237
GOOD    0164    LAS     4570    MSUMCH  6774    PRETES  0400
GOTOA   0454    LASSW0  6111    MUDDDI  7030    PRETRY  0144
GTF     6004    LASSW3  5642    MUNKNO  7067    PRINT   4473
H1      0151    LAST    0034    MWORD   6761    PSIE    6665
HALT    4461    LCD     4437    MWRITE  6715    PSKE    6663
HANGER  0116    LCDA    4440    MX      0556    PSKF    6661
HLT     4461    LCDB    4441    MX2HEA  6567    PSTB    6664
HLT16   6113    LCDBL   6243    MXEHEA  6544    PTSTOR  0352
HLT6    4075    LCDBRE  6311    NEXT    4210    Q46ID   4505
HLT7    3505    LOCKUP  4464    NEXTAC  0757    Q460D   4513
HLTNOP  1563    LSB     0156    NEXTSE  4623    Q40D    4454
HUNGPC  3353    MBYTE   6764    NOHEAD  5655    Q60D    4500
HUNGUP  3341    MCOLON  7015    NOMORE  0522    QUIET   3335
ID      0032    MCOMMA  6577    NOPRIN  6061    R1      4724
IF      4706    MCRLF   6601    NORX01  0427    R1RETR  0136
INDEXA  0455    MDASH   7016    NOSCOP  1336    R2      4725
INIT    4450    MDATAE  6752    NOSER   3322    R2RETR  0137
INITB   4451    MDESUM  7006    NOSET   0246    RANGEN  4710
INITSE  4462    MDEV    7076    NOTCL8  4537    RBUFFE  7313
INITSW  6115    MDNSER  6725    NOTEST  5453    RDC     0120
INITTR  4463    MDTEST  6532    NOTQ    0335    RDORWR  3550
INMODE  1105    MDWESE  6733    NTCLAS  1252    READ    4474
INSUMC  3761    MEDDDI  7017    NULINE  5302    READCO  4475
INTR    4447    MEHEAD  6626    NUREAD  3517    READER  3437
IOF     6002    MEOT    6602    NUWORD  5253    READL   3420
ION     6001    MESA    1004    OD      0031    READOK  3527
IPI     0002    MESAC   1276    OK      4465    READRE  3423
IRDWR   2000    MESFL   1304    OKSTAR  4641    REASK1  1407
ISZCOM  3756    MESMQ   1301    ONECRL  5671    REBEGI  0545
ISZDIG  5042    MESPAS  0260    OTHERR  6323    RECALI  6073
JMPDIG  5032    MESPC   1273    OUTPUT  4263    REDO1   0661
JMPICO  3600    MESSAG  5262    PACKDO  4531    REDOA   0415
JMPWHI  3263    MFIRST  6703    PASCNT  0255    REFILL  3214
K0007   0173    MGB     6767    PASS    0161    REMOVE  6452
K6500   4144    MHOME   6664    PAT2    3125    REREAD  3430
K6520   4361    MHUNGP  6611    PAT3    3126    RESEEK  3432
K67X1   6203    MID     6677    PAT4    3127    RESEQU  4274
K67X2A  6401    MIDENT  6471    PAT5    3130    RETURN  5505
```

REWRIT	3206	T11	1232	THENEX	4110	XC8CRL	1032
RLOGGE	3545	T12	1261	THETES	3000	XC8ECH	1072
ROK	3541	T13	1455	TICK	4466	XC8ERR	1200
RST	4476	T14	1603	TMPCNT	0746	XC8INQ	0635
RSTB	4477	T15	1601	TRACKS	0145	XC8LOO	1400
RXERRO	5600	T16	1454	TSTCHA	0721	XC8OCT	1007
RXHERE	0163	T17	1602	TSTUNT	2744	XC8PAS	0200
SAVEBS	5613	T2	0663	TTRACK	0146	XC8PAU	1317
SAVECS	5626	T20	1600	TTYBUS	0160	XC8PNT	0317
SCOPE	4502	T20STR	2323	TTYLPT	1132	XC8PSW	0651
SCOPIN	1355	T20XDR	2310	TWOCRL	5667	XC8SW	0267
SDN	4446	T21	1675	TX	2303	XC8TTY	0306
SDNSEC	6437	T22	1674	TY1ASC	5321	XC8TYP	1106
SDNUNF	3320	T23	2265	TY4OCT	4505	XCHECK	4516
SECTOR	0122	T24	1714	TY8OCT	4436	XCHK22	2541
SEQ	4276	T25	1716	TYASTA	5740	XCKSWI	3400
SEQ000	4306	T26	1720	TYCSTA	6000	XCNT	0174
SEQ001	4317	T27	2106	TYPEIT	4506	XCOMPA	3662
SEQ010	4400	T3	0734	UNIT	4242	XCRCER	3503
SEQ100	4444	T30	2200	UNITS	4235	XD	0400
SEQ111	4330	T31	2202	UNITX	4241	XDEVIC	5125
SEQ3	4422	T32	2223	UNITZ	4240	XDOLPT	1121
SEQ6	4465	T33	2241	UNKNOW	5473	XDONE	4243
SER	4445	T34	2300	UPAROW	0615	XDOSW	0523
SETUP	4500	T35	2276	UREAD	3522	XDRIN	4442
SHIFT	5015	T36	2277	VERIFY	5466	XDROUT	4443
SHIFTS	5065	T37	2275	WAIT	4471	XEMPTY	4066
SND	3506	T4	1000	WAITTY	4507	XERROR	2637
SNDLOG	0142	T4B	1004	WATMES	1307	XFLENG	3714
SPECIA	4501	T5	1065	WBUFFE	7113	XFORCE	5516
SRETRY	0143	T6	1126	WHICHR	3267	XGETAP	3035
SSTART	0123	T7	1200	WNOTOK	3264	XGETAS	4607
STARGE	0124	T70K	1214	WORDX	0154	XGETAT	4261
START	0125	TAB	4504	WORDY	0155	XGETUN	4200
STOPNT	0353	TAB12	5712	WRESEE	3212	XHALT	4115
STR	4444	TAB31	6002	WRITE	4510	XHUNG	3344
SUBSCO	4503	TAB43	6022	WRITEL	3204	XI	1100
SW0	4000	TABLA	0461	WRITEO	3257	XINIT	6434
SW1	2000	TABLB	0470	WRITER	3246	XINITB	6447
SW10	0002	TADLAS	3273	WUNITS	4236	XINITS	4600
SW11	0001	TARGET	0131	XA10	0133	XINITT	4250
SW2	1000	TEST	0167	XA11	0134	XINTR	6426
SW3	0400	TEST1	2520	XAC	5503	XK67X2	5126
SW4	0200	TEST2	2516	XAERRO	4346	XK67X3	5127
SW5	0100	TEST3	2512	XANDRE	4114	XK67X4	5130
SW6	0040	TEST4	2510	XAPTB	1546	XK67X5	5131
SW7	0020	TEST5	2522	XASTAT	3760	XK67X7	5133
SW8	0010	TESTP	0132	XBSW	2612	XKCC	0314
SW9	0004	TESTS	0460	XC	0300	XLCD	6200
T0	0611	TESTX	2526	XC8CHA	0351	XLCDA	6205
T1	0637	TESTXL	2531	XC8CKP	1050	XLCDB	6232
T10	1216	THEL	3003	XC8CNT	0400	XLCDBR	6312

XLINK	5504	XXFORC	5513
XLOCKU	2600	XXGETA	4610
XMESSA	3334	XXINIT	6445
XMX	0253	XXTAB	5243
XNOPRI	2727	XXTHEL	3024
XNULIN	5311	XXX	0135
XOCTAL	5062	XYTHEL	3026
XOK	6123	ZERO	5057
XOUTPU	5263		
XPAT6	3145		
XPATTE	3103		
XPI	6265		
XPRINT	5244		
XRDC	3416		
XREAD	3414		
XREADC	3410		
XRETUR	5507		
XRST	2437		
XRSTB	2400		
XSCOPE	1332		
XSDN	6421		
XSEQ	4333		
XSEQ2	4413		
XSEQ3	4433		
XSER	6414		
XSETUP	4077		
XSHIFT	5020		
XSPECI	5351		
XSSCOP	1342		
XSTARG	4707		
XSTR	6407		
XTAB	5215		
XTABL	5221		
XTABLA	0457		
XTABLB	0460		
XTARGE	0147		
XTCF	5343		
XTHEL	3016		
XTICK	4127		
XTY4OC	5000		
XTY8OC	5200		
XTYPEI	5305		
XWAIT	1722		
XWAITT	5400		
XWRITE	3200		
XXC8CN	1340		
XXC8IN	1345		
XXC8PS	1351		
XXC8SW	1355		
XXDMP	5064		
XXDRIN	6400		
XXDROU	6403		

ERRORS DETECTED: 0

LINKS GENERATED: 245

RUN-TIME: 36 SECONDS

4K CORE USED

SEQ 0159

A10 1317# 1598 1608 2217 2233 2847 2852 2880 2979 2982 2986 3955 3993 4049
4095 4103 5390 5397 5399
A11 1318# 2983 2988 3962 3965 3994 4050 5392 5393
A12 1319# 3947 3948
A13 1320# 1876 1960
A14 5534# 5538 5541 5557
ACL 49#
ACSAVE 271 274 494 728 852 878 919#
ACTIVE 2219 2223 2226# 2228 2232
AERROR 1441# 3779 4205 5813
ALT12 2594 2744#
ALT12L 2746# 2750
ANDRET 4769 4778#
APT8 1443# 2897
AROUND 1610 1622# 2930
ASTATU 1507# 4305 4480 5637 5658 5682 5893 6159 6170
BELL 3845# 3852 5978
BLANK 1568# 1841 1842 2279 2280 2285 2287 2307 2311 2337 2778 2779 2800 2866
3026 3169 3170 3215 3216 3226 3263 3269 3481 3528 3542 3659 3664 3667
3827
BSTATU 1508# 5783 5897 6015
BSW 1377# 5498 5515
BSWAC 3756 3761 3768 3771 3774#
BSWLIN 3758 3769 3775#
BSWRAL 3760 3766 3773#
BUSY 1494# 1600 3780 3858 4215 5621 5624 5692 5712 5722 5725 5726
BYRETR 356 359#
C8BY1 78 80 100# 115
C8BY2 893 895 908#
C8BY3 738 741 749#
C8BY4 372# 558
C8BY5 801 810#
C8CK22 72 272 514 553 739 940 952# 958 959
C8CKP 660 669 673#
C8CKSW 1350# 1944
C8CNTR 1576# 1735
C8DO1 205# 226
C8DO10 866 889#
C8DO11 455 459#
C8DO2 693# 695
C8DO3 941 947#
C8DO4 661# 670
C8DO7 388 395#
C8EXT1 77 101#
C8EXT2 153 157#
C8FILL 689 698#
C8GET 357 360 399 425 462 483# 495 523 744 749 768 905 908
C8GET1 152 154#
C8HANG 805 817# 821
C8INQU 1347# 4794
C8LOOK 1309# 2903
C8PASS 1341# 1986
C8RET2 1945 1985#

C8RET3 4795 4800#
C8RET4 2932 4188 4190#
C8RETD 457 464 467#
C8RETR 361 393 409#
C8SETD 453 458 460 466#
C8SETS 354 359 369 385 395 408#
C8STRT 377 1593#
C8SWIT 1344# 1616 4186
C8SWST 372 556 559 612 614#
C8TEST 1726 1734#
C8TMP1 658 661 665 668 672#
CAF 50# 345 2896
CCNT 5352 5357 5362 5373#
CHAR 176 177 280 297 309 311 313 475 573 586 598 602 606 608
774 776# 1740
CHARLI 5463 5523 5530 5532#
CHECKC 1338# 1615 1734 1943 1985 2902 4185 4793
CHEK22 1447# 2921 4806 4996 5488 5539
CHNDEV 1621 5378# 5382 5411
CKCOUT 79 92 94 103# 117 118
CKSWIT 1381 1574#
CLKCNT 1964 4809 4812 4820#
CNOTFI 4567 4621#
CNTRLC 332 341#
CNTRLD 337 452#
CNTRLE 336 424#
CNTRLQ 333 353#
CNTRLR 334 368#
CNTRLS 335 385# 405
CNTVAL 108 123#
COMMAN 1495# 2840 2865 2875 2972 3004 3031 3164 3167 5650 5763 6058 6059 6069
6076 6077 6078 6097 6105 6106 6107 6160
COMP 1843 3871 3875 3878#
COMPAR 4344 4419 4453 4473#
COMPRE 1496# 2998 4345 4420 4492 4565 4626 4654 4727 4745 4751 4758 5829
COUNT 3086 4811 4821#
CRCERR 4307 4341#
CSTATU 1509# 5795 5916
DASHAL 5867 5881#
DASHBC 5880 5885#
DCACTI 2219# 2234
DCADOA 3692 3700#
DCATAR 4946 4949 4957 4960 4965#
DDERRO 5671 5736#
DDIGNO 5643 5672#
DIGITS 5331 5353 5370#
DISPLA 6146 6148 6157#
DMTYPE 5761 5964 5968#
DNS 4324 4371# 4424
DNSLOG 1531# 4288 4544 4571
DOA 3700 3706#
DOB 3690 3698 3707#
DOCNT 110 113 120#

DONE 1417# 3485 3710 3916 3926
DONEA 287 294#
DOPACK 73 79#
DOSET 104 111 116 122#
DRVZRO 3869 3874#
DTESTP 1497# 1620 1623 1625 1632 1957 5379
DTYPE 5729# 5738
DWESER 4596 4600#
DWS 4325# 4349
DWSLOG 1530# 4287 4546
E0 1141 2031#
E0PRE 1131 1792#
E1 1142 2044#
E10 1148 2101#
E100 1198 2526 2533#
E11 2087#
E110 1202 2570 2577#
E120 1207 2639#
E121 1208 2643#
E122 1209 2647#
E123 1210 2652#
E124 1206 2603 2625#
E130 1241 2869#
E131 1242 2883#
E140 1259 3028#
E1PRE 1134 1851#
E2 1143 2048#
E20 2129#
E21 1152 2132#
E210 1263 5168#
E211 1271 3540#
E212 1272 3550#
E22 1153 2135#
E23 1154 2147#
E24 1155 2150#
E240 1280 3188#
E241 1282 3234#
E242 1285 3246#
E245 1281 3194#
E25 1156 2153#
E26 1157 2167#
E27 1158 2173#
E270 1289 3284#
E271 1291 3290#
E272 1292 3301#
E28 1159 2179#
E2PRE 1132 1795#
E3 1144 2052#
E30 1163 2229#
E3PRE 1133 1810# 3135 3137
E40 1170 2321#
E41 1173 2335#
E42 1167 2299#

E4PRE 1138 1868#
E50 1178 2376#
E51 1180 2383#
E52 1182 2390#
E53 1179 2380#
E54 1181 2387#
E55 1183 2394#
E56 1177 2373#
E60 1187 2411 2419#
E61 1188 2448#
E62 1189 2451#
E63 1190 2454#
E70 1194 2500#
E7000 1222 3584#
E7001 1223 3593#
E7002 1224 3603#
E7003 1231 3624#
E7004 1232 3633#
E7005 1234 3671#
E7006 1233 3652#
EA120 1211 2748 2753#
EA121 1212 2757#
EA122 1213 2788#
EA123 1216 2806#
EAC 1567# 1844 1845 1850 2093 2094 2100 2295 2297 2305 2317 2320 2328 2329
2334 2781 2782 2787 2805 3172 3174 3182 3187 3217 3227 3228 3233 3245
3266 3268 3278 3283 3300 3533 3534 3539 3589 3592 3595 3602 3605 3607
3608 3629 3632 3644 3651 3662 3670 3777 3778 3831
EB 2984# 2989
EBCOMP 2985 2994#
EBLOOP 3000# 3037
EBOK 3015 3030#
ECOMMA 1541# 5764 5858
EERROR 5768 5772 5812#
EMPTY 4499# 4500 4686
EMPTYE 4489 4692#
EMPTYL 4484# 4698
EMPTYO 4488 4713#
ENDCOM 4529 4655 4682#
ENDIT 592 597 611#
EPCSCO 2704 2714# 3783
ERETUR 4211 5706# 6028
ERR1 601 605 639#
ERRMES 871 912#
ERROR 1413# 1792 1795 1810 1851 1868 2031 2044 2048 2052 2087 2101 2129 2132
2135 2147 2150 2153 2167 2173 2179 2229 2299 2321 2335 2373 2376 2380
2383 2387 2390 2394 2419 2448 2451 2454 2500 2533 2580 2628 2639 2643
2647 2652 2753 2757 2788 2806 2869 2883 3028 3188 3194 3234 3246 3284
3290 3301 3540 3550 3584 3593 3603 3624 3633 3652 3671 5168
ERRORS 1786 1875 2674 2683 2692 2715# 3785 3943
EXIT 1415# 1436 2054 2103 2181 2212 2235 2341 2396 2456 2502 2535 2582 2815
2851 3044 3077 3080 3255 3310 3487 3712 3928 6178
EXITA 296 308#

EXITCK 5140# 5144
EXTLOO 1017# 1020
FB 2850# 2854
FB128B 3061 3417 3436 5154# 5178
FBEB 2850 2857# 2860 2861 2863 2885 2984
FILCNT 691 694 700#
FILL 4101# 4102 4105
FILLER 4098 4108#
FILLOK 4097 4120#
FIRST 1372# 1672 1676 1677 1684 3368 3393 3452 4171 5183 5255
FIRSTE 1498# 1785 1935 1962 3794 3853 5814 5972
FIRSTT 1875# 1965
FLSAVE 277 489 730 854 886 921#
FORCE 1581# 4203 4217 4573 4733 6266
GENTES 3946 4015#
GETAPA 1419# 2845 2977 3702 3895
GETASE 1421# 4075 4280
GETATR 1423# 3705 3922
GETCH1 579# 591
GETDAT 284 285 292 322#
GETUNI 1425# 3166 3364 3456 3482 3704 3897 3921
GOBIT 1543# 1601 2499 2578 2608 2626 5631 6245 6246
GOITA 290 311#
GOOD 1566# 1839 1847 2009 2081 2099 2162 2163 2169 2175 2215 2221 2296 2314
2315 2331 2357 2649 2776 2784 2799 2804 2877 2878 3010 3011 3186 3213
3230 3244 3253 3282 3299 3307 3536 3601 3650 3661 3665 3835 5155 5159
5396 5398
GOTOA 316 317 318 319 320#
GTF 48# 276 729 853
H1 1542# 3130 6150
HALT 52 1427 1428#
HANGER 1499# 1605 3132 4226 6143 6152
HLT 52# 945 1427# 1618 1956 1987 3742 3856 4189 4210 4369 4765 4846 5004
6027
HLT16 6027#
HLT6 4765#
HLT7 4369#
HLTNOP 2928 2932#
HUNGPC 4216 4224 4228#
HUNGUP 3139 4215# 6156
ID 1371# 1656 1660 1661 1669 4886 4956 4974 5028 5049 5116
IF 5197 5200 5206 5219 5292#
INDEXA 282 291 315 321#
INIT 1407# 3418 6024
INITB 1409# 2607 2636 2745
INITSE 1430# 4074 4277
INITSW 5846 5919 5938 6030# 6034 6035
INITTR 1432# 3703 3896 3920
INMODE 294 353 370 570 769 773 777#
INSUMC 4347 4422 4493 4517 4518 4668# 4717 4720 4730 4736 4743 4760
INTR 1405# 2415 2446 2491 2525 2573 2577 2606 2625 4504 4683 5634 6087 6119
IOF 851 1380# 4813 4999 5135 5537
ION 1379# 1988 2489 2528 3859 4685 5139 5552 5697 5714 5727 6088 6141

IPI 1296 1302# 2412 2488 2527 2571 2604 5549 6085 6129
IRDWR 3095 3097 3099 3164#
ISZCOM 4562 4628 4654#
ISZDIG 5345 5353# 5363
JMPDIG 5345# 5364
JMPICO 4153# 4762 4766
JMPWHI 4078 4148#
K0007 1579# 5343
K6500 4816 4819#
K6520 5003 5006#
K67X1 5414 6060#
K67X2A 5415 6206#
K67X2B 5402 6211#
K67X3A 5416 6217#
K67X3B 2170# 5404
K67X4A 5417 6223#
K67X4B 2176# 5406
K67X5A 2214 5418 6230#
K67X5B 2164# 5418
K67X6 5419 6247#
K67X7A 5420 6253#
K67X7B 5410 6273#
K7000 1578# 2927 5347
K7377 2925 2931#
K7777 1500# 4959 5330
KPETRY 1502# 4088 4090 4120 4278 4281 4291 4293 4371 4482
LAS 1381# 1619 1953 2709 3739 3745 3788 3840 3847 3854 3941 4111 4134 4199
4208 4311 4354 4367 4378 4558 4621 4695 4721 4763 5798 5973 6011 6025
6144
LASSW0 6014 6018 6021 6025#
LASSW3 5798#
LAST 1373# 1164 4168 4169 4177 5181 5243
LCD 1389# 2027 2083 2091 2127 2213 2277 2288 2369 2370 2414 2445 2486 2530
2565 2566 2616 2617 2635 2838 2970 3171 3265 3530 3581 3621 5157 5774
5786 6079 6108
LCDA 1391# 4096 4487
LCDB 1393# 4125 4296
LCDBL 6107# 6176
LCDBRE 6114 6167# 6185
LOCKUP 1434# 1874 2668 3089
LSB 1560# 3811 3813 3817 3819 4633 4635 4647 4649
MBYTE 4612 6299#
MCOLON 6304#
MCOMMA 6281#
MCRLF 3799 4630 5839 5841 6282#
MDASH 5882 5886 5890 6305#
MDATAE 4603 6297#
MDESUM 4749 6303#
MDEV 6311#
MDNSER 4598 6294#
MDTEST 1630 6278#
MDWESE 4601 6295#
MEDDDI 5729 6306#

MEHEAD 5817 6285#
MEOT 6283#
MESA 563 643#
MESAC 877 914#
MESFL 885 916#
MESMQ 881 915#
MESPAS 86 124#
MESPC 873 913#
MESSAG 5493 5494 5496 5497 5501#
MFIRST 1682 6290#
MGB 4617 6304#
MHOME 5928 5947 6286#
MHUNGP 4222 6284#
MID 1667 6289#
MIDENT 2899 6276#
MINIT 5855 6287#
MLAST 4175 6291#
MNOSER 4197 6309#
MOD 1651 6288#
MOK 4740 6302#
MORETE 1416 1874#
MQA 54# 279 733 855 1382#
MQL 51# 488 1383# 6149
MQSAVE 281 487 735 856 882 920#
MREAD 4364 4584 6293#
MSB 1561#
MSDNUN 4195 6308#
MSELEC 2906 6277#
MSNDER 4366 6296#
MSUMCH 4735 6301#
MUDDDI 5730 6307#
MUNKNO 5691 6310#
MWORD 4606 4615 6298#
MWRITE 4361 4581 6292#
MX 119 1930 1939 1948 1967#
MX2HEA 6280#
MXEHEA 3797 6279#
NEXT 4841# 4851
NEXTAC 2225 2227 2231#
NEXTSE 5217# 5247 5257
NOHEAD 5815 5826#
NOMORE 1917 1930# 2670 3091
NOPRIN 5801 5972#
NORX01 1805 1839# 3873 3876
NOSCOP 2683# 2712
NOSER 4197# 5685
NOSET 107 113#
NOTCL0 5131 5143#
NOTEST 1436# 2008 2356 2432 2550 3396 3400 3403 4227 4935
NOTQ 1705 1724#
NTCLAS 863 896#
NULINE 5511 5518#
NUREAD 4159 4387# 4395

NUWORD 5494# 5500
OD 1370# 1641 1645 1647 1653 1663 3356 3397 3448 3909 4888 4945 4985 5026
5047 5051 5106 5118
OK 1437# 1791 1794 1867 2043 2047 2051 2379 2386 2393 2638 2642 2646 2752
2756 2868 3549 3583 3623 5167
OKSTAR 5225 5231#
ONECRL 5818 5831 5837 5840#
OTHERR 6167 6172 6182# 6182
OUTPUT 5495 5499 5502#
PACKDO 5133 5137#
PASCNT 81 87 121#
PASS 1563# 1602 1603 1949 1951 1989 1991 3839 5962 5963
PAT2 4001 4010#
PAT3 4002 4011#
PAT4 4003 4012#
PAT5 4004 4013#
PAT6 4005 4038#
PATSUM 1549# 3956 3989 3991 5282
PATTER 3976 3978 3999#
PCLF 44# 803 809
PCSAVE 859 874 903 907 918#
PCSCOP 1788 1879 2685 2713 2716# 3823
PHOME 5939 5946#
PI 1302 5548 5595# 6084 6128
PIEXIT 1715 1729 1739 5508 5546 5611 5623 5694#
PISDN 5602 5620#
PNTBUF 792 796 802 812#
PNTEXT 5489 5540 5551#
PNTID 1613 2895# 2908
POLL 4839 4841 4843 4844 4865#
PRETES 1784# 4190
PRETRY 1534# 4091 4108 4115 4121 4294 4483 4692 4699 6175
PRINI 1449# 1629 1650 1666 1681 1947 2898 2900 2905 3796 3798 4174 4206 4221
4360 4363 4365 4580 4583 4597 4600 4602 4614 4616 4629 4734 4739 4748
5690 5816 5838 5840 5854 5881 5885 5889 5927 5946 5967
PSIE 47#
PSKE 45#
PSKF 43# 807
PSTB 46# 803
PTSTOR 203 205 216 225 227#
Q46ID 5077 5100 5112#
Q46OD 5082 5108 5118#
Q40D 5061 5074#
Q60D 5091 5104#
QUIET 4202 4208#
R1 5299 5302 5305 5309#
R1RETP 1528# 3458 4279 4387 4396
R2 5300 5303 5306 5307 5310#
R2RETR 1529# 4282 4373 4388
RANGEN 3980 3999 4963 5297# 5308
RBUFFE 2978 2980 2996 6315# 6316
RDC 1501# 3353 3445 4072 4276 4341 4416 4560 5198
RDORWR 4358 4394 4438# 4445 4446 4578

READ 1451# 3687 3695 3707
READCO 1453# 3689 3693 3913 3923
READER 4304#
READL 4278# 4430
READOK 4297 4415#
READRE 3465 4160 4281#
REASK1 1016 1019#
REBEGI 1872 1957# 1994
RECALI 6011#
REDO1 561# 642
REDOA 285# 293
REFILL 4094# 4114
REMOVE 2901 6275#
REREAD 4291# 4381
RESEEK 4293# 4314
RESEQU 4917# 4978 4987
RETURN 5704# 5706 5715 6081 6115 6187
REWRIT 3372 4077# 4397
RLOGGE 4310 4316 4389 4398 4429#
ROK 4418 4425#
RSI 1455# 2813 3484
RSTB 1457# 2801 3239 3294
RXERRO 5674 5723 5745 5761#
RXHERE 1565# 1624 1803 2006 2354 2430 2548 2592
SAVEBS 5773#
SAVECS 5784#
SCOPE 1463# 1787 2053 2102 2180 2220 2230 2286 2336 2395 2455 2501 2534 2581
2653 2744 2884 3029 3247 3302 3551 3672 5169 6177
SCOPIN 2676 2709#
SDN 1403# 1807 1866 2050 2128 2146 2375 2378 2447 2567 2637 2749 2862 3179
3274 3546 3586 3626 5164 5629 5776 5788 6257
SDNSEC 6032 6257#
SDNUNE 4195# 5633
SECTOR 1503# 3369 3462 4150 4429 5184
SEQ 4913 4915 4930#
SEQ000 3908 3911 4918 4930 4941# 5032
SEQ001 4931 4952# 5031
SEQ010 4932 5013#
SEQ100 4934 5058#
SEQ111 4937 4963#
SEQ3 4933 5036#
SEQ6 4936 5088#
SER 1401# 1793 2046 2134 2152 2389 2392 2453 2645 2755 2867 3193 3289 3548
3590 3630 5166 5672 5742 5779 5791 6260
SETUP 1459# 5322 5456 5566
SHIFT 5332# 5354
SHIFTS 5333 5339 5372#
SND 4324# 4325
SNDLOG 1532# 4286 4350 4415
SPECIA 1461# 3851 5977
SRETRY 1533# 4089 4131 4138 4157 4292 4308 4315 4372
SSTART 1504# 1606 4147 4428 5924 5935 6267
STARGE 1505# 3361 3453 4146 4427 5233 5245 5253 5264 5278 5954 6122

START 1506# 3904 4145 4426 4908 5931
STOPNT 228# 864
STR 1399# 1790 2042 2131 2149 2382 2385 2450 2641 2746 2751 2858 3176 3271
3543 3582 3622 4101 4499 5161 6120 6124
SUBSCO 1465# 2032 2045 2049 2088 2130 2133 2136 2148 2151 2154 2168 2174 2300
2322 2374 2377 2381 2384 2388 2391 2420 2449 2452 2629 2640 2644 2648
2754 2758 2789 2807 2870 3189 3195 3235 3285 3291 3541 3585 3594 3604
3625 3634 3653
SW0 1480# 1627
SW1 1481# 1647 1954
SW10 1490# 6145
SW11 1491# 3848 5974 6145
SW2 1482#
SW3 1483# 3789 4200 4355 4559 4722 5799
SW4 1484# 2710 4112 4135 4312 4379 4696
SW5 1485# 3746 3942
SW6 1486# 6012
SW7 1487# 3740
SW8 1488#
SW9 1489#
T0 1569 1885 2006#
T1 1886 2081#
T10 1893 2524#
T11 1894 2548#
T12 1895 2592#
T13 1896 2838# 4015
T14 1897 2969#
T15 1898 2957#
T16 1899 2834# 4016
T17 1900 2965# 3378 3422 3475
T2 1887 2126#
T20 1901 2955#
T20STR 3531 3543# 3547
T20XOR 3532# 3545
T21 1902 3061#
T22 1903 3055# 3075
T23 1904 3480# 3486
T24 1905 3094# 3222
T25 1906 3096# 3206
T26 1907 3098# 3210
T27 1908 3262#
T3 1888 2212#
T30 1909 3331# 5641
T31 1910 3347#
T32 1911 3393#
T33 1912 3435#
T34 1913 3520# 4017
T35 1914 3512# 4018
T36 1915 3516# 4019
T37 1916 3508# 4020
T4 1889 2276#
T4B 2280# 2340
T5 1890 2354#

T6 1891 2410#
T7 1892 2484#
T7OK 2487 2501#
TAB 1467# 3814 3820 3824 3828 3832 3836 3843 4178 4636 4650 4752 5844 5859
5883 5887 5894 5898 5917 5932 5936 5951 5955 5959
TAB12 5856 5859#
TAB31 5891 5917#
TAB43 5929 5936#
TABLA 323 325#
TABLB 324 332#
TADLAS 1685 4164#
TARGET 1510# 1607 3357 3449 3903 3910 4144 4425 4907 4947 4958 4965 4976 4983
5045 5052 5104 5119 5260 5271 5950 6126
TEST 1569# 1789 1877 1878 1881 3074 3205 3209 3221 3748 3816 3951 5640 5812
5843
TEST1 3695#
TEST2 3693#
TEST3 3689#
TEST4 3332 3687#
TEST5 3697#
TESTP 1511# 2844 2976 3331 3351 3438 3521 3958 3973 4039 4123 4520 4609 4641
4714 4910 5204 5655 5958 6073 6102 6158
TESTS 1885# 1959
TESTX 3702# 3711
TESTXL 3705# 3709
THEL 3901# 3915
THENEX 4782# 5365 5476 5571
THETES 3522 3895# 3917
TICK 1439# 5713
TMPCNT 578 590 615#
TRACKS 1538# 3708 3906 3914 3924 4889 4890 4942 4953 5014 5017 5020 5021 5029
5037 5041 5042 5059 5067 5069 5075 5080 5089 5094 5096 5097 5113
TSTCHA 572 580 593# 610
TSTUNT 1821 3866#
TTRACK 1539# 3905 4892 4941 4952 5013 5023 5036 5044 5058 5079 5088 5099 5112
TTYBUS 1562# 1599 1713 1717 1728 1738 4784 5321 5507 5544 5547 5589 5607 5620
TTYLPT 341 368 793 813#
TWOCRL 5828 5838#
TX 3062 3254 3308 3527# 3552
TY1ASC 5522 5526 5528 5536# 5561
TY4OCT 1469# 1631 1652 1668 1683 3812 3818 3822 3826 3830 3834 4176 4223 4634
4648 4652 4742 4750 5446 5842 5857 5892 5896 5915 5930 5934 5949 5953
5957
TY8OCT 1387# 3838 5961
TYASTA 5879 5892#
TYCSTA 5900 5915#
TYPEIT 1471# 5351 5367 5473 5516 5570
UNIT 3168 3483 4861 4873# 5784 6068 6096
UNITS 1628 2759 3078 3401 3866 4837 4863#
UNITX 4853 4854 4872#
UNITZ 4834 4849 4858 4871# 5273
UNKNOW 5630 5690#
UPAROW 343 371 424 452 472# 478

UREAD 4375 4394#
VERIFY 5673 5682#
WAIT 1445# 1806 5775 5787 6256
WAITTY 1473# 2410 2484 2524 2562 4768 4778 4789 5134 5490
WAITMES 520 917#
WBUFFE 2846 2848 2994 3024 3035 3954 3967 4094 4484 4631 5272 5279 5283 5284
6314# 6315
WHICHR 4077 4148 4157#
WNOTOK 4133 4139 4150#
WORDX 1558# 3968 3970 5285 5286 5287
WORDY 1559# 3971 5289
WRESET 4090# 4137
WRITE 1475# 3468 3699 3706 3912 4443
WRITEL 4075# 4151
WRITEO 4126 4144#
WRITER 4131#
WUNITS 1880 3165 3347 3435 4835 4836 4847 4856 4857 4864# 4878
XA10 1512# 2849 2881 2981 2995 3000 3007 3025 3034 4509 4516 4527 4653
XA11 1513# 2997 3001 3013 3027 4485 4523 4632 4644 4684
XAC 5595 5696 5699#
XAERRO 1442 4994# 4998
XANDRE 4772 4782 4783 4785 4786#
XAPTB 1444 2919# 2923
XASTAT 4481 4542 4594 4662#
XBSW 1378 3755# 3772
XC 3081# 3090
XC8CHA 1699 1700 1740#
XC8CKP 142 727# 748 750 819
XC8CNT 270# 275 303 305 308 310 358 392 401 426 456 525 745 770
965 1014
XC8CRL 83 95 301 477 518 561 611 641 685# 696 868 868
XC8ECH 571 579 764# 771 775
XC8ERR 850# 858 901 911
XC8INQ 99 513# 516 527 528 894 976 1019
XC8LOO 1012# 1018 1310
XC8OCT 88 567 655# 671 875 879 883 887
XC8PAS 71# 100 102 1342
XC8PAU 939# 943 944 946 947
XC8PNT 85 93 200# 202 204 208 219 519 562 870 872 876 880 884
XC8PSW 459 552# 555 613 984
XC8SW 74 96 139# 157 889 896 992
XC8TTY 170# 178 397 521 742 765 1013
XC8TYP 215 224 298 300 474 476 569 640 664 688 693 772 791# 811
XCHECK 1339 5126# 5132 5140 5142 5143
XCHK22 1448 3716# 3720 3721 3722
XCKSWI 1575 4245# 4252
XCNT 1580# 5355 5361 5445
XCOMPA 4578# 5770 5877
XCRCEP 4343 4357 4367#
XD 1928# 1929
XDEVIC 5391 5414#
XDOLPT 795 802#
XDONE 1418 1877# 4880 4881

XDOSW 375 377#
XDRIN 1395# 1840 2092 2304 2327 2371 2650 2777 2987 3214 3532 3588 3628 4508
5635 5781 5793
XDROUT 1397# 2853 3175 3270 4104 5160 6123 6127
XEMPTY 4694 4700 4724 4732 4747 4754 4758#
XERROR 1414 3776# 3781 3810 3860
XFLENG 4607 4613 4615#
XFORCE 5724# 5983
XGETAP 1420 3931# 3945 3950 3996 4052
XGETAS 1422 5192# 5290
XGETAT 1424 3902 4906# 4968
XGETUN 1426 4833# 4862
XHALT 1429 4788# 4798 4801
XHUNG 4221# 5766 5865
XI 2664# 2669
XINIT 1408 6252# 6268
XINITB 1410 6272# 6274
XINITS 1431 5180# 5186
XINITT 1433 4885# 4893
XINTR 1406 6244# 6249
XK67X2 5401 5415#
XK67X3 5403 5416#
XK67X4 5405 5417#
XK67X5 5407 5418#
XK67X7 5409 5420#
XKCC 1695# 5600
XLCD 1390 6057# 6061
XLCDA 1392 6067# 6080 6082 6083 6089
XLCDB 1394 6095# 6188 6189 6190
XLCDBR 6117 6168# 6183
XLINK 5597 5694 5700#
XLOCKU 1435 3738# 3749
XMESSA 4198 4204 4207#
XMX 90 119#
XNOPRI 3791 3847#
XNULIN 5520 5525#
XOCTAL 5326 5327 5328 5334 5341 5342 5369#
XOK 1438 6039# 6041 6042
XOUTPU 5503# 5517 5518
XPAT6 4043# 4051
XPATTE 3979 3980# 3995
XPI 6141# 6151 6153 6155
XPRINT 1450 4770 5487# 5491 5492 5551 5553
XRDC 4258 4276#
XREAD 1452 3464 4257 4274# 4431 4440
XREADC 1454 4255# 4256
XRETUR 5686 5712#
XRST 1456 3619# 3673
XRSTB 1458 3579# 3609
XSCOPE 1464 2673# 2684 2686 2691 2694 2702 2706
XSDN 1404 6229# 6231 6232 6233
XSEQ 4974# 5053 5120
XSEQ2 5016 5026#

```
XSEQ3     5039    5045#
XSEP      1402    6222#   6224    6225    6226
XSETUP    1460    4767#   4771    4773    4774
XSHIFT    5335#   5340
XSPECI    1462    5565#   5567    5568    5569
XSSCOP    1466    2689#   2690
XSTARG    5185    5217    5221    5222    5229    5230    5232    5293#
XSTR      1400    6216#   6218    6219    6220
XTAB      1468    5455#   5457    5461    5471
XTABL     5459#   5468
XTABLA     283     323#
XTABLB     314     324#
XTARGE    1540#   5265    6157
XTCF      1718    5556#   5609
XTHEL     3901    3912#
XTICK     1440    3088    4805#   4808    4810    4817
XTY40C    1470    5319#   5323    5324    5325    5356
XTY80C    1388    5438#   5439    5441    5449    5450
XTYPEI    1472    5519    5521#   5524    5531    5560
XWAIT     1446    3124#   3131    3133    3134    3138    6031
XWAITT    1474    5508#   5592
XWPITF    1476    3371    4070#   4110    4116    4152
XXCRCN     964#    968    1577
XXCHIN     975#    978    1348
XXCRPS     983#    986    1345
XXCRSW     991#    994    1351
XXDMP     5346    5349    5371#
XXDRIN    1396    6205#   6207
XXDROU    1398    6210#   6213
XXFORC    1582    5627    5721#   5728    5765    5769    5826    5834    5850    5864    5876    5942    5981
XXGETA    5196#
XXINIT    5835    5851    5943    6261    6267#
XXTAB     5458    5460    5462    5466    5470    5474    5477#
XXTHEL    3920#   3927
XXX       1526#   3981    3990    3992    4046    4047    4048    4441    4442    4995    5000    5739    5744
XYTHEL    3922#   3925
ZERO      5359    5366#
.L0357     223     234#   1724    1745#
.L0360     222     235#   1718    1746#
.L0361     220     236#   1715    1729    1739    1747#
.L0362     217     237#   1703    1748#
.L0363     215     224     238#   1697    1749#
.L0364     206     239#   1696    1702    1750#
.L0365     176     177     240#   1685    1751#
.L0366     175     241#   1678    1752#
.L0367     174     242#   1659    1753#
.L0370     155     243#   1646    1754#
.L0371     148     244#   1644    1755#
.L0372     142     245#   1628    1756#
.L0373      99     246#   1627    1757#
.L0374      88     247#   1622    1758#
.L0375      83      95     248#   1621    1759#
.L0376      75      97     249#   1613    1760#
```



```
.L0377      72     250#   1604    1761#
.L0560     397     430#
.L0561     372     431#
.L0562     357     360     399     425     432#
.L0563     346     433#   1964    1968#
.L0564     343     371     424     434#   1959    1969#
.L0565     341     368     435#   1958    1970#
.L0566     312     436#   1953    1971#
.L0567     301     437#   1945    1972#
.L0570     299     438#   1938    1973#
.L0571     298     300     439#   1929    1974#
.L0572     294     353     370     440#   1880    1975#
.L0573     288     297     309     311     313     441#   1843    1976#
.L0574     281     442#   1824    1977#
.L0575     277     443#   1821    1978#
.L0576     272     444#   1788    1879    1979#
.L0577     271     274     445#   1786    1875    1980#
.L0751     607     616#
.L0752     603     617#
.L0753     601     605     618#
.L0754     599     619#
.L0755     595     620#
.L0756     577     621#
.L0757     571     579     622#
.L0760     570     623#
.L0761     568     624#
.L0762     567     625#
.L0763     565     575     582     588     626#
.L0764     558     627#
.L0765     521     628#
.L0766     519     562     629#
.L0767     514     553     630#
.L0770     494     631#   2231    2236#
.L0771     489     632#   2218    2237#
.L0772     487     633#   2216    2238#
.L0773     477     518     561     611     634#   2214    2239#
.L0774     475     573     586     598     602     606     608     635#   2095    2240#
.L0775     474     476     569     636#   2082    2090    2098    2126    2241#
.L0776     473     637#   2026    2242#
.L0777     456     525     638#   1994    2243#
.L1162     745     770     825#
.L1163     744     749     768     826#
.L1164     742     765     827#
.L1165     739     828#
.L1166     735     829#
.L1167     730     830#
.L1170     728     831#
.L1171     692     832#
.L1172     687     833#
.L1173     663     834#
.L1174     662     835#   2411    2457#
.L1175     659     836#   2313    2458#
.L1176     642     837#   2306    2338    2459#
```

```
.L1177    639    838#   2276    2368    2413    2460#
.L1364    984    999#
.L1365    955   1000#
.L1366    945   1001#
.L1367    905    908    1002#
.L1370    902   1003#   2670    2717#
.L1371    894    976    1004#   2669    2718#
.L1372    889    896     992    1005#   2603    2719#
.L1373    875    879     883     887    1006#   2594    2720#
.L1374    870    872     876     880     884    1007#   2570    2721#
.L1375    868    888    1008#   2526    2722#
.L1376    864   1009#   2487    2723#
.L1377    861    965    1010#   2485    2529    2564    2615    2710    2724#
.L1570   2930   2933#
.L1571   2848   2934#
.L1572   2846   2935#
.L1573   2843   2936#
.L1574   2834   2839    2874    2876    2937#
.L1575   1019   1023#   2780    2938#
.L1576   1014   1024#   2761    2939#
.L1577   1013   1025#   2759    2940#
.L1751   3139   3141#
.L1752   3137   3142#
.L1753   3135   3143#
.L1754   3098   3144#
.L1755   3095   3097    3099    3145#
.L1756   3091   3146#
.L1757   3090   3147#
.L1760   3088   3148#
.L1761   3086   3149#
.L1762   3078   3150#
.L1763   3075   3151#
.L1764   3062   3152#
.L1765   3061   3153#
.L1766   3035   3154#
.L1767   3024   3155#
.L1770   3009   3055    3156#
.L1771   2994   3157#
.L1772   2984   3158#
.L1773   2980   3159#
.L1774   2978   2996    3160#
.L1775   2975   3161#
.L1776   2971   3003    3030    3032    3162#
.L1777   2965   3163#
.L2162   3298   3311#
.L2163   3295   3312#
.L2164   3262   3313#
.L2165   3254   3308    3314#
.L2166   3252   3306    3315#
.L2167   3243   3316#
.L2170   3240   3317#
.L2171   3225   3318#
.L2172   3222   3319#
```



```
.L2173   3212   3320#
.L2174   3210   3321#
.L2175   3206   3322#
.L2176   3168   3323#
.L2177   3165   3324#
.L2356   3529   3557#
.L2357   3522   3558#
.L2360   3520   3559#
.L2361   3512   3516    3560#
.L2362   3483   3561#
.L2363   3480   3562#
.L2364   3465   3563#
.L2365   3464   3564#
.L2366   3463   3565#
.L2367   3417   3436    3566#
.L2370   3401   3567#
.L2371   3378   3422    3475    3568#
.L2372   3372   3569#
.L2373   3371   3570#
.L2374   3370   3571#
.L2375   3350   3572#
.L2376   3347   3435    3573#
.L2377   3332   3574#
.L2563   3718   3723#
.L2564   3699   3724#
.L2565   3689   3693    3725#
.L2566   3687   3695    3726#
.L2567   3663   3727#
.L2570   3660   3728#
.L2571   3649   3729#
.L2572   3646   3730#
.L2573   3620   3731#
.L2574   3606   3732#
.L2575   3597   3733#
.L2576   3596   3600    3645    3691    3697    3734#
.L2577   3580   3735#
.L2763   3876   3881#
.L2764   3874   3882#
.L2765   3873   3883#
.L2766   3870   3884#
.L2767   3867   3885#
.L2770   3866   3886#
.L2771   3848   3887#
.L2772   3789   3888#
.L2773   3785   3889#
.L2774   3783   3890#
.L2775   3759   3891#
.L2776   3746   3892#
.L2777   3740   3893#
.L3163   3980   3999    4053#
.L3164   3976   4054#
.L3165   3972   4055#
.L3166   3967   4056#
```

```
.L3167    3961    4057#
.L3170    3960    4058#
.L3171    3954    4059#
.L3172    3946    4060#
.L3173    3943    4061#
.L3174    3942    4045    4062#
.L3175    3908    3911    4063#
.L3176    3902    4064#
.L3177    3901    4065#
.L3365    4225    4230#
.L3366    4211    4231#
.L3367    4197    4232#
.L3370    4195    4233#
.L3371    4190    4200    4234#
.L3372    4167    4235#
.L3373    4160    4236#
.L3374    4159    4237#
.L3375    4112    4135    4238#
.L3376    4094    4239#
.L3377    4077    4240#
.L3572    4443    4447#
.L3573    4397    4448#
.L3574    4347    4422    4449#
.L3575    4344    4419    4450#
.L3576    4312    4379    4451#
.L3577    4248    4355    4452#
.L3766    4631    4669#
.L3767    4612    4670#
.L3770    4606    4671#
.L3771    4578    4672#
.L3772    4559    4673#
.L3773    4529    4655    4674#
.L3774    4525    4646    4675#
.L3775    4489    4676#
.L3776    4488    4677#
.L3777    4484    4678#
.L4167    4770    4822#
.L4170    4769    4823#
.L4171    4762    4766    4824#
.L4172    4722    4825#
.L4173    4719    4826#
.L4174    4717    4720    4730    4736    4760    4827#
.L4175    4698    4828#
.L4176    4696    4829#
.L4177    4686    4830#
.L4374    4964    5007#
.L4375    4963    5008#
.L4376    4913    5009#
.L4377    4909    5010#
.L4572    5156    5171#
.L4573    5129    5172#
.L4574    5053    5120    5173#
.L4575    5032    5171#
```



```
.L4576    5031    5175#
.L4577    5019    5176#
.L4773    5279    5284    5311#
.L4774    5273    5312#
.L4775    5272    5283    5313#
.L4776    5228    5314#
.L4777    5223    5315#
.L5165    5410    5423#
.L5166    5408    5424#
.L5167    5406    5425#
.L5170    5404    5426#
.L5171    5402    5427#
.L5172    5391    5428#
.L5173    5385    5429#
.L5174    5380    5430#
.L5175    5365    5431#
.L5176    5363    5432#
.L5177    5350    5366    5433#
.L5364    5558    5572#
.L5365    5548    5573#
.L5366    5529    5574#
.L5367    5527    5575#
.L5370    5525    5576#
.L5371    5512    5577#
.L5372    5509    5578#
.L5373    5508    5546    5579#
.L5374    5504    5580#
.L5375    5476    5571    5581#
.L5376    5472    5582#
.L5377    5464    5583#
.L5566    5738    5746#
.L5567    5685    5747#
.L5570    5683    5748#
.L5571    5657    5749#
.L5572    5649    5750#
.L5573    5641    5674    5723    5745    5751#
.L5574    5636    5752#
.L5575    5633    5753#
.L5576    5609    5754#
.L5577    5600    5755#
.L5762    5900    5901#
.L5763    5891    5902#
.L5764    5846    5903#
.L5765    5835    5851    5904#
.L5766    5801    5905#
.L5767    5799    5906#
.L5770    5785    5907#
.L5771    5784    5908#
.L5772    5782    5794    5909#
.L5773    5773    5910#
.L5774    5770    5877    5911#
.L5775    5766    5865    5912#
.L5776    5765    5769    5826    5834    5850    5864    5876    5913#
```

```
.L5777   5761   5914#
.L6165   6032   6044#
.L6166   6031   6045#
.L6167   6028   6046#
.L6170   6022   6047#
.L6171   6019   6048#
.L6172   6016   6049#
.L6173   6012   6050#
.L6174   5983   6051#
.L6175   5974   6052#
.L6176   5943   6053#
.L6177   5942   5981    6054#
.L6364   6182   6191#
.L6365   6156   6192#
.L6366   6155   6193#
.L6367   6146   6194#
.L6370   6145   6195#
.L6371   6142   6196#
.L6372   6116   6197#
.L6373   6114   6185    6198#
.L6374   6084   6128    6199#
.L6375   6081   6115    6187    6200#
.L6376   6075   6104    6201#
.L6377   6068   6096    6202#
.V0001   3848   3887#   5974    6052#
.V0002   3512   3516    3560#   5019    5176#
.V0003   6145   6195#
.V0007    607    616#    662     835#
.V0010   2231   2236#
.V0012   3620   3731#   5527    5575#   5785    5907#
.V0014   3098   3144#
.V0015   5525   5576#
.V0016   3580   3735#   5649    5750#   5773    5910#
.V0020    155    243#    565     575     582     588     626#   3740    3893#
.V0021    148    244#
.V0022    955   1000#
.V0032   4167   4235#
.V0037   1958   1970#
.V0040    568    624#   1824    1977#   2761    2939#   2965   3163#   3298   3311#   6012   6050#
.V0052   1644   1755#
.V0053   1659   1753#
.V0070   3243   3316#   4909    5010#
.V0073   5683   5748#
.V0077    217    237#
.V0100    222    235#    312     436#   2306    2338    2459#  2834   2839   2874   2876   2937#  2971   3003
         3030   3032    3162#   3212    3320#   3746    3892#  3942   4045   4062#  5156   5171#  5657   5749#
         6075   6104    6201#
.V0102   3529   3557#
.V0110   5464   5583#
.V0115   3262   3313#
.V0177    174    242#   1696    1702    1750#   2026    2242#  4964   5007#
.V0200    175    241#   1697    1749#   2082    2090    2098   2126   2241#  2276   2368   2413   2460#  2485
         2529   2564    2615    2710    2724#   3480    3562#  4112   4135   4238#  4312   4379   4451#  4696
```



```
         4829#
.V0212    692    832#
.V0215    595    620#    687     833#
.V0226   2930   2933#
.V0240    223    234#   5472    5582#
.V0262    663    834#   5350    5366    5433#
.V0267    889    896     992    1005#
.V0277    299    438#    639     838#   3663    3727#
.V0300   3090   3147#
.V0306    397    430#    521     628#    742     765    827#   1013   1025#
.V0314   5600   5755#
.V0317    519    562     629#    670     872     876    880    884   1007#
.V0336    473    637#
.V0353    864   1009#
.V0377   2313   2458#   3009    3055    3156#   3252   3306   3315#  3606   3732#  4525   4646   4675#  4719
         4826#  5636    5752#   5782    5794    5909#
.V0400     75     97     249#    456     525     638#   745    770    825#   861    965   1010#  1014   1024#
         1929   1974#   3789    3888#   4190    4200   4234#  4248   4355   4452#  4559   4673#  4722   4825#
         5129   5172#   5799    5906#
.V0423   3137   3142#
.V0425   3876   3881#
.V0426   3873   3883#
.V0457   1959   1969#
.V0466   2980   3159#
.V0520    558    627#
.V0522   2670   2717#   3091    3146#
.V0545   1994   2243#
.V0600   1945   1972#
.V0615    343    371     424     434#
.V0624    357    360     399     425     432#   744    749    768    826#   905    908   1002#
.V0635     99    246#    894     976    1004#   1019   1023#
.V0651    984    999#
.V0661    642    837#
.V0665   3024   3155#   4631    4669#
.V0666   2848   2934#   3035    3154#
.V0700   5380   5430#
.V0712   5408   5424#
.V0720   5404   5426#
.V0726   5406   5425#
.V0745    372    431#
.V1000    601    605     618#   1622    1758#   3520   3559#  3597   3733#
.V1007     88    247#    567     625#    875     879    883    887   1006#
.V1032     83     95     248#    301     437#    477    518    561    611    634#   868    888   1008#
.V1050    142    245#
.V1072    571    579     622#
.V1100   2669   2718#
.V1104    176    177     240#    288     297     309    311    313    441#   475    573    586    598    602
          606    608     635#
.V1105    294    353     370     440#    570     623#
.V1106    215    224     238#    298     300     439#   474    476    569    636#
.V1132    341    368     435#
.V1137   2411   2457#
.V1214   2487   2723#
```

```
.V1227   2526   2722#
.V1253   2570   2721#
.V1276   2603   2719#   4913    5009#
.V1314    271    274     445#    494     631#    728     831#
.V1315    281    442#    487     633#    735     829#   3976    4054#
.V1316    277    443#    489     632#    730     830#
.V1330     72    250#    272     444#    514     553     630#    739     828#
.V1333   5835   5851    5904#   5943    6053#
.V1341   6032   6044#
.V1362   3783   3890#
.V1363   1786   1875    1980#   3785    3889#   3943    4061#
.V1364   1788   1879    1979#
.V1400   2594   2720#
.V1476   2984   3158#
.V1530   1613   1760#
.V1602   3378   3422    3475    3568#
.V1705   6146   6194#
.V1722   6031   6045#
.V2000   1954   1971#   3095    3097    3099    3145#
.V2222   3370   3571#
.V2264   3463   3565#
.V2303   3062   3152#   3254    3308    3314#
.V2510   3332   3574#
.V2744   1821   1978#
.V2756   1843   1976#
.V3000   3522   3558#   3646    3730#
.V3016   3901   4065#
.V3130   3946   4060#
.V3200   3371   3570#
.V3206   4397   4448#
.V3207   3372   3569#
.V3270   4443   4447#
.V3273   1685   1751#
.V3320   5633   5753#
.V3322   5685   5747#
.V3341   3139   3141#   6156    6192#
.V3414   3464   3564#
.V3423   3465   3563#   4160    4236#
.V3517   4159   4237#
.V3550   4578   4672#
.V3600   4762   4766    4824#
.V3601   4344   4419    4450#
.V3607   4698   4828#
.V3617   4686   4830#
.V3702   5512   5577#
.V3740    220    236#
.V3761   4347   4422    4449#   4717    4720    4730    4736    4760    4827#
.V4000   3718   3723#   3867    3885#   4529    4655    4674#
.V4005   4489   4676#
.V4016   4488   4677#
.V4100   5509   5578#
.V4107   4769   4823#
.V4110   5365   5431#   5476    5571    5581#
```



```
.V4116   5770   5877    5911#
.V4127   3088   3148#
.V4145   1964   1968#
.V4146   3086   3149#
.V4235   1628   1756#   2759    2940#   3078    3150#   3401    3567#   3866    3886#
.V4236   1880   1975#   3165    3324#   3347    3435    3573#
.V4240   5273   5312#
.V4242   3168   3323#   3483    3561#   5784    5908#   6068    6096    6202#
.V4261   3902   4064#
.V4306   3908   3911    4063#   5032    5174#
.V4317   5031   5175#
.V4333   5053   5120    5173#
.V4434   5766   5865    5912#
.V4461    945   1001#
.V4474   3687   3695    3726#
.V4475   3689   3693    3725#
.V4510   3699   3724#
.V4541   3061   3153#   3417    3436    3566#
.V4710   3980   3999    4053#   4963    5008#
.V5000   3649   3729#
.V5067   1621   1759#
.V5124   5391   5428#
.V5242   5363   5432#
.V5244   4770   4822#
.V5267   4077   4240#
.V5323   6182   6191#
.V5343   1718   1746#   5609    5754#
.V5405   5548   5573#   6084    6128    6199#
.V5476   1715   1729    1739    1747#   5508    5546    5579#
.V5500   1938   1973#
.V5505   6081   6115    6187    6200#
.V5506   4211   4231#   6028    6046#
.V5513   5765   5769    5826    5834    5850    5864    5876    5913#   5942    5981    6054#
.V5516   5983   6051#
.V5523   5738   5746#
.V5600   5641   5674    5723    5745    5751#
.V6000   1627   1757#   2843    2936#   2975    3161#   3350    3572#   5900    5901#
.V6002   5891   5902#
.V6060   3210   3321#   5761    5914#
.V6061   5801   5905#
.V6062   3206   3322#
.V6064   3222   3319#
.V6104   3075   3151#
.V6115   5846   5903#
.V6265   6155   6193#
.V6311   6114   6185    6198#
.V6404   5402   5427#
.V6422   2214   2239#
.V6450   5410   5423#
.V6701   5385   5429#
.V6705   2218   2237#
.V6761   4606   4671#
.V6764   4612   4670#
```

.V7000	3596	3600	3645	3691	3697	3734#	3972	4055#	6116	6197#
.V7042	4195	4233#								
.V7055	4197	4232#								
.V7112	2846	2935#	2994	3157#	4094	4239#				
.V7113	4484	4678#	5272	5283	5313#					
.V7114	3954	4059#	5279	5284	5311#					
.V7115	3967	4056#								
.V7312	2978	2996	3160#							
.V7355	3135	3143#								
.V7402	902	1003#								
.V7477	3870	3884#								
.V7510	603	617#								
.V7520	599	619#								
.V7571	5558	5572#								
.V7600	346	433#	2095	2240#						
.V7640	6016	6049#								
.V7664	1646	1754#								
.V7670	5529	5574#								
.V7677	2780	2938#	3225	3318#	3874	3882#				
.V7700	206	239#	3960	4058#	5504	5580#				
.V7704	3961	4057#								
.V7710	3240	3317#								
.V7740	1604	1761#	3295	3312#	4225	4230#	6019	6048#	6142	6196#
.V7745	5223	5315#								
.V7746	1678	1752#								
.V7747	5228	5314#								
.V7757	1703	1748#								
.V7770	6022	6047#								
.V7771	2216	2238#								
.V7772	3759	3891#								
.V7773	3660	3728#								
.V7774	659	836#								
.V7775	577	621#								