

4. When ALL devices have been entered, press CTRL Z to end the input session and have the SYSGEN utility calculate the proper addresses for the set of hardware you have entered.

```

DEVICE> CTRL Z
DEVICE: UDA      NAME: PUA  CSR: 772150  Vector: 154  Support: yes
DEVICE: TU81     NAME: PTA  CSR: 774500  Vector: 260  Support: yes
DEVICE: QNA      NAME: XQA  CSR: 774440  Vector: 120  Support: yes
DEVICE: UDA      NAME: PUB  CSR: 760334*  Vector: 300*  Support: yes
DEVICE: TU81     NAME: PTB  CSR: 760444*  Vector: 350*  Support: yes

```

```

SYSGEN> EXIT
$
$

```

5. Entering EXIT at the SYSGEN prompt allows you to exit from SYSGEN.