


NOTES

1. USE THE WRAPS (X) ITEM "10 APPROXIMATELY EVERY THREE (3) ROWS WHEN NECESSARY, AND AT EVERY BREAKOUT POINT.
2. ATTACH MALE FASTON "DEE" # (9008219-0) WITH "4 WOOD SCREWS (16 PLACES).
3. USE CONN. BRKT. "C-MD-9305761-H15-0, MOUNT WITH "6 WOOD SCREWS. USE MATING CONN. "1209350-15.
4. USE CONN. BRKT. "C-MD-9305761-H6-0, MOUNT WITH "6 WOOD SCREWS. USE MATING CONN. "1209350-06.
5. DOT (•) INDICATES NAIL LOCATIONS FOR ASSEMBLY USE ONLY. COVER NAILS WITH "HARLINK TUBING TO PREVENT CUTTING HARNESS.



DO NOT REDUCE
DO NOT BUILD FROM REDUCED PRINT

[illegible]