


6. Watch the lights and turn on the power.



SHR-0301.84.B

Turn on the power to the TK50. The tape drive's red light goes on steady for about 5 to 15 seconds (while it runs an internal self-test), then goes off. The green light comes on. If at any time the red light flashes rapidly, there is a problem with the TK50. Refer to Chapter 5.