

DHMCA

IDENTIFICATION

PRODUCT CODE: MAINDEC-8E-D1HB-D
PRODUCT NAME: PDP8-E MEMORY EXTENSION
AND TIME SHARE CONTROL TEST
DATE CREATED: OCTOBER 8, 1971
MAINTAINER: DIAGNOSTIC PROGRAMMING GROUP
AUTHOR: J. VROBEL

M. C. N. REQUIRED
THIS PROGRAM REQUIRES MCN(S)
IN ORDER TO WORK PROPERLY

1. ABSTRACT

THIS PROGRAM TESTS THE MEMORY EXTENSION AND TIME SHARE CONTROL LOGIC FOR PROPER OPERATION. THE PROGRAM EXERCISES AND TESTS ALL IOT'S ASSOCIATED WITH MEMORY EXTENSION AND TIME SHARE CONTROL.

ERRORS ENCOUNTERED DURING RUNNING WILL RESULT IN A PROGRAM "HALT" OR A "JUMP TO SELF", WHICH MAY OCCUR IN ANY FIELD DEPENDING ON THE PORTION OF THE TEST EXECUTED. ERRORS MAY BE IDENTIFIED BY REFERENCING THE PROGRAM LISTING.

2. REQUIREMENTS

2.1 EQUIPMENT

PDP8-E COMPUTER WITH THE KM8-E OPTION INSTALLED AND AT LEAST 4K OF EXTENDED MEMORY.

2.2 STORAGE

THE PROGRAM REQUIRES 4200(8) LOCATIONS OF CORE MEMORY AND MUST RESIDE IN FIELD 0 ONLY.

2.3 PRELIMINARY PROGRAMS

ALL THE PROGRAMS FOR THE BASIC PDP8-E MUST HAVE BEEN RUN SUCCESSFULLY.

3. LOADING PROCEDURE

3.1 METHOD

THE PROGRAM IS LOADED INTO "FIELD 0" USING THE STANDARD BINARY LOADER TECHNIQUE.

4. STARTING PROCEDURE

4.1 CONTROL SWITCH SETTINGS

SR 9, 10, AND 11 MUST CONTAIN AN OCTAL VALUE EQUAL TO THE NUMBER OF EXTENDED FIELDS AVAILABLE. NOTE THAT FIELD 0 IS NOT INCLUDED.

SR0=0 WILL RESULT IN COMPLETE PROGRAM EXECUTION OF THE MEMORY

EXTENSION AND TIME SHARE CONTROL.

SR0=1 WILL LOOP THE PROGRAM ON THE MEMORY EXTENSION PORTION
AND TEST THAT THE TIME SHARE IS DISABLED.

SR1=1 WILL RESULT IN AN END OF TEST HALT AT LOCATION 1565(8).

4.2 STARTING ADDRESS

THE STARTING ADDRESS IS LOCATION 0200(8).

4.3 OPERATOR ACTION

4.3.1 MEMORY EXTENSION AND TIME SHARE CONTROL (TIME SHARE ENABLED)

WITH THE PROGRAM IN MEMORY, SET THE SWITCH REGISTER TO 0000.

PRESS EXTENDED ADDRESS LOAD.

SET THE REGISTER TO 0200 OCTAL.

PRESS ADDRESS LOAD.

PLACE THE OCTAL VALUE OF EXTENDED FIELDS AVAILABLE IN SR9-11.

PRESS CLEAR AND THEN CONTINUE.

THE PROGRAM SHOULD RUN UNTIL A FAILURE OCCURS OR UNTIL
STOPPED BY THE OPERATOR WITH SR1=1. NOTE THAT THE PROGRAM
SHOULD ALWAYS BE STOPPED WITH SR1=1.

THE TTY BELL WILL SIGNAL A SUCCESSFUL TEST AT THE COMPLETION
OF EVERY PASS.

4.3.2 MEMORY EXTENSION PORTION (TIME SHARE DISABLED)

WITH THE PROGRAM IN MEMORY, SET THE SWITCH REGISTER TO 0000.

PRESS EXTENDED ADDRESS LOAD.

SET THE SWITCH REGISTER TO 0200 OCTAL.

PRESS ADDRESS LOAD.

PLACE THE OCTAL VALUE OF EXTENDED FIELDS AVAILABLE IN SR9-11.

PLACE SR0=1 TO EXECUTE MEMORY EXTENSION ONLY.

PRESS CLEAR AND THEN CONTINUE.

THE PROGRAM SHOULD HALT AT LOCATION 3651(8). THIS WILL

0007

VERIFY THAT THE TIME SHARE IS DISABLED. ALL OTHER ERRORS
AT THIS TIME WILL BE CONSIDERED AS AN ILLEGAL CONDITION.

PRESS CONTINUE.

THE PROGRAM SHOULD LOOP UNTIL AN ERROR OCCURS OR UNTIL STOPPED
BY THE OPERATOR WITH SR1=1.

THE TTY BELL WILL SIGNAL A SUCCESSFULL TEST AT THE END
OF EVERY PASS.

5. OPERATING PROCEDURE

5.1 OPERATOR ACTION

5.1.1 MEMORY EXTENSION AND TIME SHARE CONTROL

VISUALLY VERIFY THAT THE TIME SHARE DISABLE JUMPER IS "OUT"
ON THE M837 MODULE AND FOLLOW THE OPERATOR ACTION IN 4.3.

5.1.2 MEMORY EXTENSION PORTION

VISUALLY VERIFY THAT THE TIME SHARE DISABLE JUMPER IS "IN"
ON THE M837 MODULE AND FOLLOW THE OPERATOR ACTION 4.3.

6. ERRORS

6.1 ERROR DESCRIPTION

BOTH "HALTS" AND "JUMP TO SELF" ARE USED TO INDICATE ERROR
CONDITIONS. IN EITHER CASE REFER TO THE PROGRAM LISTING
FOR MORE INFORMATION.

6.2 ERROR RECOVERY

ALL ERRORS ENCOUNTERED MUST BE CORRECTED BEFORE PROCEEDING
ON IN THE PROGRAM.

7. RESTRICTIONS

7.1 OPERATING RESTRICTIONS

PDP8-E ONLY WITH THE KM8-E OPTION INSTALLED AND AT LEAST 4K
OF EXTENDED MEMORY.

THE NUMBER OF EXTENDED AVAILABLE FIELDS MUST BE IN SR9-11.