

GT40,VT11

GT40 ROM VERIFY
CDGTDD0

AH-7926D-MC

COPYRIGHT 75-80
FICHE 1 OF 1

JAN 1980

digital

MADE IN USA

.TITLE GT40 ROM BOOTSTRAP TEST MAINDEC-11-DGTD-D

.REM

IDENTIFICATION

PRODUCT CODE: AC-7924D-MC
PRODUCT NAME: CDGTDDO GT40 ROM VERIFY
DATE: AUG. 1979
MAINTAINER: DIAGNOSTIC GROUP

COPYRIGHT (C) 1975, 1976, 1979 DIGITAL EQUIPMENT CORP., MAYNARD, MASS.

THIS SOFTWARE IS FURNISHED TO PURCHASER UNDER A LICENSE FOR USE
ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION
OF DEC'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT
AS MAY OTHERWISE BE PROVIDED IN WRITING BY DEC.

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT
NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL
EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF
OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

1. ABSTRACT

THIS VERSION OF THE PROGRAM SUPPORTS NON-SWITCH REGISTER CPU'S.
FOR THESE CPU'S, THE SWITCH REGISTER CAN BE CHANGED BY CHANGING
THE CONTENTS OF SWREG (170).

THE CDGTD DIAGNOSTIC PROGRAM IS WRITTEN TO BE USED AS AN AID
TO HARDWARE DEBUGGING AND MAINTENANCE OF THE GT40 ROM
BOOTSTRAP LOADER VERSION 1, 2 OR 3.

THE AVAILABLE TESTS ARE
PRG0 - LOGIC TESTS
PRG1 - ROM DATA DUMP TO THE CONSOLE TELETYPE

2. REQUIREMENTS

2.1 EQUIPMENT

GT40 DISPLAY PROCESSOR WITH ROM BOOTSTRAP VERSION 1, 2 OR 3.

2.2 STORAGE

THIS PROGRAM USES MEMORY LOCATIONS 0-7776 + 16000-16776(8).

3. LOADING PROCEDURE

PROCEDURE FOR A NORMAL BINARY TAPE SHOULD BE FOLLOWED.

4. STARTING PROCEDURE

4.1 STARTING ADDRESSES

0200 PROGRAM 0, ROM LOGIC TEST.
0204 PROGRAM 1, ROM DATA DUMP ON CONSOLE TTY.

4.2 SWITCH SETTINGS

CONSOLE SW 11-0	NORMAL RUN (64. INTERACTIONS/TEST)
CONSOLE SW 11 1	SUPPRES SUBPROGRAM INTERACTIONS
CONSOLE SW 08 0	TEST AS VERSION 2 OR 3 ROM (512. WORDS)
CONSOLE SW 08 1	TEST AS VERSION 1 ROM (256. WORDS)

5. PROGRAM DESCRIPTIONS

5.1 PRG0 - LOGIC TESTS

THE LOGIC TESTS CONSIST OF 4 ROUTINES TO TEST THE GT40 ROM
BOOTSTRAP LOGIC

5.1.1 ROUTINE DESCRIPTIONS

ROUTINE

TESTS

T1	ADDRESSABILITY OF GT40 ROM BOOTSTRAP
T2	DATA RELIABILITY
T3	THAT GT40 ROM BOOTSTRAP TIMES OUT WHEN REFERENCED BY A DATIP BUS CYCLE
T4	THAT DATA READ FROM THE ROM IS CORRECT

5.2 PRG1 - ROM DATA DUMP

THIS PROGRAM TYPES OUT THE 512./256. WORDS OF ROM DATA ON THE
CONSOLE TELETYPE AND HALTS.

6. ERRORS

THE PROGRAM WILL ONLY HALT ON ERROR. THE PROGRAM DOES NOT
CONTAIN FACILITIES FOR REPORTING ERROR CONDITIONS.
TO PLACE THE PROGRAM INTO A SCOPE LOOP, REPLACE THE ERROR
HALT WITH A NOP.

7. EXECUTION TIME

PRG0 TAKES APPROX. 5 SECONDS PER PASS.
PRG1 N/A
PRG2 N/A

8. XXDP/ACT/APT

THE PROGRAM IS CHAINABLE UNDER XXDP OR ACT BUT WILL NOT
SCRIPT UNDER APT.

-

```

156                                     .LIST ME,BIN,SEQ,LD
157                                     .ENABL ABS,AMA
158
159                                     ;LOAD ADDRESS=0200
160                                     ;DEPRESS START
161                                     ;STACK POINTER IS AT 500
162
169                                     .LIST
170                                     .-34
171 000034 002140                       SCOPEC
172 000036 000000                       0
173                                     .-46
174 000046 001600                       LOGICAL
175                                     .-52
176 000052 000000                       0
177                                     ;EQUATE STATEMENTS
178                                     SCOPE=TRAP
179                                     TPCSR=177564
180                                     TPDBR=177566
181                                     PSW=177776
182                                     DSWR=177570
183                                     ERRVEC=4
184                                     STKPTR=500
185                                     .-170
186 000170 000000                       SWREG: .WORD 0
187 000172 177570                       SWR:   DSWR
188                                     .-200
189 000200 000137 001040               JMP     PRMTRS
190 000204 000137 001614               JMP     PRG1

```

```

;END ADDRESS FOR ACT/XXDP
;NO MANUAL INTERVENTION REQUIRED

;ADDRESS OF SWITCH REGISTER
;INITIAL STACK SETTING

```

```
192
193      001000      001000      . = 1000
194 001000 166000 ROMADD: 166000 ; ROM ADDRESS
195 001002 001000 WORDS: 512. ; 256. ; ROM LENGTH
196 001004 006000 IMAGE: START ; STARTA ; ROM IMAGE
197 001006 172002 DSR: 172002 ; DISPLAY STATUS REGISTER
198 001010 000000 R0SAV: 0 ; CONTENTS OF REGISTERS
199 001012 000000 R1SAV: 0
200 001014 000000 R2SAV: 0
201 001016 000000 R3SAV: 0
202 001020 000000 R4SAV: 0
203 001022 000000 R5SAV: 0
204 001024 000010 FILLER: 10 ; # OF FILLER CHAR
205 001026 000010 FILCNT: 10
206 001030 000000 ICNT: 0
207 001032 000000 DUMP: 0
208 001034 000000 CHARA: 0
209 001036 000000 TERM: 0
210 001040 012706 000500 PRMTR: MOV #STKPTR,%6 ; SET STACK PTR
211 001044 004737 002424 JSR PC,SWITCH ; CHECK ROM VERSION
212
213 ; PROGRAM 0 LOGIC TESTS
214
215 001050 005037 001030 PRG0: CLR ICNT ; CLEAR PASS COUNT
216 001054 012706 000500 PRGOR: MOV #STKPTR,%6
217 001060 012737 001054 002214 MOV #PRGOR,RETURN ; SET RETURN ADDRESS FOR SCOPE
218
219 ; TEST1 TEST ABILITY TO REFERENCE ROM WITHOUT TIMING OUT
220
221 001066 013700 001000 T1: MOV ROMADD,%0 ; GET ROM ADDRESS
222 001072 013701 001002 MOV WORDS,%1 ; GET ADDRESS COUNTER
223 001076 012737 001136 000004 MOV #ERROR1,4 ; SET UP TIME OUT VECTOR
224 001104 011003 *1A: MOV (0),%3 ; REFERENCE
225 001106 005720 TST (0)+ ; ROM
226 001110 064037 001032 ADD -(0),DUMP ;
227 001114 021010 CMP (0),(0) ;
228 001116 132020 BITB (0)+,(0)+ ;
229 001120 164037 001032 SUB -(0),DUMP ;
230 001124 062700 000002 ADD #2,%0 ; INCREMENT POINTER
231 001130 005301 DEC %1 ; DECREMENT ADDRESS COUNTER
232 001132 001364 BNE T1A ; BRANCH IF NOT FINISHED
233 001134 000405 BR T1B ; GO TO SCOPE LOOP
234 001136 022626 ERROR1: CMP (6)+,(6)+ ; REPOSITION STACK
235 001140 004737 002372 JSR PC,SAVE05 ; SAVE R0-R5
236 001144 000000 HALT ; ERROR, TIME-OUT ON ROM ADDRESS
237 001146 000756 BR T1A ; LOOP ON ERROR
238 001150 104400 T1B: SCOPE
239
```

```

241
242 ;TEST2 TEST THAT ROM DATA CAN BE READ RELIABLY.
243
244 001152 013700 001000 T2: MOV ROMADD,%0 ;GET ROM ADDRESS
245 001156 013701 001002 MOV WORDS,%1 ;GET ADDRESS COUNTER
246 001162 012737 000006 000004 MOV #6,%4 ;INITIALIZE TIME OUT VECTOR
247 001170 005037 001032 T2A: CLR DUMP ;INITIALIZE DUMP
248 001174 011003 MOV (0),%3 ;GET DATA
249 001176 062037 001032 ADD (0)+,DUMP ;ADD DATA TO DUMP
250 001202 163703 001032 SUB DUMP,%3 ;SUBTRACT DATA FROM DATA
251 001206 001404 BEQ T2B ;BRANCH IF EQUAL
252 001210 004737 002372 ERROR2: JSR PC,SAVE05 ;SAVE R0-R5
253 001214 000000 HALT ;DATA ERROR
254 001216 000764 BR T2A ;LOOP ON ERROR
255 001220 044037 001032 T2B: BIC -(0),DUMP ;CLEAR DUMP BITS
256 001224 001404 BEQ T2C ;BRANCH IF EQUAL TO 0
257 001226 004737 002372 JSR PC,SAVE05 ;SAVE R0-R5
258 001232 000000 HALT ;DATA ERROR
259 001234 000771 BR T2B ;LOOP ON ERROR
260 001236 021010 T2C: CMP (0),(0) ;COMPARE DATA
261 001240 001404 BEQ T2D ;BRANCH IF EQUAL
262 001242 004737 002372 JSR PC,SAVE05 ;SAVE R0-R5
263 001246 000000 HALT ;DATA ERROR
264 001250 000772 BR T2C ;LOOP ON ERROR
265 001252 122040 T2D: CMPB (0)+,-(0) ;COMPARE DATA (BYTE OPERATION)
266 001254 001404 BEQ T2E ;BRANCH IF EQUAL
267 001256 004737 002372 JSR PC,SAVE05 ;SAVE R0-R5
268 001262 000000 HALT ;DATA ERROR
269 001264 000772 BR T2D ;LOOP ON ERROR
270 001266 005720 T2E: TST (0)+ ;INCREMENT ADDRESS POINTER
271 001270 005301 DEC %1 ;DECREMENT ADDRESS COUNTER
272 001272 001336 BNE T2A ;RETURN IF NOT DONE
273 001274 104400 SCOPE
274

```



```
276
277 ;TEST3 TEST THAT ROM TIMES OUT IF REFERENCED BY OTHER
278 ;THAN DATA BUS CYCLE
279
280 001276 012706 000500 T3: MOV #STKPTR,%6 ;SET STACK PTR
281 001302 013700 001000 MOV ROMADD,%0 ;GET ROM ADDRESS
282 001306 013701 001002 MOV WORDS,%1 ;GET ADDRESS COUNTER
283 001312 012737 001332 000004 T3AA: MOV #T3B,%4 ;SET UP TIME OUT VECTOR
284 001320 010010 T3A: MOV %0,(0) ;ATTEMPT TO ALTER DATA
285 001322 004737 002372 JSR PC,SAVE05 ;SAVE R0-R5
286 001326 000000 HALT ;HERE IF DID NOT TIME OUT
287 001330 000773 BR T3A ;LOOP ON ERROR
288 001332 012737 001354 000004 T3B: MOV #T3D,%4 ;SET UP TIME OUT VECTOR
289 001340 022626 T3C: CMP (6)+,(6)+ ;REPOSITION STACK
290 001342 005210 INC (0) ;ATTEMPT TO ALTER DATA
291 001344 004737 002372 JSR PC,SAVE05 ;SAVE R0-R5
292 001350 000000 HALT ;HERE IF DID NOT TIME OUT
293 001352 000773 BR T3C ;LOOP ON ERROR
294 001354 012737 001400 000004 T3D: MOV #T3F,%4 ;SET UP TIME OUT VECTOR
295 001362 022626 CMP (6)+,(6)+ ;REPOSITION STACK
296 001364 005077 177410 T3E: CLR @ROMADD ;ATTEMPT TO ALTER DATA
297 001370 004737 002372 JSR PC,SAVE05 ;SAVE R0-R5
298 001374 000000 HALT ;HERE IF DID NOT TIME OUT
299 001376 000772 BR T3E ;LOOP ON ERROR
300 001400 005720 T3F: TST (0)+ ;INCREMENT ADDRESS POINTER
301 001402 022626 CMP (6)+,(6)+ ;REPOSITION STACK
302 001404 005301 DEC %1 ;DECREMENT ADDRESS COUNTER
303 001406 001341 BNE T3AA ;RETURN IF NOT DONE
304 001410 012737 000006 000004 MOV #6,%4 ;RESTORE TIME OUT TRAP
305 001416 104400 SCOPE ;SCOPE LOOP
306
307 ;COMPARE THE ROM DATA TO THE IMAGE DATA
308 ;
309 ; R0-WORD NUMBER
310 ; R1-GOOD ADDRESS
311 ; R2-GOOD DATA
312 ; R3=BAD ADDRESS
313 ; R4=BAD DATA
314 001420 012700 000000 T4: MOV #0,%0 ;SET UP INITIAL WORD COUNT
315 001424 013701 001004 MOV IMAGE,%1 ;SET UP STARTING ADDRESS OF ROM IMAGE
316 001430 013703 001000 MOV ROMADD,%3 ;SET UP STARTING ROM ADDRESS
317 001434 011102 T4A: MOV (%1),%2 ;READ EXPECTED VALUE
318 001436 011304 MOV (%3),%4 ;READ ROM VALUE
319 001440 020204 CMP %2,%4 ;COMPARE EXPECTED TO THE VALUE READ
320 001442 001422 BEQ T4E ;BRANCH IF CORRECT
321 001444 012705 002536 MOV #TABLE0,%5 ;LOAD PATCH POINTER
322 001450 020015 T4B: CMP %0,(%5) ;TEST IF PATCHED LOCATION
323 001452 001406 BEQ T4C ;BR IF IT IS
324 001454 020527 002652 CMP %5,#TABLEX ;TEST IF END OF PATCH TABLE
325 001460 001407 BEQ T4D ;BR IF END OF TABLE * MUST BE A BAD ROM WORD
326 001462 062705 000004 ADD #4,%5 ;ADJUST PATCH POINTER
327 001466 000770 BR T4B ;TRY AGAIN
328 001470 005725 T4C: TST (%5)+ ;POINT TO PATCH WORD VALUE
329 001472 011502 MOV (%5),%2 ;GET PATCHED WORD VALUE
330 001474 020204 CMP %2,%4 ;COMPARE EXPECTED TO VALUE READ
331 001476 001404 BEQ T4E ;BR IF CORRECT
```



```

332 001500 004737 002372      14D:  JSR    PC,SAVE05      ;SAVE CONTENTS OF R0 - R5
333 001504 000000                      HALT                      ;ERROR, ROM VALUE FAILED TO EQUAL EXPECTED
334 001506 000752                      BR      T4A
335
336 001510 022123                      14E:  CMP    (%1)+, (%3)+      ;INCREMENT ADDRESSES POINTERS
337 001512 005200                      INC     %0              ;INCREMENT WORD COUNT
338 001514 023700 001002          CMP    WORDS,%0        ;COMPARE IF END WORD
339 001520 001345                      BNE     T4A              ;BRANCH IF NOT LAST WORD
340 001522 104400                      SCOPE
341
342 001524 005237 001030          END:   INC     ICNT          ;INCREMENT PASS COUNT
343 001530 012777 000001 177250      MOV    #1,@DSR        ;RING THE GT40 BELL
344 001536 012737 000207 177566      DONE0: MOV    #207,@TPDBR    ;RING THE TELETYPE BELL
345 001544 105737 177564          TSTB   @TPCSR
346 001550 100375                      BPL     -4
347 001552 012737 000207 177566      MOV    #207,@TPDBR
348 001560 105737 177564          1$:   TSTB   @TPCSR
349 001564 100375                      BPL     1$
350 001566 013700 000042          MOV    @#42,%0      ;RETURN TO XXDP/ACT MONITOR?
351 001572 001406                      BEQ     DONE1
352 001574 000005                      RESET
353 001576 000005                      RESET
354 001600 004710          LOGICAL:  JSR      7,(0)          ;RETURN.
355 001602 000240                      NOP
356 001604 000240                      NOP
357 001606 000240                      NOP
358 001610 000137 001050          DONE1: JMP     PRG0
359

```

```

361
362 ;THIS PROGRAM TYPES OUT ROM DATA
363
364 001614 012706 000500 PRG1: MOV #STKPTR,%6 ;INITIALIZE STACK
365 001620 012737 000006 000004 MOV #6,%4 ;SET UP BUSS ERROR
366 001626 004737 002424 JSR PC,SWITCH
367 001632 004537 001776 JSR 5,TYPEM
368 001636 002361 M8
369 001640 004537 001776 JSR 5,TYPEM ;TYPE MESSAGE
370 001644 002336 M7 ;'ROM DATA'
371 001646 013701 001002 MOV WORDS,%1 ;GET # OF WORDS
372 001652 013700 001000 PRG1A: MOV ROMADD,%0 ;GET STARTING ADDRESS
373 001656 012702 000010 MOV #10,%2 ;GET ADDRESS INDICATOR
374 001662 105737 177564 TSTB TPCSR ;WAIT FOR
375 001666 100375 BPL -4 ;TELEPRINTER FLAG
376 001670 010037 002230 PRG1B: MOV %0,D2BTYP ;GET ADDRESS
377 001674 004737 002232 JSR 7,02A ;AND TYPE IT
378 001700 004537 001776 JSR 5,TYPEM ;TYPE
379 001704 002365 M9 ;CR/LF
380 001706 012037 002230 PRG1C: MOV (0)+,D2BTYP ;TYPE
381 001712 004737 002232 JSR 7,02A ;DATA
382 001716 105737 177564 TSTB TPCSR ;WAIT FOR
383 001722 100375 BPL -4 ;TELEPRINTER FLAG
384 001724 012737 000040 177566 MOV #' ',TPDBR ;TYPE SPACE
385 001732 005301 DEC %1 ;ALL DATA TYPED
386 001734 001410 BEQ PRG1D ;GO TO FINISH
387 001736 005302 DEC %2
388 001740 001362 BNE PRG1C ;RETURN TO PRG1B
389 001742 012702 000010 MOV #10,%2 ;GET ADDRESS INDICATOR
390 001746 004537 001776 JSR 5,TYPEM ;TYPE
391 001752 002361 M8 ;CR/LF
392 001754 000745 BR PRG1B ;RETURN TO PRG1B
393 001756 004537 001776 PRG1D: JSR 5,TYPEM
394 001762 002361 M8
395 001764 004537 001776 JSR 5,TYPEM
396 001770 002361 M8
397 001772 000000 HALT
398 001774 000707 BR PRG1
399
400 ;ROUTINE TO LOOP ON A SINGLE ADDRESS
401

```

```

403 ;ROUTINE TO TYPE A MESSAGE
404
405 001776 010026 TYPEM: MOV %0,(6)+ ;SAVE REGISTER 0
406 002000 012500 MOV (5)+,%0 ;PLACE MESSAGE ADDRESS IN R0
407 002002 112037 001036 MOV (0)+,TERM ;GET TERMINATOR CHARACTER
408 002006 112037 001034 TYPEMA: MOV (0)+,CHARA ;GET NEXT CHARACTER
409 002012 123737 001034 001036 CMPB CHARA,TERM ;WAS NEXT CHARACTER THE TERM
410 002020 001005 BNE TYPEMB ;CHARACTER
411 002022 014600 MOV -(6),%0 ;RESTORE R0
412 002024 105737 177564 TSTB TPCSR
413 002030 100375 BPL -4
414 002032 000205 RTS 5 ;AND EXIT
415 002034 123727 001034 000045 TYPEMB: CMPB CHARA,#'% ;WAS CHARACTER %
416 002042 001027 BNE TYPEMC
417 002044 105737 177564 TSTB TPCSR ;TEST TELEPRINTER FLAG
418 002050 100375 BPL -4 ;AND WAIT FOR DONE
419 002052 012737 000215 177566 MOV #215,TPDBR ;LOAD TELEPRINTER WITH CAR. RET
420 002060 013737 001024 001026 MOV FILLER,FILCNT ;LOAD FILLER COUNT
421 002066 000403 BR 1$
422 002070 012737 000006 177566 2$: MOV #6,TPDBR ;PRINT FILLER CHAR
423 002076 105737 177564 1$: TSTB TPCSR ;TEST TELEPRINTER FLAG
424 002102 100375 BPL -4 ;AND WAIT FOR DONE
425 002104 005337 001026 DEC FILCNT ;FINISHED FILLERS ?
426 002110 001367 BNE 2$ ;BR IF NOT
427 002112 012737 000212 177566 MOV #212,TPDBR ;LOAD TELEPRINTER WITH LINE FEED
428 002120 000732 BR TYPEMA ;GET NEXT CHARACTER
429 002122 105737 177564 TYPEMC: TSTB TPCSR ;TEST TELEPRINTER FLAG
430 002126 100375 BPL -4 ;AND WAIT FOR DONE
431 002130 013737 001034 177566 MOV CHARA,TPDBR ;LOAD TELEPRINTER BUFFER
432 002136 000723 BR TYPEMA ;AND GET NEXT CHARACTER
433
434 ;SCOPE ROUTINE. THIS ROUTINE IS ENTERED AT THE END OF EACH SUBTEST.
435
436 002140 032777 040000 176024 SCOPEC: BIT #40000,@SWR ;TEST SR FOR SCOPE
437 002146 001023 BNE SCOPEB ;YES SCOPE
438 002150 032777 004000 176014 BIT #4000,@SWR ;TEST FOR ITERATION
439 002156 001007 BNE SCOPEG ;INHIBIT ITERATION
440 002160 023737 002212 002210 CMP SCOPEF,ICOUNT ;ITERATION COMPLETE
441 002166 001403 BEQ SCOPEG ;ITERATION COMPLETE GO TO SCOPEG
442 002170 005237 002212 INC SCOPEF ;INCREMENT ITERATION COUNT
443 002174 000410 BR SCOPEB ;GO TO SCOPEB
444 002176 005037 002212 SCOPEG: CLR SCOPEF ;CLEAR ITERATION COUNT
445 002202 011637 002214 MOV @%6,RETURN ;GET ADDRESS OF NEXT TEST
446 002206 000002 RTI ;EXIT
447 002210 000100 ICOUNT: 100
448 002212 000000 SCOPEF: 0 ;CONTAINS SUBTEST ITERATION COUNT
449 002214 000000 RETURN: .WORD 0 ;CONTAINS RETURN PC FOR SCOPE
450 002216 005726 SCOPEB: TST (6)+ ;POP PC
451 002220 012637 177776 MOV (6)+,%PSW ;RESTORE CONDITION CODES
452 002224 000177 177764 JMP @RETURN
453

```

```
455
456
457 ;THIS ROUTINE CONVERTS AN OCTAL NUMBER TO ASCII AND TYPES IT ON THE TTY.
458
459 002230 000000 D2BTYP: 0
460 002232 013746 177564 02A: MOV TPCSR, -(6) ;SAVE TPCSR
461 002236 010246 MOV %2, -(6) ;SAVE R2
462 002240 010146 MOV %1, -(6) ;SAVE R1
463 002242 010046 MOV %0, -(6) ;SAVE R0
464 002244 013700 002230 MOV D2BTYP, %0 ;GET DATA TO BE TYPED
465 002250 012701 000006 MOV #6, %1 ;GET COUNTER
466 002254 005002 CLR %2 ;CLEAR WORKING REGISTER
467 002256 006100 ROL %0 ;MOV FIRST BIT (MSB) INTO
468 002260 006102 ROL %2 ;R2
469 002262 062702 000260 02AA: ADD #260, %2 ;FORM ASCII CODE
470 002266 105737 177564 TSTB TPCSR ;TEST TELEPRINTER
471 002272 100375 BPL -4 ;FLAG AND WAIT UNTIL DONE
472 002274 010237 177566 MOV %2, TPDBR ;LOAD TELEPRINTER BUFFER
473 002300 005002 CLR %2 ;CLEAR WORKING REGISTER
474 002302 006100 ROL %0 ;ROTATE THE
475 002304 006102 ROL %2 ;NEXT
476 002306 006100 ROL %0 ;OCTAL CHARACTER
477 002310 006102 ROL %2 ;INTO
478 002312 006100 ROL %0 ;REGISTER
479 002314 006102 ROL %2 ;TWO
480 002316 005301 DEC %1 ;DECREMENT COUNTER
481 002320 001360 BNE 02AA ;GO TO 02AA IF NOT 0
482 002322 012600 MOV (6)+, %0 ;FINISHED. RESTORE REGISTERS
483 002324 012601 MOV (6)+, %1 ;
484 002326 012602 MOV (6)+, %2 ;
485 002330 012637 177564 MOV (6)+, TPCSR ;AND TPCSR
486 002334 000207 RTS 7 ;AND EXIT
487
488 ;ASCII MESSAGES
489 002336 022500 052107 032055 M7: .ASCII 'a%GT-40 ROM DATA%a'
490 002344 020060 047522 020115
491 002352 040504 040524 022445
492 002360 100
493 002361 100 022445 100 M8: .ASCII 'a%a'
494 002365 100 020040 100 M9: .ASCII 'a a'
495 002372 .EVEN
496
497 ;SUBROUTINE TO SAVE R0-R5 NEAR LOC. 1000
498 SAVE05: MOV R0, R0SAV
499 MOV R1, R1SAV
500 MOV R2, R2SAV
501 MOV R3, R3SAV
502 MOV R4, R4SAV
503 MOV R5, R5SAV
504 RTS PC ;EXIT
```


503	002424	013746	000004		SWITCH:	MOV	@#ERRVEC, -(SP)	;SAVE VECTORS CONTENTS
504	002430	012737	002456	000004		MOV	#1\$, @#ERRVEC	;SET UP FOR TRAP
505	002436	012737	177570	000172		MOV	#DSWR, @#SWR	;SET UP TO TEST FOR SWITCH REGISTER
506	002444	022777	177777	175520		CMP	#-1, @#SWR	;TEST FOR SWITCH REGISTER
507	002452	001005				BNE	3\$	;SWITCH REGISTER IS PRESENT
508	002454	000401				BR	2\$	;NO SWITCH REGISTER
509	002456	022626			1\$:	CMP	(SP)+, (SP)+	;POP 2 WORDS OFF STACK
510	002460	012737	000170	000172	2\$:	MOV	#SWREG, @#SWR	;SET UP FOR SOFTWARE SWITCH REGISTER
511	002466	012637	000004		3\$:	MOV	(SP)+, @#ERRVEC	;RESTORE VECTORS CONTENTS
512	002472	032777	000400	175472		BIT	#400, @#SWR	;TEST BIT 8
513	002500	001007				BNE	4\$	;BR IF VERSION 1
514	002502	012737	001000	001002		MOV	#512, WORDS	;SET UP VERSION 2 LENGTH
515	002510	012737	006000	001004		MOV	#START, IMAGE	;SET UP VERSION 2 STARTING ADD.
516	002516	000406				BR	5\$	
517	002520	012737	000400	001002	4\$:	MOV	#256, WORDS	;SET UP VERSION 1 LENGTH
518	002526	012737	016000	001004		MOV	#STARTA, IMAGE	;SET UP VERSION 1 STARTING ADD.
519	002534	000207			5\$:	RTS	PC	

520
521 .SBTTL ROM VERSION 3 PATCH VALUE FOR VERSION 2
522

523	002536	000001	000137	TABLE:	.WORD	1,137
524	002542	000002	167636		.WORD	2,167636
525	002546	000003	000000		.WORD	3,0
526	002552	000327	000137		.WORD	215,137
527	002556	000330	167620		.WORD	216,167620
528	002562	000710	105737		.WORD	456,105737
529	002566	000711	175614		.WORD	457,175614
530	002572	000712	100375		.WORD	458,100375
531	002576	000713	112337		.WORD	459,112337
532	002602	000714	175616		.WORD	460,175616
533	002606	000715	000203		.WORD	461,203
534	002612	000716	000000		.WORD	462,0
535	002616	000717	005037		.WORD	463,5037
536	002622	000720	177776		.WORD	464,177776
537	002626	000721	012737		.WORD	465,12737
538	002632	000722	010007		.WORD	466,10007
539	002636	000723	175610		.WORD	467,175610
540	002642	000724	000137		.WORD	468,137
541	002646	000725	166010		.WORD	469,166010

542
543 TABLEX: 0 .SBTTL ROM VERSION 2 VALUES

545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598

: EXCEPT FOR THE NEW ORIGIN ADDRESS AND SEVERAL '!160000'
: FOR ADDRESS FUDGING THIS IS AN EXACT COPY OF THE CONTENTS
: OF THE GT-40 BOOTSTRAP VERSION #2
: *****

.TITLE SCROLLING ROM BOOTSTRAP FOR THE GT40

; BOOTGT.T16 OCT 10, 1973

; COPYRIGHT 1973, DIGITAL EQUIPMENT CORPORATION
; 146 MAIN STREET
; MAYNARD, MASSACHUSETTS 01754

; WRITTEN BY JACK BURNES.

; THIS PROGRAM IS THE SECOND VERSION THE THE ROM BOOTSTRAP FOR
; THE GT40 DISPLAY TERMINAL. IT INCLUDES SCROLLING AND AN END OF
; MEMORY SEARCH FOR THE LOADER.

.ENABL ABS,AMA ;ASSEMBLER DIRECTIVES FOR ABSOLUTE BINARY OUTPUT
; NOTE: USE 'MACDLX' TO ASSEMBLE THIS PROGRAM.

.SBTTL DEFINITION SECTION
.PAGE

599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652REGISTER DEFINITIONS
-----BASIC DEFINITIONS

000000	R0=R0	;DEFINE STANDARD VALUES.
000001	R1=R1	
000002	R2=R2	
000003	R3=R3	
000004	R4=R4	
000005	R5=R5	
000006	SP=R6	
000007	PC=R7	

GT40 DEFINITIONS

000000	CHAR=R0	;CONTAINS THE INPUT CHARACTER.
000001	POINTR=R1	;POINTS TO NEXT INSERTION BYTE IN DISPLAY BUFFER
000002	TABCNT=R2	;CHARACTER COUNTER FOR THE 'TAB' FEATURE.
000003	SCAN=R3	;GENERALLY CONTAINS A POINTER WHICH
		;IS USED WHEN SCANNING MEMORY FOR SOMETHING.
000004	HOLD=R4	;TYPICALLY A TEMPORARY WHICH IS USED TO RETAIN
000005	COUNTR R5	;A VALUE FOR A SHORT TIME
		;TYPICALLY USED AS A COUNTER.

LOADER DEFINITIONS

000000	L.BYT=CHAR	;CHARACTER INPUT FOR THE LOADER.
000001	L.ADR=POINTR	;CURRENT MEMORY ADDRESS TO BE LOADED.
000002	L.BC=TABCNT	;NUMBER OF DATA ITEMS TO LOAD.
000005	L.CKSM=COUNTR	;CHECKSUM ON THE INPUT DATA.
000003	INDEX=SCAN	;INDICATES HOW TO ASSEMBLE THE 8 BIT CHARACTER.

.PAGE

MAJOR SYSTEM DEFINITIONS

```
653
654
655      :
656      :
657
658
659
660      166000      ORIGIN=166000      ;ORIGIN OF THE BOOTSTRAP.
661
662      175610      DL11IS=175610      ;INPUT STATUS REGISTER OF DL11
663      175612      DL11IB=DL11IS+2    ;INPUT CHARACTER FROM DL11
664      175614      DL11OS=DL11IB+2    ;OUTPUT STATUS OF THE DL11
665      175616      DL11OB=DL11OS+2    ;OUTPUT CHARACTER TO THE DL11
666
667      177560      KBDIS=177560      ;KEYBOARD INPUT STATUS
668      177562      KBDIB=KBDIS+2      ;CURRENT CHARACTER FROM KEYBOARD.
669
670      172000      GT40PC=172000      ;GT40 PROGRAM COUNTER.
671      172002      GT40SR=GT40PC+2    ;GT40 STATUS REGISTER ADDRESS.
672
673
674      001000      BSTART=1000        ;START OF THE DISPLAY BUFFER
675      007000      BLIMIT=7000        ;APPROXIMATE END OF THE DISPLAY BUFFER.
676      007776      TMPEND=7776        ;LOCATION OF INITIALIZATION STACK.
677      000004      CORSTR=4           ;LOCATION OF PDF-11 TRAP VECTOR.
678      007012      JMPADD=BLIMIT+10.  ;WHERE THE POINTER IS TO FIRST CHAR ON SCREEN
679      000040      NUMLIN=32.         ;NUMBER OF LINES ON TEXT TO SHOW ON THE SCREEN
680
681      005015      CRLF=5015           ;CARRIAGE RETURN - LINE FEED
682      000175      ALTMOD=175         ;THE 'KEY' CHARACTER [I.E. ALTMODE].
683
684      160000      DISJMP=160000      ;THE GT40 JMP INSTRUCTION
685      173000      DISTOP=173000      ;THE GT40 STOP DISPLAY INSTRUCTION.
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704      .SBTTL  INITIALIZATION AND RESTART CODE
705      .PAGE
```

```
706
707
708
709      ;          GT40 BOOTSTRAP CODE
710      :          -----
711
712
713
714
715      006000      .=6000
716
717      :          .=ORIGIN          ;DEFINE ORIGIN OF THE BOOTSTRAP.
718
719
720
721
722
723
724      :          COLD INITIALIZATION CODE
725      :          -----
726
727
728
729 006000 000005      START: RESET          ;RESET ALL HARDWARE NOW.
730 006002 012737 000007 175610      MOV      #7,DL11IS      ;INITIALIZE DL-11 INPUT NOW.
731 006010 012706 007776      MOV      #TMPEND,SP      ;ESTABLISH A GOOD TEMPORARY STACK
732      ;POINTER FOR CORE SEARCH.
733 006014 005237 175614      INC      DL110S      ;SET BREAK BIT
734 006020 004337 166652      JSR      SCAN,OUTLIT!160000      ;FOR 2 CHARACTER TIMES
735 006024 000000      .WORD 0      ;SEND TWO ZERO'S
736
737 006026 012703 000004      MOV      #CORSTR,SCAN      ;GET ADDRESS OF BAD CORE TRAP VECTOR.
738 006032 012723 166042      MOV      #NOTHERE!160000,(SCAN)+ ;AND INSERT A POINTER TO US THERE.
739
740 006036 005023      ENDCOR: CLR      (SCAN)+      ;NOW CLEAR ALL OF MEMORY BEYOND THE POINTER,
741 006040 000776      BR          ENDCOR      ;UNTIL WE RUN OUT OF MEMORY AND TRAP.
742
743
744 006042 005743      NOTHER: TST      -(SCAN)      ;WHEN WE TRAP OUT, WE COME HERE.
745      ;WE BACK UP POINTER TO GOOD CORE.
746      ;NOTE THAT IF WE TRAP OUT AGAIN, IT
747      ;IS STILL OK, BECAUSE WE WILL LOOP
748      ;UNTIL WE GET A GOOD CORE ADDRESS.
749 006044 010306      MOV      SCAN,SP      ;WHEN WE GET ONE, THAT IS LAST LOCATION
750      ;IN THE MACHINE, AND HENCE OUR SP.
751 006046 105737 175614      1$: TSTB   DL110S      ;SEE IF BREAK IS DONE
752 006052 100375      BPL      1$      ;NO GO BACK
753 006054 005037 175614      CLR      DL110S      ;CLEAR BREAK BIT
754
755
756
757
758
759
760      :          RESTART INITIALIZATION CODE WHEN COMMUNICATIONS IS WORKING.
761      :          -----
```



```

762
763
764
765 006060 052706 007776      RESTRT: BIS      #TMPEND,SP      ;FORCE THE SP TO LIMIT OF EXISTING CORE.
766
767
768 006064 012703 006700      MOV      #BLIMIT-NUMLIN-NUMLIN,SCAN      ;NOW WE WILL FILL THE KEY AREAS OF THE
769 006070 012702 000040      MOV      #NUMLIN,TABCNT      ;DISPLAY BUFFER WITH INITIAL CR-LF'S.
770
771 006074 012723 005015      SETLP1: MOV      #CRLF,(SCAN)+      ;INSERT A CRLF NOW.
772 006100 005302              DEC      TABCNT      ;AND LOOP UNTIL DONE.
773 006102 003374              BGT      SETLP1      ;THUS DISPLAY CORE IS ALMOST CORRECT.
774
775
776 006104 012703 166432      MOV      #SETUP!160000,SCAN      ;NOW WE WILL INITIALIZE CORE FOR THE
777                                ;DISPLAY. PICK UP POINTER TO LIST.
778
779 006110 012302      SETLP2: MOV      (SCAN)+,TABCNT      ;GET NUMBER OF ITEMS TO INSERT.
780 006112 001405      BEQ      SETDUN      ;IF ZERO, WE ARE DONE.
781 006114 012301      MOV      (SCAN)+,POINTR      ;PICK UP FIRST CORE ADDRESS POINTER.
782
783 006116 012321      SETLP3: MOV      (SCAN)+,(POINTR)+      ;MOVE OVER A DATA ITEM NOW.
784 006120 005302      DEC      TABCNT      ;ALL DONE?
785 006122 003375      BGT      SETLP3      ;NOPE. MOVE OVER THE NEXT.
786 006124 000771      BR      SETLP2      ;YES. GET NEXT MAJOR LIST TO INSERT.
787
788
789 006126 012701 006776      SETDUN: MOV      #BLIMIT-2,POINTR      ;ESTABLISH THE BUFFER POINTER NOW.
790
791
792
793
794
795
796
797
798
799
800
801
802

```

.SBTTL VT05 SIMULATOR
.PAGE

```

803
804
805
806          :          VT05 (SCROLLING) PORTION OF THE BOOTSTRAP
807          :          -----
808
809
810
811 006132 004737 166564      NXTCHR: JSR      PC,GETCHR!160000      ;GET A CHARACTER NOW.
812 006136 020027 000177      CMP      CHAR,#177      ;IS IT OUT OF RANGE?
813 006142 002373      BGE      NXTCHR      ;YEP. GET ANOTHER ONE.
814 006144 020027 000040      CMP      CHAR,#40      ;IS IT A PRINTING CHARACTER?
815 006150 002020      BGE      NORMAL      ;YES. IT'S A NORMAL PRINTING CHARACTER.
816 006152 010003      MOV      CHAR,SCAN      ;MOVE IT OVER SO WE CAN PLAY WITH IT.
817 006154 162703 000007      SUB      #7,SCAN      ;BIAS SO THAT BELL [7] IS ZERO.
818 006160 020327 000007      CMP      SCAN,#7      ;IF CHARACTER IS LESS THEN BELL OR
819 006164 103362      BHS      NXTCHR      ;GREATER THEN CR, THEN IGNORE.
820 006166 006303      ASL      SCAN      ;IF GOOD, MAKE IT WORD INDEX.
821 006170 060307      ADD      SCAN,PC      ;AND GO TO THE CORRECT ROUTINE.
822
823          BR      BELL      ;7=BELL
824          BR      NORMAL    ;10=BACKSPACE
825          BR      TAB       ;11=TAB
826          BR      LF        ;12=LINE FEED [LF]
827          BR      VT        ;13=VERTICAL TAB [VT]
828          BR      FF        ;14=FORM FEED [FF]
829          BR      FF        ;15=CARRIAGE RETURN [CR]
830
831
832 006206 012702 177777      CR:      MOV      #-1,TABCNT      ;RESET TAB POSITION ON A CR, AND
833                                     ;FALL THROUGH TO INSERT THE CHARACTER.
834
835
836 006212 004737 166350      NORMAL: JSR      PC,INSERT!160000      ;INSERT THE CHARACTER IN THE BUFFER.
837 006216 005202      INC      TABCNT      ;UPDATE TAB POSITION NOW.
838 006220 000744      BR      NXTCHR      ;AND GET NEXT CHARACTER.
839
840
841
842
843 006222 012700 000040      TAB:      MOV      #40,CHAR      ;ON A TAB, INSERT BLANKS UNTIL THE
844 006226 004737 166350      JSR      PC,INSERT!160000      ;NEXT CHARACTER POSITION IS A MULTIPLE
845 006232 005202      INC      TABCNT      ;OF 8.
846 006234 032702 000007      BIT      #7,TABCNT      ;ARE WE DONE YET?
847 006240 001370      BNE      TAB       ;NOPE.
848 006242 000733      BR      NXTCHR      ;YES.
849
850
851 006244 111705      VT:      MOV      (PC),COUNTR      ;THIS PUTS THE LOW BYTE OF THE
852                                     ;BRANCH CODE IN COUNTR-SAVE A WORD
853          BR      FFLOOP
854
855 006250 005037 172002      BELL:   CLR      GT40SR      ;RING BELL -WRITE IN GT40SR
856 006254 000726      BR      NXTCHR      ;AND LOOP BACK
857
858 006256 012705 000040      FF:      MOV      #NUMLIN,COUNTR      ;FORM FEED IS DONE BY INSERTING LF'S.

```

859						
860	006262	012703	000012	FFLOOP: MOV	#12,CHAR	;MAKE THE CHARACTER A LINEFEED.
861	006266	004737	166304		JSR	PC,LFSUB.160000
862	006272	005305			DEC	COUNTR
863	006274	003372			BGT	FFLOOP
864	006276	000715			BR	NXTCHR
865						;YES. NOW RETURN. DO NOT FALL THROUGH.
866						
867	006300	012746	166132	LF: MOV	#NXTCHR.160000,-(SP)	;RETURN TO NXTCHR AFTER PROCESSING
868						;THE LF BY FAKING A JSR.
869						
870	006304	013703	007012	LFSUB: MOV	JMPADD,SCAN	;GET POINTER TO FIRST CHAR ON SCREEN
871						
872	006310	122300		LFLOOP: CMPB	(SCAN)+,CHAR	;AND LOOK FOR A LINEFEED.
873	006312	001406			BEQ	LFOUND
874	006314	020327	007000		CMP	SCAN,#BLIMIT
875	006320	103773			BLO	LFLOOP
876	006322	012703	001000		MOV	#BSTART,SCAN
877	006326	000770			BR	LFLOOP
878						;AND KEEP ON LOOKING.
879	006330	005203		LFOUND: INC	SCAN	;WE'VE GOT THE LINE FEED. STOP SHOWING
880	006332	042703	000001		BIC	#1,SCAN
881	006336	010337	007012		MOV	SCAN,JMPADD
882	006342	004737	166350		JSR	PC,INSERT!160000
883	006346	005000			CLR	CHAR
884						;INSERT THE LF IN THE BUFFER.
885						;AND THEN INSERT ONE NULL CHARACTER BECAUSE
886						;THE 'DISJMP' ADDRESS MUST BE EVEN, AND
887						;THIS GUARANTEES WE WILL NOT LOSE A
888						;A GOOD DATA CHARACTER. WE FALL THROUGH
889						;TO INSERT THE NULL IN THE BUFFER.
890	006350	110021		INSERT: MOVB	CHAR,(POINTR)+	;STICK IN THE CHARACTER NOW.
891	006352	032701	000001		BIT	#1,POINTR
892	006356	001021			BNE	INSRTX
893	006360	020127	007000		CMP	POINTR,#BLIMIT
894	006364	103410			BLO	INSRTL
895	006366	010103			MOV	POINTR,SCAN
896	006370	012701	001000		MOV	#BSTART,POINTR
897	006374	004737	166406		JSR	PC,INSRTL!160000
898	006400	005023			CLR	(SCAN)+
899	006402	005013			CLR	(SCAN)
900	006404	000207			RTS	PC
901						;AND THEN RETURN.
902	006406	022121		INSRTL: CMP	(POINTR)+,(POINTR)+	;BYPASS THE 'DISJMP' BY ADDING 4 TO POINTR.
903	006410	012711	166474		MOV	#HEADER.160000,(POINTR)
904	006414	012741	160000		MOV	#DISJMP,-(POINTR)
905	006420	005041			CLR	-(POINTR)
906						;MAKE AVAILABLE A NEW CHARACTER SPOT.
907	006422	000207		INSRTX: RTS	PC	;FINALLY RETURN TO THE CALLER.
908						
909						
910						
911						
912						
913	006424	012737	001000 172000	GTBUSE: MOV	#BSTART,GT40PC	;ON A BUS ERROR, WE MERELY RESTART THE GT40 AT
914						

```

915                                     ;THE RTI FOR THIS ROUTINE
916                                     ;IS THE FIRST WORD OF THE TABLE
917                                     ;BELOW-IT SAVES A WORD.
918
919
920
921
922
923
924
925
926
927
928
929                                     :
930                                     :
931                                     :
932                                     :
933                                     :
934 006432 000002      SETUP: .WORD 2      ;INITIALIZE 2 WORDS.--ALSO RTI FROM ABOVE
935 006434 000330      .WORD 330      ;STARTING AT LOCATION 330
936 006436 166424      .WORD GTBUSE!160000 ;FIRST WORD IS POINTER TO BUS ERROR ROUT
937 006440 000200      .WORD 200      ;SECOND WORD IS NEW STATUS WORD ON INTERRUPT.
938
939 006442 000007      .WORD 7      ;INITIALIZE THE END OF THE BUFFER TO
940 006444 006776      .WORD BLIMIT-2 ;A CLEAR SPACE TO INSERT THE CHARACTER.
941 006446 000000      .WORD 0      ;THIS IS THE 'RUNNING' START. THIS IS
942 006450 160000 166474 .WORD DISJMP,HEADER!160000 ;FOLLOWED BY A DISJMP TO OUR HEADER BLOC
943 006454 160000 001000 .WORD DISJMP,BSTART ;AND THEN A DISJMP TO THE START OF THE BUFFER
944 006460 160000 006700 .WORD DISJMP,BLIMIT-NUMLIN-NUMLIN ;AND A DISJMP TO THE FIRST CHAR ON SCREE
945
946 006464 000001      .WORD 1      ;FINALLY START THE GT40 GOING AT
947 006466 172000      .WORD GT40PC ;THE POSITION INSTRUCTION IN THE
948 006470 166474      .WORD HEADER!160000 ;HEADER BLOCK.
949
950 006472 000000      .WORD 0      ;END OF INIT CODE
951
952                                     :
953                                     :
954 006474 103334      HEADER: .WORD 103334 ;ENABL CHAR MODE,BLINKING
955 006476 000177      .WORD 177      ;A BLINKING BOX-RUB OUT.
956 006500 116124      .WORD 116124 ;GO TO POINT MODE
957 006502 171340      .WORD 171340 ;LOAD STATUS REGISTER
958 006504 000000 001352 .WORD 0,1352 ;POINT TO UPPER LEFT
959 006510 103324      .WORD 103324 ;BACK TO CHAR MODE
960 006512 160000 007010 .WORD DISJMP,JMPADD-2 ;AND TO THE CHANGING JMP INST.
961
962                                     .SBTTL COMMUNICATIONS AND MISC. SUPPORT ROUTINES
963                                     .PAGE

```

COMMUNICATIONS HANDLING ROUTINES

THE DL-11 HANDLER

```

964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980 006516 105737 175610 GETDL: TSTB DL11IS ;CHECK THE HOST INPUT STATUS.
981 006522 100011 BPL GETDL1 ;HOST DID NOT SEND ANYTHING, YET.
982 006524 113700 175612 MOV DL11IB,CHAR ;HOST SENT US A CHARACTER. PROCESS IT.
983 006530 012737 000007 175610 MOV #7,DL11IS ;REENABLE THE HOST TELECOMMUNICATIONS.
984 006536 042700 177600 BIC #-200,CHAR ;MAKE CHARACTER JUST SEVEN BITS.
985 006542 001765 BEQ GETDL ;IF NULL, IGNORE IT.
986 006544 000207 RTS PC ;ELSE RETURN NOW.
987
988 006546 105737 177560 GETDL1: TSTB KBDIS ;DID USER TYPE A CHARACTER?
989 006552 100361 BPL GETDL ;NO. GO BACK AND CHECK HOST MACHINE.
990 006554 113737 177562 175616 MOV KBDIB,DL11OB ;MOVE THE CHARACTER TO THE HOST.
991 006562 000755 BR GETDL ;AND CHECK AGAIN FOR INPUT.
992
993
994
995
996
997
998
999
1000
1001
1002 006564 004737 166516 GETCHR: JSR PC,GETDL!160000 ;GET A CHARACTER FROM THE HOST NOW.
1003 006570 020027 000175 CMP CHAR,#ALTMOD ;IS IT AN 'ALTMODE'?
1004 006574 001025 BNE GETEXT ;NO. EXIT NOW.
1005
1006 006576 004737 166516 JSR PC,GETDL!160000 ;YES. GET ANOTHER ONE NOW.
1007 006602 020027 000114 CMP CHAR,#'L' ;IS IT AN 'L'?
1008 006606 001501 BEQ LOADER ;YES. START LOADING NOW.
1009 006610 020027 000122 CMP CHAR,#'R' ;IS IT AN 'R'?
1010 006614 001015 BNE GETEXT ;NO. IGNORE THE ALTMODE AND JUST RETURN THE CHAR
1011
1012 006616 012737 173000 007010 MOV #DISTOP,JMPADD-2 ;YES. RESET. STOP DISPLAY BY INSERTING A 'DISTOP
1013 006624 000137 166060 PRESTR: JMP RESTR!160000 ;INSTRUCTION IN THE BUFFER, AND RESTART.
1014
1015
1016
1017
1018
1019

```

THE 'GET A SIX BIT CHARACTER' ROUTINE

```

1020      :      --- --- --- --- ---
1021
1022
1023
1024 006630 004737 166564  GETSIX: JSR    PC,GETCHR!160000      ;GET A CHARACTER NOW.
1025 006634 020027 000040      CMP    CHAR,#40          ;IS IT A LEGAL PRINTING CHARACTER?
1026 006640 002517      BLT    L.BAD          ;NOPE. ABORT
1027 006642 020027 000137      CMP    CHAR,#137       ;IT'S BIG ENOUGH. IS IT TOO BIG?
1028 006646 003114      BGT    L.BAD          ;YEP. ABORT.
1029
1030 006650 000207  GETTEXT: RTS    PC          ;RETURN TO THE CALLER.
1031
1032
1033      :      THIS OUTPUTS TWO CHARACTERS VIA A
1034      :      JSR SCAN,OUTLIT
1035      :      'TWO CHARACTERS'
1036
1037 006652 112337 175616  OUTLIT: MOVB   (SCAN)+,DL110B
1038 006656 112337 175616      MOVB   (SCAN)+,DL110B      ;DOUBLE BUFFERED
1039 006662 000203      RTS    SCAN          ;RETURN
1040
1041
1042
1043
1044
1045
1046
1047      :      THE 'GET AN EIGHT BIT CHARACTER' ROUTINE
1048      :      --- --- --- --- ---
1049
1050
1051
1052      :      THIS ROUTINE DIFFERS FROM THE PREVIOUS ROUTINES
1053      :      IN THAT IT WILL TAKE SIX BIT CHARACTERS AND ASSEMBLE
1054      :      THEM FOR THE LOADER TO USE. NOTE THAT FROM THIS POINT
1055      :      ON WE WILL SWITCH TO THE LOADER DEFINITIONS OF THE
1056      :      REGISTERS. THUS THE CHARACTER IS RETURNED IN
1057      :      REGISTER 'L.BYT' RATHER THAN CHAR (THOUGH THEY ARE
1058      :      PHYSICALLY THE SAME).
1059
1060
1061
1062 006664 004737 166630  GET8:   JSR    PC,GETSIX!160000      ;GET A SIXBIT CHARACTER.
1063 006670 010046      MOV    L.BYT,-(SP)      ;SAVE IT ON THE STACK.
1064 006672 005723      TST    (INDEX)+        ;UPDATE INDEX TO NEXT ITEM (ALL ARE *2)
1065 006674 000163 166676      JMP    GET8TB-2!160000(INDEX) ;AND DISPATCH ACCORDING TO THE INDEX.
1066
1067 006700 000404  GET8TB: BR    GET81          ;INDEX=2: ASSEMBLE FIRST CHAR
1068 006702 000416      BR    GET82          ;INDEX=4: ASSEMBLE SECOND CHAR
1069 006704 000432      BR    GET83          ;INDEX=6: ASSEMBLE THIRD AND LAST CHAR
1070      :      ;INDEX=8: RESET INDEX TO 0 [2] AND RETRY.
1071
1072
1073 006706 012703 000002  GET84: MOV    #2,INDEX      ;THE FOURTH INDEX IS THE SAME AS THE FIRST
1074      :      ;INDEX. JUST RESET IT AND FALL THROUGH.
1075

```


1076					
1077	006712	004737	166630	GET81:	JSR PC,GETSIX!160000
1078	006716	010004			MOV L.BYT,HOLD
1079	006720	006300			ASL L.BYT
1080	006722	006300			ASL L.BYT
1081	006724	106300			ASLB L.BYT
1082	006726	106116			ROLB (SP)
1083	006730	106300			ASLB L.BYT
1084	006732	106116			ROLB (SP)
1085	006734	012600			MOV (SP)+,L.BYT
1086	006736	000207			RTS PC
1087					
1088					
1089	006740	006300		GET82:	ASL L.BYT
1090	006742	006300			ASL L.BYT
1091	006744	106300			ASLB L.BYT
1092	006746	106104			ROLB HOLD
1093	006750	106300			ASLB L.BYT
1094	006752	106104			ROLB HOLD
1095	006754	106300			ASLB L.BYT
1096	006756	106104			ROLB HOLD
1097	006760	106300			ASLB L.BYT
1098	006762	106104			ROLB HOLD
1099	006764	010400			MOV HOLD,L.BYT
1100	006766	012604			MOV (SP)+,HOLD
1101	006770	000207			RTS PC
1102					
1103					
1104	006772	006100		GET83:	ROL L.BYT
1105	006774	106100			ROLB L.BYT
1106	006776	006004			ROR HOLD
1107	007000	106000			RORB L.BYT
1108	007002	006004			ROR HOLD
1109	007004	106000			RORB L.BYT
1110	007006	005726			TST (SP)+
1111	007010	000207			RTS PC
1112					
1113					
1114					
1115					
1116					
1117					
1118					
1119					
1120					
1121					
1122					
1123					
1124					
1125					

;GET ANOTHER CHARACTER NOW.
 ;AND PRESERVE IT FOR NEXT TIME THROUGH.
 ;NOW THROW AWAY LEFT MOST BITS OF
 ;THE 8 BIT CHARACTER. NOW MERGE IN
 ;THE LEFT TWO BITS OF THE
 ;NEW SIX BIT CHARACTER WITH THE SIX
 ;BITS FROM THE CHARACTER ON THE
 ;STACK. 1ST CHARACTER IS NOW ASSEMBLED,
 ;SO WE'LL RETURN IT TO THE USER.
 ;AND THEN WE SHALL RETURN TO HIM.

;THE SECOND CHARACTER IS CREATED FROM
 ;THE 4 RIGHT BITS OF THE PREVIOUS CHARACTER
 ;AND THE FOUR MIDDLE BITS OF THE PRESENT
 ;8 BIT CHARACTER.
 ;WE WILL CREATE THE NEW 8 BIT
 ;IN THIS REGISTER, SINCE IT
 ;MORE CONVIENT. WE WILL MOVE OVER THE
 ;ANSWER AT THE END.
 ;ONE MORE TO GO
 ;DONE.
 ;BRING OVER THE VALUE.
 ;AND REMEMBER THE LAST CHARACTER WE RECEIVED.
 ;AND RETURN TO THE CALLER.

;FINAL CHARACTER IS EASY. JUST A
 ;SIMPLE MERGER OF LEFT TWO BITS OF
 ;PREVIOUS VALUE WITH RIGHT SIX BITS
 ;OF LAST (4TH) CHARACTER RECEIVED.
 ;AND WE ARE DONE.
 ;FINALLY THROW AWAY STACK.
 ;AND RETURN TO THE CALLER.

.SBTTL THE LOADER
 .PAGE


```
1126
1127
1128
1129      :      THE LOADER
1130      :      ---
1131
1132
1133
1134
1135 007012 012737 173000 007010 LOADER: MOV    #DISTOP,JMPADD-2      ;STOP THE GT40 BY INSERTING A 'DISTOP' IN THE LI
1136
1137 007020 005003              CLR    INDEX      ;RESET THE 8 BIT ASSEMBLER TO THE FIRST CHAR
1138
1139
1140 007022 005005              L.LD2:  CLR    L.CKSM      ;CLEAR THE CHECKSUM
1141 007024 004737 167114      JSR    PC,L.PTR!160000      ;GET A BYTE NOW.
1142 007030 105300            DECB   L.BYT      ;IS IT A ONE (HEADER)?
1143 007032 001373            BNE    L.LD2      ;NO. WAIT FOR THE ONE.
1144
1145 007034 004737 167114      JSR    PC,L.PTR!160000      ;YES. SKIP OVER THE NEXT CHARACTER NOW.
1146
1147 007040 004737 167126      JSR    PC,L.GWRD!160000      ;ASSEMBLE A WORD NOW.
1148 007044 010002            MOV    L.BYT,L.BC      ;MOVE OVER TO THE COUNTER.
1149 007046 162702 000004      SUB    #4,L.BC      ;REDUCE TO ACTUAL DATA COUNT.
1150 007052 022702 000002      CMP    #2,L.BC      ;ANY DATA AT ALL?
1151 007056 001433            BEQ    L.JMP      ;NO. MUST BE END
1152 007060 004737 167126      JSR    PC,L.GWRD!160000      ;YES. ASSEMBLE A DATA WORD NOW.
1153 007064 010001            MOV    L.BYT,L.ADR      ;AND THIS MUST BE THE FIRST ADDRESS.
1154
1155
1156 007066 004737 167114      L.LD3:  JSR    PC,L.PTR!160000      ;GET A BYTE OF DATA NOW.
1157 007072 002006            BGE    L.LD4      ;ALL DONE?
1158 007074 105705            TSTB   L.CKSM      ;YEP. COUNTER IS MINUS. CHECK CHECKSUM.
1159 007076 001751            BEQ    L.LD2      ;CHECKSUM GOOD. GET NEXT COMMAND.
1160
1161
1162 007100 004337 166652      L.BAD:  JSR    SCAN,OUTLIT!160000      ;BAD LOAD INFORM HOST
1163 007104      175      102      .BYTE  ALTMOD,'B      ;SEND ALTMODE B
1164 007106 000646            BR     PRESTR      ;AND RESTART THE DISPLAY.
1165
1166
1167 007110 110021            L.LD4:  MOVB   L.BYT,(L.ADR)+      ;INSERT BYTE INTO MEMORY.
1168 007112 000765            BR     L.LD3      ;AND GET THE NEXT BYTE.
1169
1170
1171
1172 007114 004737 166664      L.PTR:  JSR    PC,GET8!160000      ;ASSEMBLE AN 8 BIT CHARACTER NOW.
1173 007120 060005            ADD    L.BYT,L.CKSM      ;UPDATE THE CHECKSUM NOW.
1174 007122 005302            DEC    L.BC      ;DECREMENT THE CHARACTER COUNTER.
1175 007124 000207            RTS    PC      ;AND RETURN TO THE CALLER NOW.
1176
1177
1178
1179 007126 004737 167114      L.GWRD: JSR    PC,L.PTR!160000      ;ASSEMBLE A WORD. FIRST GET A CHARACTER
1180 007132 010046            MOV    L.BYT,-(SP)      ;AND SAVE IT.
1181 007134 004737 167114      JSR    PC,L.PTR!160000      ;AND THEN GET ANOTHER ONE.
```

```

1182 007140 000300          SWAB    L.BYT          ;AND THEN REASSEMBLE THE MESS.
1183 007142 052600          BIS     (SP)+,L.BYT    ;WITH THE FEARSOME POWER OF THE 11.
1184 007144 000207          RTS      PC            ;AND RETURN TO THE CALLER.
1185
1186
1187
1188
1189 007146 004737 167126    L.JMP: JSR     PC,L.GWRD!160000      ;ALL DONE WITH THE LOAD. ASSEMBLE
1190 007152 010046          MOV     L.BYT,-(SP)      ;THE STARTING ADDRESS NOW.
1191 007154 004737 167114    JSR     PC,L.PTR!160000    ;AND DON'T FORGET TO CHECKSUM IT.
1192 007160 105705          TSTB    L.CKSM
1193 007162 001346          BNE     L.BAD            ;A BAD CHECKSUM. ALL IS EVIL.
1194
1195 007164 004337 166652    JSR     SCAN,OUTLIT!160000      ;GOOD CHKSUM, INFORM HOST
1196 007170      175      107    .BYTE  ALTMOD,'G        ;WITH ALTMOD G
1197
1198 007172 032716 000001    BIT     #1,(SP)          ;DO WE WANT TO START EXECUTION?
1199 007176 001401          BEQ     L.JMP1          ;YES. AWAY WE GO.
1200
1201 007200 000000          L.HALT: HALT              ;IF NOT, HALT.
1202
1203 007202 000136          L.JMP1: JMP     @ (SP)+      ;IF GO, THEN GO ALREADY. WHEEEE.
1204
1205
1206
1207          .SBTTL  THE SELF TEST
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220          .PAGE

```

;THIS IS GT40 QUICK TEST
;GIVES QUICK VISUAL TEST
;OF CONDITION OF MACHINE
;WITHOUT READING IN DIAG.

1221		
1222		
1223		
1224		
1225	100000	CHAR=100000
1226	104000	SHORTV=104000
1227	110000	LONGV=110000
1228	114000	POINT=114000
1229	120000	GRAPHX=120000
1230	124000	GRAPHY=124000
1231	130000	RELATV=130000
1232		
1233	002000	INT0=2000
1234	002200	INT1=2200
1235	002400	INT2=2400
1236	002600	INT3=2600
1237	003000	INT4=3000
1238	003200	INT5=3200
1239	003400	INT6=3400
1240	003600	INT7=3600
1241		
1242	000100	LPOFF=100
1243	000140	LPON=140
1244	000020	BLKOFF=20
1245	000030	BLKON=30
1246		
1247	000004	LINE0=4
1248	000005	LINE1=5
1249	000006	LINE2=6
1250	000007	LINE3=7
1251		
1252	160000	DJMP=160000
1253	164000	DNOP=164000
1254	170000	STATSA=170000
1255	173400	DSTOP=173400
1256		
1257	000300	LPLITE=300
1258	000200	LPDARK=200
1259	000040	ITAL0=40
1260	000060	ITAL1=60
1261	000004	SYNON=4
1262		
1263		
1264	174000	STATSB=174000
1265		
1266	000100	INCR=100
1267	040000	INTX=40000
1268	001777	MAXX=1777
1269	001377	MAXY=1377
1270	020000	MINUSX=20000
1271	020000	MINUSY=MINUSX
1272	017600	MAXSX=17600
1273	000077	MAXSY=77
1274	000100	MINSUY=100
1275		
1276		

;BRIGHTEST

;STOP INTERRUPT

;ITALICS OFF
;ON
;SYNC ON

;LOAD GRAPH INCR
;INTENSIFY BIT
;BIGGEST X VECTOR
;BIGGEST Y VECTOR
;THE MINUS BIT

;BIGGEST X IN SHORTVEC
;Y IN
;MINUS BIT FOR Y IN SHORTVEC

1277	007204	012737	167214	172000	MOV #FILE0.160000,GT40PC	START THE GT40
1278	007212	000001			WAIT	;AND WAIT
1279						
1280	007214	114020			FILE0: POINT!BLKOFF	;POINT--INVISIBLE
1281	007216	000000			0	
1282	007220	001377			MAXY	
1283						
1284	007222	112004			LONGV!INT0:LINE0	;DRAW TOP LINE
1285	007224	041777			INTX:MAXX	
1286	007226	000000			0	
1287						
1288	007230	112405			LONGV!INT2:LINE	
1289	007232	040000			INTX	;DRAW LINE TO RIGHT
1290	007234	021377			MINUSX:MAXY	
1291						
1292	007236	113006			LONGV!INT4:LINE2	
1293	007240	061777			INTX:MINUSX:MAXX	;DRAW BOTTOM LINE
1294	007242	000000			0	
1295						
1296	007244	113407			LONGV!INT6:LINE3	
1297	007246	040000			INTX	
1298	007250	001377			MAXY	;DRAW LINE TO LEFT
1299						
1300	007252	114000			POINT	
1301	007254	000400			400	
1302	007256	000500			500	
1303	007260	106200			SHORTV!INT1	
1304	007262	057677			57677	;+X+Y
1305	007264	106600			SHORTV!INT3	
1306	007266	077677			77677	;+X-Y
1307	007270	107200			SHORTV!INT5	
1308	007272	077777			77777	;-X-Y
1309	007274	107600			SHORTV!INT7	
1310	007276	057777			57777	;-X+Y
1311						
1312	007300	114000			POINT	
1313	007302	001400			1400	
1314	007304	000500			500	
1315	007306	133030			RELATV!INT4:BLKCN	
1316	007310	057677			57677	;+X+Y
1317	007312	077677			77677	;+X-Y
1318	007314	077777			77777	;-X-Y
1319	007316	057777			57777	;-X+Y
1320						
1321	007320	114000			POINT	
1322	007322	000400			400	
1323	007324	000100			100	
1324	007326	174120			STATSB!INCR+20	;TRY GRAPH MODES
1325	007330	114000			POINT	
1326	007332	001000			1000	
1327	007334	000200			200	
1328						
1329	007336	120000			GRAPHX	
1330	007340	001010			1010	
1331	007342	001020			1020	
1332	007344	001030			1030	

1333	007346	001040	1040
1334	007350	001050	1050
1335			
1336	007352	114000	POINT
1337	007354	001000	1000
1338	007356	001200	1200
1339			
1340	007360	124000	GRAPHY
1341	007362	001020	1020
1342	007364	001030	1030
1343	007366	001040	1040
1344	007370	001050	1050
1345	007372	001060	1060
1346			
1347	007374	160000	DJMP
1348	007376	167214	FILE0:160000
1349			
1350			.SBTTL PAPER TAPE BOOT

```

1352
1353
1354
1355          177550
1356          177560
1357
1358
1359 007400 012701 160000
1360 007404 012702 000004
1361 007410 012703 167500
1362 007414 010712
1363 007416 012706 000024
1364 007422 014304
1365 007424 005714
1366 007426 100775
1367 007430 010712
1368 007432 012706 000024
1369 007436 010441
1370
1371 007440 040601
1372 007442 010111
1373 007444 011102
1374 007446 005214
1375 007450 105714
1376 007452 100376
1377 007454 116412 000002
1378 007460 005211
1379 007462 120227 000375
1380 007466 001366
1381 007470 105222
1382 007472 000142
1383
1384
1385
1386 007474 177560
1387 007476 177550
1388
1389

; PAPER TAPE BOOT
HSR=177550 ;HIGH SPEED READER ADDRESS
LSR=177560 ;LOW SPEED READER ADDRESS
;
;.=ORIGIN+1400
PTBOOT: MOV #160000,R1 ;SET MEMORY CHECK LIMITS
        MOV #4,R2 ;TRAP ADDRESS IS LOC. 4
        MOV #DEV+4!160000,R3 ;POINTER TO DEVICE ADDRESSES
        MOV PC,@R2 ;PRESET TRAP ADDRESS IN LOC. 4
        MOV #24,SP ;STACK SET UP AT SPECIAL ADDRESS
DEV1: MOV -(R3),R4 ;GET DEVICE ADDRESS
      TST @R4 ;CHECK AVAILABILITY OF DEVICE
      BMI DEV1 ;CHECK DEVICE FOR ERRORS
      MOV PC,@R2 ;RESET TRAP ADDRESS AT LOC. 4
      MOV #24,SP ;SPECIAL ADDRESS USED AS MASK LATER
      MOV R4,-(R1) ;DO MEM CHK:READER STATUS ADDRESS
      ;IS MOVED
      BIC SP,R1 ;SET R1=X7752,MASK IN SP=24
      MOV R1,@R1 ;STORE OWN ADDRESS IN POINTER
LOOP: MOV @R1,R2 ;GET BYTE POINTER
      INC @R4 ;ENABLE READER
      TSTB @R4 ;TEST DONE BIT
      BPL -2 ;WAIT UNTIL READY
      MOVB 2(R4),@R2 ;THEN PICK IT UP AND STORE IT
      INC @R1 ;BUMP POINTER
      CMPB R2,#375 ;STORED JUMP OFFSET?
      BNE LOOP ;NOT YET
      INCB (R2)+ ;YES,ALL DONE
      JMP -(R2) ;GO EXECUTE AS BRANCH

;
; DEVICE ADDRESSES FOLLOW - DO NOT CHANGE THE ORDER
;
DEV: LSR ;LOW SPEED READER
     HSR ;HIGH SPEED READER

.SBTTL CASSETTE BOOT

```



```

1392
1393
1394
1395      177500
1396
1397 007500 012700 177500
1398 007504 005010
1399 007506 010701
1400 007510 062701 000052
1401 007514 012702 000375
1402 007520 112103
1403
1404 007522 112110
1405 007524 100413
1406 007526 130310
1407 007530 001776
1408 007532 105202
1409 007534 100772
1410 007536 116012 000002
1411 007542 120337 000000
1412 007546 001767
1413 007550 000000
1414 007552 000755
1415
1416 007554 005710
1417 007556 100774
1418 007560 005007
1419
1420 007562 017640
1421
1422 007564 002415
1423
1424 007566 112024
1425
1426 007570 000000 000000
1427 007574 167500
1428 007576 000340
1429
1430
1431

; CASSETTE BOOT
TACS=177500
;TA-11 CONTROL AND STATUS REGISTER
;=ORIGIN+1500
TABOOT: MOV #TACS,R0
        CLR (R0)
        ;SELECT UNIT #0
RES:     MOV PC,R1
        ;USE FOR PIC
        ADD #TABLE--,R1
        ;R1 HOLDS ADDR. OF COMMAND TABLE
        MOV #375,R2
        ;MEMORY PTR. AND DATA FLAG
        MOVB (R1)+,R3
        ;TEST BITS

LOOP1:  MOVB (R1)+,(R0)
        ;COMMAND FROM TABLE TO TACS
        BMI DONE
        ;WHEN COMMAND CODE NEG., QUIT
NOP2:   BITB R3,(R0)
        ;TEST READY AND T-REQ BITS IN TACS
        BEQ LOOP2
        ;LOOP 'TIL SOMETHING COMES UP
        INCB R2
        ;ADVANCE MEMORY POINTER
        BMI LOOP1
        ;IF MINUS, TRY NEXT COMMAND
        MOVB 2(R0),(R2)
        ;READ DATA INTO MEMORY
        CMPB R3,#0
        ;FIRST BYTE READ SHOULD BE '240'
        BEQ LOOP2
        ;IF O.K., GO READ ANOTHER BYTE
STOP:   HALT
        ;HALT ON ERROR
        BR RES
        ;RESTART ON CONTINUE

DONE:   TST (R0)
        ;CHECK FOR ERROR
        BMI STOP
        ;HALT ON ERROR
        CLR PC
        ;= 'JMP #0'

TABLE:  .WORD 17640
        ;.BYTE 240: READY+T-REQ.
        .WORD 2415
        ;.BYTE 37: ILBS+READY+GO
        .WORD 112024
        ;.BYTE 15: SFB+GO
        .WORD 0,0
        ;.BYTE 5: READ+GO
        .WORD TABOOT,160000
        ;.BYTE 24: READ+ILBS
        .WORD 340
        ;.BYTE 224: READ+ILBS+E.O.TABLE
        ;THESE ARE FILLER WORDS
        ;POWER UP VECTOR AND PRIORITY
;
.SBTTL MR11-DB BOOT

```

```

1433      :MR11-DB BULK STORAGE PROGRAM LOADER LISTING
1434
1435      :      .=ORIGIN+1600      ;KEEP TRACK OF ORIGIN
1436
1437 007600 010702      RF11:  MOV PC,R2      ;FIXED HEAD DISK (256 KW)
1438 007602 000451      BR OTHER
1439 007604 177462      177462
1440 007606 000005      5
1441
1442 007610 010702      RK11:  MOV PC,R2      ;MOVING HEAD DISK (CARTRIDGE)
1443 007612 000445      BR OTHER
1444 007614 177406      177406
1445 007616 000005      5
1446
1447
1448 007620 010702      TC11:  MOV PC,R2
1449 007622 000417      BR TAPES
1450 007624 177344      177344      ;ADDRESS OF WORD COUNT
1451 007626 000005      5      ;LAST COMMAND
1452 007630 004003      4003      ;FIRST COMMAND
1453 007632 100000      100000      ;DONE MASK
1454 007634 024000      24000      ;ERROR MASK
1455
1456
1457 007636 010702      TM11:  MOV PC,R2
1458 007640 000410      BR TAPES
1459 007642 172524      172524      ;ADDRESS OF BYTE COUNT
1460 007644 060003      60003      ;LAST COMMAND
1461 007646 060011      60011      ;FIRST COMMAND
1462 007650 000200      200      ;DONE MASK
1463 007652 100000      100000      ;ERROR MASK
1464
1465
1466 007654 010702      RP11:  MOV PC,R2      ;MOVING HEAD DISK (PACK)
1467 007656 000423      BR OTHER
1468 007660 176716      176716
1469
1470
1471 007662 000005      TAPES:  RESET
1472 007664 010200      MOV R2,R0      ;GET THE ADDRESS OF THE BRANCH
1473 007666 005720      TST (0)+      ;R0 TO POINT AT LAST COMMAND
1474 007670 012001      MOV (0)+,R1      ;GET THE WORD COUNT ADDRESS
1475 007672 005311      DEC (1)      ;SET UP FOR ADVANCE 1 RECORD
1476 007674 005720      TST (0)+      ;MOVE R0 TO FIRST COMMAND
1477 007676 012041      MOV (0)+,-(1)      ;COMMAND WORD TO COMMAND REG.
1478 007700 031011      BIT (0),(1)      ;LOOK FOR DONE INDICATORS
1479 007702 001776      BEQ -2      ;NONE SET, TRY AGAIN
1480 007704 005720      TST (0)+      ;DONE FIRST COMMAND, CHECK FOR ERROR
1481 007706 031041      BIT (0),-(1)      ;LOOK FOR SET ERROR BITS
1482 007710 001406      BEQ OTHER      ;NO ERRORS - TRY THE READ
1483 007712 000112      AGAIN:  JMP (2)      ;RERUN FOR ERRORS
1484
1485
1486 007714 167600      RFVEC:  RF11:160000      ;RF11 POWER UP VECTOR
1487 007716 000340      340
1488

```


1489 007720 010702
 1490 007722 000401
 1491 007724 177450
 1492
 1493
 1494 007726 000005
 1495 007730 010200
 1496 007732 005720
 1497 007734 012001
 1498 007736 012711 177000
 1499 007742 011041
 1500 007744 032711 100200
 1501 007750 001775
 1502 007752 100757
 1503 007754 005007
 1504
 1505 007756 000000
 1506 007760 167610
 1507 007762 000340
 1508 007764 167720
 1509 007766 000340
 1510 007770 167654
 1511 007772 000340
 1512 007774 167620
 1513 007776 000340
 1514
 1515
 1516

RC11: MOV PC,R2 ;FIXED HEAD DISK (64KW)
 BR OTHER
 177450 ;ADRS OF WORD COUNT (COMMAND+2)
 ;COMMAND WORD (5) IS THE RESET

OTHER: RESET
 MOV R2,R0 ;R0 TO POINT AT WORD COUNT ADRS
 TST (0)+ ;POINT TO ADDRESS
 MOV (0)+,R1 ;WORD COUNT ADDRESS TO R1
 MOV #-1000,(1) ;LOAD WORD COUNT
 MOV (0),-(1) ;COMMAND TO COMMAND REGISTER
 BIT #100200,(1) ;CHECK FOR ERROR OR DONE
 BEQ .-4 ;IF NEITHER, KEEP LOOKING
 BMI AGAIN ;ERROR, TRY AGAIN
 CLR PC

0 ;FILLER

RKVEC: RK11!160000 ;RK POWER UP VECTOR
 340

RCVEC: RC11!160000 ;RC POWER UP VECTOR
 340

RPVEC: RP11!160000 ;RP POWER UP VECTOR
 340

TCVEC: TC11!160000 ;TC11 POWER UP VECTOR
 340

.SBTTL ROM VERSION 1 VALUES
 .PAGE

```
1517          .DSABL AMA
1518
1519      ;DATA PATTERN STORED IN THE GT40 BOOTSTRAP VERSION 1
1520
1521      ;      ***** THIS IS A IMAGE LISTING OF THE GT40 <VT40> BOOTSTRAP *****
1522      ;
1523      ;      THE DATA IS A MIRROR IMAGE OF THAT IN THE BOOTSTRAP ROMS
1524      ;      ONLY THE ADDRESS FIELD IS CHANGED
1525
1526      ;BOOTVT.S09 5/2/72      <SPECIAL>
1527
1528
1529      ;      VT-40 BOOTSTRAP LOADER, VERSION S09, RELEASE R01, 5/2/72
1530
1531      ;      COPYRIGHT 1972, DIGITAL EQUIPMENT CORPORATION.
1532      ;      146 MAIN STREET
1533      ;      MAYNARD, MASSACHUSSETTS
1534      ;
1535      ;
1536      ;
1537      ;      WRITTEN BY JACK BURNES, SENIOR SYSTEMS ARCHITECT!
1538
1539
1540
1541
1542      ;      THIS ROUTINE IS INTENDED TO BE LOADED IN THE ROM PORTION OF THE VT-40.
1543
1544
1545      ;      REGISTER DEFINITIONS:
1546
1547      000000      R0=%0
1548      000001      R1=%1
1549      000002      R2=%2
1550      000003      R3=%3
1551      000004      R4=%4
1552      000005      R5=%5
1553      000006      R6=%6
1554      000007      R7=%7
1555
1556      000006      SP=R6
1557      000007      PC=R7
1558
1559      000000      RET1=R0      ;RETURN OF VALUE REGISTER.
1560      000001      INP1=R1      ;ARGUMENT FOR CALLED FUNCTION
1561      000002      INP2=R2      ;SECOND ARGUMENT.
1562      000003      WORK1=R3      ;FIRST WORK REGISTER.
1563      000004      WORK2=R4      ;SECOND WORKING REGISTER.
1564      000005      SCR1=R5      ;SCRATCH REGISTER.
1565
1566      000003      LCKSM=WORK1      ;OVERLAPPING DEFINITIONS FOR LOADER PORTION.
1567      000000      LBYT=RET1
1568      000005      LBC=SCR1
1569      000001      LADR=INP1
1570
1571
1572
```

1573									
1574		036000		COREND=36000					;FIRST LOCATION OF NON-CORE.
1575		166000		ROMORG=166000					;WHERE THE ROM PROGRAM SHOULD GO.
1576									
1577		000000		STARTX=0					;WHERE TO START DISPLAYING THE X POSITIONS.
1578		001360		STARTY=1360					;WHERE TO START DISPLAYING THE Y.
1579									
1580									
1581		022000		VT40PC=172000-150000					;VT40 PROGRAM COUNTER.
1582		027560		KBDIS=27560					;TTY INPUT STATUS.
1583		025614		P100S=25614					;PDP-10 OUTPUT STATUS.
1584		025610		P10IS=25610					;PDP-10 INPUT STATUS.
1585									
1586		027562		KBDIB=KBDIS+2					;TTY INPUT BUFFER.
1587		025612		P10IB=P10IS+2					;PDP-10 INPUT CHARACTER.
1588		025616		P10OB=P100S+2					;PDP-10 OUTPUT BUFFER.
1589									
1590									
1591		045776		P100C=COREND-2+10000					;CHARACTER TO BE SENT TO THE PDP-10
1592		045772		P10IC=P100C-4					;INPUT CHARACTER FROM 10 PLUS ONE SAVE CHARACTER
1593		015770		STKSRT=P10IC-2-30000					;FIRST LOCATION OF STACK.
1594									
1595									
1596		160000		JMPDIS=160000					;THE VT-40 DISPLAY JUMP INSTRUCTION.
1597									
1598									
1599		000024		PWRFAL 24					;POWER FAIL RESTART LOCATION.
1600									
1601									
1602									
1603									
1604									
1605									
1606									
1607									
1608									
1609									
1610									
1611		016000		. =16J00					
1612				; .-ROMORG					;SET THE ORIGIN NOW...!
1613									
1614									
1615									
1616									
1617									
1618									
1619									
1620	016000	012705	000026	STARTA: MOV	#PWRFAL+2,SCR1				;PICK UP POINTER TO P.F. STATUS.
1621	016004	005015		CLR	@SCR1				;CLEAR IT OUT TO BE SURE.
1622	016006	010745		MOV	PC,-(SCR1)				;SET UP THE RESTART LOCATION.
1623									
1624	016010	000005		RESET					;RESET THE BUS.
1625									
1626	016012	012767	000007	007570	MOV	#7,P10IS			;INITIALIZE PDP-10 INPUT
1627	016020	012767	000001	011532	MOV	#1,KBDIS			;INITIALIZE TTY INPUT.
1628	016026	012767	000201	007560	MOV	#201,P100S			;INITIALIZE PDP-10 OUTPUT.

1629							
1630							
1631							
1632	016034	012706	015770	RSTRT:	MOV	#STKSRT,SP	;SET UP THE STACK NOW!
1633	016040	005001			CLR	LADR	;CLEAR ADDRESS POINTER.
1634	016042	012702	160000		MOV	#JMPDIS,INP2	;PLACE A DISPLAY JUMP INSTRUCTION IN A REGISTER.
1635	016046	010221			MOV	INP2,(LADR)+	;MOVE IT TO LOCATION 0.
1636	016050	012711	166756		MOV	#DISPRG+150000,(LADR)	;MOVE ADDRESS POINTER INTO 2.
1637	016054	012701	000030		MOV	#PWRFAL+4,LADR	;SET UP WHERE WE WILL STORE CHARACTERS.
1638	016060	005000			CLR	RET1	;PREPARE TO INSERT A ZERO CHARACTER.
1639	016062	004767	000022		JSR	PC,DOCHAR	;INSERT IT NOW.
1640	016066	005067	003706		CLR	VT40PC	;CLEAR THE DISPLAY PROGRAM COUNTER AND START.
1641							
1642	016072	004767	000210	MAJOR:	JSR	PC,GTCHR	;GT A CHARACTER NOW.
1643	016076	000240			NOP		
1644	016100	000240			NOP		
1645	016102	000240			NOP		
1646	016104	012746	166072		MOV	#MAJOR+150000,-(SP)	;INSERT IN DISPLAY BUFFER NOW.
1647							
1648	016110	010105		DOCHAR:	MOV	LADR,SCR1	;GT CURRENT BUUFER POSITION NOW.
1649	016112	022525			CMP	(SCR1)+,(SCR1)+	;BYPASS CURRENT DISPLAY JUMP.
1650	016114	005025			CLR	(SCR1)+	;CLEAR FUTURE ADDRESS FOR JUMP.
1651	016116	010225			MOV	INP2,(SCR1)+	;STICK IN TEMPORARY JUMP WHILE WE REPLACE CURREN
1652	016120	005015			CLR	(SCR1)	;A DISPLAY JUMP TO ZERO.
1653	016122	005011			CLR	(LADR)	;NOW REPLACE CURRENT DISPLAY JUMP BY THE CHARACT
1654	016124	050021			BIS	RET1,(LADR)+	;IT'S DONE THIS WAY TO WASTE 2 CYCLES.
1655	016126	010211			MOV	INP2,(LADR)	;TO AVOID TIMING PROBLEMS WITH THE VT40.
1656	016130	000207			RTS	PC	;AND FINALLY RETURN.
1657							
1658							
1659							
1660							
1661							
1662							
1663							
1664							
1665							
1666							
1667							
1668							
1669							
1670							
1671							
1672							
1673	016132	004767	000124	GT8:	JSR	PC,GTSIX	;GT SIX BITS NOW.
1674	016136	010046			MOV	RET1,-(SP)	;SAVE THE CHARACTER NOW.
1675	016140	000401			BR	GTP84	;BYPASS THE 8'ER
1676	016142	005002		GT84:	CLR	INP2	;RESET THE MAGIC REGISTER NOW.
1677	016144	005722		GTP84:	TST	(INP2)+	;INCREMENT WHERE TO GO.
1678	016146	066207	166250		ADD	GT8TB+150000(INP2),PC	;UPDATE PC NOW.
1679							
1680		016152		GT8P=.			
1681							
1682	016152	004767	000104	GT81:	JSR	PC,GTSIX	;GT A CHARACTER NOW.
1683	016156	010004			MOV	RET1,WORK2	;SAVE FOR A SECOND.
1684	016160	006300			ASL	RET1	

1685	016162	006300		ASL	RET1	;SHIFT TO LEFT OF BYTE
1686	016164	106300		ASLB	RET1	
1687	016166	106116		ROLB	@SP	;PACK THEM IN.
1688	016170	106300		ASLB	RET1	
1689	016172	106116		ROLB	@SP	;A GOOD 8 BIT THING.
1690	016174	012600		MOV	(SP)+,RET1	;POP AND RETURN NOW.
1691	016176	000207		RTS	PC	
1692						
1693	016200	006300	GT82:	ASL	RET1	;WORST CASE. SHIFT 4
1694	016202	006300		ASL	RET1	
1695	016204	106300		ASLB	RET1	
1696	016206	106104		ROLB	WORK2	
1697	016210	106300		ASLB	RET1	
1698	016212	106104		ROLB	WORK2	
1699	016214	106300		ASLB	RET1	
1700	016216	106104		ROLB	WORK2	
1701	016220	106300		ASLB	RET1	
1702	016222	106104		ROLB	WORK2	
1703	016224	010400		MOV	WORK2,RET1	
1704	016226	012604		MOV	(SP)+,WORK2	
1705	016230	000207		RTS	PC	
1706						
1707	016232	006100	GT83:	ROL	RET1	
1708	016234	006100		ROL	RET1	
1709	016236	006004		ROR	WORK2	
1710	016240	106000		RORB	RET1	
1711	016242	006004		ROR	WORK2	
1712	016244	106000		RORB	RET1	;FINAL CHARACTER ASSEMBLED.
1713	016246	005726		TST	(SP)+	;FUDGE STACK.
1714	016250	000207		RTS	PC	;AND RETURN NOW.
1715						
1716		016250	GT8TB	=	.-2	;PUSH ZERO CONDITION BACK INTO NEVER-NEVER LAND.
1717						
1718	016252	000000		.WORD	GT81-GT8P	
1719	016254	000026		.WORD	GT82-GT8P	
1720	016256	000060		.WORD	GT83-GT8P	
1721	016260	177770		.WORD	GT84-GT8P	
1722						
1723						
1724	016262	004767	000020	GTSEX:	JSR	PC,GTCHR
1725	016266	020027	000040		CMP	RET1,#40
1726	016272	002546			BLT	LBAD
1727	016274	020027	000137		CMP	RET1,#137
1728	016300	003143			BGT	LBAD
1729	016302	000207			RTS	PC
1730						
1731						
1732						
1733	016304	005726	GTCHP:	TST	(SP)+	;UPDATE THE STACK.
1734						
1735	016306	012700	015772	GTCHR:	MOV	#P10IC-30000,RET1
1736	016312	004767	000064	GTCHL:	JSR	PC,CHECK
1737	016316	005710			TST	@RET1
1738	016320	001774			BEQ	GTCHL
1739	016322	011046			MOV	@RET1,-(SP)
1740	016324	005020			CLR	(RET1)+

1741	016326	042716	177600		BIC	#-200,(SP)	;CLEAR AWAY PARITY NOW.
1742	016332	001764			BEQ	GTCHP	;IF ZERO, GT ANOTHER
1743	016334	022716	000177		CMP	#177,(SP)	
1744	016340	001761			BEQ	GTCHP	;ALSO IGNORE RUBOU'S.
1745	016342	022710	000175		CMP	#175,@RET1	;WAS IT A '175'
1746	016346	001007			BNE	GTNP	;NOPE.
1747	016350	011610			MOV	(SP),@RET1	;YEP. RESET IN CASE OF ABORT.
1748	016352	021027	000122		CMP	@RET1,#122	;IS IT AN R
1749	016356	001626			BEQ	RSTRT	;YEP. RESTART
1750	016360	021027	000114		CMP	@RET1,#114	;IS IT AN L
1751	016364	001455			BEQ	LOAD	;YEP. LOAD.
1752							
1753	016366	011610			GTNP: MOV	(SP),@RET1	;NOW DO THE FDUGING.
1754	016370	012600			MOV	(SP)+,RET1	
1755	016372	020027	000175		CMP	RET1,#175	
1756	016376	001743			BEQ	GTCHR	;IF ALTMODE, LOOP
1757	016400	000207			RTS	PC	
1758							
1759							
1760							
1761							
1762							
1763							
1764							
1765							
1766	016402	005767	027370		CHECK: TST	P100C	;DO WE WANT TO OUTPUT?
1767	016406	001410			BEQ	CHECK1	;NO.
1768	016410	105767	007200		TSTB	P100S	;WE DO. IS THE 10 READY?
1769	016414	100005			BPL	CHECK1	;NOT QUITE.
1770	016416	016767	027354	007172	MOV	P100C,P100B	;IT'S READY. SEND THE CHARACTER.
1771	016424	005067	027346		CLR	P100C	;AND THE SAVED CHARACTER.
1772							
1773	016430	105767	011124		CHECK1: TSTB	KBDIS	;HEY, IS THE KEYBOARD READY?
1774	016434	100014			BPL	CHECK3	;NOPE. NO LUCK.
1775	016436	116746	011120		MOVB	KBDIB,-(SP)	;YEP. SAVE THE CHARACTER NOW.
1776	016442	012767	000001	011110	MOV	#1,KBDIS	;AND REENABLE THE COMMUNICATIONS DEVICE.
1777							
1778	016450	004767	177726		CHECK2: JSR	PC,CHECK	;IS THE OUTPUT READY?
1779	016454	005767	027316		TST	P100C	
1780	016460	001373			BNE	CHECK2	;IF NOT, WAIT TILL DONE.
1781	016462	012667	007130		MOV	(SP)+,P100B	;AND THEN SEND OUT THE CHARACTER.
1782							
1783							
1784	016466	105767	007116		CHECK3: TSTB	P101S	;IS THE 10 TALKING TO ME.
1785	016472	100011			BPL	CHECK4	;NOPE. EXIT.
1786	016474	116767	007112	027270	MOVB	P101B,P101C	;GT THE CHARACTER NOW.
1787	016502	052767	177400	027262	BIS	#-400,P101C	;MAKE SURE IT'S NONE ZERO.
1788	016510	012767	000007	007072	MOV	#7,P101S	;REINITIALIZE COMMUNICATION LINE.
1789							
1790	016516	000207			CHECK4: RTS	PC	;AND RETURN.
1791							
1792							
1793							
1794							
1795							
1796							


```

1797
1798
1799
1800
1801
1802
1803
1804
1805
1806
1807
1808
1809 016520 005002
1810 016522 012712 172000
1811 016526 012706 015770
1812
1813 016532 005003
1814 016534 004767 000070
1815 016540 105300
1816 016542 001373
1817 016544 004767 000060
1818
1819 016550 004767 000072
1820 016554 010005
1821 016556 162705 000004
1822 016562 022705 000002
1823 016566 001437
1824 016570 004767 000052
1825 016574 010001
1826
1827 016576 004767 000026
1828 016602 002010
1829 016604 105703
1830 016606 001751
1831
1832 016610 012700
1833
1834 016612 102 175
1835 016614 004767 000110
1836 016620 000167 177210
1837
1838 016624 110021
1839 016626 000763
1840
1841 016630 004767 177276
1842 016634 060003
1843 016636 042700 177400
1844 016642 005305
1845 016644 000207
1846
1847 016646 004767 177756
1848 016652 010046
1849 016654 004767 177750
1850 016660 000300
1851 016662 052600
1852 016664 000207

```

; THE L O A D E R

LOAD: CLR INP2 ;RESET TO FIRST 8 BIT CHARACTER.
MOV #172000,(INP2) ;AND ALSO CLEVERLY STOP THE VT40.
MOV #STKSRT,SP ;RESET STACK POINTER NOW.

LLD2: CLR LCKSM ;CLEAR THE CHECKSUM
JSR PC,LPTR ;GT A BYTE NOW.
DECB LBYT ;IS IT ONE?
BNE LLD2 ;NOPE. WAIT AWHILE
JSR PC,LPTR ;YEP. GT NEXT CHARACTER.

JSR PC,LGWRD ;GT A WORD.
MOV LBYT,LBC ;GT THE COUNTER NOW.
SUB #4,LBC ;CHOP OFF EXTRA STUFF.
CMP #2,LBC ;NULL?
BEQ LJMP ;YEP. MUST BE END.
JSR PC,LGWRD ;NOPE. GT THE ADDRESS.
MOV LBYT,LADR ;AND REMEMBER FOR OLD TIMES SAKE.

LLD3: JSR PC,LPTR ;GT A BYTE (DATA)
BGE LLD4 ;ALL DONE WITH THE COUNTER?
TSTB LCKSM ;YEP. GOOD CHECK SUM?
BEQ LLD2 ;NOPE. LOAD ERROR.

LBAD: MOV (PC)+,RET1 ;SEND OUT SOME CHARACTERS NOW.
; .BYTE 175,102 ;'CTRL BAD'
; .BYTE 102,175 ;'BAD CTRL'
JSR PC,SENDIT
JMP RSTRT

LLD4: MOVB LBYT,(LADR)+
BR LLD3 ;PLACE THE BYTE IN CORE.
;GT ANOTHER ONE.

LPTR: JSR PC,GT8 ;GT 8 BITS NOW.
ADD LBYT,LCKSM ;UPDATE CHECKSUM
BIC #177400,LBYT ;CLEAN UP THE BYTE NOW.
DEC LBC ;UPDATE THE COUNTER.
RTS PC ;RETURN NOW.

LGWRD: JSR PC,LPTR ;GT A CHARACTER.
MOV LBYT,-(SP) ;SAVE FOR A SECOND.
JSR PC,LPTR ;GT ANOTHER CHARACTER.
SWAB LBYT ;NOW ASSEMBLE THE WORD.
BIS (SP)+,LBYT ;AND RETURN WITH A 16 BITER.
RTS PC

1853					
1854	016666	004767	177754	LJMP:	JSR PC, LGWRD ;GT A WORD
1855	016672	010046			MOV LBYT, -(SP) ;SAVE ON THE STACK.
1856	016674	004767	177730		JSR PC, LPTR ;GT A CHARACTER.
1857	016700	105703			TSTB LCKSM ;IS IT ZERO?
1858	016702	001342			BNE LBAD ;YEP. WHAT CRAP.
1859	016704	032716	000001		BIT #1, (SP) ;IS IT ODD?
1860	016710	001406			BEQ LJMP1 ;YEP. START PROGRAM GOING NOW.
1861	016712	012700			MOV (PC)+, RET1 ;TELL PDP-10 WE'VE LOADED OK.
1862				:	.BYTE 175, 107 ;'CTRL GOOD'
1863	016714	107	175		.BYTE 107, 175 ;'GOOD CTRL'
1864	016716	004767	000006		JSR PC, SENDIT
1865	016722	000000			HALT
1866	016724	000776			BR .-2
1867					
1868	016726	000136		LJMP1:	JMP @ (SP)+ ;AND AWAY WE GO.
1869					
1870					
1871					
1872					
1873					
1874					
1875					
1876					
1877					
1878					
1879					
1880					
1881					
1882					
1883					
1884					
1885					
1886	016730	004767	177446	SENDIT:	JSR PC, CHECK ;POLL THE OUTPUT DEVICE NOW.
1887	016734	005767	027036		TST P100C ;OUTPUT CLEAR?
1888	016740	001373			BNE SENDIT ;NOPE. LOOP AWHILE LONGER.
1889	016742	010067	006650		MOV RET1, P100B ;SEND OUT THE CHARACTER.
1890	016746	105000			CLRB RET1 ;CLEAR THE BYTE.
1891	016750	000300			SWAB RET1 ;AND SWAP THEM NOW.
1892	016752	001366			BNE SENDIT ;IF NOT EQUAL, REPEAT.
1893	016754	000207			RTS PC
1894					
1895					
1896					
1897					
1898					
1899					
1900					
1901					
1902					
1903					
1904					
1905					
1906					
1907					
1908					

1909
1910
1911
1912
1913
1914
1915
1916
1917
1918
1919
1920
1921
1922
1923
1924
1925
1926
1927
1928
1929
1930
1931
1932
1933
1934
1935
1936
1937
1938
1939
1940
1941

016756 170256
016760 115124
016762 000000
016764 001360
016766 100000
016770 160000
016772 000030
016774 000000
016776 000000

000001

DISPRG: .WORD 170256
 .WORD 115124
 .WORD STARTX
 .WORD STARTY
 .WORD 100000
 .WORD JMPDIS
 .WORD PWRFAL+4
 .WORD 0
 .WORD 0

.END

: THIS IS THE INITIALIZING VT40 PROGRAM WHICH WILL
: JUMP TO THE PROGRAM AFTER THE POWER FAIL LOCATIONS
: WHICH WILL JUMP TO ZERO WHICH WILL JUMP BACK TO HERE.

:LOAD STATUS REGISTER FOR NORMAL OPERATION.
:SET POINT MODE, 'NORMAL'.
:X COORDINATE
:Y COORDINATE
:SET CHARACTER MODE.
:THEN JUMP TO THE POWERFAIL LOCATION.
:TO DISPLAY USERS CHARACTERS.

AGAIN	007712	1483#	1502						
ALTMOD=	000175	682#	1003	1163	1196				
BELL	006250	823	855#						
BLIMIT=	007000	675#	678	768	789	874	893	940	944
BLKOFF=	000020	1244#	1280						
BLKON =	000030	1245#	1315						
BSTART=	001000	674#	876	896	913	943			
CHAR =	100000	625#							
CHARA	001034	208#	408*	409	415	431			
CHECK	016402	1736	1766#	1778	1886				
CHECK1	016430	1767	1769	1773#					
CHECK2	016450	1778#	1780						
CHECK3	016466	1774	1784#						
CHECK4	016516	1785	1790#						
COREND=	036000	1574#	1591						
CORSTR=	000004	677#	737						
CR	006206	832#							
CRLF =	005015	681#	771						
DEV	007474	1361	1386#						
DEV1	007422	1364#	1366						
DISJMP=	160000	684#	904	942	943	944	960		
DISPRG	016756	1636	1919#						
DISTOP=	173000	685#	1012	1135					
DJMP =	160000	1252#	1347						
DL11IB=	175612	663#	664	982					
DL11IS=	175610	662#	663	730*	980	983*			
DL11OB=	175616	665#	990*	1037*	1038*				
DL11OS=	175614	664#	665	733*	751	753*			
DNOP =	164000	1253#							
DOCHAR	016110	1639	1648#						
DONE	007554	1405	1416#						
DONE0	001536	344#							
DONE1	001610	351	358#						
DSR	001006	197#	343*						
DSTOP =	173400	1255#							
DSWR =	177570	182#	187	505					
DUMP	001032	207#	226*	229*	247*	249*	250	255*	
D2BTYP	002230	376*	380*	459#	464				
END	001524	342#							
ENDCOR	006036	740#	741						
ERROR1	001136	223	234#						
ERROR2	001210	252#							
ERRVEC=	000004	183#	503	504*	511*				
FF	006256	828	858#						
FFLOOP	006262	853	860#	863					
FILCNT	001026	205#	420*	425*					
FILE0	007214	1277	1280#	1348					
FILLER	001024	204#	420						
GETCHR	006564	811	1002#	1024					
GETDL	006516	980#	985	989	991	1002	1006		
GETDL1	006546	981	988#						
GETEXT	006650	1004	1010	1030#					
GETSIX	006630	1024#	1062	1077					
GET8	006664	1062#	1172						
GET8TB	006700	1065	1067#						
GET81	006712	1067	1077#						

GET82	006740	1068	1089#						
GET83	006772	1069	1104#						
GET84	006706	1073#							
GRAPHX=	120000	1229#	1329						
GRAPHY=	124000	1230#	1340						
GTBUSE	006424	913#	936						
GTCHL	016312	1736#	1738						
GTCHP	016304	1733#	1742	1744					
GTCHR	016306	1642	1724	1735#	1756				
GTNP	016366	1746	1753#						
GTP84	016144	1675	1677#						
GTSIX	016262	1673	1682	1724#					
GT40PC=	172000	670#	671	913*	947	1277*			
GT40SR=	172002	671#	855*						
GT8	016132	1673#	1841						
GT8P =	016152	1680#	1718	1719	1720	1721			
GT8TB =	016250	1678	1716#						
GT81	016152	1682#	1718						
GT82	016200	1693#	1719						
GT83	016232	1707#	1720						
GT84	016142	1676#	1721						
HEADER	006474	903	942	948	954#				
HSR =	177550	1355#	1387						
ICNT	001030	206#	215*	342*					
ICOUNT	002210	440	447#						
IMAGE	001004	196#	315	515*	518*				
INCR =	000100	1266#	1324						
INSERT	006350	836	844	882	890#				
INSRTL	006406	894	897	902#					
INSRTX	006422	892	907#						
INTX =	040000	1267#	1285	1289	1293	1297			
INT0 =	002000	1233#	1284						
INT1 =	002200	1234#	1303						
INT2 =	002400	1235#	1288						
INT3 =	002600	1236#	1305						
INT4 =	003000	1237#	1292	1315					
INT5 =	003200	1238#	1307						
INT6 =	003400	1239#	1296						
INT7 =	003600	1240#	1309						
ITAL0 =	000040	1259#							
ITAL1 =	000060	1260#							
JMPADD=	007012	678#	870	881*	960	1012*	1135*		
JMPDIS=	160000	1596#	1634	1924					
KBDIB =	027562	668#	990	1586#	1775				
KBDIS =	027560	667#	668	988	1582#	1586	1627*	1773	1776*
LBAD	016610	1726	1728	1832#	1858				
LF	006300	826	867#						
LFLOOP	006310	872#	875	877					
LFOUND	006330	873	879#						
LFSUB	006304	861	870#						
LGWRD	016646	1819	1824	1847#	1854				
LINE0 =	000004	1247#	1284						
LINE1 =	000005	1248#	1288						
LINE2 =	000006	1249#	1292						
LINE3 =	000007	1250#	1296						
LJMP	016666	1823	1854#						

LJMP1	016726	1860	1868#						
LLD2	016532	1813#	1816	1830					
LLD3	016576	1827#	1839						
LLD4	016624	1828	1838#						
LOAD	016520	1751	1809#						
LOADER	007012	1008	1135#						
LOGICA	001600	174	354#						
LONGV =	110000	1227#	1284	1288	1292	1296			
LOOP	007444	1373#	1380						
LOOP1	007522	1404#	1409						
LOOP2	007526	1406#	1407	1412					
LPUARK=	000200	1258#							
LPLITE=	000300	1257#							
LPOFF =	000100	1242#							
LPON =	000140	1243#							
LFTR	016630	1814	1817	1827	1841#	1847	1849	1856	
LSR =	177560	1356#	1386						
L.BAD	007100	1026	1028	1162#	1193				
L.GWRD	007126	1147	1152	1179#	1189				
L.HALT	007200	1201#							
L.JMP	007146	1151	1189#						
L.JMP1	007202	1199	1203#						
L.LD2	007022	1140#	1143	1159					
L.LD3	007066	1156#	1168						
L.LD4	007110	1157	1167#						
L.PTR	007114	1141	1145	1156	1172#	1179	1181	1191	
MAJOR	016072	1642#	1646						
MAXSX =	017600	1272#							
MAXSY =	000077	1273#							
MAXX =	001777	1268#	1285	1293					
MAXY =	001377	1269#	1282	1290	1298				
MINSUY=	000100	1274#							
MINUSX=	020000	1270#	1271	1290	1293				
MINUSY=	020000	1271#							
M7	002336	370	489#						
M8	002361	368	391	394	396	490#			
M9	002365	379	491#						
NORMAL	006212	815	824	836#					
NOTHER	006042	738	744#						
NUMLIN=	000040	679#	768	769	858	944			
NXTCHR	006132	811#	813	819	838	848	856	864	867
ORIGIN=	166000	660#							
OTHER	007726	1438	1443	1467	1482	1490	1494#		
OUTLIT	006652	734	1037#	1162	1195				
O2A	002232	377	381	460#					
O2AA	002262	469#	481						
POINT =	114000	1228#	1280	1300	1312	1321	1325	1336	
PRESTR	006624	1013#	1164						
PRGO	001050	215#	358						
PRGOR	001054	216#	217						
PRG1	001614	190	364#	398					
PRG1A	001652	372#							
PRG1B	001670	376#	392						
PRG1C	001706	380#	388						
PRG1D	001756	386	393#						
PRMTRS	001040	189	210#						

[illegible]

SCROLLING ROM BOOTSTRAP FOR THE GT40
CDGTDD.P11 31-AUG-79 11:12

MACY11 30G(1063) 31-AUG-79 12:59 PAGE 17-4
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0045

TAB	006222	825	843#	847															
TABLE	007562	1400	1420#																
TABLEX	002652	324	542#																
TABLEO	002536	321	523#																
TABOOT	007500	1397#	1427																
TACS =	177500	1395#	1397																
TAPES	007662	1449	1458	1471#															
TCVEC	007774	1512#																	
TC11	007620	1448#	1512																
TERM	001036	209#	407*	409															
IMPEND=	007776	676#	731	765															
TM11	007636	1457#																	
TPCSR =	177564	179#	345	348	374	382	412	417	423	429	460	470	485*						
TPDBR =	177566	180#	344*	347*	384*	419*	422*	427*	431*	472*									
TYPEM	001776	367	369	378	390	393	395	405#											
TYPEMA	002006	408#	428	432															
TYPEMB	002034	410	415#																
TYPEMC	002122	416	429#																
T1	001066	221#																	
T1A	001104	224#	232	237															
T1B	001150	233	238#																
T2	001152	244#																	
T2A	001170	247#	254	272															
T2B	001220	251	255#	259															
T2C	001236	256	260#	264															
T2D	001252	261	265#	269															
T2E	001266	266	270#																
T3	001276	280#																	
T3A	001320	284#	287																
T3AA	001312	283#	303																
T3B	001332	283	288#																
T3C	001342	290#	293																
T3D	001354	288	294#																
T3E	001364	296#	299																
T3F	001400	294	300#																
T4	001420	314#																	
T4A	001434	317#	334	339															
T4B	001450	322#	327																
T4C	001470	323	328#																
T4D	001500	325	332#																
T4E	001510	320	331	336#															
VT	006244	827	851#																
VT40PC=	022000	1581#	1640*																
WORDS	001002	195#	222	245	282	338	371	514*	517*										
.	- 017000	164#	168	170#	173#	175#	185#	188#	193#	346	375	383	413	418					
		424	430	471	492#	715#	1376	1400	1479	1501	1611#	1680	1716	1866					

. ABS. 017000 000 CON RW ABS LCL I

ERRORS DETECTED: 0

CDGTDD,CDGTDD/CRF-CDGTDD
RUN-TIME: 2 4 .6 SECONDS
RUN-TIME RATIO: 18/7-2.5

SCROLLING ROM BOOTSTRAP FOR THE GT40
CDGTDD.P11 31-AUG-79 11:12

MACY11 30G(1063) 31-AUG-79^{H 4} 12:59 PAGE 17-5
(CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0046

CORE USED: 7k (13 PAGES)