

LN01

PRINTER DIAG
CZLNAA0

AH-T344A-MC
FICHE 1 OF 1

MAY 1983
COPYRIGHT © 1983
MADE IN USA



.REM 8

IDENTIFICATION

PRODUCT CODE : AC-T343A-MC
PRODUCT NAME: CZLNAAO LN01 PRINTER DIAG
MAINTAINER: SMALL SYSTEMS DIAGNOSTICS
PRODUCT DATE: JAN. 1983
AUTHOR: GLENN A. PERNA

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1983 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	

TABLE OF CONTENTS

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.2	SYSTEM REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
1.5	ASSUMPTIONS
2.0	OPERATING INSTRUCTIONS
2.1	COMMANDS
2.2	SWITCHES
2.3	FLAGS
2.4	HARDWARE QUESTIONS
2.5	SOFTWARE QUESTIONS
2.6	EXTENDED P-TABLE DIALOGUE
2.7	QUICK STARTUP PROCEDURE
3.0	ERROR INFORMATION
4.0	PERFORMANCE AND PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
6.0	TEST SUMMARIES

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

THIS DIAGNOSTIC PROGRAM VERIFIES PROPER OPERATION OF THE BASIC LINE PRINTER FUNCTIONS ONLY OF THE LN01 ELECTRONIC PRINTER AND ITS ASSOCIATED M7258 CONTROL UNIT WHICH INTERFACES TO THE PDP-11 CPU. THE BROAD RANGE OF TESTS ASSURES A COMPREHENSIVE TEST OF THE FUNCTIONAL CAPABILITY OF THE PRINTER. THE INDIVIDUAL TESTS ARE IDENTIFIED AS FOLLOWS:

TEST 1	INTERFACE LOGIC
TEST 2	DATA TRANSFER PATHS
TEST 3	PRINTABLE CHARACTERS
TEST 4	NON-PRINTABLE CHARACTERS
TEST 5	PRINT CONTROL
TEST 6	MULTIPLE LINE ADVANCE
TEST 7	OVERSTRIKE TEST
TEST 8	INTERLOCK TEST

THIS DIAGNOSTIC HAS BEEN WRITTEN FOR USE WITH THE DIAGNOSTIC RUNTIME SERVICES SOFTWARE (SUPERVISOR). THESE SERVICES PROVIDE THE INTERFACE TO THE OPERATOR AND TO THE SOFTWARE ENVIRONMENT. THIS PROGRAM CAN BE USED WITH XXDP+ OPERATING SYSTEM.

FOR A COMPLETE DESCRIPTION OF THE RUNTIME SERVICES, REFER TO THE XXDP+ USER'S MANUAL. THERE IS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES IN SECTION 2 OF THIS DOCUMENT.

1.2 SYSTEM REQUIREMENTS

1.2 SYSTEM REQUIREMENTS

A TEST STATION IS REQUIRED CONSISTING OF A PDP-11 CPU WITH A MINIMUM OF 16K WORDS OF MEMORY AND A CONSOLE TERMINAL WITH INTERFACE AT DEVICE ADDRESS 777560. THE SYSTEM ALSO REQUIRES AN XXDP SUPPORTED DEVICE SUCH AS AN RK05/RK11 DISK DRIVE TO AFFORD A MEANS TO LOAD THE DIAGNOSTIC PROGRAM.

1.3 RELATED DOCUMENTS AND STANDARDS

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

THIS DIAGNOSTIC IS COMPATIBLE WITH ALL MEMBERS OF THE PDP-11 COMPUTER FAMILY. THE DIAGNOSTIC IS INTERFACED TO THE PDP-11 DIAGNOSTIC SUPERVISOR THROUGH WHICH IT INTERFACES TO THE ENVIRONMENT.

THE DIAGNOSTIC CAN BE USED IN A VARIETY OF OPERATING SYSTEMS TO FULFILL DIFFERENT REQUIREMENTS. THE DIAGNOSTIC CAN BE

LOADED USING XXDP IN A FIELD SERVICE OPERATION, LOADED USING THE APT/ACT/SLIDE DIAGNOSTIC MONITORS IN A MANUFACTURING ENVIRONMENT, OR MANUALLY LOADED USING PAPER TAPE.

THE APPLICABLE PDP-11 CPU, MEMORY, AND PERIPHERALS SHOULD BE RUN TO VALIDATE PROPER OPERATION OF THE SYSTEM BEFORE RUNNING THIS DIAGNOSTIC.

1.5 ASSUMPTIONS

THE PRINTERS UNDER TEST SHOULD HAVE POWER APPLIED AND BE PLACED ON LINE IN READINESS FOR TESTING. EACH LINE PRINTER MUST HAVE ITS OWN M7258 CONTROLLER SET UP AT A DIFFERENT DEVICE ADDRESS. THE DIAGNOSTIC PROVIDES A DEFAULT DEVICE ADDRESS OF 777514 WHICH CAN BE USED WHEN A SINGLE LINE PRINTER IS BEING TESTED OR FOR THE FIRST UNIT WHEN MULTIPLE LINE PRINTERS ARE UNDER TEST. IT WILL BE NECESSARY FOR THE OPERATOR TO RUN THE LINE PRINTER OFF LINE IN THE SELF TEST MODE BEFORE RUNNING THE DIAGNOSTIC. EACH PRINTER SHOULD BE IN THE 8 BIT MODE

2.0 OPERATING INSTRUCTIONS

THIS SECTION CONTAINS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES. FOR DETAILED INFORMATION, REFER TO THE XXDP+ USER'S MANUAL (CHQUS).

2.1 COMMANDS

THERE ARE ELEVEN LEGAL COMMANDS FOR THE DIAGNOSTIC RUNTIME SERVICES (SUPERVISOR). THIS SECTION LISTS THE COMMANDS AND GIVES A VERY BRIEF DESCRIPTION OF THEM. THE XXDP+ USER'S MANUAL HAS MORE DETAILS.

COMMAND	EFFECT
-----	-----
START	START THE DIAGNOSTIC FROM AN INITIAL STATE
RESTART	START THE DIAGNOSTIC WITHOUT INITIALIZING
CONTINUE	CONTINUE AT TEST THAT WAS INTERRUPTED (AFTER ^C)
PROCEED	CONTINUE FROM AN ERROR HALT
EXIT	RETURN TO XXDP+ MONITOR (XXDP+ OPERATION ONLY!)
ADD	ACTIVATE A UNIT FOR TESTING (ALL UNITS ARE CONSIDERED TO BE ACTIVE AT START TIME)
DROP	DEACTIVATE A UNIT
PRINT	PRINT STATISTICAL INFORMATION (IF IMPLEMENTED BY THE DIAGNOSTIC - SECTION 4.0)
DISPLAY	TYPE A LIST OF ALL DEVICE INFORMATION
FLAGS	TYPE THE STATE OF ALL FLAGS (SEE SECTION 2.3)
ZFLAGS	CLEAR ALL FLAGS (SEE SECTION 2.3)

A COMMAND CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. SO YOU MAY, FOR EXAMPLE, TYPE "STA" INSTEAD OF "START".

2.2 SWITCHES

THERE ARE SEVERAL SWITCHES WHICH ARE USED TO MODIFY SUPERVISOR OPERATION. THESE SWITCHES ARE APPENDED TO THE LEGAL COMMANDS. ALL OF THE LEGAL

SWITCHES ARE TABULATED BELOW WITH A BRIEF DESCRIPTION OF EACH.
IN THE DESCRIPTIONS BELOW, A DECIMAL NUMBER IS DESIGNATED BY "DDDDD".

SWITCH	EFFECT
/TESTS:LIST	EXECUTE ONLY THOSE TESTS SPECIFIED IN THE LIST. LIST IS A STRING OF TEST NUMBERS, FOR EXAMPLE - /TESTS:1:5:7-10. THIS LIST WILL CAUSE TESTS 1,5,7,8,9,10 TO BE RUN. ALL OTHER TESTS WILL NOT BE RUN.
/PASS:DDDDD	EXECUTE DDDDD PASSES (DDDDD = 1 TO 64000)
/FLAGS:FLGS	SET SPECIFIED FLAGS. FLAGS ARE DESCRIBED IN SECTION 2.3.
/EOP:DDDDD	REPORT END OF PASS MESSAGE AFTER EVERY DDDDD PASSES ONLY. (DDDDD = 1 TO 64000)
/UNITS:LIST	TEST/ADD/DROP ONLY THOSE UNITS SPECIFIED IN THE LIST. LIST EXAMPLE - /UNITS:0:5:10-12 USE UNITS 0,5,10,11,12 (UNIT NUMBERS = 0-63)

EXAMPLE OF SWITCH USAGE:

START/TESTS:1-5/PASS:1000/EOP:100

THE EFFECT OF THIS COMMAND WILL BE: 1) TESTS 1 THROUGH 5 WILL BE EXECUTED, 2) ALL UNITS WILL TESTED 1000 TIMES AND 3) THE END OF PASS MESSAGES WILL BE PRINTED AFTER EACH 100 PASSES ONLY. A SWITCH CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. YOU MAY, FOR EXAMPLE, TYPE "/TES:1-5" INSTEAD OF "/TESTS:1-5".

BELOW IS A TABLE THAT SPECIFIES WHICH SWITCHES CAN BE USED BY EACH COMMAND.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

2.3 FLAGS

FLAGS ARE USED TO SET UP CERTAIN OPERATIONAL PARAMETERS SUCH AS LOOPING ON ERROR. ALL FLAGS ARE CLEARED AT STARTUP AND REMAIN CLEARED UNTIL EXPLICITLY SET USING THE FLAGS SWITCH. FLAGS ARE ALSO CLEARED AFTER A START COMMAND UNLESS SET USING THE FLAG SWITCH. THE ZFLAGS COMMAND MAY ALSO BE USED TO CLEAR ALL FLAGS. WITH THE EXCEPTION OF THE START AND ZFLAGS COMMANDS, NO COMMANDS AFFECT THE STATE OF THE FLAGS; THEY REMAIN SET OR

CLEARED AS SPECIFIED BY THE LAST FLAG SWITCH.

FLAG	EFFECT
HOE	HALT ON ERROR - CONTROL IS RETURNED TO RUNTIME SERVICES COMMAND MODE
LOE	LOOP ON ERROR
IER*	INHIBIT ALL ERROR REPORTS
IBR*	INHIBIT ALL ERROR REPORTS EXCEPT FIRST LEVEL (FIRST LEVEL CONTAINS ERROR TYPE, NUMBER, PC, TEST AND UNIT)
IXR*	INHIBIT EXTENDED ERROR REPORTS (THOSE CALLED BY PRINTX MACRO'S)
PRI	DIRECT MESSAGES TO LINE PRINTER
PNT	PRINT TEST NUMBER AS TEST EXECUTES
BOE	"BELL" ON ERROR
UAM	UNATTENDED MODE (NO MANUAL INTERVENTION)
ISR	INHIBIT STATISTICAL REPORTS (DOES NOT APPLY TO DIAGNOSTICS WHICH DO NOT SUPPORT STATISTICAL REPORTING)
IDR	INHIBIT PROGRAM DROPPING OF UNITS
ADR	EXECUTE AUTODROP CODE
LOT	LOOP ON TEST
EVL	EXECUTE EVALUATION (ON DIAGNOSTICS WHICH HAVE EVALUATION SUPPORT)

*ERROR MESSAGES ARE DESCRIBED IN SECTION 3.1

SEE THE XXDP+ USER'S MANUAL FOR MORE DETAILS ON FLAGS. YOU MAY SPECIFY MORE THAN ONE FLAG WITH THE FLAG SWITCH. FOR EXAMPLE, TO CAUSE THE PROGRAM TO LOOP ON ERROR, INHIBIT ERROR REPORTS AND TYPE A "BELL" ON ERROR, YOU MAY USE THE FOLLOWING STRING:

/FLAGS:LOE:IER:BOE

2.4 HARDWARE QUESTIONS

WHEN A DIAGNOSTIC IS STARTED, THE RUNTIME SERVICES WILL PROMPT THE USER FOR HARDWARE INFORMATION BY TYPING "CHANGE HW (L) ?" YOU MUST ANSWER "Y" AFTER A START COMMAND UNLESS THE HARDWARE INFORMATION HAS BEEN "PRELOADED" USING THE SETUP UTILITY (SEE CHAPTER 6 OF THE XXDP+ USER'S MANUAL). WHEN YOU ANSWER THIS QUESTION WITH A "Y", THE RUNTIME SERVICES WILL ASK FOR THE NUMBER OF UNITS (IN DECIMAL). YOU WILL THEN BE ASKED THE FOLLOWING QUESTIONS FOR EACH UNIT.

#UNITS (D) ? 1

UNIT 1
 LP11 ADDRESS: (O) (177514) ?
 INTERRUPT VECTOR : (O) (200) ?

2.5 SOFTWARE QUESTIONS

AFTER YOU HAVE ANSWERED THE HARDWARE QUESTIONS OR AFTER A RESTART OR CONTINUE COMMAND, THE RUNTIME SERVICES WILL ASK FOR SOFTWARE PARAMETERS. THESE PARAMETERS WILL GOVERN SOME DIAGNOSTIC SPECIFIC OPERATION MODES. YOU WILL BE PROMPTED BY "CHANGE SW (L) ?". IF YOU WISH TO CHANGE ANY PARAMETERS, ANSWER BY TYPING "Y". THE SOFTWARE QUESTIONS AND THE DEFAULT VALUES ARE DESCRIBED IN THE NEXT PARAGRAPH(S).

RUN MANUAL INTERVENTION TESTS (N) ? DEFAULT IS NO
TESTING IN U.S.A. (Y) ?
AUTODROP ERROR COUNT (D) 5 ? DROPS ANY UNIT FROM TEST WHICH EXCEEDS SPECIFIED NO. OF ERRORS

2.6 EXTENDED P-TABLE DIALOGUE

WHEN YOU ANSWER THE HARDWARE QUESTIONS, YOU ARE BUILDING ENTRIES IN A TABLE THAT DESCRIBES THE DEVICES UNDER TEST. THE SIMPLEST WAY TO BUILD THIS TABLE IS TO ANSWER ALL QUESTIONS FOR EACH UNIT TO BE TESTED. IF YOU HAVE A MULTIPLEXED DEVICE SUCH AS A MASS STORAGE CONTROLLER WITH SEVERAL DRIVES OR A COMMUNICATION DEVICE WITH SEVERAL LINES, THIS BECOMES TEDIOUS SINCE MOST OF THE ANSWERS ARE REPETITIOUS.

TO ILLUSTRATE A MORE EFFICIENT METHOD, SUPPOSE YOU ARE TESTING A FICTIONAL DEVICE, THE XY11. SUPPOSE THIS DEVICE CONSISTS OF A CONTROL MODULE WITH EIGHT UNITS (SUB-DEVICES) ATTACHED TO IT. THESE UNITS ARE DESCRIBED BY THE OCTAL NUMBERS 0 THROUGH 7. THERE IS ONE HARDWARE PARAMETER THAT CAN VARY AMONG UNITS CALLED THE Q-FACTOR. THIS Q-FACTOR MAY BE 0 OR 1. BELOW IS A SIMPLE WAY TO BUILD A TABLE FOR ONE XY11 WITH EIGHT UNITS.

UNITS (D) ? 8<CR>

UNIT 1
CSR ADDRESS (O) ? 160000<CR>
SUB-DEVICE # (O) ? 0<CR>
Q-FACTOR (O) 0 ? 1<CR>

UNIT 2
CSR ADDRESS (O) ? 160000<CR>
SUB-DEVICE # (O) ? 1<CR>
Q-FACTOR (O) 1 ? 0<CR>

UNIT 3
CSR ADDRESS (O) ? 160000<CR>
SUB-DEVICE # (O) ? 2<CR>
Q-FACTOR (O) 0 ? <CR>

UNIT 4
CSR ADDRESS (O) ? 160000<CR>
SUB-DEVICE # (O) ? 3<CR>
Q-FACTOR (O) 0 ? <CR>

UNIT 5
CSR ADDRESS (O) ? 160000<CR>

SUB-DEVICE # (0) ? 4<CR>
Q-FACTOR (0) 0 ? <CR>

UNIT 6
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 5<CR>
Q-FACTOR (0) 0 ? <CR>

UNIT 7
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 6<CR>
Q-FACTOR (0) 0 ? 1<CR>

UNIT 8
CSR ADDRESS (0) 160000<CR>
SUB-DEVICE # (0) ? 7<CR>
Q-FACTOR (0) 1 ? <CR>

NOTICE THAT THE DEFAULT VALUE FOR THE Q-FACTOR CHANGES WHEN A
NON-DEFAULT RESPONSE IS GIVEN. BE CAREFUL WHEN SPECIFYING
MULTIPLE UNITS!

AS YOU CAN SEE FROM THE ABOVE EXAMPLE, THE HARDWARE PARAMETERS
DO NOT VARY SIGNIFICANTLY FROM UNIT TO UNIT. THE PROCEDURE SHOWN IS
NOT VERY EFFICIENT.

THE RUNTIME SERVICES CAN TAKE MULTIPLE UNIT SPECIFICATIONS HOWEVER.
LET'S BUILD THE SAME TABLE USING THE MULTIPLE SPECIFICATION
FEATURE.

UNITS (0) ? 8<CR>

UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0,1<CR>
Q-FACTOR (0) 0 ? 1,0<CR>

UNIT 3
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 2-5<CR>
Q-FACTOR (0) 0 ? 0<CR>

UNIT 7
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 6,7<CR>
Q-FACTOR (0) 0 ? 1<CR>

AS YOU CAN SEE IN THE ABOVE DIALOGUE, THE RUNTIME SERVICES WILL
BUILD AS MANY ENTRIES AS IT CAN WITH THE INFORMATION GIVEN IN ANY
ONE PASS THROUGH THE QUESTIONS. IN THE FIRST PASS, TWO ENTRIES
ARE BUILT SINCE TWO SUB-DEVICES AND Q-FACTORS WERE SPECIFIED. THE
SERVICES ASSUME THAT THE CSR ADDRESS IS 160000 FOR BOTH SINCE IT
WAS SPECIFIED ONLY ONCE. IN THE SECOND PASS, FOUR ENTRIES WERE
BUILT. THIS IS BECAUSE FOUR SUB-DEVICES WERE SPECIFIED. THE
"--" CONSTRUCT TELLS THE RUNTIME SERVICES TO INCREMENT THE DATA
FROM THE FIRST NUMBER TO THE SECOND. IN THIS CASE, SUB-DEVICES

2, 3, 4 AND 5 WERE SPECIFIED. (IF THE SUB-DEVICE WERE SPECIFIED BY ADDRESSES, THE INCREMENT WOULD BE BY 2 SINCE ADDRESSES MUST BE ON AN EVEN BOUNDARY.) THE CSR ADDRESSES AND Q-FACTORS FOR THE FOUR ENTRIES ARE ASSUMED TO BE 160000 AND 0 RESPECTIVELY SINCE THEY WERE ONLY SPECIFIED ONCE. THE LAST TWO UNITS ARE SPECIFIED IN THE THIRD PASS.

THE WHOLE PROCESS COULD HAVE BEEN ACCOMPLISHED IN ONE PASS AS SHOWN BELOW.

UNITS (D) ? 8<CR>

UNIT 1

CSR ADDRESS (D) ? 160000<CR>

SUB-DEVICE # (D) ? 0-7<CR>

Q-FACTOR (D) 0 ? 0,1,0,,,,1,1<CR>

AS YOU CAN SEE FROM THIS EXAMPLE, NULL REPLIES (COMMAS ENCLOSING A NULL FIELD) TELL THE RUNTIME SERVICES TO REPEAT THE LAST REPLY.

2.7 QUICK START-UP PROCEDURE (XXDP+)

TO START-UP THIS PROGRAM:

1. BOOT XXDP+
2. TYPE 'R NAME', WHERE NAME IS THE NAME OF THE BIN OR BIC FILE FOR THIS PROGRAM
3. TYPE 'START'
4. ANSWER THE 'CHANGE HW' QUESTION WITH 'Y'
5. ANSWER ALL THE HARDWARE QUESTIONS
6. ANSWER THE 'CHANGE SW' QUESTION WITH 'N'

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING ONLY THE DEFAULTS FOR FLAGS AND SOFTWARE PARAMETERS. THESE DEFAULTS ARE DESCRIBED IN SECTIONS 2.3 AND 2.5.

3.0 ERROR INFORMATION

3.1 TYPES OF ERROR MESSAGES

THERE ARE THREE LEVELS OF ERROR MESSAGES THAT MAY BE ISSUED BY A DIAGNOSTIC: GENERAL, BASIC AND EXTENDED. GENERAL ERROR MESSAGES ARE ALWAYS PRINTED UNLESS THE 'IER' FLAG IS SET (SECTION 2.3). THE GENERAL ERROR MESSAGE IS OF THE FORM:

NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX
ERROR MESSAGE

WHERE; NAME = DIAGNOSTIC NAME
TYPE = ERROR TYPE (SYS FATAL, DEV FATAL, HARD OR SOFT)
NUMBER = ERROR NUMBER

UNIT NUMBER = 0 - N (N IS LAST UNIT IN PTABLE)
TST NUMBER = TEST AND SUBTEST WHERE ERROR OCCURRED
PC:XXXXXX = ADDRESS OF ERROR MESSAGE CALL

BASIC ERROR MESSAGES ARE MESSAGES THAT CONTAIN SOME ADDITIONAL INFORMATION ABOUT THE ERROR. THESE ARE ALWAYS PRINTED UNLESS THE "IER" OR "IBR" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL MESSAGE.

EXTENDED ERROR MESSAGES CONTAIN SUPPLEMENTARY ERROR INFORMATION SUCH AS REGISTER CONTENTS OR GOOD/BAD DATA. THESE ARE ALWAYS PRINTED UNLESS THE "IER", "IBR" OR "IXR" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL ERROR MESSAGE AND ANY ASSOCIATED BASIC ERROR MESSAGES.

3.2 SPECIFIC ERROR MESSAGES

ERROR	DESCRIPTION
1	"PRINTER ERROR" ERROR CONDITION IN THE PRINTER.
2	"PRINTER NOT READY" PRINTER NOT READY TO ACCEPT DATA.
3	"PRINTER DID NOT INTERRUPT" FAILURE IN INTERFACE LOGIC.
4	"LOADING PRINTER BUFFER DOES NOT CLEAR READY" FAILURE IN INTERFACE LOGIC.
5	"PRINTER INTERRUPTED AT SAME LEVEL AS THE PROCESSOR" FAILURE IN INTERFACE LOGIC.
6	"PRINTER ERROR" ERROR CONDITION IN THE PRINTER.
7	"PRINTER NOT READY" PRINTER NOT READY TO ACCEPT DATA.
8	"PAPER OUT INTERLOCK SWITCH FAILURE" FAULTY INTERLOCK SWITCH
9	"PAPER TRAY HANDLE INTERLOCK SWITCH FAILURE" FAULTY INTERLOCK SWITCH
10	"FRONT DOOR INTERLOCK SWITCH FAILURE" FAULTY INTERLOCK SWITCH
	"NOTE" ERROR MESSAGES #11 THRU #12 HAVE BEEN ELIMINATED
13	"INTERRUPT SERVICING FOR THE FOLLOWING DEVICE DID NOT OCCUR"

- GLOBAL ERROR INDICATING INTERRUPT FOR
DATA TRANSFER DID NOT OCCUR.
- 14 'PRINTER STATUS ERROR'
GLOBAL ERROR INDICATING PRINTER ERROR
CONDITION.
- 15 'OUTPUT TIMEOUT ERROR'
GLOBAL ERROR INDICATING TRANSMISSION
OF LAST CHARACTER DID NOT OCCUR
WITHIN A GIVEN TIME.

4.0 PERFORMANCE AND PROGRESS REPORTS

PERFORMANCE AND PROGRESS REPORTS ARE NOT SUPPLIED.

5.0 DEVICE INFORMATION TABLES

DEVICE INFORMATION APPEARS IN THE GLOBAL DATA SECTION.

6.0 TEST SUMMARIES

TEST 1

INTERFACE LOGIC

VERIFIES OPERATION OF INTERFACE LOGIC BETWEEN THE PRINTER AND THE CPU.

TEST 2

DATA TRANSFER PATHS

CHECKS THE DATA TRANSFER PATHS FROM THE PRINTER OUTPUT TO
THE PROCESSOR INTERFACE.

TEST 3

PRINTABLE CHARACTERS

CHECKS FOR PROPER PRINTING OF ALL PRINTABLE CHARACTERS.

TEST 4

NON-PRINTABLE CHARACTERS

CHECKS FOR PROPER DETECTION OF ALL NON-PRINTABLE CHARACTERS.

TEST 5

PRINT CONTROL

CHECKS THAT CHARACTERS IN EXCESS OF 132 CHARACTERS ON A LINE
ARE DISREGARDED.

TEST 6

MULTIPLE LINE ADVANCE

CHECKS THE MULTIPLE LINE ADVANCE FOR PROPER PAPER MOVEMENT.

TEST 7

OVERSTRIKE

THIS TEST CHECKS THE MACHINE'S OVERSTRIKE CAPABILITY AS WELL AS PAGE
BUFFER AND LINE BUFFER LIMITATIONS.

INTERLOCK TEST 8
THIS TEST MAKES SURE THAT THE ERROR BIT IN THE PRINTER
INTERFACE IS SET WHENEVER INTERLOCK SWITCHES ARE TRIPPED
IN THE PRINTER.

8

```
601 .TITLE CZLNAAO LN01 DIAGNOSTIC
602 .ENAB: AMA
603 .SBTTL IDENTIFICATION
604
605 : PRODUCT CODE: AC-T343A-MC
606
607 : PRODUCT NAME: CZLNAAO LN01 DIAG
608
609 : MAINTAINER: SMALL SYSTEMS DIAGNOSTICS
610
611 : AUTHORS: GLENN A. PERNA
612
613 : DATE JAN 1983
614
615 : COPYRIGHT (C) 1983, BY
616 : DIGITAL EQUIPMENT CORPORATION, MAYNARD MASSACHUSETTS 01754
617
618 : THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A
619 : SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLU-
620 : SION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY
621 : OTHER COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE
622 : AVAILABLE TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM
623 : AND TO ONE WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND
624 : OWNERSHIP OF THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DEC.
625
626 : THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT
627 : NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL
628 : EQUIPMENT CORPORATION.
629
630 : DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF
631 : ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.
```

633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653

: **
: FUNCTIONAL DESCRIPTION
: THIS DIAGNOSTIC PROGRAM VERIFIES PROPER OPERATION OF THE LN01
: LINE PRINTER, AND IT'S ASSOCIATED INTERFACE MODULE.
: A TOTAL OF 16 PRINTERS CAN BE TESTED.
: THE PROGRAM CONSISTS OF T-B-S TESTS,
: THE PROGRAM IS COMPATIBLE TO THE PDP-11 DIAGNOSTIC SUPERVISOR, ACT/SLIDE, AND
: XXDP+.
: --

: VERSION A-0 JAN 1983 GLENN A. PERNA

: HISTORY REV. A-0 INITIAL RELEASE

```

655 .TITLE CZLNAAO LN01 TEST
656 .SBTTL PROGRAM HEADER
657
658 .MCALL SVC
659 000000' SVC ;INITIALIZE SUPERVISOR MACROS
660 .MCALL STRUCT
661 000000' STRUCT ;STRUCTURED MACRO PACKAGE
662 000000 $LSTIN= 0 ;LIST ASSY CODE LEFT
663 000000 $LSTTAG= 0 ;LIST TAGS LEFT
664 177777 $LOCTAG= -1
665
666 000000 SVCINS= 0 ;LIST INSTRUCTIONS
667 000000 SVCTST= 0 ;LIST TEST TAGS
668 000000 SVCSUB= 0 ;LIST SUBTEST TAGS
669 000000 SVCGBL= 0 ;LIST GLOBAL TAGS
670 000000 SVCTAG= 0 ;LIST OTHER TAGS
671
672 .ENABL AMA
673 .ENABL ABS
674 .ENABL LC
675 002000 .=2000
676
677 002000 BGNMOD
678 002000 POINTER BGNSW,BGNSFT
679
680 002000 HEADER CZLNAA,0,60,1,340
(4) 002000 L$NAME:: ;DIAGNOSTIC NAME
(4) 002000 103 .ASCII /C/
(4) 002001 132 .ASCII /Z/
(4) 002002 114 .ASCII /L/
(4) 002003 116 .ASCII /N/
(4) 002004 101 .ASCII /A/
(6) 002005 000 .BYTE 0
(6) 002006 000 .BYTE 0
(5) 002007 000 .BYTE 0
(5) 002010 L$REV:: ;REVISION LEVEL
(4) 002010 101 .ASCII /A/
(5) 002011 L$DEPO:: ;0
(4) 002011 060 .ASCII /O/
(5) 002012 L$UNIT:: ;NUMBER OF UNITS
(4) 002012 000000 .WORD 0
(5) 002014 L$TIML:: ;LONGEST TEST TIME
(4) 002014 000060 .WORD 60
(5) 002016 L$HPCP:: ;PTR. TO H.W. PTABLE
(4) 002016 022140 .WORD L$HARD
(5) 002020 L$SPCP:: ;PTR. TO S.W. PTABLE
(4) 002020 022220 .WORD L$SOFT
(5) 002022 L$HPTP:: ;PTR. TO DEF. H.W. PTABLE
(4) 002022 002222 .WORD L$HW
(5) 002024 L$SPTP:: ;PTR. TO S.W. PTABLE
(4) 002024 002234 .WORD L$SW
(5) 002026 L$LADP:: ;DIAG. END ADDRESS
(4) 002026 022370 .WORD L$LAST
(5) 002030 L$STA:: ;RESERVED FOR APT STATS
(4) 002030 000000 .WORD 0
(5) 002032 L$CO::

```

(4)	002032	000000	LSDTYP::	.WORD	0	;DIAGNOSTIC TYPE
(5)	002034		LSAPT::	.WORD	1	;APT EXPANSION
(4)	002034	000001	LSDTP::	.WORD	0	;PTR. TO DISPATCH TABLE
(5)	002036	000000	LSPRIO::	.WORD	340	;DIAGNOSTIC RUN PRIORITY
(4)	002040	002132	LSENV1::	.WORD	0	;FLAGS DESCRIBE HOW IT WAS SETUP
(5)	002042	000340	LSEXP1::	.WORD	0	;EXPANSION WORD
(4)	002044	000000	LSMREV::	.WORD	0	;SVC REV AND EDIT #
(5)	002046	000000	LSREVISION	.BYTE		
(4)	002050	003	LSEDIT	.BYTE		
(3)	002051	003	LSREF::	.WORD	0	;DIAG. EVENT FLAGS
(5)	002052			.WORD	0	
(4)	002052	000000	LSGPC::	.WORD	0	
(5)	002054	000000	LSDEVP::	.WORD	0	; POINTER TO DEVICE TYPE LIST
(4)	002056	000000	LSREPP::	.WORD	0	;PTR. TO REPORT CODE
(5)	002060	002212	LSREPP4::	.WORD	0	
(4)	002062	000000	LSREPP5::	.WORD	0	
(5)	002064	000000	LSAUT::	.WORD	0	;PTR. TO ADD UNIT CODE
(4)	002066	000000	LSAUT::	.WORD	0	;PTR. TO DROP UNIT CODE
(5)	002070	000000	LSLUN::	.WORD	0	;LUN FOR EXERCISERS TO FILL
(4)	002072	000000	LSLUN::	.WORD	0	;PTR. TO DIAG. DESCRIPTION
(5)	002074	000000	LSDESC::	.WORD	0	;GENERATE SPECIAL AUTOLOAD EMT
(4)	002076	002152	LSLOAD::	.WORD	0	;PTR. TO ERRIBL
(5)	002100	104035	LSLOAD	EMT		
(4)	002102	000000	LSICP::	.WORD	0	;PTR. TO INIT CODE
(5)	002104	005456	LSICP::	.WORD	0	;PTR. TO CLEAN-UP CODE
(4)	002106	007232	LSACP::	.WORD	0	;PTR. TO AUTO CODE
(5)	002110	002226	LSACP::	.WORD	0	;PTR. TO PROTECT TABLE
(4)	002112	002122	LSPT::	.WORD	0	;TEST NUMBER
(5)	002114	000000	LSPT::	.WORD	0	;DELAY COUNT
(4)	002116	000000	LSHIME::	.WORD	0	;PTR. TO HIGH MEM
(5)	002120	000000		.WORD	0	

682			:	
683			:	THE FOLLOWING IS A LOAD PROTECTION TABLE
684			:	
685	002122			BGNPROT
(3)	002122		L\$PROT::	
686	002122	000000		.WORD 0
687	002124	177777		.WORD -1
688	002126	177777		.WORD -1
689	002130			ENDPROT

```

691 .SBTTL DISPATCH TABLE
692
693
694 ;++
695 ; THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
696 ; IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.
697 ;--
698 002130 DISPATCH 8 ;X= NUMBER OF TESTS
(4) 002130 000010 .WORD 8
(3) 002132 L$DISPATCH::
(6) 002132 007426 .WORD T1
(6) 002134 010722 .WORD T2
(6) 002136 011356 .WORD T3
(6) 002140 012020 .WORD T4
(6) 002142 013050 .WORD T5
(6) 002144 014302 .WORD T6
(6) 002146 014770 .WORD T7
(6) 002150 016522 .WORD T8
699
700 ;
701 ;FOR USE ON REVISION C OF THE SUPERVISOR
702 ;
702 002152 DESCRIP <CZLNAAO LINE PRINTER DIAGNOSTIC>
(4) 002152 L$DESC::
(3) 002152 055103 047114 040501 .ASCIZ /CZLNAAO LINE PRINTER DIAGNOSTIC/
(3) 002160 020060 044514 042516
(3) 002166 050040 044522 052116
(3) 002174 051105 042040 040511
(3) 002202 047107 051517 044524
(3) 002210 000103
(2)
703 002212 .EVEN
(4) 002212 DEVTYP <LN01>
(3) 002212 047114 030460 000 L$DVTYP::
(2) 002220 .ASCIZ /LN01/
704 .EVEN
705
706

```

```

708      .SBTTL  DEFAULT HARDWARE P-TABLE
709
710      ;++
711      ; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
712      ; THE TEST-DEVICE PARAMETERS. THE STRUCTURE OF THIS TABLE
713      ; IS IDENTICAL TO THE RUN-TIME P-TABLE.
714      ;--
715
716      002220      BGNHW      DFPTBL
(3) 002220      000002      .WORD      L10001-L$HW/2
(3) 002222
(3) 002222      L$HW::
717      002222      177514      DFPTBL::      .WORD      177514      ;LP11 REGISTER ADDRESS
718      002224      000200      .WORD      200      ;LP11 INTERRUPT VECTOR
719
720      ; INTERRUPT VECTOR PRIORITY IS 4 AND CANNOT BE CHANGED
721
722
723      002226      ENDHW
(3) 002226      L10001:
724
725
726
727      002226      BGNAUTO
(3) 002226      L$AUTO::
728
729      002226      000240      NOP      ; NOT USED
730
731      002230      ENDAUTO
(3) 002230      L10002:
(3) 002230      104461      TRAP      C$AUTO
  
```

```
733      .SBTTL  SOFTWARE P-TABLE
734
735      ;++
736      ; THE SOFTWARE P-TABLE CONTAINS THE VALUES OF THE PROGRAM
737      ; PARAMETERS THAT CAN BE CHANGED BY THE OPERATOR.
738      ;--
739
740      002232      BGNSW  SFPTBL
(3) 002232 000002      .WORD  L10003-L$SW/2
(3) 002234
(3) 002234
741
742      002234 000000      INHINT: .WORD  0
743                                     :0 IF NO INTERVENTION TESTS
744                                     :1 IF MANUAL INTERVENTION TESTS
745                                     :DEFAULT IS NO
746      002236 000005      MAXERR: .WORD  5
747                                     ; AUTODROP ERROR COUNT
748                                     ; IF ERROR COUNT EXCEEDS MAXERR THE UNIT WILL BE DROPPED FROM TEST
749      002240
(3) 002240      L10003:  ENDSW
750
```

```

752 .SBTTL I/O MACRO DEFINITIONS
753
754 .MACRO OUTPUT ADD,BFCNT,ERR,PRINTS
755 MOV ADD,BUFADD ;SAVE THE BUFFER ADDRESS
756 MOV BFCNT,BUFCNT ;BUFFER BYTE COUNT BFCNT
757 MOV #-1,PRINTR ; OUTPUT TO ALL UNITS
758 .IF B ERR
759 MOV #LPERR,ERRSVC
760 .ENDC
761 .IF NB ERR
762 MOV ERR,ERRSVC
763 .ENDC
764 .IF B PRINTS
765 MOV #1,BUFREP ; PRINT ONCE DEFAULT
766 .ENDC
767 .IF NB PRINTS
768 MOV PRINTS,BUFREP ; SUPPLY PRINT COUNT
769 .ENDC
770 JSR PC,IOCTRL ;CALL THE DRIVER
771 .ENDM OUTPUT
772
773 .MACRO OUTPUI ADD,BFCNT,ERR,UNIT,PRINTS
774 MOV ADD,BUFADD ;SAVE BUFFER ADDRESS
775 MOV BFCNT,BUFCNT ;BUFFER BYTE COUNT BFCNT
776 .IF B ERR
777 MOV #LPERR,ERRSVC
778 .ENDC
779 .IF NB ERR
780 MOV ERR,ERRSVC
781 .ENDC
782 .IF B PRINTS
783 MOV #1,BUFREP ; PRINT ONCE DEFAULT
784 .ENDC
785 .IF NB PRINTS
786 MOV PRINTS,BUFREP ; SUPPLY PRINT COUNT
787 .ENDC
788 MOV UNIT,PRINTR ; SUPPLY UNIT NUMBER
789 JSR PC,IOCTRL ;CALL THE DRIVER
790 .ENDM OUTPUI
791
792 ; PRINTS IS A PARAMETER CONTROLLING THE NUMBER IF TIMES THE DATA OR
793 ; MESSAGE IS TO BE PRINTED (SENT TO THE PRINTER). DEFAULT IS 1.
794
795 ; A TIMEOUT OF 20. SECONDS IS FURNISHED BASED ON THE FOLLOWING ASSUMPTIONS :
796 ; 1 A PRINTER SPEED OF 300 LPM
797 ; 2 A REPEAT COUNT OF 88 MAX. ( 1 PAGE OF LINES AT 8 LPI. )
798 ; 3 AN INITIAL BAND STARTUP TIME OF 2.5 SECONDS.
799
800 .....
801 ENDMOD
802

```

002240

```

804      .SBTTL  GLOBAL AREAS
805
806      002240      BGNMOD
807
808      :+
809      : THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES
810      : THAT ARE USED IN MORE THAN ONE TEST.
811      :--
812
816      002240      EQUALS
(1)      :
(1)      : BIT DIFINITIONS
(1)      :
(1)      100000      BIT15== 100000
(1)      040000      BIT14== 40000
(1)      020000      BIT13== 20000
(1)      010000      BIT12== 10000
(1)      004000      BIT11== 4000
(1)      002000      BIT10== 2000
(1)      001000      BIT09== 1000
(1)      000400      BIT08== 400
(1)      000200      BIT07== 200
(1)      000100      BIT06== 100
(1)      000040      BIT05== 40
(1)      000020      BIT04== 20
(1)      000010      BIT03== 10
(1)      000004      BIT02== 4
(1)      000002      BIT01== 2
(1)      000001      BIT00== 1
(1)      :
(1)      001000      BIT9==  BIT09
(1)      000400      BIT8==  BIT08
(1)      000200      BIT7==  BIT07
(1)      000100      BIT6==  BIT06
(1)      000040      BIT5==  BIT05
(1)      000020      BIT4==  BIT04
(1)      000010      BIT3==  BIT03
(1)      000004      BIT2==  BIT02
(1)      000002      BIT1==  BIT01
(1)      000001      BIT0==  BIT00
(1)      :
(1)      : EVENT FLAG DEFINITIONS
(1)      : EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
(1)      :
(1)      000040      EF.START== 32.      : START COMMAND WAS ISSUED
(1)      000037      EF.RESTART== 31.     : RESTART COMMAND WAS ISSUED
(1)      000036      EF.CONTINUE== 30.    : CONTINUE COMMAND WAS ISSUED
(1)      000035      EF.NEW== 29.        : A NEW PASS HAS BEEN STARTED
(1)      000034      EF.PWR== 28.        : A POWER-FAIL/POWER-UP OCCURRED
(1)      :
(1)      :
(1)      : PRIORITY LEVEL DEFINITIONS
(1)      :
(1)      000340      PRI07== 340
(1)      000300      PRI06== 300
(1)      000240      PRI05== 240
  
```

```

(1)      000200      PRI04== 200
(1)      000140      PRI03== 140
(1)      000100      PRI02== 100
(1)      000040      PRI01== 40
(1)      000000      PRI00== 0
(1)
(1)      ;
(1)      ;OPERATOR FLAG BITS
(1)      ;
(1)      000004      EVL==      4
(1)      000010      LOT==      10
(1)      000020      ADR==      20
(1)      000040      IDU==      40
(1)      000100      ISR==     100
(1)      000200      UAM==     200
(1)      000400      BOE==     400
(1)      001000      PNT==    1000
(1)      002000      PRI==    2000
(1)      004000      IXE==    4000
(1)      010000      IBE==   10000
(1)      020000      IER==   20000
(1)      040000      LOE==   40000
(1)      100000      HOE==  100000
817
821      000012      LF==12
822      000014      FF==14
823      000015      CR==15
824      000177      DEL==177
825
826      ;GLOBAL ERROR CODES FOR USE BY GENERAL ERROR ROUTINE
827      ;
828      000001      STATER= 1      ;TRANSMITTER STATUS ERROR IN OUTPUT
829      000002      TIMEOUT= 2    ;TIMEOUT ERROR IN IO DRIVER MODULE
830      ;THIS ERROR INDICATES THE LAST CHARACTER
831      ;WAS NOT TRANSMITTED WITHIN A GIVEN TIME
832      000003      NOINTR= 3      ;GROSS TIME OUT ERROR. THE SPECIFIED DID NOT
833      ;INTERRRUPT. THEREFORE IO DRIVER MODULE WAS
834      ;NOT CALLED
835
836      ;SBTTL GENERAL REGISTER USAGE DEFINITIONS
837      ;
838      ;R0      RESERVED FOR USE BY THE MACRO PACKAGES
839      ;R1      MAXIMUM NUMBER OF UNITS TO TEST L$UNIT-1
840      ;R2      UNIT NUMBER BY 2. USED TO CALCULATE OFFSET INTO PROPER
841      ;PRINTER TABLE
842      ;R3      TEMPORARY STORAGE
843      ;R4
844      ;R5
845      ;R6      STACK POINTER
846      ;R7      PROGRAM COUNTER
847      ;
848
849
850
851      ;LP STATUS TABLE BIT DEFINITIONS
852
853      100000      ERROR = BIT15
  
```

854	040000	DROPED = BIT14
855	020000	ACTIVE = BIT13
856	000377	LOBYTE = 377 ; BIT MASK FOR CLEARING LOBYTE (COUNTER)
857		
858		

```

860          .SBTTL  GLOBAL DATA SECTION
861
862
863
864 002240 000000 FLAG: .WORD 0 ;<CR> FLAG FOR USE BY SUPERVISOR
865 002242 000000 LINCNT: .WORD 0 ;LINE COUNTER
866 002244 000000 LSTCNT: .WORD 0
867 002246 000000 COUNT: .WORD 0
868 002250 000000 CCNT: .WORD 0
869 002252 000000 STRCNT: .WORD 0
870 002254 000000 CHRGEN: .WORD 0
871 002256 000000 UNIT: .WORD 0 ;UNIT COUNTER FOR SINGLE UNIT TESTING
872 002260 000000 LUNIT: .WORD 0 ;UNIT COUNTER FOR ERRORS
873 ;AND TESTS NOT USING THE OUTPUT
874 ;MACROS.
875 002262 000000 PTABAD: .WORD 0 ;P-TABLE ADDRESS RETURNED BY GPHARD
876 002264 000000 PRINTR: .WORD 0 ;SELECTED LINE NO.
877 ;MACRO
878 002266 000000 CLKTYP: .WORD 0 ;CLOCK TYPE CONTROL WORD
879 ;1= NO CLOCK AVAILABLE
880 ;2= KW11-L LINE CLOCK
881 ;3= KW11-P PROGRAMABLE CLOCK
882 002270 000000 CLOCKP: .WORD 0 ;CLOCK P-TABLE ADDRESS
883 002272 000000 CLKCSR: .WORD 0 ;CLOCK CSR ADDRESS
884 002274 000000 CLKSET: .WORD 0 ;CLOCK TIME SET REG ADDRESS
885 002276 000000 CLKVEC: .WORD 0 ;CLOCK VECTOR ADDRESS
886 002300 000000 CLKENA: .WORD 0 ;CLOCK ENABLE BITS
887 002302 000000 ERRCOD: .WORD 0 ;ERROR CODE TYPE FOR GENERAL
888 ;ERROR ROUTINE
889 002304 000000 ERRFLG: .WORD 0 ;EXPECTED ERROR INDICATOR
890 002306 000000 UUT: .WORD 0 ;# UNITS ACTUALLY UNDER TEST
891 ;EXITS BACK TO IO DRIVER EQUAL
892 ;1 IF ERROR WAS EXPECTED.
893
894 002310 000000 INDEX: .WORD 0
895 002312 000000 VFUCMD: .WORD 0
896 ;
897 ;MACRO VARIABLES
898
899 002314 000000 BUFADD: .WORD 0 ;BUFFER ADDRESS OF DATA TO BE SENT
900 ;TO THE PRINTER
901 002316 000000 BUFCNT: .WORD 0 ;NUMBER OF BYTES TO TRANSFER
902
903 002320 000000 BUFREP: .WORD 0 ; NUMBER OF TIMES TO PRINT
904 ;
905 ;
906 ;
907 ;LN01 PARAMETER WORD TABLES
908 ;
909 002322 000020 LPCSR: .REPT 16. ; ADDRESS OF CSR FOR EACH LP11
910 ;.WORD 0
911 ;.ENDR
912 002362 000016 LPVEC: .REPT 16 ; INTERRUPT VECTOR ADDRESS
913 ;.WORD 0
914 ;.ENDR
915 002416 000020 LPBUF: .REPT 16. ; DATA BUFFER REGISTER ADDRESS

```

```

916          .WORD      0
917          .ENDR
918 002456 000020      STATUS: .REPT 16.          ; UNIT STATUS
919          .WORD      0
920          .ENDR
921 002516 000020      CURADD: .REPT 16.          ; CURRENT ADDRESS OF OUTPUT DATA BYTE
922          .WORD      0
923          .ENDR
924 002556 000020      MSGCNT: .REPT 16.          ; INITIAL BYTE COUNT OF MSG FOR REPEAT RESTORE
925          .WORD      0
926          .ENDR
927 002616 000020      REPCNT: .REPT 16.          ; NO. OF TIMES TO REPEAT MESSAGE
928          .WORD      0
929          .ENDR
930 002656 000020      MSGADR: .REPT 16.          ; ADDRESS OF DATA TO PRINT START OF DATA
931          .WORD      0
932          .ENDR
933 002716 000020      CURCNT: .REPT 16.          ; CURRENT COUNT REMAINING TO OUTPUT
934          .WORD     -1
935          .ENDR
936 002756 000020      LFINTR: .REPT 16.          ; INTERRUPT ROUTINE ADDRESS
937          .WORD      0
938          .ENDR
939 003016 000020      DELCNT: .REPT 16.          ; TIMEOUT DELAY COUNTER
940          .WORD      0
941          .ENDR
942 003056 000000      ERRSVC: .WORD      0          ; ERROR ROUTINE DISPATCH ADDRESS
943 003060 000020      ERRLBL: .REPT 16.          ; ERROR COUNT FOR EACH UNIT
944          .WORD      0
945          .ENDR
946
947 003120 000000      WORK:: .WORD      0          ; WORK AREA
948 003122 000000      WORK1: .WORD      0
949
950
951          .SBTTL  OUTPUT BUFFER
952          ;
953          ;150 BYTES IS RESERVED FOR THE OUTPUT BUFFER AREA
954          ;
955          ;
956
957          .EVEN
958 003124 000226      OUTBUF: .REPT 150.
959          .BYTE      0
960          .ENDR
961

```

```
963 .SBTTL GLOBAL TEXT SECTION
964
965 .NLIST BEX
966
967 : **
968 : THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
969 : MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
970 : MORE THAN ONE TEST.
971 : --
971 003352 051120 047111 042524 CSRERR: .ASCIIZ /PRINTER ERROR/
972 003370 051120 047111 042524 RDYERR: .ASCIIZ /PRINTER NOT READY/
973 003412 040520 042520 020122 PAPSWI: .ASCIIZ /PAPER OUT INTERLOCK SWITCH FAILURE/
974 003455 120 050101 051105 HANSWI: .ASCIIZ /PAPER TRAY HANDLE INTERLOCK SWITCH FAILURE/
975 003530 051106 047117 020124 DOOSWI: .ASCIIZ /FRONT DOOR INTERLOCK SWITCH FAILURE/
976 003574 051124 047101 046523 INTER1: .ASCIIZ /TRANSMIT INTERRUPT TIMEOUT/
977 003627 120 044522 052116 TXERR: .ASCIIZ /PRINTER STATUS ERROR/
978 003654 052517 050124 052125 OUTTIM: .ASCIIZ /OUTPUT TIMEOUT ERROR/
979 003701 125 044516 020124 TXNOIN: .ASCIIZ /UNIT FAILED TO INTERRUPT/
980 003732 046101 020114 047125 UUTEQO: .ASCIIZ /ALL UNITS HAVE BEEN DROPPED..RESTART../
981 004002
982
983
984 :
985 :
986
987 .LIST BEX
988
989 : FORMAT STATEMENTS USED IN PRINT CALLS
990 :
991
992 004002 040445 050114 030461 LPDROP: .ASCIIZ /%ALP11 UNIT %D2%A DROPPED FROM TEST%N/
993 004010 052440 044516 020124
994 004016 042045 022462 020101
995 004024 051104 050117 042520
996 004032 020104 051106 046517
004040 052040 051505 022524
004046 000116
```

```

998      .SBTTL GLOBAL SUBROUTINES SECTION
999
1000
1001      :++
1002      : THE GLOBAL SUBROUTINE SECTION CONTAINS THE SUBROUTINES
1003      : THAT ARE USED BY MORE THAN ONE TEST.
1004      :--
1005
1006      :++
1007      : FUNCTIONAL DESCRIPTION:
1008      : SUBROUTINE TO PRINT THE GENERAL ERROR INFORMATION.
1009      : PRINTS THE ERROR MESSAGE IN THE FOLLOWING FORMAT:
1010
1011      : "ERROR AT CSR XXXXXX UNIT YY"
1012
1013      : WHERE XXXXXX=  DEVICE CSR ADDRESS
1014      :                YY=  UNIT NUMBER THAT FAILED
1015
1016      : CALLING SEQUENCE
1017      : JSR PC,LPERR
1018      : REQUIRED PARAMETERS
1019      :   ERRCOD MUST BE SET TO ONE OF THE ERROR CODES DESCRIBED
1020      :   UNDER ERROR CODES.
1021
1022      :--
1023
1024
1025      : R2 IS USED INTERNAL TO THE ROUTINE.
1026      : THE ROUTINE DOES A SAVE ON R2
1027      : AND RESTORES IT PRIOR TO EXITING.
1028
1029
1030      LPERR:  SELECT ERRCOD OF 3 VERIFY      ;SELECT PROPER MESSAGE FORMAT
1031      (2) 004050 013746 002302      MOV      ERRCOD,-(SP)
1032      (6) 004054 002455      BLT      50005$
1033      (3) 004056 023727 002302 000003      CMP      ERRCOD,#3
1034      (7) 004064 003051      BGT      50005$
1035      (2) 004066 006316      ASL      (SP)
1036      (3) 004070 062716 004076      ADD      #50000$,(SP)
1037      (2) 004074 013607      MOV      @ (SP)+,PC
1038      (3) 004076      50000$:
1039      (5) 004076 004214      .WORD     50004$
1040      (5) 004100 004106      .WORD     50003$
1041      (5) 004102 004134      .WORD     50002$
1042      (5) 004104 004162      .WORD     50001$
1043
1044      50003$:  CASE 1      ;STATUS ERROR
1045      LET ERRIBL(R2) := ERRIBL(R2) + #1
1046      INC      ERRIBL(R2)
1047      LET L$LUN := R2 SHIFT -1
1048      MOV      R2,L$LUN
1049      ASR      L$LUN
1050      ERHRD    14,TXERR
1051      TRAP     C$ERHRD
1052      .WORD    14
  
```

```

(5) 004126 003627 .WORD TXERR
(5) 004130 000000 .WORD 0
1036
1037 004132 CASE 2 ;OUTPUT TIMEOUT ERROR
(4) 004132 000430 BR 50006$
(5) 004134 50002$:
1038 004134 LET ERRTBL(R2) := ERRTBL(R2) + #1
(7) 004134 005262 003060 INC ERRTBL(R2)
1039 004140 LET L$LUN := R2 SHIFT -1
(5) 004140 010237 002074 MOV R2,L$LUN
(8) 004144 006237 002074 ASR L$LUN
1040 004150 ERRHRD 15,OUTTIM ;
(4) 004150 104456 TRAP C$ERRHRD
(5) 004152 000017 .WORD 15
(5) 004154 003654 .WORD OUTTIM
(5) 004156 000000 .WORD 0
1041
1042 004160 CASE 3
(4) 004160 000415 BR 50006$
(5) 004162 50001$:
1043 ; NEVER RECIEVED THE INTERRUPT
1044 004162 LET ERRTBL(R2) := ERRTBL(R2) + #1
(7) 004162 005262 003060 INC ERRTBL(R2)
1045 004166 LET L$LUN := R2 SHIFT -1
(5) 004166 010237 002074 MOV R2,L$LUN
(8) 004172 006237 002074 ASR L$LUN
1046 004176 ERRHRD 16,TXNOIN
(4) 004176 104456 TRAP C$ERRHRD
(5) 004200 000020 .WORD 16
(5) 004202 003701 .WORD TXNOIN
(5) 004204 000000 .WORD 0
1047
1048
1049
1050 004206 ENDSELECT
(3) 004206 000402 BR 50006$
(3) 004210 50005$:
(2) 004210 062706 000002 ADD #2,SP
(3) 004214 50004$:
(3) 004214 50006$:
1051
1052 004214 IF ERRTBL(R2) GT MAXERR THEN
(6) 004214 026237 003060 002236 CMP ERRTBL(R2),MAXERR
(10) 004222 003402 BLE 50007$
1053 004224 004737 005314 JSR PC,DROPIT ; MAXIMUM ERROR COUNT EXCEEDED !
1054 004230 ENDIF
(4) 004230 50007$:
1055 004230 LET STATUS(R2) := STATUS(R2) CLR BY #ERROR
(7) 004230 042762 100000 002456 BIC #ERROR,STATUS(R2)
1056 004236 LET ERRCOD := #0
(4) 004236 005037 002302 CLR ERRCOD
1057 004242 LET @LPCSR(R2) := #100 ; CLEAR THE ERROR BIT AND ENABLE INTERRUPTS
(4) 004242 012772 000100 002322 MOV #100,@LPCSR(R2)
1058 004250 000207 RTS PC ;AND EXIT
1059
1060 ;=====

```

```

1061      ; BIN2DA      BINARY TO DECIMAL ASCII CONVERSION ROUTINE
1062      :             ENTER WITH NUMBER TO BE CONVERTED ON THE STACK
1063      :             FOLLOWED BY THE ADDRESS OF A 5 BYTE BUFFER
1064      :             FOR THE ASCII STRING. 5 DIGITS WILL BE CONVERTED
1065      :             LEADING ZEROES WILL BE CONVERTED TO SPACES.
1066      :             CALL BY JSR PC,BIN2DA
1067      :=====
1068
1069      BIN2DA: PUSH R4,R5
1070      (2) 004252 010446      MOV R4,-(SP)
1071      (3) 004254 010546      MOV R5,-(SP)
1072      (4) 004256 016504 000006      LET R4 := 6(SP)      ; GET ADDRESS FOR ASCII STRING
1073      (4) 004262 012705 004444      LET R5 := #TABLDA      ; GET ADDRESS OF DECIMAL TABLE
1074      (4) 004266 005037 004456      MOV #TABLDA,R5
1075      (4) 004272 005037 004460      LET FLAGDA := #0      ; LEADING ZERO FLAG
1076      (5) 004276 012737 000004 004462      CLR FLAGDA
1077      (7) 004304 000402      LET COUNTD := #0
1078      (6) 004306 005337 004462      CLR COUNTD
1079      (7) 004312 005737 004462      ; 8.(SP) HAS NUMBER TO BE CONVERTED
1080      (9) 004316 002435      DECR DIGITS FROM #4 TO #0 BY #1 ; DO 5 DIGITS
1081      (4) 004320 026615 000010      MOV #4,DIGITS
1082      (6) 004320 002405      BR 50010$
1083      (7) 004326 161566 000010      50011$: DEC DIGITS
1084      (7) 004332 005237 004460      50010$: TST DIGITS
1085      (4) 004336 000770      BLT 50012$
1086      (6) 004340 005737 004460      WHILE 8.(SP) GE (R5) DO      ; CREATE A DIGIT
1087      (8) 004344 003003      50013$: CMP 8.(SP),(R5)
1088      (6) 004346 005737 004456      BLT 50014$
1089      (10) 004352 003410      LET 8.(SP) := 8.(SP) - (R5)
1090      (6) 004354 052737 000060 004460      SUB (R5),8.(SP)
1091      (7) 004362 113724 004460      LET COUNTD := COUNTD + #1
1092      (4) 004366 005237 004456      INC COUNTD
1093      (7) 004372 000402      ENDDO
1094      (3) 004374      BR 50013$
1095      (6) 004376      50014$:      ; CONVERT DIGIT TO ASCII OR SUPPLY A SPACE
1096      (8) 004378      IF COUNTD GT #0 OR FLAGDA GT #0 THEN
1097      (10) 004382      TST COUNTD
1098      (6) 004384      BGT 50015$
1099      (4) 004386      TST FLAGDA
1100      (7) 004388      BLE 50016$
1101      (6) 004390      50015$:      LET COUNTD := COUNTD SET.BY #60
1102      (8) 004392      BIS #60,COUNTD
1103      (10) 004396      LET (R4)+ :B= COUNTD
1104      (6) 004398      MOVB COUNTD,(R4)+
1105      (4) 004400      LET FLAGDA := FLAGDA + #1
1106      (7) 004402      INC FLAGDA
1107      (3) 004404      ELSE
1108      (6) 004406      BR 50017$
1109      (8) 004408      50016$:      LET (R4)+ :B= #40
  
```

(4)	004374	112724	000040			MOVB #40,(R4)+
1087	004400					ENDIF
(4)	004400				50017\$:	
1088						: DO THE NEXT DIGIT
1089	004400					LET R5 := R5 + #2
(7)	004400	062705	000002			ADD #2,R5
1090	004404					LET COUNTD := #0
(4)	004404	005037	004460			CLR COUNTD
1091	004410					ENDDECR
(5)	004410	000736				BR 50011\$
(4)	004412				50012\$:	
1092						: IF NUMBER WAS A ZERO PRINT A '0'
1093	004412					IF FLAGDA EQ #0 THEN
(6)	004412	005737	004456			TST FLAGDA
(10)	004416	001002				BNE 50020\$
1094	004420					LET -(R4) :B= #60
(4)	004420	112744	000060			MOVB #60,-(R4)
1095	004424					ENDIF
(4)	004424				50020\$:	
1096						: CLEAN UP THE STACK AND EXIT
1097	004424					LET 8.(SP) := 4.(SP)
(4)	004424	016666	000004	000010		MOV 4.(SP),8.(SP)
1098	004432					POP R5,R4
(2)	004432	012605				MOV (SP)+,R5
(3)	004434	012604				MOV (SP)+,R4
1099	004436					LET SP := SP + #4
(7)	004436	062706	000004			ADD #4,SP
1100	004442	000207				RTS PC
1101						
1102						
1103	004444	023420	001750	000144	TABLDA:	.WORD 10000.,1000.,100.,10.,1
	004452	000012	000001			
1104	004456	000000			FLAGDA:	.WORD 0
1105	004460	000000			COUNTD:	.WORD 0
1106	004462	000000			DIGITS:	.WORD 0
1107						

```

1109 .SBTTL I/O DRIVER
1110
1111
1112
1113
1114 **
1115 THE I/O DRIVER ROUTINE IS INVOKED BY MEANS OF THE INTERRUPT SYSTEM.
1116 CALL TO IT IS JMP IODRV.
1117 RETURN RTI.
1118 ENTER ROUTINE WITH R2 SET UP TO DESIRED UNIT *2. R2 IS USED
1119 TO CALCULATE OFFSET INTO PROPER TABLE.
1120 R1 EQUALS MAXIMUM NUMBER OF UNITS ON SYSTEM UNDER TEST.
1121
1122
1123
1124
1125
1126
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1140
1141
1142
1143
1144
1145
1146

```

004464	032772	100000	002322	
(6) 004464	001061			
(10) 004472				
004474				
(6) 004474	005762	002716		
(10) 004500	003416			
004502				
(4) 004502	117272	002516	002416	
004510				
(7) 004510	005262	002516		
004514				
(7) 004514	052762	020000	002456	
004522				
(7) 004522	005362	002416		
004526				
(7) 004526	052772	000100	002322	
004534				
(4) 004534	000437			
(3) 004536				
004536				
(7) 004536	005362	002616		
004542				
(6) 004542	005762	002616		
(10) 004546	003424			
004550				
(4) 004550	016262	002656	002516	
004556				
(4) 004556	016262	002556	002716	
004564				
(4) 004564	117272	002516	002416	
004572				
(7) 004572	005262	002516		
004576				

```

IODRV: IF #BIT15 NOTSETIN @LPCSR(R2) THEN
      BIT #BIT15,@LPCSR(R2)
      BNE 50021$

      IF CURCNT(R2) GT #0 THEN
        TST CURCNT(R2)
        BLE 50022$
        LET @LPBUF(R2) :B= @CURADD(R2)
        MOV @CURADD(R2),@LPBUF(R2)
        LET CURADD(R2) := CURADD(R2) + #1
        INC CURADD(R2)

      ENABLE INTERRUPT FOR NEXT BYTE

      LET STATUS(R2) := STATUS(R2) SET.BY #ACTIVE
      BIS #ACTIVE,STATUS(R2)
      LET CURCNT(R2) := CURCNT(R2) - #1
      DEC CURCNT(R2)
      LET @LPCSR(R2) := @LPCSR(R2) SET.BY #100
      BIS #100,@LPCSR(R2)
      ELSE
        BR 50023$
50022$:
      ; CURRENT MSG DONE, IF PRINT COUNT NOT ZERO SEND AGAIN
      LET REPCNT(R2) := REPCNT(R2) - #1
      DEC REPCNT(R2)
      IF REPCNT(R2) GT #0 THEN
        TST REPCNT(R2)
        BLE 50024$
        LET CURADD(R2) := MSGADR(R2) ; RESTORE THE MSG ADDR
        MOV MSGADR(R2),CURADD(R2)
        LET CURCNT(R2) := MSGCNT(R2) ; RESTORE THE BYTE COUNT
        MOV MSGCNT(R2),CURCNT(R2)
        LET @LPBUF(R2) :B= @CURADD(R2) ; RESEND THE MESSAGE
        MOV @CURADD(R2),@LPBUF(R2)
        LET CURADD(R2) := CURADD(R2) + #1 ; BUMP THE POINTER
        INC CURADD(R2)
        LET CURCNT(R2) := CURCNT(R2) - #1 ; DROP BYTE COUNT

```

```

(7) 004576 005362 002716 DEC CURCNT(R2)
1147 004602 052762 020000 002456 BIS #ACTIVE,STATUS(R2) LET STATUS(R2) := STATUS(R2) SET.BY #ACTIVE
(7) 004602 012772 000100 002322 MOV #100,@LPCSR(R2) LET @LPCSR(R2) := #100 ; RE-ENABLE INTERRUPTS
(4) 004610 000406 BR 50025$ ELSE
1149 004616 50024$: ; CURRENT MSG DONE, REPEAT COUNT =0
(4) 004616 042762 020000 002456 BIC #ACTIVE,STATUS(R2) LET STATUS(R2) := STATUS(R2) CLR.BY #ACTIVE
(3) 004620 012772 000000 002322 MOV #00,@LPCSR(R2) LET @LPCSR(R2) := #00
1150 50025$: ; CLEAR ACTIVE AND DISABLE INTERRUPTS.
1151 50023$: ; CLEAR ERROR CONDITION, ENABLE INTERRUPTS
1152 004620 000410 BR 50026$ ELSE
(7) 004620 052762 100000 002456 BIS #ERROR,STATUS(R2) LET STATUS(R2) := STATUS(R2) SET.BY #ERROR
1153 004626 012737 000001 002302 MOV #STATER,ERRCOD LET ERRCOD := #STATER ; STATUS ERROR
(4) 004626 004777 176200 JSR PC,@ERRSVC ; ERROR SERVICE SHOULD CLEAR ERROR BIT AND ENABLE INTR
1154 004634 50026$: POP R2
(4) 004634 012602 MOV (SP)+,R2
1155 004634 000002 RTI
(4) 004634
1156 004634
(4) 004634
(3) 004636
1157 004636
1158 004636
1159 004636
(7) 004636 052762 100000 002456 BIS #ERROR,STATUS(R2) LET STATUS(R2) := STATUS(R2) SET.BY #ERROR
1160 004644 012737 000001 002302 MOV #STATER,ERRCOD LET ERRCOD := #STATER ; STATUS ERROR
(4) 004644 004777 176200 JSR PC,@ERRSVC ; ERROR SERVICE SHOULD CLEAR ERROR BIT AND ENABLE INTR
1161 004652 012602 MOV (SP)+,R2
1162 004656 000002 RTI
(4) 004656
1163 004656
(2) 004656 012602 MOV (SP)+,R2
1164 004660 000002 RTI
1165 004660 000002 RTI

```

```

1167 .SBTTL I/O CONTROL
1168 **
1169
1170 THE I/O CONTROL SUBROUTINE IS A SINGLE ENTRY QUEUE MANAGER.
1171 THIS ROUTINE IS INVOKED BY A JSR FROM AN I/O CALL.
1172 INPUTS: PRINTR -1 FOR ALL TERMINALS
1173          N FOR PRINTER NUMBER 'N'
1174          BUFADD ADDRESS OF MESSAGE TO PRINT
1175          BUFcnt BYTE COUNT TO TRANSMIT TO PRINTER
1176
1177          ERRSVC ADDRESS OF ERROR SERVICE SUBROUTINE
1178          BUFREP IS NO. OF TIMES TO PRINT THE MSG
1179 --
1180
1181 IOCTRL: PUSH R2,R3
1182          MOV R2,-(SP)
1183          MOV R3,-(SP)
1184
1185 IF PRINTR IS -1 QUE OUTPUT TO ALL PRINTERS SELECTED
1186 OTHERWISE TO UNIT NUMBER IN PRINTR.
1187
1188 IF PRINTR EQ #-1 THEN
1189   CMP PRINTR,#-1
1190   BNE 50027$
1191   LET R3 := L$UNIT
1192   MOV L$UNIT,R3
1193   LET L$LUN := #0
1194   CLR L$LUN
1195 ELSE
1196   BR 50030$
1197
1198 50027$: LET R3 := #1
1199   MOV #1,R3
1200   LET L$LUN := PRINTR
1201   MOV PRINTR,L$LUN
1202   ENDIF
1203
1204 50030$:
1205 REPEAT TILL R3 = 0
1206
1207 CTLLP: IF R3 EQ #0 THEN
1208   TST R3
1209   BNE 50031$
1210   INLINE <JMP CTLEND>
1211   JMP CTLEND
1212   ENDIF
1213
1214 50031$:
1215 USE R2 AS AN INDEX INTO THE UNIT TABLES
1216
1217 LET R2 := L$LUN SHIFT 1
1218 MOV L$LUN,R2
1219 ASL R2
1220 LET ERRCOD := #0
1221 CLR ERRCOD

```

```

1205
1206      ; IF THE UNIT HAS BEEN DROPPED SELECT THE NEXT UNIT
1207      ;
1208      004744      IF #DROPED NOTSETIN STATUS(R2) THEN
(6) 004744 032762 040000 002456      BIT #DROPED,STATUS(R2)
(10) 004752 001123      BNE 50032$
1209
1210      ; TEST FOR DVC ERROR BIT SET
1211      ;
1212      004754      IF #BIT15 SETIN @LPCSR(R2) THEN
(6) 004754 032772 100000 002322      BIT #BIT15,@LPCSR(R2)
(10) 004762 001407      BEQ 50033$
1213      004764      LET ERRCOD := #STATER      ; STATUS REG ERROR BIT 15 SET IN CSR
(4) 004764 012737 000001 002302      MOV #STATER,ERRCOD
1214      004772      LET STATUS(R2) := STATUS(R2) SFT.BY #ERROR
(7) 004772 052762 100000 002456      BIS #ERROR,STATUS(R2)
1215      005000      ELSE
(4) 005000 000455      BR 50034$
(3) 005002      50033$:
1216      ;
1217      ; MAKE SURE PREVIOUS MSG IS DONE
1218      ;
1219      005002      IF CURCNT(R2) GT #0 THEN
(6) 005002 005762 002716      TST CURCNT(R2)
(10) 005006 003452      BLE 50035$
1220      005010      IF #ACTIVE NOTSETIN STATUS(R2) THEN
(6) 005010 032762 020000 002456      BIT #ACTIVE,STATUS(R2)
(10) 005016 001004      BNE 50036$
1221
1222      ; OUTPUT WAS QUEUED BUT I/O DRIVER WAS NEVER INVOKED (VIA INTERRUPT)
1223      ;
1224      005020      LET ERRCOD := #NOINTR      ; NO INTERRUPT
(4) 005020 012737 000003 002302      MOV #NOINTR,ERRCOD
1225      005026      ELSE
(4) 005026 000442      BR 50037$
(3) 005030      50036$:
1226      005030      WHILE #ACTIVE SETIN STATUS(R2) DO
(4) 005030      50040$:
(6) 005030 032762 020000 002456      BIT #ACTIVE,STATUS(R2)
(10) 005036 001436      BEQ 50041$
1227      005040      LET DELCNT(R2) := #100.      ; 220 SEC
(4) 005040 012762 000144 003016      MOV #100.,DELCNT(R2)
1228      005046      DELAY 2.      ; 200MS LOOPS
(2) 005046 012727 000002      MOV #2.,(PC)+
(2) 005052 000000      .WORD 0
(2) 005054 013727 002116      MOV L$DLY,(PC)+
(2) 005060 000000      .WORD 0
(2) 005062 005367 177772      DEC -6(PC)
(2) 005066 001375      BNE -4
(2) 005070 005367 177756      DEC -22(PC)
(2) 005074 001367      BNE -20
1229      005076      LET DELCNT(R2) := DELCNT(R2) - #1
(7) 005076 005362 003016      DEC DELCNT(R2)
1230      005102      IF DELCNT(R2) EQ #0 THEN
(6) 005102 005762 003016      TST DELCNT(R2)
(10) 005106 001011      BNE 50042$

```

```

1231 005110          LET ERRCOD := #TIMOUT
    (4) 005110 012737 000002 002302      MOV    #TIMOUT,ERRCOD
1232 005116          LET STATUS(R2) := STATUS(R2) CLR.BY #ACTIVE
    (7) 005116 042762 020000 002456      BIC    #ACTIVE,STATUS(R2)
1233 005124          LET STATUS(R2) := STATUS(R2) SET.BY #ERROR
    (7) 005124 052762 100000 002456      BIS    #ERROR,STATUS(R2)
1234 005132          ENDIF
    (4) 005132 50042$:
1235 005132          ENDDO
    (4) 005132 000736      BR    50040$
    (3) 005134 50041$:
1236 005134          ENDIF
    (4) 005134 50037$:
1237 005134          ENDIF
    (4) 005134 50035$:
1238 005134          ENDIF
    (4) 005134 50034$:
1239 005134          IF ERRCOD NE #0 THEN
    (6) 005134 005737 002302      TST    ERRCOD
    (10) 005140 001403      BEQ    50043$
1240
1241      ; REPORT THE ERROR
1242      ;
1243 005142 004777 175710      JSR    PC,@ERRSVC
1244 005146          ELSE
    (4) 005146 000425      BR    50044$
    (3) 005150 50043$:
1245
1246      ; Q UP THE MESSAGE AND ENABLE INTERRUPTS
1247      ; THE I/O DRIVER WILL PICK UP FROM HERE.
1248      ;
1249 005150          LET CURADD(R2) := BUFADD      ; BYTE ADDRESS
    (4) 005150 013762 002314 002516      MOV    BUFADD,CURADD(R2)
1250 005156          LET MSGADR(R2) := BUFADD      ; MESSAGE ADDRESS
    (4) 005156 013762 002314 002656      MOV    BUFADD,MSGADR(R2)
1251 005164          LET CURCNT(R2) := BUFCNT      ; OUTPUT COUNT
    (4) 005164 013762 002316 002716      MOV    BUFCNT,CURCNT(R2)
1252 005172          LET MSGCNT(R2) := BUFCNT      ; BYTE COUNT
    (4) 005172 013762 002316 002556      MOV    BUFCNT,MSGCNT(R2)
1253 005200          LET REPCNT(R2) := BUFREP      ; PRINT COUNT
    (4) 005200 013762 002320 002616      MOV    BUFREP,REPCNT(R2)
1254 005206          IF CURCNT(R2) GT #0 THEN
    (6) 005206 005762 002716      TST    CURCNT(R2)
    (10) 005212 003403      BLE    50045$
1255 005214          LET @LPCSR(R2) := #100      ; ENABLE INTERRUPTS
    (4) 005214 012772 000100 002322      MOV    #100,@LPCSR(R2)
1256 005222          ENDIF
    (4) 005222 50045$:
1257 005222          ENDIF
    (4) 005222 50044$:
1258 005222          ENDIF
    (4) 005222 50032$:
1259
1260      ; CLEAR OUT ANY TIMEOUT COUNT
1261      ;
1262 005222          LET DELCNT(R2) := #0
  
```

CZLNAAO LN01 TEST DNMAC X24.07-563 12-JAN-83 08:16 PAGE 16-3^{L 3}
CZLNAA.P11 12-JAN-83 08:16 I/O CONTROL

SEQ 0037

```
(4) 005222 005062 003016 CLR DELCNT(R2)
1263
1264 : SELECT THE NEXT UNIT AND DECRIMENT THE LINECOUNT
1265 :
1266 005226 LET R3 := R3 - #1
(7) 005226 005303 DEC R3
1267 005230 LET L$LUN := L$LUN + #1
(7) 005230 005237 002074 INC L$LUN
1268 005234 000137 004722 JMP CTLL0P
1269 005240 CTLEND: POP R3,R2
1270 005240 MOV (SP)+,R3
(2) 005240 012603 MOV (SP)+,R2
(3) 005242 012602 RTS PC
1271 005244 000207
1272
1273 :++++
1274 : SUBROUTINE QUIET
1275 :
1276 : THIS SUBROUTINE WILL EFFECTIVLY DELAY UNTIL ALL QUEUED OUTPUT
1277 : IS FINISHED. THE DELAY IS ACCOMPLISHED BY QUEUEING A NULL
1278 : MESSAGE TO ALL LINES.
1279 :-----
1280
1281 005246 QUIET: OUTPUT #0,#0 ; NULL MESSAGE OUTPUT
1282 005310 NOP
1283 005312 000207 RTS PC
1284
```

```

1286
1287
1288
1289
1290
1291
1292
1293
1294 005314
(7) 005314 052762 040000 002456
1295 005322
(4) 005322 012762 177777 002716
1296 005330
(4) 005330 005072 002322
1297 005334
(8) 005334 013746 002074
(7) 005340 012746 004002
(6) 005344 012746 000002
(3) 005350 010600
(4) 005352 104417
(4) 005354 062706 000006
1298 005360
(4) 005360 005062 003060
1299 005364
(7) 005364 005337 002306
1300 005370
(6) 005370 005737 002306
(10) 005374 001011
1301 005376
(7) 005376 012746 003732
(6) 005402 012746 000001
(3) 005406 010600
(4) 005410 104417
(4) 005412 062706 000004
1302 005416
(3) 005416 104444
1303 005420
(4) 005420
1304 005420 000207
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315 005422
(4) 005422 005037 002074
1316 005426
(4) 005426
(6) 005426 023737 002074 002012
(10) 005434 002007
1317 005436
  
```

```

=====
: DROPIIT      FUNCTIONAL DESCRIPTION :
: THIS SUBROUTINE IS USED TO DROP A BAD PRINTER FROM THE TEST
: DISABLE ANY INTERRUPTS FROM THE PRINTER, AND NOTIFY THE
: OPERATOR THAT THE PRINTER WAS DROPPED.
=====
DROPIIT: LET STATUS(R2) := STATUS(R2) SET.BY #DROPED
        BIS      #DROPED,STATUS(R2)
        LET CURCNT(R2) := #-1
        MOV      #-1,CURCNT(R2)
        LET @LPCSR(R2) := #0
        CLR      @LPCSR(R2)
        PRINTF #LPDROD, L$LUN
        MOV      L$LUN,-(SP)
        MOV      #LPDROD,-(SP)
        MOV      #2,-(SP)
        MOV      SP,R0
        TRAP     C$PNTF
        ADD      #6,SP
        LET ERRIBL(R2) := #0
        CLR      ERRIBL(R2)
        LET UUT := UUT - #1
        DEC      UUT
        IF UUT EQ #0 THEN
          TST     UUT
          BNE     50046$
          PRINTF #UUTEQ0
          MOV     #UUTEQ0,-(SP)
          MOV     #1,-(SP)
          MOV     SP,R0
          TRAP     C$PNTF
          ADD     #4,SP
          DOCLN    ; NOTHING TO TEST
          TRAP     C$DCLN
        ENDIF
50046$: RTS      PC
  
```

```

=====
: FAKE      FUNCTIONAL DESCRIPTION:
: THIS SUBROUTINE IS REQUIRED TO INSURE PROPER PASS COUNT REPORTS
: IN A MULTI UNIT MODE OF OPERATION.
=====
FAKE: LET L$LUN := #0
      CLR      L$LUN
      WHILE L$LUN LT L$UNIT DO
50047$: CMP      L$LUN,L$UNIT
      BGE      50050$
      GPHARD    L$LUN, R3
  
```

CZLNAAO LN01 TEST DNMAC X24.07-563 12-JAN-83 08:16 PAGE 17-1^{N 3}
CZLNAA.P11 12-JAN-83 08:16 I/O CONTROL

SEQ 0039

(3)	005436	013700	002074	MOV	L\$LUN,RO
(3)	005442	104442		TRAP	C\$GPHRD
(3)	005444	010003		MOV	RO,R3
1318	005446			LET	L\$LUN := L\$LUN + #1
(7)	005446	005237	002074	INC	L\$LUN
1319	005452			ENDDO	
(4)	005452	000765		BR	50047\$
(3)	005454				
1320	005454	000207		RTS	PC
1321					
1322					
1323	005456			ENDMOD	

```

1325 .SBTTL INITIALIZATION SECTION
1326 :
1327 :THE INITIALIZE ROUTINE IS EXECUTED AT THE BEGINNING OF EACH SUB-PASS AND IS
1328 :PRIMARILY USED FOR REQUESTING P-TABLE PARAMETERS. INFORMATION REQUESTED FROM
1329 :THE OPERATOR INCLUDE THE NUMBER OF UNITS UNDER TEST, DEVICE ADDRESSES, VECTORS,
1330 :AND CLOCK TYPE.
1331 :
1332 BGNMOD
1333 BGNINIT
1334 L$INIT::
1335 :RESET EXTERNAL BUS IF START EVENT FLAG IS SET
1336 :OR POWER FAIL RESTART
1337 READEF #EF.START ;TEST START EF INDICATOR
1338 MOV #EF.START,R0
1339 TRAP C$REFG
1340 BCOMPLETE 1$ ;BRANCH IF FROM START UP
1341 BCS 1$
1342 READEF #EF.RESTART ;NOW THE RESTARTFLAG
1343 MOV #EF.RESTART,R0
1344 TRAP C$REFG
1345 BCOMPLETE 1$ ;IF EITHER START OR POWER FAIL RESTART
1346 BCS 1$
1347 JSR PC,FAKE ;DO A BUS RESET
1348 SETPRI #PRI00 ; UPDATE PASS COUNT
1349 MOV #PRI00,R0 ; PRIORITY ZERO
1350 TRAP C$SPRI
1351 LET OUTBUF :B= #14
1352 MOVB #14,OUTBUF
1353 OUTPUT #OUTBUF,#1
1354 DECR WORK1 FROM #6 TO #1 BY #1
1355 MOV #6,WORK1
1356 BR 50051$
1357 50052$: DEC WORK1
1358 50051$: CMP WORK1,#1
1359 BLT 50053$
1360 DELAY 250
1361 MOV #250,(PC)+
1362 .WORD 0
1363 MOV L$DLY,(PC)+
1364 .WORD 0
1365 DEC -6(PC)
1366 BNE -4
1367 DEC -22(PC)
1368 BNE -20
1369 ENDDEC
1370 BR 50052$
1371 50053$: EXIT INIT ; ELSE EXIT INIT CODE
1372 TRAP C$EXIT
1373 .WORD L10004-.
1374 :
1375 :POWER UP RESTART OR START COMMAND ISSUED
1376 :

```

```

1352 005642          1$: BRESET                      ;RESET THE BUS
    (3) 005642 104433 TRAP C$RESET
1353 005644          IF L$UNIT GT #16. THEN
    (6) 005644 023727 002012 000020 CMP L$UNIT,#16.
    (10) 005652 003420 BLE 50054$
1354 005654          PRINTF #NRGT16
    (7) 005654 012746 006506 MOV #NRGT16,-(SP)
    (6) 005660 012746 000001 MOV #1,-(SP)
    (3) 005664 010600 MOV SP,R0
    (4) 005666 104417 TRAP C$PRINTF
    (4) 005670 062706 000004 ADD #4,SP
1355 005674          PRINTF #NRGT17
    (7) 005674 012746 006571 MOV #NRGT17,-(SP)
    (6) 005700 012746 000001 MOV #1,-(SP)
    (3) 005704 010600 MOV SP,R0
    (4) 005706 104417 TRAP C$PRINTF
    (4) 005710 062706 000004 ADD #4,SP
1356 005714          ENDF
    (4) 005714          50054$:
1357 005714          MANUAL                          ; CHECK FOR UNATTENDED MODE
    (3) 005714 104450 TRAP C$MANI
1358 005716          BNCOMPLETE 2$                  ; IF UNATTENDED BYPASS MANUAL INSTRUCTIONS
    (2) 005716 103024 BCC 2$
1359
1360 005720          PRINTF #RESET1
    (7) 005720 012746 006701 MOV #RESET1,-(SP)
    (6) 005724 012746 000001 MOV #1,-(SP)
    (3) 005730 010600 MOV SP,R0
    (4) 005732 104417 TRAP C$PRINTF
    (4) 005734 062706 000004 ADD #4,SP
1361
1362          ;WAIT FOR A "CR" BEFORE GOING ON
1363          ;
1364 005740          LET FLAG := #0
    (4) 005740 005037 002240 CLR FLAG
1365 005744          LET ERRCOD := #0
    (4) 005744 005037 002302 CLR ERRCOD
1366 005750          LET UUT := #0
    (4) 005750 005037 002306 CLR UUT
1367 005754          100$:
1368 005754          GMANIL READY,FLAG,100000,YES
    (3) 005754 104443 TRAP C$GMAN
    (3) 005756 000404 BR 10000$
    (4) 005760 002240 .WORD FLAG
    (5) 005762 000130 .WORD T$CODE
    (5) 005764 006752 .WORD READY
    (5) 005766 100000 .WORD 100000
    (3) 005770          10000$:
1369          ;REQUEST P-TABLE FOR PRINTERS UNDER TEST
1370          ;
1371          ;
1372 005770          2$: LET R1 := L$UNIT - #1          ;MAXIMUM NUMBER OF UNITS
    (5) 005770 013701 002012 MOV L$UNIT,R1
    (7) 005774 005301 DEC R1
1373 005776          INCR L$LUN FROM #0 TO R1 BY #1
    (5) 005776 005037 002074 CLR L$LUN
  
```

```

(7) 006002 000402
(6) 006004
(10) 006004 005237 002074
(7) 006010
(7) 006010 023701 002074
(9) 006014 003073
1374 006016
(3) 006016 013700 002074
(3) 006022 104442
(3) 006024 010003
1375 006026
(2) 006026 103062
1376 006030
(5) 006030 013702 002074
(8) 006034 006302
1377 006036
(4) 006036 005062 003060
1378 006042
(4) 006042 012762 177777 002716
1379 006050
(4) 006050 005062 003016
1380 006054
(4) 006054 005062 002616
1381
1382
1383
1384 006060
(4) 006060 012362 002322
1385 006064
(5) 006064 016262 002322 002416
(7) 006072 062762 000002 002416
1386
1387
1388
1389 006100
(4) 006100 012362 002362
1390
1391
1392
1393 006104
(5) 006104 010237 003120
(8) 006110 006337 003120
(8) 006114 006337 003120
(8) 006120 006337 003120
1394 006124
(7) 006124 062737 021460 003120
1395 006132
(4) 006132 013762 003120 002756
1396 006140
(7) 006140 012746 000200
(6) 006144 016246 002756
(5) 006150 016246 002362
(4) 006154 012746 000003
(3) 006160 104437
(2) 006162 062706 000010
1397

50056$: BR 50055$
50055$: INC L$LUN
50055$: CMP L$LUN,R1
BGT 50057$
GPHARD L$LUN,R3 ;REQUEST P-TABLE ADDRESS
MOV L$LUN,R0
TRAP C$GPHRD
MOV R0,R3
BNCOMPLETE 3$ ;BRANCH IF DEVICE NOT PRESENT
BCC 3$
LET R2 := L$LUN SHIFT 1
MOV L$LUN,R2
ASL R2
LET ERRIBL(R2) := #0
CLR ERRIBL(R2)
LET CURCNT(R2) := #-1
MOV #-1,CURCNT(R2)
LET DELCNT(R2) := #0
CLR DELCNT(R2)
LET REPCNT(R2) := #0
CLR REPCNT(R2)

;LOAD CSR ADDRESS INTO TABLE
LET LPCSR(R2) := (R3)+ ;SET UP CSR ADDRESS FOR DEVICE
MOV (R3)+,LPCSR(R2)
LET LPBUF(R2) := LPCSR(R2) + #2
MOV LPCSR(R2),LPBUF(R2)
ADD #2,LPBUF(R2)

;SET UP VECTOR ADDRESS INTO GIVEN TABLE
LET LPVEC(R2) := (R3)+
MOV (R3)+,LPVEC(R2)

;SET UP DEVICE INTERRUPT VECTOR INFORMATION
LET WORK := R2 SHIFT 3
MOV R2,WORK
ASL WORK
ASL WORK
ASL WORK
LET WORK := WORK + #INT00
ADD #INT00,WORK
LET LPINTR(R2) := WORK
MOV WORK,LPINTR(R2)
SETVEC LPVEC(R2),LPINTR(R2),#PRI04
MOV #PRI04,-(SP)
MOV LPINTR(R2),-(SP)
MOV LPVEC(R2),-(SP)
MOV #3,-(SP)
TRAP C$SVEC
ADD #10,SP

```

```

1398      ; ADD ONE TO UNIT UNDER TEST COUNT
1399      ;
1400      LET UUT := UUT + #1
1401      INC UUT
1402      BR 4$
1403      ; INDICATE L$LUN NOT AVAILABLE FOR TESTING
1404      ;
1405      3$: LET STATUS(R2) := STATUS(R2) SET.BY #DROPED
1406      BIS #DROPED,STATUS(R2)
1407      4$: ENDINC ;GO BACK AND DO IT AGAIN
1408      BR 50056$
1409      50057$:
1410      ; *****
1411      ; SETUP TO HANDLE CLOCK INTERRUPTS
1412      ; IF AN L-CLOCK IS ON THE SYSTEM THEN SETUP A NOOP INTERRUPT
1413      ; HANDLER BECAUSE LSI SYSTEMS MAY HAVE THE CLOCK ENABLED AT ALL TIMES.
1414      LET CLKTYP := #1 ; DEFAULT FOR NO CLOCK ON SYSTEM
1415      MOV #1,CLKTYP
1416      CLOCK L,R4 ; TEST FOR L-CLOCK
1417      MOV #L,R0
1418      TRAP C$CLK
1419      MOV R0,R4
1420      IFCOND CS THEN ; WE HAVE AN L-CLOCK
1421      BCC 50060$
1422      LET CLKTYP := #2
1423      MOV #2,CLKTYP
1424      LET CLOCKP := R4
1425      MOV R4,CLOCKP
1426      LET CLKCSR := @CLOCKP
1427      MOV @CLOCKP,CLKCSR
1428      LET @CLKCSR := #00 ; TRY TO DISABLE INTERRUPTS
1429      MOV #00,@CLKCSR
1430      ; SETUP THE NOOP HANDLER
1431      LET CLKVEC := 4(R4)
1432      MOV 4(R4),CLKVEC
1433      SETVEC CLKVEC,#IGNORE,#PRI06
1434      MOV #PRI06,-(SP)
1435      MOV #IGNORE,-(SP)
1436      MOV CLKVEC,-(SP)
1437      MOV #3,-(SP)
1438      TRAP C$SVEC
1439      ADD #10,SP
1440      ENDIF
1441      50060$:
1442      ; IF A P-CLOCK IS ON THE SYSTEM UPGRADE CLOCK TYPE TO 3
1443      CK1: CLOCK P,R4
1444      MOV #P,R0
1445      TRAP C$CLK
1446      MOV R0,R4
1447      IFCOND CS THEN ; WE HAVE A P-CLOCK
1448      BCC 50061$
1449      LET CLKTYP := #3
1450      MOV #3,CLKTYP
1451      LET CLOCKP := R4
1452      MOV R4,CLOCKP

```

```

1427 006332          LET CLKCSR := @CLOCKP
(4) 006332 017737 173732 002272    MOV @CLOCKP,CLKCSR
1428 006340          LET CLKVEC := 4(R4)
(4) 006340 016437 000004 002276    MOV 4(R4),CLKVEC
1429                                ; TRY TO DISABLE THE P-CLOCK
1430 006346          LET @CLKCSR := #00
(4) 006346 012777 000000 173716    MOV #00,@CLKCSR
1431 006354          ENDIF
(4) 006354
1432 50061$:
1433 ; IF NO CLOCKS ON THE SYSTEM NOTIFY THE OPERATOR
(6) 006354 023727 002266 000001    IF CLKTYP EQ #1 THEN
(10) 006362 001020                    CMP CLKTYP,#1
1434 006364          PRINTF #NOCLCK
(7) 006364 012746 007007            MOV #NOCLCK,-(SP)
(6) 006370 012746 000001            MOV #1,-(SP)
(3) 006374 010600                    MOV SP,R0
(4) 006376 104417                    TRAP C$PNTF
(4) 006400 062706 000004            ADD #4,SP
1435 006404          PRINTF #NOTIM
(7) 006404 012746 007051            MOV #NOTIM,-(SP)
(6) 006410 012746 000001            MOV #1,-(SP)
(3) 006414 010600                    MOV SP,R0
(4) 006416 104417                    TRAP C$PNTF
(4) 006420 062706 000004            ADD #4,SP
1436 006424          ENDIF
(4) 006424
1437 50062$:
(3) 006424 012700 000000            SETPRI #PRI00
(3) 006430 104441                    MOV #PRI00,R0
1438 006432          TRAP C$SPRI
(4) 006432 112737 000014 003124    LET OUTBUF:B= #14
1439 006440          MOV #14,OUTBUF
1440 006502          OUTPUT #OUTBUF,#1
(3) 006502 104432                    EXIT INIT
(3) 006504 000440                    TRAP C$EXIT
1441                                .WORD L10004-.
1442                                .NLIST BEX
1443 006506 047045 040445 052516    NRGT16: .ASCIZ /%NUMBER OF LINE PRINTERS UNDER TEST EXCEEDS 16./
1444 006571 045 022516 047501      NRGT17: .ASCIZ /%ONLY 16 WILL BE TESTED./
1445 006625 045 022516 051101      MRESET: .ASCIZ /%ARESET PRINTER(S), AND PLACE ON LINE.%N/
1446 006701 045 022516 051101      RESET1: .ASCIZ /%ARESET PRINTER(S) AND PLACE ON LINE.%N/
1447
1448 006752 042504 051120 051505    READY: .ASCIZ /DEPRESS "RETURN" WHEN READY./
1449 007007 045 022516 044101      NOCLCK: .ASCIZ /%HARDWARE CLOCK NOT AVAILABLE./
1450 007051 045 022516 040501      NOTIM: .ASCIZ /%AAUTO PRINTING SPEED MEASUREMENT CANNOT BE PERFORMED./
1451                                .EVEN
1452 007142 000000                    PLOC: .WORD 0
1453
1454                                .LIST BEX
1455 007144          ENDINIT
(3) 007144          L10004:
(3) 007144 104411                    TRAP C$INIT
1456
1457                                ::::::::::::::AN INTERRUPT CATCHER FOR THE L-CLOCK::::::::::::
1458                                ; IGNORE

```

```

1459                                     :          THAT IGNORES THE INTERRUPT.
1460                                     :          USED FOR SYSTEMS WHERE CLOCK CANNOT BE TURNED OFF.
1461                                     :          .....
1462                                     :
1463 007146 000002      IGNORE:          ; NOOP
1464 007146          RTI
1465
1466
1467
1468 -----
1469 : RESVEC          FUNCTIONAL DESCRIPTION
1470 :
1471 :          THIS SUBROUTINE WILL SETUP ALL UNITS VECTOR AREAS
1472 :          TO THE 'NORMAL' INTERRUPT ROUTINES STARTING AT INT00.
1473 : -----
1474
1475
1476 007150      RESVEC::          PUSH    R3,R4
1477 (2) 007150 010346      MOV      R3,-(SP)
1478 (3) 007152 010446      MOV      R4,-(SP)
1479 007154          LET    R4 := #0
1480 (4) 007154 005004      CLR      R4
1481 007156          LET    R3 := LSUNIT
1482 (4) 007156 013703 002012      MOV      LSUNIT,R3
1483 007162          WHILE R3 GT #0 DO
1484 (4) 007162          50063$:
1485 (6) 007162 005703      TST      R3
1486 (10) 007164 003417      BLE      50064$
1487 007166          SETVEC LPVEC(R4), LPINTR(R4), #PRIO4
1488 (7) 007166 012746 000200      MOV      #PRIO4,-(SP)
1489 (6) 007172 016446 002756      MOV      LPINTR(R4),-(SP)
1490 (5) 007176 016446 002362      MOV      LPVEC(R4),-(SP)
1491 (4) 007202 012746 000003      MOV      #3,-(SP)
1492 (3) 007206 104437      TRAP     C$SVEC
1493 (2) 007210 062706 000010      ADD      #10,SP
1494 007214          LET    R4 := R4 + #2
1495 (7) 007214 062704 000002      ADD      #2,R4
1496 007220          LET    R3 := R3 - #1
1497 (7) 007220 005303      DEC      R3
1498 007222          ENDDO
1499 (4) 007222 000757      BR       50063$
1500 (3) 007224          50064$:
1501 007224          POP    R4,R3
1502 (2) 007224 012604      MOV      (SP)+,R4
1503 (3) 007226 012603      MOV      (SP)+,R3
1504 007230 000207      RTS      PC
1505
1506

```

```

1488 .SBTTL CLEANUP CODING SECTION
1489 STARS
1490 .....
1491 .....
1492 :THE PURPOSE OF THE CLEANUP SECTION IS TO CLEANUP ALL PRINTERS UNDER TEST
1493 :AND RETEST ANY UNITS WHICH HAVE BEEN DROPPED FROM TESTING TO INSURE THAT
1494 :THEY HAVE NOT COME BACK ON LINE. IF THE DEVICE HAS COME BACK ON LINE
1495 :TESTING WILL BE RESTARTED ON THE DEVICE. THIS INSURES THAT
1496 :IN THE EVENT A PAPER OUT OCCURRED AND THE OPERATOR HAS PUT ADDITIONAL PAPER
1497 :INTO THE UNIT UNDER TEST, THE INITIALIZATION SEQUENCE DOES NOT
1498 :HAVE TO BE DONE AGAIN IN ORDER TO GET THE DEVICE ACTIVE.
1499 STARS
1500 .....
1501 BGNCLN
1502 L$CLEAN::
1503     SETPRI #PRI07
1504     MOV     #PRI07,R0
1505     TRAP    C$SPRI
1506     BRESET
1507     TRAP    C$RESET
1508
1509 CLEAN: LET R1 := L$UNIT - #1 ;NUMBER OF UNITS-1
1510     MOV     L$UNIT,R1
1511     DEC     R1
1512     INCR L$LUN FROM #0 TO R1 BY #1
1513     CLR     L$LUN
1514     BR      50065$
1515
1516 50066$: INC     L$LUN
1517 50065$: CMP     L$LUN,R1
1518     BGT     50067$
1519     ; DISABLE ALL INTERRUPTS, SELECT ALL LINES
1520     ; ZERO ALL ERROR COUNTS
1521     LET R2 := L$LUN SHIFT 1
1522     MOV     L$LUN,R2
1523     ASL     R2
1524     ; CLEAR ALL BITS IN STATUS EXCEPT DEVICE TYPE
1525     LET STATUS(R2) := STATUS(R2) CLR.BY #ERROR!DROPPED!ACTIVE!LOBYTE
1526     BIC     #ERROR!DROPPED!ACTIVE!LOBYTE,STATUS(R2)
1527     LET CURCNT(R2) := #-1
1528     MOV     #-1,CURCNT(R2)
1529     LET ERRIBL(R2) := #0
1530     CLR     ERRIBL(R2)
1531     LET DELCNT(R2) := #0
1532     CLR     DELCNT(R2)
1533     LET REPCNT(R2) := #0
1534     CLR     REPCNT(R2)
1535     ENDINC
1536     BR      50066$
1537
1538 50067$: JSR     PC,RESVEC ; RESET THE VECTORS
1539     IF CLK TYP EQ #3 THEN
1540     CMP     CLK TYP,#3
1541     BNE     50070$
1542
1543 (2) 007232
1544 (3) 007232
1545 (3) 007232 012700 000340
1546 (3) 007236 104441
1547 (3) 007240 104433
1548 (5) 007242 013701 002012
1549 (7) 007246 005301
1550 (5) 007250 005037 002074
1551 (7) 007254 000402
1552 (6) 007256
1553 (10) 007256 005237 002074
1554 (7) 007262
1555 (7) 007262 023701 002074
1556 (9) 007266 003020
1557
1558 (5) 007270 013702 002074
1559 (8) 007274 006302
1560
1561 (7) 007276 042762 160377 002456
1562 (4) 007304 012762 177777 002716
1563 (4) 007312 005062 003060
1564 (4) 007316 005062 003016
1565 (4) 007322 005062 002616
1566 (5) 007326 000753
1567 (4) 007330
1568 (5) 007330 004737 007150
1569 (6) 007334 023727 002266 000003
1570 (10) 007342 001006
  
```

```

1518 007344          CLRVEC @CLKVEC
      (3) 007344 017700 172726      MOV @CLKVEC,R0
      (3) 007350 104436          TRAP C$CVEC
1519 007352          LET @CLKCSR := #00
      (4) 007352 012777 000000 172712      MOV #00,@CLKCSR
1520 007360          ENDIF
      (4) 007360          50070$:
1521 007360          IF CLKTYP EQ #2 THEN
      (6) 007360 023727 002266 000002      CMP CLKTYP,#2
      (10) 007366 001013          BNE 50071$
1522 007370          SETVEC CLKVEC,#IGNORE,#PRI06
      (7) 007370 012746 000300      MOV #PRI06,-(SP)
      (6) 007374 012746 007146      MOV #IGNORE,-(SP)
      (5) 007400 013746 002276      MOV CLKVEC,-(SP)
      (4) 007404 012746 000003      MOV #3,-(SP)
      (3) 007410 104437          TRAP C$SVEC
      (2) 007412 062706 000010      ADD #10,SP
1523 007416          ENDIF
      (4) 007416          50071$:
1524 007416          SETPRI #PRI00
      (3) 007416 012700 000000      MOV #PRI00,R0
      (3) 007422 104441          TRAP C$SPRI
1525 007424          ENDCLN
      (3) 007424          L10005:
      (3) 007424 104412          TRAP C$CLEAN
1526
1527 007426          ENDMCD
1528          .SBTTL INTERFACE LOGIC
1529
1530 007426          BGNMOD
1531          :++
1532          :THIS TEST VERIFIES THE OPERATION OF THE INTERFACE LOGIC. TESTS ARE
1533          :PERFORMED FOR PRINTER ERROR, PRINTER READY, AND CLEARING PRINTER READY
1534          :BY LOADING A CHARACTER INTO THE OUTPUT BUFFER. ALSO IT IS VERIFIED
1535          :THAT THE PRINTER WILL NOT INTERRUPT IF IT IS AT THE SAME PRIORITY LEVEL
1536          :AS THE PROCESSOR, BUT WILL INTERRUPT IF THE PROCESSOR IS AT A LOWER
1537          :PRIORITY LEVEL. THE PRINTER IS AT PRIORITY LEVEL 4.
1538          :
1539          :
1540          :--
1541 007426          BGNTEST 1
      (3) 007426          T1::
1542 007426          LET R1 := L$UNIT - #1          ;MAX NUMBER OF UNITS ON SYSTEM
      (5) 007426 013701 002012      MOV L$UNIT,R1
      (7) 007432 005301          DEC R1
1543          :
1544          :HARD CODED INCREMENT LOOP
1545          :INCR LUNIT FROM #0 TO R1 BY #1          ;START LOOP
1546          :
1547 007434 005037 002260          CLR LUNIT          ;UNIT TO 0
1548 007440 000402          BR T1C          ;DO COMPARE
1549 007442          T1A:
1550 007442 005237 002260          INC LUNIT          ;UPDATE UNIT NUMBER
1551 007446          T1C:
1552 007446 023701 002260          CMP LUNIT,R1          ;DO COMPARISON OF UNIT NUMBER
1553 007452 003402          BLE 1$          ;ONTO NEXT UNIT
  
```

1554	007454	000137	010220		JMP	T1B		;EXIT LOOP
1555	007460				1\$:			
1556	007460					LET R2 := LUNIT SHIFT 1		
(5)	007460	013702	002260		MOV	LUNIT,R2		
(8)	007464	006302			ASL	R2		
1557	007466				IF #BIT15 SETIN @LPCSR(R2) THEN			
(6)	007466	032772	100000	002322	BIT	#BIT15,@LPCSR(R2)		
(10)	007474	001416			BEQ	50072\$		
1558	007476				LET STATUS(R2) := STATUS(R2) SET.BY #ERROR			
(7)	007476	052762	100000	002456	BIS	#ERROR,STATUS(R2)		
1559	007504				LET ERRIBL(R2) := ERRIBL(R2) + #1			
(7)	007504	005262	003060		INC	ERRIBL(R2)		
1560	007510				LET L\$LUN := LUNIT			
(4)	007510	013737	002260	002074	MOV	LUNIT,L\$LUN		
1561	007516				ERRHRD 1,CSREHR			;ERROR BIT WAS SET. SAY SO
(4)	007516	104456			TRAP	CSREHRD		
(5)	007520	000001			.WORD	1		
(5)	007522	003352			.WORD	CSREHR		
(5)	007524	000000			.WORD	0		
1562	007526				LET @LPCSR(R2) := #0			
(4)	007526	005072	002322		CLR	@LPCSR(R2)		
1563	007532				ENDIF			
(4)	007532				50072\$:			
1564					;TIME DELAY			
1565					; IF NOT READY ALLOW 3 SECONDS TO COME UP			
1566	007532				IF #BIT7 NOTSETIN @LPCSR(R2) THEN			
(6)	007532	032772	000200	002322	BIT	#BIT7,@LPCSR(R2)		
(10)	007540	001027			BNE	50073\$		
1567	007542				DECR WORK1 FROM #12. TO #1 BY #1			
(5)	007542	012737	000014	003122	MOV	#12,WORK1		
(7)	007550	000402			BR	50074\$		
(6)	007552				50075\$:			
(10)	007552	005337	003122		DEC	WORK1		
(7)	007556				50074\$:			
(7)	007556	023727	003122	000001	CMP	WORK1,#1		
(9)	007564	002415			BLT	50076\$		
1568	007566				DELAY 250			
(2)	007566	012727	000250		MOV	#250,(PC)+		
(2)	007572	000000			.WORD	0		
(2)	007574	013727	002116		MOV	L\$DLY,(PC)+		
(2)	007600	000000			.WORD	0		
(2)	007602	005367	177772		DEC	-6(PC)		
(2)	007606	001375			BNE	-4		
(2)	007610	005367	177756		DEC	-22(PC)		
(2)	007614	001367			BNE	-20		
1569	007616				ENDDEC			
(5)	007616	000755			BR	50075\$		
(4)	007620				50076\$:			
1570	007620				ENDIF			
(4)	007620				50073\$:			
1571					;NOW TEST FOR PRINTER READY			
1572					:			
1573					:			
1574	007620				IF #BIT07 NOTSETIN @LPCSR(R2) THEN			;TEST FOR THE READY BIT
(6)	007620	032772	000200	002322	BIT	#BIT07,@LPCSR(R2)		
(10)	007626	001014			BNE	50077\$		

1575	007630				LET STATUS(R2) := STATUS(R2) SET.BY #ERROR
(7)	007630	052762	100000	002456	BIS #ERROR,STATUS(R2)
1576	007636				LET L\$LUN := LUNIT
(4)	007636	013737	002260	002074	MOV LUNIT,L\$LUN
1577	007644				LET ERRIBL(R2) := ERRIBL(R2) + #1
(7)	007644	005262	003060		INC ERRIBL(R2)
1578	007650				ERRHRD 2,RDYERR ;REPORT AN ERROR
(4)	007650	104456			TRAP C\$ERRHD
(5)	007652	000002			.WORD 2
(5)	007654	003370			.WORD RDYERR
(5)	007656	000000			.WORD 0
1579	007660				ENDIF
(4)	007660				50077\$:
1580					:
1581					:INSURE LOADING CHARACTER CAUSES PRINTER READY TO GO AWAY
1582					:
1583	007660				LET @LPBUF(R2) := #12
(4)	007660	012772	000012	002416	MOV #12,@LPBUF(R2)
1584	007666				IF #BIT07 SET IN @LPCSR(R2) THEN
(6)	007666	032772	000200	002322	BIT #BIT07,@LPCSR(R2)
(10)	007674	001416			BEQ 50100\$
1585	007676				LET STATUS(R2) := STATUS(R2) SET.BY #ERROR
(7)	007676	052762	100000	002456	BIS #ERROR,STATUS(R2)
1586	007704				LET ERRIBL(R2) := ERRIBL(R2) + #1
(7)	007704	005262	003060		INC ERRIBL(R2)
1587	007710				LET L\$LUN := LUNIT
(4)	007710	013737	002260	002074	MOV LUNIT,L\$LUN
1588	007716				ERRHRD 3,ERR11 ;REPORT AN ERROR
(4)	007716	104456			TRAP C\$ERRHD
(5)	007720	000003			.WORD 3
(5)	007722	010504			.WORD ERR11
(5)	007724	000000			.WORD 0
1589	007726				LET @LPCSR(R2) := #0
(4)	007726	005072	002322		CLR @LPCSR(R2)
1590	007732				ENDIF
(4)	007732				50100\$:
1591					:
1592					:VERIFY THAT THE PRINTER WILL NOT INTERRUPT IF IT IS AT A PRIORITY LEVEL
1593					:THE SAME AS THE CPU
1594					:
1595	007732				SETPRI #PRI04 ;CPU TO PRIORITY 4
(3)	007732	012700	000200		MOV #PRI04,R0
(3)	007736	104441			TRAP C\$SPRI
1596	007740				SETVEC LPVEC(R2),#INTERR,#PRI04 ;LP VECTOR SET UP
(7)	007740	012746	000200		MOV #PRI04,-(SP)
(6)	007744	012746	010366		MOV #INTERR,-(SP)
(5)	007750	016246	002362		MOV LPVEC(R2),-(SP)
(4)	007754	012746	000003		MOV #3,-(SP)
(3)	007760	104437			TRAP C\$SVEC
(2)	007762	062706	000010		ADD #10,SP
1597	007766				LET @LPCSR(R2) := @LPCSR(R2) SET.BY #100 ;INTERRUPT ENABLE
(7)	007766	052772	000100	002322	BIS #100,@LPCSR(R2)
1598	007774				DECR WORK1 FROM #12 TO #1 BY #1
(5)	007774	012737	000012	003122	MOV #12,WORK1
(7)	010002	000402			BR 50101\$
(6)	010004				50102\$:

```

(10) 010004 005337 003122      DEC      WORK1
(7)  010010      >0101$:      CMP      WORK1,#1
(7)  010010 023727 003122 000001      BLT      50103$
(9)  010016 002415      DELAY      250.      ; ALLOW 3 SEC FOR DELAY
1599 010020      MOV      #250.,(PC)+
(2)  010020 012727 000372      .WORD      0
(2)  010024 000000      MOV      L$DLY,(PC)+
(2)  010026 013727 002116      .WORD      0
(2)  010032 000000      DEC      -6(PC)
(2)  010034 005367 177772      BNE      -4
(2)  010040 001375      DEC      -22(PC)
(2)  010042 005367 177756      BNE      -20
(2)  010046 001367      ENDDEC
1600 010050      BR      50102$
(5)  010050 000755      50103$:
(4)  010052      :
1601      :NOW TEST THAT THE PRINTER WILL INTERRUPT IF THE CPU PRIORITY IS LOWER THAN
1602      :THE PRINTER PRIORITY
1603      :
1604      :
1605 010052      LET @LPCSR(R2) := @LPCSR(R2) CLR.BY #100      ;CLEAR INTERRUPT ENABLE
(7)  010052 042772 000100 002322      BIC      #100,@LPCSR(R2)
1606 010060      SETPRI #PRI03      ;CPU TO PRICRITY 3
(3)  010060 012700 000140      MOV      #PRI03,R0
(3)  010064 104441      TRAP      C$SPRI
1607 010066      SETVEC LPVEC(R2),#INTHDL,#PRI04
(7)  010066 012746 000200      MOV      #PRI04,-(SP)
(6)  010072 012746 010416      MOV      #INTHDL,-(SP)
(5)  010076 016246 002362      MOV      LPVEC(R2),-(SP)
(4)  010102 012746 000003      MOV      #3,-(SP)
(3)  010106 104437      TRAP      C$SVEC
(2)  010110 062706 000010      ADD      #10,SP
1608 010114      LET @LPCSR(R2) := @LPCSR(R2) SET.BY #100      ;INTERRUPT ENABLE
(7)  010114 052772 000100 002322      BIS      #100,@LPCSR(R2)
1609 010122      DELAY 30      ; ALLOW 3 SEC DELAY
(2)  010122 012727 000030      MOV      #30,(PC)+
(2)  010126 000000      .WORD      0
(2)  010130 013727 002116      MOV      L$DLY,(PC)+
(2)  010134 000000      .WORD      0
(2)  010136 005367 177772      DEC      -6(PC)
(2)  010142 001375      BNE      -4
(2)  010144 005367 177756      DEC      -22(PC)
(2)  010150 001367      BNE      -20
1610 010152      LET ERRIBL(R2) := FRRIBL(R2) + #1
(7)  010152 005262 003060      INC      ERRIBL(R2)
1611 010156      LET L$LUN := LUNIT
(4)  010156 013737 002260 002074      MOV      LUNIT,L$LUN
1612 010164      ERRHRD 4,ERR13
(4)  010164 104456      TRAP      C$ERRHD
(5)  010166 000004      .WORD      4
(5)  010170 010643      .WORD      ERR13
(5)  010172 000000      .WORD      0
1613 010174      END2:      LET @LPCSR(R2) := #00      ; CLEAR THE LPCSR
(4)  010174 012772 000000 002322      MOV      #00,@LPCSR(R2)
1614 010202      LET STATUS(R2) := STATUS(R2) CLR.BY #ERROR DROPE!ACTIVE
(7)  010202 042762 160000 002456      BIC      #ERROR!DROPE!ACTIVE,STATUS(R2)

```

```

1615 010210          LET DELCNT(R2) := #0
      (4) 010210 005062 003016      CLR      DELCNT(R2)
1616
1617      :END OF HARD CODED INCREMENT LOOP
1618      :ENDINC
1619
1620 010214 000137 007442      JMP      T1A          ;UPDATE UNIT #
1621 010220 004737 007150      T1B: JSR      PC,RESVEC      ; RESET STANDARD VECTORS
1622 010224          SETPRI #PRI00
      (3) 010224 012700 000000      MOV      #PRI00,R0
      (3) 010230 104441          TRAP      C$SPRI
1623 010232          OUTPUT #INTFAC,#47.
1627 010274          LET OUTBUF :B= #14
      (4) 010274 112737 000014 003124      MOV      #14,OUTBUF
1628 010302          OUTPUT #OUTBUF,#1
1629 010344 004737 005246      JSR PC,QUIET
1630 010350          WHILE #BIT7 NOTSETIN @LPCSR(R2) DO      ;WAIT FOR READY
      (4) 010350          50104$: BIT      #BIT7,@LPCSR(R2)
      (6) 010350 032772 000200 002322      BNE      50105$
      (10) 010356 001001          ENDDO
1631 010360          BR      50104$
      (4) 010360 000773          50105$:
      (3) 010362          EXIT TST      ;EXIT THE TEST
1632 010362          TRAP      C$EXIT
      (3) 010362 104432          .WORD    L10006-.
      (3) 010364 000334
1633
1634      : INTERRUPT HANDLER TO SERVICE FAULTY INTERRUPT FROM LP INTERFACE.
1635      : THIS ROUTINE IS ENTERED ONLY WHEN THE LP INTERRUPTS AT THE SAME LEVEL AS
1636      : THE CPU AND IS CONSIDERED AN ERROR.
1637
1638 010366      BGNSRV
1639 010366      INTERR: LET ERRtbl(R2) := ERRtbl(R2) + #1
      (7) 010366 005262 003060      INC      ERRtbl(R2)
1640 010372      LET L$LUN := LUNIT
      (4) 010372 013737 002260 002074      MOV      LUNIT,L$LUN
1641 010400      ERRHRD 5,ERR12
      (4) 010400 104456          TRAP      C$ERRHRD
      (5) 010402 000005          .WORD    5
      (5) 010404 010560          .WORD    ERR12
      (5) 010406 000000          .WORD    0
1642 010410      LET (SP) := #END2
      (4) 010410 012716 010174      MOV      #END2,(SP)
1643 010414      ENDSRV
      (3) 010414          L10007:
      (2) 010414 000002          RTI
1644
1645      : INTERRUPT HANDLER FOR EXPECTED INTERRUPT
1646
1647 010416      BGNSRV
1648
1649 010416      INTHDL: LET (SP) := #END2
      (4) 010416 012716 010174      MOV      #END2,(SP)
1650 010422      ENDSRV
      (3) 010422          L10010:
      (2) 010422 000002          RTI

```

```
1651  
1652  
1653 010424 047111 042524 043122 .NLIST BEX  
1654 INTFAC: .ASCIZ /INTERFACE LOGIC TEST 1 ---- TEST COMPLETE/<12><12>  
1655  
1656 .ERROR MESSAGES ASSOCIATED WITH THIS TEST  
1657 010504 047514 042101 047111 ERR11: .ASCIZ /LOADING PRINTER BUFFER DOES NOT CLEAR READY/  
1658 010560 051120 047111 042524 ERR12: .ASCIZ /PRINTER INTERRUPTED AT SAME LEVEL AS THE PROCESSOR/  
1659 010643 120 044522 052116 ERR13: .ASCIZ /PRINTER DID NOT INTERRUPT AT CPU PRIORITY 3/  
1660 010720 .EVEN  
1661 010720 ENDTST  
1662 (3) 010720 L10006:  
1663 (3) 010720 104401 TRAP C$ETST  
1664 010722 .LIST BEX  
ENDMOD
```

```

1666 .SBTTL DATA TRANSFER PATHS
1667
1668 010722 BGNMOD
1669 :++
1670 :THIS TEST CHECKS THE DATA TRANSFER
1671 :PATHS FROM THE PROCESSOR INTERFACE
1672 :TO THE PRINTER OUTPUT. AN ALTERNATING
1673 :PATTERN OF ONES AND ZEROES CORRESPONDING
1674 :TO AN ALTERNATING STRING OF '*' AND
1675 :'U' CHARACTERS ARE TRANSMITTED ON THE
1676 :FULL 132 COLUMNS. AFTER 16 LINES OF
1677 :THIS PATTERN, THE OUTPUT PATTERN IS
1678 :SWITCHED TO AN ALTERNATING PATTERN
1679 :OF '?' AND '@' CHARACTERS FOR ANOTHER
1680 :16 LINES.
1681 :--
1682
1683 010722 BGNTEST 2
1684 (3) 010722 T2::
1685
1688 :PRINT TEST IDENTIFICATION
1689 010722 OUTPUT #DATPTH,#29.
1690 :PRINT ALTERNATING STRINGS OF CHARACTERS
1691 010764 INCR PATTERN FROM #1 TO #2 BY #1
1692 (5) 010764 012737 000001 011352 MOV #1,PATTERN
1693 (7) 010772 000402 BR 50106$
1694 (6) 010774 50107$: INC PATTERN
1695 (10) 010774 005237 011352 50106$: CMP PATTERN,#2
1696 (7) 011000 023727 011352 000002 BGT 50110$
1697 (9) 011006 003111 IF PATTERN EQ #1 THEN
1698 011010 023727 011352 000001 CMP PATTERN,#1
1699 (6) 011010 001004 BNE 50111$
1700 (10) 011016 112737 000125 011312 LET CHAR :B= #'U
1701 (4) 011020 112737 000125 011312 MOVB #'U,CHAR
1702 (4) 011026 000403 ELSE BR 50112$
1703 (3) 011030 50111$: LET CHAR :B= #'?
1704 011030 112737 000077 011312 MOVB #'?,CHAR
1705 (4) 011036 012704 003124 ENDF
1706 011036 012704 003124 50112$: LET R4 := #OUTBUF
1707 011042 012737 000001 002250 MOV #OUTBUF,R4
1708 (5) 011042 000402 INCR CCNT FROM #1 TO #66. BY #1
1709 (7) 011050 000402 MOV #1,CCNT
1710 (6) 011052 005237 002250 50114$: BR 50113$
1711 (10) 011052 005237 002250 INC CCNT
1712 (7) 011056 023727 002250 000102 50113$: CMP CCNT,#66.
1713 (9) 011064 003017 BGT 50115$
1714 011066 113724 011312 LET (R4)+ :B= CHAR
1715 (4) 011066 105137 011312 MOVB CHAR,(R4)+
1716 011072 105137 011312 COMB CHAR

```

```

1701 011076          LET CHAR :B= CHAR CLR.BY #200
(7) 011076 142737 000200 011312 BICB #200,CHAR
1702 011104          LET (R4)+ :B= CHAR
(4) 011104 113724 011312 MOVB CHAR,(R4)+
1703 011110 105137 011312 COMB CHAR
1704 011114          LET CHAR :B= CHAR CLR.BY #200
(7) 011114 142737 000200 011312 BICB #200,CHAR
1705 011122          ENDINC
(5) 011122 000753 BR 50114$
(4) 011124 50115$: LET (R4)+ :B= #15
1706 011124 112724 000015 MOVB #15,(R4)+
(4) 011124 LET (R4) :B= #12
1707 011130 112714 000012 MOVB #12,(R4)
1708 011134          INCR LINCNT FROM #1 TO #16. BY #1
(5) 011134 012737 000001 002242 MOV #1,LINCNT
(7) 011142 000402 BR 50116$
(6) 011144 50117$: INC LINCNT
(10) 011144 005237 002242 50116$: CMP LINCNT,#16.
(7) 011150 BGT 50120$
(9) 011156 003024 000020          OUTPUT #OUTBUF, #134.
1709 011160          JSR PC, QUIET
1710 011222 004737 005246          ENDINC
1711 011226          BR 50117$
(5) 011226 000746 50120$: ENDINC
(4) 011230 BR 50107$
1712 011230 000661 50110$: LET OUTBUF :B= #14
(4) 011232 MOVB #14,OUTBUF
1713 011232 112737 000014 003124 OUTPUT #OUTBUF, #1
1714 011240 004737 005246 JSR PC,QUIET
1715 011302 004737 005246 EXIT TST
1716 011306 104432 TRAP C$EXIT
(3) 011306 000044 .WORD L10011-.
1717 011312 000000 .NLIST BEX
1718 011314 040504 040524 052040 CHAR: .WORD 0
1719 011314 040504 040524 052040 DATPTH: .ASCIIZ /DATA TRANSFER PATHS TEST 2/ <12><12><12>
1720 011352 000000 .EVEN
1721 011352 000000 PATTERN: .WORD 0
1722 011352 000000 .EVEN
1723 011352 000000 .EVEN
1724 011352 000000 .LIST BEX
1725 011352 000000 .LIST BEX
1726 011352 000000 .LIST BEX
1727 011354          ENDTST
(3) 011354 L10011: TRAP C$TST
(3) 011354 104401
1728 011356          ENDMOD
1729 011356

```

```

1731 .SBTTL PRINTABLE CHARACTERS
1732 011356 BGNMOD
1733 :++
1734 : THIS TEST WILL PRINT A FULL LINE OF EACH UPPER AND LOWER CASE PRINTABLE CHARACTER
1735 : IN THE 7 BIT RANGE
1736 :--
1737
1738 011356 BGNTST 3
1739 (3) 011356 T3::
1742 011356 OUTPUT #PRTCHR, #30. ; PRINT TEST ID
1743
1744 : PRINT ALL CHARACTERS ON ALL UNITS
1745
1746 $BRJMP=1
1747 011420 INCR WORK FROM #40 TO #177 BY #1
1748 (5) 011420 012737 000040 003120 MOV #40,WORK
1749 (7) 011426 000402 BR 50122$
1750 (6) 011430 50121$: INC WORK
1751 (8) 011430 005237 003120 50122$: CMP WORK,#177
1752 (6) 011434 023727 003120 000177 BLE 50123$
1753 (7) 011442 003402 JMP 50124$
1754 (7) 011444 000137 011566 50123$: LET R4 := #OUTBUF
1755 (6) 011450 MOV #OUTBUF,R4
1756 1748 011450 012704 003124 INCR COUNT FROM #1 TO #132. BY #1
1757 (4) 011450 012737 000001 002246 MOV #1,COUNT
1758 (5) 011454 000402 BR 50125$
1759 (7) 011462 000402 50125$: INC COUNT
1760 (6) 011464 005237 002246 50126$: CMP COUNT,#132.
1761 (8) 011464 005237 002246 000204 BLE 50127$
1762 (6) 011470 023727 002246 000204 JMP 50130$
1763 (7) 011476 003402 50127$: LET (R4)+ :B= WORK
1764 (7) 011500 000137 011512 MOVB WORK,(R4)+
1765 (6) 011504 ENDINC
1766 1750 011504 113724 003120 BR 50125$
1767 (4) 011510 000765 50130$: LET (R4)+ :B= #LF
1768 (4) 011512 112724 000012 MOVB #LF,(R4)+
1769 1752 011512 112724 000012 OUTPUT #OUTBUF,#133.
1770 1753 011516 004737 005246 JSR PC,QUIET
1771 1754 011560 004737 005246 ENDINC
1772 1755 011564 000721 BR 50121$
1773 (4) 011564 000721 50124$: OUTPUT #DONE,#14. ; TEST DONE MESSAGE
1774 (4) 011566 LET OUTBUF :B= #14
1775 1756 011566 112737 000014 003124 MOVB #14,OUTBUF
1776 (4) 011630 112737 000014 003124 OUTPUT #OUTBUF,#1 ; EXECUTE TOP
1777 1758 011636 004737 005246 JSR PC, QUIET
1778 1759 011700 004737 005246 $BRJMP=-1
1779 1760 177777 EXIT 1ST
1780 1761 011704 TRAP C$EXIT
1781 (3) 011704 104432

```

CZLNAAO LN01 TEST DNMAC X24.07-563 12-JAN-83 08:16 PAGE 19-10^{E 5}
CZLNAA.P11 12-JAN-83 08:16 PRINTABLE CHARACTERS

SEQ 0056

```
(3) 011706 000110 .WORD L10012-.
1762 .NLIST BEX
1763 011710 051120 047111 040524 PRTCHR: .ASCIZ /PRINTABLE CHARACTERS TEST 3/ <12><12><12>
1764 011747 124 051505 020124 DONE: .ASCII /TEST COMPLETE/<12>
1765 011765 033 120 061 PORSQ: .BYTE 33,120,61,73,62,73,61,61,171,124,151,164
1766 012001 141 156 061 .BYTE 141,156,61,60,55,120,33,134,33,133,61,61,155 : SEQs TO ASSIGN AND SET
1767 .EVEN
1768
1769 012016 ENDTST
(3) 012016 L10012:
(3) 012016 104401 TRAP C$ETST
1770 .LIST BEX
1771 012020 ENDMOD
```

```

1773 .SBTTL NON-PRINTABLE CHARACTERS
1774
1775 012020 BGNMOD
1776 :++
1777 :THIS TEST CHECKS FOR DETECTION OF ALL NON-PRINTABLE CHARACTERS
1778 :EXCEPT FOR HORIZONTAL TAB, LINE FEED, VERTICAL TAB, FORM
1779 :FEED, CARRIAGE RETURN, AND ESCAPE WHICH
1780 :WOULD BE INTERPRETED AS VALID CONTROL CHARACTERS BY THE LN01. EACH
1781 :CHARACTER WILL APPEAR ON THE PRINTER OUTPUT IN THE FORM OF ITS OCTAL
1782 :CODE ACCOMPANIED WITH ITS MNEMONIC.
1783 :122 OF THE TESTED CODE ARE THEN SENT FOLLOWED BY AN '@' CHARACTER.
1784 :IF THE CONTROL CODE HAS TAKEN UP A SPACE IN THE BUFFER THE '@' CHARACTER
1785 :WILL APPEAR AT THE RIGHT MARGIN OF THE PAGE. IF THE CONTROL CODE HAS NOT
1786 :TAKEN UP SPACE IN THE BUFFER THE '@' WILL APPEAR IMMEDIATELY TO THE RIGHT
1787 :OF THE MNEMONIC FOR THE CONTROL CODE.
1788
1789 :NOTE
1790 :
1791 : IF THIS TEST IS ASSEMBLED AS PART OF VERSION 1 LN01 DIAGNOSTIC
1792 : IT WILL ALSO SEND ALL 8 BIT CONTROL CODES. THE ASSEMBLER
1793 : WILL SEE THE CONDITIONAL STATEMENT: ".IF DF VERS.1", AND, IF
1794 : VERS.1 IS DEFINED IN SKEL 2 THEN IT WILL ASSEMBLE THE CODE
1795 : FOR THE 8 BIT CONTROL CODES AS WELL AS THE NORMAL 7 BIT CONTROL
1796 : CODES.
1797 :--
1798 012020 BGNTEST 4
1799 (3) 012020 T4::
1800 :INDICATE TEST CURRENTLY BEING DONE
1801
1802 012020 OUTPUT #NONCHR,#70.
1803 (4) 012062 012704 012461 LET R4 := #NONBUF
1804 (4) 012066 012737 000033 003122 MOV #NONBUF,R4
1805 : LET WORK1 := #27.
1806 : MOV #27.,WORK1
1807 :
1808 : DO ONE LINE FOR EACH TABLE ENTRY
1809 :
1810 : LET COUNT := #0
1811 : CLR COUNT
1812 : INCR LINCNT FROM #1 TO WORK1 BY #1
1813 (5) 012100 012737 000001 002242 MOV #1,LINCNT
1814 (7) 012106 000402 50132$: BR 50131$
1815 (6) 012110 005237 002242 50132$: INC LINCNT
1816 (7) 012114 023737 002242 003122 50131$: CMP LINCNT,WORK1
1817 (9) 012122 003063 BGT 50133$
1818 1809 012124 012703 003124 LET R3 := #OUTBUF
1819 (4) : MOV #OUTBUF,R3
1820 :
1821 : MOVE CODE AND MNEMONIC TO PRINT BUFFER
1822 :
1823 : INCR WORK FROM #1 TO #8. BY #1
1824 (5) 012130 012737 000001 003120 MOV #1,WORK
1825 (7) 012136 000402 50134$: BR 50134$
1826 (6) 012140 50135$:

```

```

(10) 012140 005237 003120      INC      WORK
(7) 012144      50134$: CMP      WORK,#8.
(7) 012144 023727 003120 000010 BGT      50136$
(9) 012152 003002      LET (R3)+ :B= (R4)+
1814 012154      MOV      (R4)+,(R3)+
(4) 012154 112423      ENDINC
1815 012156      BR      50135$
(5) 012156 000770      50136$:
(4) 012160      :
1816      : PUT 120 BYTES OF CODE INTO PRINT BUFFER
1817      :
1818      : INCR WORK FROM #1 TO #122. BY #1
1819      :
1820 012160 012737 000001 003120 MOV      #1,WORK
(5) 012160 000402      BR      50137$
(7) 012166      50140$: INC      WORK
(6) 012170      50137$: CMP      WORK,#122.
(10) 012170 005237 003120 BGT      50141$
(7) 012174 023727 003120 000172 LET (R3)+ :B= (R4)
(7) 012174 003002      MOV      (R4),(R3)+
(9) 012202 003002      ENDINC
1821 012204 111423      BR      50140$
(4) 012204 000770      50141$:
1822 012206 000770      :
(5) 012206      : FOLLOWED BY AN 'a' CHARACTER AND A LF
(4) 012210      :
1823 012210 112723 000100      LET (R3)+ :B= #100 ;'a'
(4) 012210 000012      MOV      #100,(R3)+
1828 012214 112723 000012      LET (R3)+ :B= #12 ;LF
(4) 012214      MOV      #12,(R3)+
1829      :
1830      : PRINT LINE OF OCTAL CODE, MNEMONIC, 120 BYTES(NONPRINTABLE CODE), AND 'a'
1831      :
1832 012220      OUTPUT #OUTBUF,#132.
1833 012262 004737 005246      JSR PC, QUIET
1834 012266      LET R4 := R4 + #1
(7) 012266 005204      INC      R4
1835 012270      ENDINC
(5) 012270 000707      BR      50132$
(4) 012272      50133$: LET OUTBUF :B= #14
1872 012272 112737 000014 003124 MOV      #14,OUTBUF
(4) 012272 004737 005246      OUTPUT #OUTBUF,#1
1873 012300      JSR PC, QUIET
1874 012342 104432      EXIT      TST ;AND EXIT TEST
(3) 012346 000476      TRAP      C$EXIT
(3) 012350      .WORD      L10013-.
1876      :
1877      : CHARACTER BUFFER AND TEST HEADER MESSAGE
1878      :
1879      : NLIST BEX
1880 012352 047516 026516 051120 NONCHR: .ASCII /NON-PRINTABLE CHARACTERS TEST 4/<12>

```

1881 012412 020101 052506 046114 .ASCIIZ /A FULL LINE OF EACH CODE WILL BE SENT/<12>

1882
1883 012461 040 030060 020060 NONBUF: .ASCII / 000 NUL/<0>
1884 012472 030040 030460 051440 .ASCII / 001 SOH/<1>
1885 012503 040 030060 020062 .ASCII / 002 STX/<2>
1886 012514 030040 031460 042440 .ASCII / 003 ETX/<3>
1887 012525 040 030060 020064 .ASCII / 004 EOT/<4>
1888 012536 030040 032460 042440 .ASCII / 005 ENQ/<5>
1889 012547 040 030060 020066 .ASCII / 006 ACK/<6>
1890 012560 030040 033460 041040 .ASCII / 007 BEL/<7>
1891 012571 040 030460 020060 .ASCII / 010 BS /<10>
1892 012602 030040 033061 051440 .ASCII / 016 SO /<16>
1893 012613 040 030460 020067 .ASCII / 017 SI /<17>
1894 012624 030040 030062 042040 .ASCII / 020 DLE/<20>
1895 012635 040 031060 020061 .ASCII / 021 XON/<21>
1896 012646 030040 031062 042040 .ASCII / 022 DC2/<22>
1897 012657 040 031060 020063 .ASCII / 023 XOF/<23>
1898 012670 030040 032062 042040 .ASCII / 024 DC4/<24>
1899 012701 040 031060 020065 .ASCII / 025 NAK/<25>
1900 012712 030040 033062 051440 .ASCII / 026 SYN/<26>
1901 012723 040 031060 020067 .ASCII / 027 ETB/<27>
1902 012734 030040 030063 041440 .ASCII / 030 CAN/<30>
1903 012745 040 031460 020061 .ASCII / 031 EM /<31>
1904 012756 030040 031063 051440 .ASCII / 032 SUB/<32>
1905 012767 040 031460 020064 .ASCII / 034 FS /<34>
1906 013000 030040 032463 043440 .ASCII / 035 GS /<35>
1907 013011 040 031460 020066 .ASCII / 036 RS /<36>
1908 013022 030040 033463 052440 .ASCII / 037 US /<37>
1909 013033 040 033461 020067 .ASCII / 177 DEL/<177>

1944
1945 013044 000000 .EVEN
1946 NUM: .WORD 0

1947 .LIST BEX
1948 ENDIST
(3) 013046 L10013:
(3) 013046 104401 TRAP C\$EIST

1949
1950 013050 ENDMOD

```

1952 .SBTTL PRINT CONTROL
1953
1954 013050 BGNMOD
1955
1956 :++
1957 :THIS TEST CHECKS THE PRINT CONTROL BY SENDING MORE THAN 132 CHARACTERS
1958 :BEFORE SENDING A CARRIAGE RETURN AND LINE FEED. ALL CHARACTERS IN EXCESS
1959 :OF 132 CHARACTERS SHOULD BE DISREGARDED.
1960
1961 :THREE LINES ARE PRINTED PER ITERATION, THESE LINES WILL IDENTIFY THE
1962 :COLUMN NUMBERS ACROSS THE PAGE. EXAMPLE :
1963 :      0      0      0.....
1964 :      1      2      3.....
1965 :123456789012345678901234567890.....
1966 :NOTICE THAT THE PRINTOUT SHOULD IDENTIFY 132 COLUMNS ACROSS THE PAGE.
1967
1968 :THIS OUTPUT IS REPEATED 13 TIMES.
1969 :--
1970 013050 BGNTEST 5
1971 (3) 013050
1972
1973 (5) 013050 013701 002012
1974 (7) 013054 005301
1975 000001
1976 013056 INCR LUNIT FROM #0 TO R1 BY #1
1977 (5) 013056 005037 002260
1978 (7) 013062 000402
1979 (6) 013064
1980 (8) 013064 005237 002260
1981 (6) 013070
1982 (7) 013070 023701 002260
1983 (9) 013074 003402
1984 (7) 013076 000137 013734
1985 (6) 013102
1986 013102
1987 (5) 013102 013702 002260
1988 (8) 013106 006302
1989 013110
1990 013152
1991 (4) 013152 012737 000015 002246
1992 013160
1993 013160
1994 (4) 013160 012705 014210
1995 013164
1996 (4) 013164
1997 (6) 013164 005715
1998 (8) 013166 001002
1999 (9) 013170 000137 013236
2000 013174
2001 013234
2002 (3) 013234 000753
2003 (3) 013236
2004 013236
2005 (4) 013236 112737 000012 003124
2006 013244
2007

```

```

1988 013306          012705 014244          MOV      LET R5 := #TABLE2
(4) 013306          012705 014244          #TABLE2,R5
1989 013312          012705 014244          WHILE (R5) NE #0 DO
(4) 013312          012705 014244          50150$:
(6) 013312          005715          TST      (R5)
(8) 013314          001002          BNE      +6
(9) 013316          000137 013364          JMP      50151$
1990 013322          012705 014244          OUTPUTI (R5)+,#10,,,LUNIT
1991 013362          000753          ENDDO
(3) 013362          000753          50151$: BR      50150$
(3) 013364          000753          50151$:
1992 013364          000753          OUTPUTI #OUTBUF,#1,,LUNIT
1993 013364          000753          50151$:
1994 013426          012737 000016 002242          MOV      DECR LINCNT FROM #14. TO #1 BY #1
(5) 013426          012737 000016 002242          #14. LINCNT
(7) 013434          000402          50152$: BR      50153$
(6) 013436          005337 002242          50152$: DEC      LINCNT
(8) 013436          005337 002242          50153$:
(6) 013442          023727 002242 000001          CMP      LINCNT,#1
(7) 013442          023727 002242 000001          50154$: BGE      50155$
(9) 013450          002002          50154$: JMP      50155$
(7) 013452          000137 013522          50154$:
(6) 013456          000137 013522          OUTPUTI #X11,#10,,,LUNIT
1995 013456          000137 013522          ENDDO
1996 013520          000746          50155$: BR      50152$
(4) 013520          000746          50155$:
(4) 013522          000746          50155$:
1997 013522          000746          OUTPUTI #OUTBUF,#1,,LUNIT
1998 013564          000746          OUTPUTI #OUTBUF,#1,,LUNIT
1999 013626          005337 002246          LET COUNT := COUNT - #1
(7) 013626          005337 002246          DEC      COUNT
2000 013632          005737 002246          IF COUNT GT #0 THEN
(6) 013632          005737 002246          TST      COUNT
(8) 013636          003002          BGT      +6
(9) 013640          000137 013650          JMP      50156$
2001 013644          000137 013650          JMP 1$
2002 013650          000137 013650          ENDDO
(4) 013650          000137 013650          50156$:
2003 013650          004737 005246          JSR PC, QUIET
2004 013654          112737 000014 003124          MOV      LET OUTBUF :B= #14
(4) 013654          112737 000014 003124          #14,OUTBUF
2005 013662          004737 005246          OUTPUTI #OUTBUF,#1,,LUNIT
2006 013724          004737 005246          JSR PC,QUIET
2007 013730          000137 013064          ENDINCR
(4) 013730          000137 013064          JMP      50142$
(4) 013734          000137 013064          50145$:
2008 013734          177777          $BRJMP=-1
2009 013734          104432          EXIT TST
(3) 013734          104432          TRAP
(3) 013736          000342          .WORD    C$EXIT
2010 013736          000342          L10014-.
2011 013740          051120 047111 020124          .NLIST BEX
2012 013766          044123 052517 042114          PRTCTL: .ASCII /PRINT CONTROL TEST 5/ <12>
2013 013766          044123 052517 042114          .ASCIIZ /SHOULD SHOW 132 COLUMNS PRINTED/<12><12><15>
2014 014031          040 020040 020040          x0:      .ASCII /
2015 014043          040 020040 020040          x1:      .ASCII /

```

CZLNAAO LN01 TEST DNMAC X24.07-563 12-JAN-83 08:16 PAGE 19-16^{K 5}
CZLNAA.P11 12-JAN-83 08:14 PRINT CONTROL

SEQ 0062

```
2016 014055 040 020040 020040 X2: .ASCII / 2/
2017 014067 040 020040 020040 X3: .ASCII / 3/
2018 014101 040 020040 020040 X4: .ASCII / 4/
2019 014113 040 020040 020040 X5: .ASCII / 5/
2020 014125 040 020040 020040 X6: .ASCII / 6/
2021 014137 040 020040 020040 X7: .ASCII / 7/
2022 014151 040 020040 020040 X8: .ASCII / 8/
2023 014163 040 020040 020040 X9: .ASCII / 9/
2024
2025 014175 061 031462 032464 11: .ASCII /1234567890/
2026
2027 014210 014210 .EVEN
2028 014210 014031 014031 014031 TABLE1: .WORD X0,X0,X0,X0,X0,X0,X0,X0,X0,X1,X1,X1,X1,0
2029 014244 014043 014055 014067 TABLE2: .WORD X1,X2,X3,X4,X5,X6,X7,X8,X9,X0,X1,X2,X3,0
2030 .EVEN
2031
2032 .LIST BEX
2033 014300 ENDTST
(3) 014300 L10014:
(3) 014300 104401 TRAP C$ETST
2034 014302 ENDMOD
```

```

2036 .SBTTL MULTIPLE LINE ADVANCE
2037
2038 014302 BGNMOD
2039 :++
2040 :THIS TEST CHECKS THE MULTIPLE LINE ADVANCE OF THE LN01. A LINE OF
2041 :NUMBERS IS SENT AND THEN A NUMBER OF LINE FEEDS ARE SENT. THUS THE
2042 :NUMBER PRINTED WILL INDICATE THE NUMBER OF BLANK LINES FOLLOWING THAT
2043 :LINE. THE NUMBER OF LINES IS VARIED BETWEEN 2 AND 7 AND A LINE OF
2044 :ALL 0'S WILL INDICATE THE END OF THE TEST SEQUENCE.
2045 :--
2046
2047
2048 014302 BGNIST 6
      (3) 014302 T6::
2049
2050 :PRINT TEST IDENTIFICATION
2051
2055 014302 OUTPUT #MULINE,#86.
2056
2057 014344 LET STACHR := #TABSTR ;OUTPUT CHARACTERS
      (4) 014344 012737 014622 014620 MOV #TABSTR,STACHR
2058
2059 014352 REPEAT
      (3) 014352 50157$:
2060 014352 LET LINCNT := @STACHR ;GET A CHARACTER TO OUTPUT
      (4) 014352 117737 000242 002242 MOV @STACHR,LINCNT
2061 014360 LET LINCNT := LINCNT AND #7 ;MAKE THE ASCII TO OCTAL
      (7) 014360 013746 002242 MOV LINCNT,-(SP)
      (7) 014364 042716 000007 BIC #7,(SP)
      (7) 014370 042637 002242 BIC (SP)+,LINCNT
2062 014374 LET R3 := #OUTBUF ;SET UP OUTPUT BUFFER
      (4) 014374 012703 003124 MOV #OUTBUF,R3
2063 014400 INCR CCNT FROM #1 TO #132. BY #1
      (5) 014400 012737 000001 002250 MOV #1,CCNT
      (7) 014406 000402 BR 50160$
      (6) 014410 50161$:
      (10) 014410 005237 002250 INC CCNT
      (7) 014414 50160$:
      (7) 014414 023727 002250 000204 CMP CCNT,#132.
      (9) 014422 003003 BGT 50162$
2064 014424 LET (R3)+ := @STACHR ;PUT CHARACTER IN OUTPUT BUFFER
      (4) 014424 117723 000170 MOV @STACHR,(R3)+
2065 014430 ENDINC
      (5) 014430 000767 BR 50161$
      (4) 014432 50162$:
2066 014432 LET R4 := #0
      (4) 014432 005004 CLR R4
2067 014434 WHILE R4 NE LINCNT DO
      (4) 014434 50163$:
      (6) 014434 020437 002242 CMP R4,LINCNT
      (10) 014440 001404 BEQ 50164$
2068 014442 LET (R3)+ := #12 ;FILL WITH LINE FEEDS
      (4) 014442 112723 000012 MOV #12,(R3)+
2069 014446 LET R4 := R4 + #1
      (7) 014446 005204 INC R4
2070 014450 ENDDO

```

```

(4) 014450 000771          BR      50163$
(3) 014452          50164$:
2071
2072          ;NOW OUTPUT THE ACTUAL LINE
2073
2074 014452          LET R4 := LINCNT + #132.          ;NUMBER OF CHARACTERS TO OUTPUT
(5) 014452 013704 002242      MOV      LINCNT,R4
(7) 014456 062704 000204      ADD      #132.,R4
2075 014462          LET STACHR := STACHR + #1          ; UPDATE CHARACTER COUNT
(7) 014462 005237 014620      INC      STACHR
2076 014466          OUTPUT #OUTBUF,R4          ;OUTPUT THE LINE
2077 014526 004737 005246      JSR PC,      QUIET
2078
2079 014532          UNTIL LINCNT EQ #0
(3) 014532 005737 002242      TST      LINCNT
(7) 014536 001305          BNE      50157$
2080 014540          LET OUTBUF :B= #14
(4) 014540 112737 000014 003124      MOVB      #14,OUTBUF
2081 014546          OUTPUT #OUTBUF,#1
2082 014610 004737 005246      JSR PC,QUIET
2083 014614          EXIT TST
(3) 014614 104432          TRAP      C$EXIT
(3) 014616 000150          .WORD      L10015-.
2084
2085
2086 014620 000000          STACHR: .WORD 0
2087          .LIST BEX
2088 014622 033462 033062 033463      TABSTR: .ASCIIZ /272637463540/
2089 014637 115 046125 044524      MULINE: .ASCII /MULTIPLE LINE ADVANCE TEST 6/<12>
2090 014675 116 046525 042502      .ASCIIZ /NUMBERS PRINTED REPRESENT # LINES TO NEXT LINE PRINTED/<12><12>
2091
2092
2093
2094          .EVEN
2095          .LIST BEX
2096
2097 014766          ENDTST
(3) 014766          L10015:
(3) 014766 104401          TRAP      C$ETST
2098 014770          ENDMOD
  
```

```

2100 .SBTTL DVSTRIKE
2101 ;MODULE DVSTR1.P11
2102 014770 BGNMOD
2103 ;**
2104 ;THIS TEST WILL VERIFY CORRECT OPERATION OF THE PRINTER WHILE OPERATING
2105 ;JUST WITHIN OVERSTRIKE, LINE BUFFER AND PAGE BUFFER LIMITS.
2106 ;A TOTAL OF 4 OVERSTRIKES ON ONE LINE IS ALLOWED AND IS TESTED.
2107 ;WE ARE LIMITED WHEN SENDING CHARACTERS TO THE LINE BUFFER. IF YOU USE THE DEFAULT
2108 ;FONT AND PRINT SEQUENTIAL LINES, THE LIMIT IS 148 TOTAL CHARACTERS PER LINE COUNTING
2109 ;ALL CHARACTERS THAT ARE ACTUALLY TRANSMITTED FROM THE LP11 HOST INTERFACE.
2110 ;THIS LIMIT IS TESTED AS WELL.
2111 ;THE PAGE BUFFER LIMIT IS 10,000 CHARACTERS AND THIS TEST OPERATES "JUST"
2112 ;WITHIN THAT LIMIT, USING OVER 9,900 CHARACTERS.
2113
2114 NOTE:
2115     THIS TEST IN A SOMEWHAT MODIFIED FORM IS BEING USED ALSO FOR
2116     THE VAX VERSION OF THE LN01 EXTENDED DIAGNOSTIC.
2117
2118     IN THE PDP-11 FORM (WHICH IS THIS MODULE) THE PAGE BUFFER ENDS UP CONTAINING
2119     A TOTAL OF 9,939 CHARACTERS. THIS INCLUDES THE EVER PRESENT 7 CHARACTERS FOR
2120     EACH LINE THAT THE PRINTER USES.
2121
2122     IN THE VAX FORM (WHICH IS USED IN THE VAX PRINTER DIAGNOSTIC) THE PAGE BUFFER
2123     ENDS UP CONTAINING A TOTAL OF 9,949 CHARACTERS. THIS INCLUDES 7 THE EVER PRESENT
2124     CHARACTERS FOR EACH LINE THAT THE PRINTER USES.
2125
2126 NOTE:
2127     ONE THING NOT COUNTED HERE IS THE POSSIBILITY OF THE PRINTER USING ONE EXTRA
2128     SPACE PER LINE FEED IN ITS BUFFER WHEN IN "LINE FEED-NEWLINE MODE".
2129     THE WORST CASE IF THIS SHOULD HAPPEN IS THAT 66 EXTRA CHARACTERS WOULD END
2130     UP ADDED TO THE PREVIOUS PAGE BUFFER TOTAL. I DON'T BELIEVE THAT EVEN THIS
2131     CASE WOULD CAUSE A FAILURE. HOWEVER, THE POSSIBILITY EXISTS BECAUSE THE PAGE BUF
2132     WOULD SLIGHTLY EXCEED ITS LIMIT ON THE PDP11 VERSION AS WELL AS THE VAX VERSION.
2133
2134
2135 014770 BGNTST 7
2136 (3) 014770 T7::
2137 014770
2138 (4) 014770 012704 003124
2139 (4) 014774 112724 000116
2140 (4) 015000 112724 000132
2141 (4) 015004 112724 000116
2142 (4) 015010 112724 000015
2143 (4) 015014 112724 000012
2144 (4) 015020 112724 000014
2145 (4) 015024 112724 000040
2146 015030
2147 015072
  
```

```

LET R4 := #OUTBUF ; ADDRESS OF BUFFER
MOV #OUTBUF,R4
LET (R4)+ :B= #116 ; 'N'
MOVB #116,(R4)+
LET (R4)+ :B= #132 ; 'Z'
MOVB #132,(R4)+
LET (R4)+ :B= #116 ; 'N'
MOVB #116,(R4)+
LET (R4)+ :B= #CR ; CARRIAGE RET.
MOVB #CR,(R4)+
LET (R4)+ :B= #LF ; LINE FEED
MOVB #LF,(R4)+
LET (R4)+ :B= #FF ; FORM FEED
MOVB #FF,(R4)+
LET (R4)+ :B= #40 ; SPACE
MOVB #40,(R4)+
OUTPUT #DVSTR,15. ; TEST ID WITHOUT LINE FEED
OUTPUT #OUTBUF+6,#1,,#90. ; DO 90 SPACES TO TAKE UP LINE BUFFER SP
  
```

```

2150 015134 OUTPUT #OUTBUF+4,#1 ; DO LINE FEED
2151 015176 OUTPUT #ZN1,#3 ; 1ST OVERPRINT LINE
2152 015240 OUTPUT #OUTBUF+6,#1,,#90. ; 90 SPACES
2153 015302 OUTPUT #OUTBUF+4,#1 ; LINE FEED
2154 015344 OUTPUT #ZN2,#7. ; 2ND
2155 015406 OUTPUT #OUTBUF+6,#1,,#90. ; DO 90 SPACES TO TAKE UP LINE BUFFER SP
2156 015450 OUTPUT #OUTBUF+4,#1 ; DO LINE FEED
2157 015512 OUTPUT #ZN3,#12. ; 3RD
2158 015554 OUTPUT #OUTBUF+6,#1,,#90. ; DO 90 SPACES TO TAKE UP LINE BUFFER SP
2159 015616 OUTPUT #OUTBUF+4,#1 ; DO LINE FEED
2160 015660 OUTPUT #ZN4,#18. ; 4TH
2161 015722 OUTPUT #OUTBUF+6,#1,,#90. ; DO 90 SPACES TO TAKE UP LINE BUFFER SP
2162 015764 OUTPUT #OUTBUF+4,#1 ; DO LINE FEED
2163 016026 004737 005246 JSR PC,QUIET
2164 016032 012737 000001 002246 INCR COUNT FROM #1 TO #61. BY #1 ; 61 LINES OF OVERPRINTING
(5) 016032 000402 MOV #1,COUNT
(7) 016040 50166$: BR 50165$
(6) 016042 50165$: INC COUNT
(10) 016042 005237 002246 50165$: CMP COUNT,#61.
(7) 016046 023727 002246 000075 BGT 50167$
(9) 016054 003135 OUTPUT #OUTBUF,#2,,#36. ; LINE OF NZ
2165 016056 OUTPUT #OUTBUF+3,#1 ; CARRIAGE RET. (NO LF)
2166 016120 OUTPUT #OUTBUF+1,#2,,#36. ; LINE OF ZN
2167 016162 IF COUNT EQ #61. THEN ; IS THIS THE LAST LINE?
2168 016224 023727 002246 000075 CMP COUNT,#61.
(6) 016224 001022 BNE 50170$
(10) 016232 OUTPUT #OUTBUF+3,#1 ; CARRIAGE RETURN ONLY ON LAST LINE
2169 016234 ELSE
2170 016276 000421 BR 50171$
(4) 016276 50170$: OUTPUT #OUTBUF+3,#2 ; CR AND LF ON EVERY OTHER LINE
(3) 016300 50171$: ENDF
2171 016342 004737 005246 JSR PC,QUIET
2172 016342 000635 ENDINC ; WHEN DONE FALL THROUGH
(4) 016346 50167$: BR 50166$
(5) 016350 50167$: OUTPUT #OUTBUF+5,#1 ; DO FORM FEED
2175 016350 JSR PC,QUIET
2176 016412 004737 005246 EXIT TST
2177 016416 104432 TRAP C$EXIT
(3) 016416 000100 .WORD L10016-.
2178 016422 .NLIST BEX
2179 016424 000000 ZNUM: .WORD 0
2180 016426 000000 SPANUM: .WORD 0
2181 016430 053104 052123 044522 NEWSPA: .WORD 0
2182 016450 006532 116 DVSTR: .ASCII /DVSTRIKE TEST 7/
2183 016453 132 006532 006516 ZN1: .ASCII //<15>/N/
2184 016462 055132 006532 006516 ZN2: .ASCII /ZZ/<15>/N/<15><40>/N/
2185 016476 055132 055132 047015 ZN3: .ASCII /ZZZ/<15>/N/<15><40>/N/<15><40><40>/N/
2186 016520 .EVEN
2187 016520 ENDTST
(3) 016520 L10016:

```

(3)	016520	104401			TRAP C\$ETST
2189					.LIST BEX
2190	016522				ENDMOD
2191					.SBTTL READY LINE INTERLOCKS TEST 8
2192					
2193	016522				BGNMOD
2194					++
2195					:THIS TEST CHECKS THE OPERATION OF THE
2196					:PRINTER READY INTERLOCK SWITCHES.
2197					:MANUAL INTERVENTION IS USED TO
2198					:OPEN THE INTERLOCKS TO PRODUCE FAULTS
2199					:IN THE PRINTER AFTER WHICH THE RESULTANT ERROR
2200					:INDICATION IS VERIFIED.
2201					--
2202					
2203	016522				BGNTST 8.
(3)	016522				T8::
2204					:DETERMINE IF MANUAL INTERVENTION IS ALLOWED
2205	016522				MANUAL
(3)	016522	104450			TRAP C\$MANI
2206	016524				B\$COMPLETE 11\$
(2)	016524	103402			BCS 11\$
2207	016526				EXIT TST
(3)	016526	104432			TRAP C\$EXIT
(3)	016530	002726			.WORD L10017-
2208					:EXIT TEST IF MANUAL INTERVENTION TESTS ARE NOT SPECIFIED
2209	016532				11\$: IF INHINT EQ #0 THEN
(6)	016532	005737	002234		TST INHINT
(10)	016536	001002			BNE 50172\$
2210	016540				EXIT TST
(3)	016540	104432			TRAP C\$EXIT
(3)	016542	002714			.WORD L10017-
2211	016544				ENDIF
(4)	016544				50172\$:
2212	016544				LET FLAG := #0
(4)	016544	005037	002240		CLR FLAG
2213	016550				LET R1 := L\$UNIT - #1
(5)	016550	013701	002012		MOV L\$UNIT,R1
(7)	016554	005301			DEC R1
2214					
2215					:CHECK FOR ERROR IN EACH PRINTER UNDER TEST
2216	016556				INCR LUNIT FROM #0 TO R1 BY #1
(5)	016556	005037	002260		CLR LUNIT
(7)	016562	000402			BR 50173\$
(6)	016564				50174\$:
(10)	016564	005237	002260		INC LUNIT
(7)	016570				50173\$:
(7)	016570	023701	002260		CMP LUNIT,R1
(9)	016574	003020			BGT 50175\$
2217	016576				LET R2 := LUNIT SHIFT 1
(5)	016576	013702	002260		MOV LUNIT,R2
(8)	016602	006302			ASL R2
2218	016604				IF #BIT15 SET IN @LPCSR(R2) THEN
(6)	016604	032772	100000	002322	BIT #BIT15,@LPCSR(R2)
(10)	016612	001410			BEO 50176\$
2219	016614				LET ERRIBL(R2) := ERRIBL(R2) + #1

(7)	016614	005262	003060	INC	ERRTBL(R2)
2220	016620			TRAP	ERRHRD 6, CSRERR
(4)	016620	104456		.WORD	6
(5)	016622	000006		.WORD	CSRERR
(5)	016624	003352		.WORD	0
(5)	016626	000000			LET @LPCSR(R2) := #0
2221	016630			CLR	@LPCSR(R2)
(4)	016630	005072	002322	ENDIF	
2222	016634			50176\$:	
(4)	016634			ENDINC	
2223	016634			BR	50174\$
(5)	016634	000753		50175\$:	
(4)	016636			;CHECK FOR READY IN EACH PRINTER UNDER TEST	
2224				INCR LUNIT FROM #0 TO R1 BY #1	
2225	016636			CLR	LUNIT
(5)	016636	005037	002260	BR	50177\$
(7)	016642	000402		50200\$:	
(6)	016644			INC	LUNIT
(10)	016644	005237	002260	50177\$:	
(7)	016650			CMP	LUNIT,R1
(7)	016650	023701	002260	BGT	50201\$
(9)	016654	003021		LET R2 := LUNIT SHIFT 1	
2226	016656			MOV	LUNIT,R2
(5)	016656	013702	002260	ASL	R2
(8)	016662	006302		LET L\$LUN := LUNIT	
2227	016664			MOV	LUNIT,L\$LUN
(4)	016664	013737	002260 002074	IF #BIT07 NOTSETIN @LPCSR(R2) THEN	
2228	016672			BIT	#BIT07,@LPCSR(R2)
(6)	016672	032772	000200 002322	BNE	50202\$
(10)	016700	001006		LET ERRTBL(R2) := ERRTBL(R2) + #1	
2229	016702			INC	ERRTBL(R2)
(7)	016702	005262	003060	TRAP	ERRHRD 7, RDYERR
2230	016706			.WORD	7
(4)	016706	104456		.WORD	RDYERR
(5)	016710	000007		.WORD	0
(5)	016712	003370		ENDIF	
(5)	016714	000000		50202\$:	
2231	016716			ENDINC	
(4)	016716			BR	50200\$
2232	016716			50201\$:	
(5)	016716	000752		; PRINT TEST NAME	
(4)	016720			; OUTPUT #INTLK,#29.	
2233				;VERIFY OPERATION OF PAPER OUT INTERLOCK SWITCH	
2234				;HARD CODED INCREMENT LOOP	
2235				;	
2236	016720			LET ERRFLG := #0	
2237				CLR	ERRFLG
2238				CLR LUNIT	
2239				BR	1\$
2240	016762			2\$:	
(4)	016762	005037	002304	INC LUNIT	
2241	016766	005037	002260	LET R2 := LUNIT SHIFT 1	
2242	016772	000405			
2243	016774				
2244	016774	005237	002260		
2245	017000				

(5)	017000	013702	002260	MOV	LUNIT,R2	
(8)	017004	006302		ASL	R2	
2246	017006			1\$:		
2247	017006	023701	002260	CMP	LUNIT,R1	
2248	017012	003402		BLE	3\$	
2249	017014	000137	017546	JMP	4\$	
2250	017020			3\$:		
2251	017020			LET	FLAG := #0	
(4)	017020	005037	002240	CLR	FLAG	
2252	017024			PRINTF	#PAPRSW	
(7)	017024	012746	020400	MOV	#PAPRSW,-(SP)	
(6)	017030	012746	000001	MOV	#1,-(SP)	
(3)	017034	010600		MOV	SP,R0	
(4)	017036	104417		TRAP	(\$PNTF	
(4)	017040	062706	000004	ADD	#4,SP	
2253	017044			PRINTF	#PAPSW1,LUNIT	
(8)	017044	013746	002260	MOV	LUNIT,-(SP)	
(7)	017050	012746	020455	MOV	#PAPSW1,-(SP)	
(6)	017054	012746	000002	MOV	#2,-(SP)	
(3)	017060	010600		MOV	SP,R0	
(4)	017062	104417		TRAP	(\$PNTF	
(4)	017064	062706	000006	ADD	#6,SP	
2254	017070			PRINTF	#PAPSW2	
(7)	017070	012746	020535	MOV	#PAPSW2,-(SP)	
(6)	017074	012746	000001	MOV	#1,-(SP)	
(3)	017100	010600		MOV	SP,R0	
(4)	017102	104417		TRAP	(\$PNTF	
(4)	017104	062706	000004	ADD	#4,SP	
2255	017110			GMANIL	READY, FLAG, 100000, YES	
(3)	017110	104443		TRAP	(\$GMAN	
(3)	017112	000404		BR	10000\$	
(4)	017114	002240		.WORD	FLAG	
(5)	017116	000130		.WORD	T\$CODE	
(5)	017120	006752		.WORD	READY	
(5)	017122	100000		.WORD	100000	
(3)	017124			10000\$:		
2256	017124			LET	LINCNT := #2	; LINE COUNT WILL ALLOW FOR 3 PAGES OF PAPER
(4)	017124	012737	000002 002242	MOV	#2,LINCNT	
2257	017132			LET	ERRFLG := #0	
(4)	017132	005037	002304	CLR	ERRFLG	
2258	017136			REPEAT		
(3)	017136			50203\$:		
2259	017136			OUTPUT	#PAPTST,#15.,#5\$,LUNIT	
2260	017200			LET	LINCNT := LINCNT + #1	
(7)	017200	005237	002242	INC	LINCNT	
2261	017204			IF	LINCNT EQ #65. OR LINCNT EQ #130. OR LINCNT EQ #195. THEN	
(6)	017204	023727	002242 000101	CMP	LINCNT,#65.	
(8)	017212	001410		BEQ	50204\$	
(6)	017214	023727	002242 000202	CMP	LINCNT,#130.	
(8)	017222	001404		BEQ	50204\$	
(6)	017224	023727	002242 000303	CMP	LINCNT,#195.	
(10)	017232	001024		BNE	50205\$	
(6)	017234			50204\$:		
2262	017234			LET	OUTBUF := #14	; FORM FEED
(4)	017234	012737	000014 003124	MOV	#14,OUTBUF	
2263	017242			OUTPUT	#OUTBUF,#1,5\$,LUNIT	; OUTPUT THE FORM FEED

```

2264 017304          ENDIF
(4) 017304          50205$: UNTIL LINCNT EQ #260. OR ERRFLG NE #0          ; UNTIL FOUR PAGES PRINTED OR IN
2265 017304          CMP      LINCNT,#260.
(4) 017304 023727 002242 000404      BEQ      50206$
(6) 017312 001403      TST      ERRFLG
(4) 017314 005737 002304      BEQ      50203$
(8) 017320 001706
(4) 017322          50206$: IF ERRFLG EQ #0 THEN
2266 017322          TST      ERRFLG
(6) 017322 005737 002304      BNE      50207$
(10) 017326 001035      LET OUTBUF := #14          ; FORM FEED
2267 017330          MOV      #14,OUTBUF
(4) 017330 012737 000014 003124      OUTPUT #OUTBUF,#1,5$,LUNIT          ; OUTPUT THE FF
2268 017336          ERRHRD 8,PAPSWI
2269 017400          TRAP     C$ERHRD
(4) 017400 104456      .WORD   8
(5) 017402 000010      .WORD   PAPSWI
(5) 017404 003412      .WORD   0
(5) 017406 000000      LET ERRTBL(R2) := ERRTBL(R2) + #1
2270 017410          INC      ERRTBL(R2)
(7) 017410 005262 003060      INLINE <JMP 11002$>
2271 017414          JMP      11002$
(2) 017414 000137 017426      ELSE
2272 017420          BR       50210$
(4) 017420 000402
(3) 017422          50207$: LET ERRFLG := #0
2273 017422          CLR      ERRFLG
(4) 017422 005037 002304      ENDIF
2274 017426          50210$: PRINTF #PAPRDY,LUNIT
(4) 017426          11002$: MOV      LUNIT,-(SP)
2275 017426          MOV      #PAPRDY,-(SP)
(8) 017426 013746 002260      MOV      #2,-(SP)
(7) 017432 012746 020577      MOV      SP,R0
(6) 017436 012746 000002      TRAP     C$PNTF
(3) 017442 010600      ADD      #6,SP
(4) 017444 104417      LET FLAG := #0
(4) 017446 062706 000006      CLR      FLAG
2276 017452          GMANIL READY,FLAG,100000,YES
(4) 017452 005037 002240      TRAP     C$GMAN
2277 017456          BR       10001$
(3) 017456 104443      .WORD   FLAG
(3) 017460 000404      .WORD   T$CODE
(4) 017462 002240      .WORD   READY
(5) 017464 000130      .WORD   100000
(5) 017466 006752
(5) 017470 100000
(3) 017472          10001$: LET R2 := LUNIT SHIFT 1
2278 017472          MOV      LUNIT,R2
(5) 017472 013702 002260      ASL      R2
(8) 017476 006302      LET @LP(CSR(R2)) := #0          ; RESET THE LP CSR
2279 017500          CLR      @LP(CSR(R2))
(4) 017500 005072 002322      JMP 2$
2280 017504 000137 016774
2281          ;EXPECTED ERROR HANDLER.
2282          ;JUST SET EXPECTED ERROR INDICATOR.
2283          ;

```

```

2284 017510 5$: LET ERRFLG := #1
(4) 017510 012737 000001 002304 MOV #1,ERRFLG
2285 017516 LET ERRCOD := #0
(4) 017516 005037 002302 CLR ERRCOD
2286 017522 LET STATUS(R2) := STATUS(R2) CLR.BY #ERROR!ACTIVE
(7) 017522 042762 120000 002456 BIC #ERROR!ACTIVE,STATUS(R2)
2287 017530 LET CURCNT(R2) := #0 ; CLEAN UP THE DRIVER PARAMETERS
(4) 017530 005062 002716 CLR CURCNT(R2)
2288 017534 LET CURADD(R2) := #0
(4) 017534 005062 002516 CLR CURADD(R2)
2289 017540 LET REPCNT(R2) := #0
(4) 017540 005062 002616 CLR REPCNT(R2)
2290 017544 000207 RTS PC
2291 ;AND RETURN
2292 ;VERIFY OPERATION OF PAPER TRAY HANDLE INTERLOCK SWITCH.
(5) 017546 005037 002260 4$: INCR LUNIT FROM #0 TO R1 BY #1
(7) 017552 000402 CLR LUNIT
(6) 017554 50212$: BR 50211$
(10) 017554 005237 002260 50212$: INC LUNIT
(7) 017560 50211$: CMP LUNIT,R1
(7) 017560 023701 002260 BGT 50213$
(9) 017564 003117 LET R2 := LUNIT SHIFT 1
2293 017566 MOV LUNIT,R2
(5) 017566 013702 002260 ASL R2
(8) 017572 006302 LET L$LUN := LUNIT
2294 017574 MOV LUNIT,L$LUN
(4) 017574 013737 002260 002074 LET FLAG := #0
2295 017602 CLR FLAG
(4) 017602 005037 002240 PRINTF #HANRSW
2296 017606 MOV #HANRSW,-(SP)
(7) 017606 012746 020706 MOV #1,-(SP)
(6) 017612 012746 000001 MOV SP,R0
(3) 017616 010600 TRAP C$PNTF
(4) 017620 104417 ADD #4,SP
(4) 017622 062706 000004 PRINTF #HANSW1,LUNIT
2297 017626 MOV LUNIT,-(SP)
(8) 017626 013746 002260 MOV #HANSW1,-(SP)
(7) 017632 012746 020770 MOV #2,-(SP)
(6) 017636 012746 000002 MOV SP,R0
(3) 017642 010600 TRAP C$PNTF
(4) 017644 104417 ADD #6,SP
(4) 017646 062706 000006 PRINTF #HANSW2
2298 017652 MOV #HANSW2,-(SP)
(7) 017652 012746 021055 MOV #1,-(SP)
(6) 017656 012746 000001 MOV SP,R0
(3) 017662 010600 TRAP C$PNTF
(4) 017664 104417 ADD #4,SP
(4) 017666 062706 000004 GMANIL READY, FLAG, 100000, YES
2299 017672 TRAP C$GMAN
(3) 017672 104443 BR 10002$
(3) 017674 000404 .WORD FLAG
(4) 017676 002240 .WORD T$CODE
(5) 017700 000130 .WORD READY
(5) 017702 006752 .WORD 100000
(5) 017704 100000
(3) 017706 10002$:

```

```

2300 017706          IF #BIT15 SET IN @LPCSR(R2) THEN
(6) 017706 032772 100000 002322  BIT #BIT15,@LPCSR(R2)
(10) 017714 001431  BEQ 50214$
2301 017716          PRINTF #HANRDY
(7) 017716 012746 021114  MOV #HANRDY,-(SP)
(6) 017722 012746 000001  MOV #1,-(SP)
(3) 017726 010600  MOV SP,R0
(4) 017730 104417  TRAP C$PNTF
(4) 017732 062706 000004  ADD #4,SP
2302 017736          PRINTF #HANRD1,LUNIT
(8) 017736 013746 002260  MOV LUNIT,-(SP)
(7) 017742 012746 021201  MOV #HANRD1,-(SP)
(6) 017746 012746 000002  MOV #2,-(SP)
(3) 017752 010600  MOV SP,R0
(4) 017754 104417  TRAP C$PNTF
(4) 017756 062706 000006  ADD #6,SP
2303 017762          GMANIL READY, FLAG, 100000, YES
(3) 017762 104443  TRAP C$GMAN
(3) 017764 000404  BR 10003$
(4) 017766 002240  .WORD FLAG
(5) 017770 000130  .WORD T$CODE
(5) 017772 006752  .WORD READY
(5) 017774 100000  .WORD 100000
(3) 017776          10003$:
2304 017776          ELSE
(4) 017776 000411  BR 50215$
(3) 020000          50214$:
2305 020000          LET ERRIBL(R2) := ERRIBL(R2) + #1
(7) 020000 005262 003060  INC ERRIBL(R2)
2306 020004          LET L$LUN := LUNIT
(4) 020004 013737 002260 002074  MOV LUNIT,L$LUN
2307 020012          ERRHRD 9,HANSWI
(4) 020012 104456  TRAP C$ERHRD
(5) 020014 000011  .WORD 9
(5) 020016 003455  .WORD HANSWI
(5) 020020 000000  .WORD 0
2308 020022          ENDIF
(4) 020022          50215$:
2309 020022          ENDINC
(5) 020022 000654  BR 50212$
(4) 020024          50213$:
2310          ;VERIFY OPERATION OF FRONT DOOR INTERLOCK SWITCH.
2311          INCR LUNIT FROM #0 TO R1 BY #1
(5) 020024 005037 002260  CLR LUNIT
(7) 020030 000402  BR 50216$
(6) 020032          50217$:
(10) 020032 005237 002260  INC LUNIT
(7) 020036          50216$:
(7) 020036 023701 002260  CMP LUNIT,R1
(9) 020042 003107  BGT 50220$
2312 020044          LET R2 := LUNIT SHIFT 1
(5) 020044 013702 002260  MOV LUNIT,R2
(8) 020050 006302  ASL R2
2313 020052          LET FLAG := #0
(4) 020052 005037 002240  CLR FLAG
2314 020056          PRINTF #DOORSW,LUNIT
  
```

(8)	020056	013746	002260		MOV	LUNIT,-(SP)
(7)	020062	012746	021247		MOV	#DOORSW,-(SP)
(6)	020066	012746	000002		MOV	#2,-(SP)
(3)	020072	010600			MOV	SP,R0
(4)	020074	104417			TRAP	C\$PNTF
(4)	020076	062706	000006		ADD	#6,SP
2315	020102				PRINTF	#DOOSW1
(7)	020102	012746	021324		MOV	#DOOSW1,-(SP)
(6)	020106	012746	000001		MOV	#1,-(SP)
(3)	020112	010600			MOV	SP,R0
(4)	020114	104417			TRAP	C\$PNTF
(4)	020116	062706	000004		ADD	#4,SP
2316	020122				GMANIL	READY, FLAG, 100000, YES
(3)	020122	104443			TRAP	C\$GMAN
(3)	020124	000404			BR	10004\$
(4)	020126	002240			.WORD	FLAG
(5)	020130	000130			.WORD	T\$CODE
(5)	020132	006752			.WORD	READY
(5)	020134	100000			.WORD	100000
(3)	020136					
2317	020136				10004\$:	IF #BIT15 SET IN @LPCSR(R2) THEN
(6)	020136	032772	100000	002322	BIT	#BIT15,@LPCSR(R2)
(10)	020144	001431			BEQ	50221\$
2318	020146				PRINTF	#DOORDY,LUNIT
(8)	020146	013746	002260		MOV	LUNIT,-(SP)
(7)	020152	012746	021354		MOV	#DOORDY,-(SP)
(6)	020156	012746	000002		MOV	#2,-(SP)
(3)	020162	010600			MOV	SP,R0
(4)	020164	104417			TRAP	C\$PNTF
(4)	020166	062706	000006		ADD	#6,SP
2319	020172				PRINTF	#DOORD1
(7)	020172	012746	021423		MOV	#DOORD1,-(SP)
(6)	020176	012746	000001		MOV	#1,-(SP)
(3)	020202	010600			MOV	SP,R0
(4)	020204	104417			TRAP	C\$PNTF
(4)	020206	062706	000004		ADD	#4,SP
2320	020212				GMANIL	READY, FLAG, 100000, YES
(3)	020212	104443			TRAP	C\$GMAN
(3)	020214	000404			BR	10005\$
(4)	020216	002240			.WORD	FLAG
(5)	020220	000130			.WORD	T\$CODE
(5)	020222	006752			.WORD	READY
(5)	020224	100000			.WORD	100000
(3)	020226					
2321	020226				10005\$:	ELSE
(4)	020226	000411			BR	50222\$
(3)	020230				50221\$:	
2322	020230					LET ERRIBL(R2) := ERRIBL(R2) + #1
(7)	020230	005262	003060		INC	ERRIBL(R2)
2323	020234					LET L\$LUN := LUNIT
(4)	020234	013737	002260	002074	MOV	LUNIT,L\$LUN
2324	020242					ERRHRD 10, DOOSWI
(4)	020242	104456			TRAP	C\$ERHRD
(5)	020244	000012			.WORD	10
(5)	020246	003530			.WORD	DOOSWI
(5)	020250	000000			.WORD	0

```

2325 020252          ENDIF
      (4) 020252      50222$: LET @LPCSR(R2) := #00
2326 020252          MOV      #00,@LPCSR(R2)
      (4) 020252      012772 000000 002322      ENDINC
2327 020260          BR      50217$
      (5) 020260      000664
      (4) 020262      50220$: LET OUTBUF := #14
2328 020262          MOV      #14,OUTBUF
      (4) 020262      012737 000014 003124      OUTPUT #OUTBUF,#1
2329 020270          JSR PC,QUIET
2330 020332      004737 005246      EXIT TST
2331 020336          TRAP      C$EXIT
      (3) 020336      104432          .WORD      L10017-.
      (3) 020340      001116
2332
2333          .NLIST BEX
2334
2335 020342      042522 042101 020131 INTLK: .ASCIIZ /READY LINE INTERLOCK TEST 9/ 2><12>
2336 020400      047045 040445 042522 PAPRSW: .ASCIIZ /%NZAREMOVE ALL PAPER FROM BOTH PAPER TRAYS%N/
2337 020455          045 053501 052111 PAPSW1: .ASCIIZ /%AWITH EXCEPTION OF ONE PER TRAY ON LUNIT %D2%N/
2338 020535          045 052101 020117 PAPSW2: .ASCIIZ /%ATO CHECK PAPER OUT INTERLOCK.%N/
2339 020577          045 022516 051101 PAPRDY: .ASCIIZ /%NZARESTORE PAPER, CLEAR, PLACE LUNIT %D2%A ON LINE.%N/
2340 020666      040520 042520 020122 PAPTST: .ASCIIZ /PAPER OUT TEST/<12>
2341 020706      047045 040445 052524 HANRSW: .ASCIIZ /%NZATURN PAPER TRAY HANDLE COUNTER CLOCKWISE TO%N/
2342 020770      040445 047510 044522 HANSW1: .ASCIIZ /%AHORIZONTAL POSITION UNTIL IT STOPS, ON LUNIT %D2%N/
2343 021055          045 052101 020117 HANSW2: .ASCIIZ /%ATO CHECK INTERLOCK SWITCH.%N/
2344 021114      047045 040445 042522 HANRDY: .ASCIIZ /%NZARETURN PAPER TRAY HANDLE TO VERTICAL POSITION.%N/
2345 021201          045 041501 042514 HANRD1: .ASCIIZ /%ACLEAR, PLACE LUNIT %D2%A ON LINE.%N/
2346 021247          045 022516 047501 DOORSW: .ASCIIZ /%NZAOPEN FRONT DOOR ON LUNIT %D2%A TO CHECK /
2347 021324      047045 040445 047111 DOOSW1: .ASCIIZ /%NZAINTERLOCK SWITCH.%N/
2348 021354      047045 040445 046103 DOORDY: .ASCIIZ /%NZACLOSE FRONT DOOR ON LUNIT %D2%A,%N/
2349 021423          045 041501 042514 DOORD1: .ASCIIZ /%ACLEAR, PLACE ON LINE.%N/
2350          021456
2351
2352          .LIST BEX
2353 021456      ENDTST
      (3) 021456      L10017:
      (3) 021456      104401          TRAP      C$ETST
2354
2355 021460      ENDMOD
2356
2357          .SBTTL INTERRUPT SERVICE ROUTINES
2358 021460      BGNSRV
2359
2360          ;++
2361          ;INTERRUPT VECTORS ARE ESTABLISHED DURING INITIALIZATION
2362          ;POINTING TO THE BASIC ROUTINES WHICH
2363          ;SET UP THE UNIT NUMBER CAUSING THE INTERRUPTS.
2364          ;LINE NUMBER IS RETURNED IN R2
2365          ;
2366          ;--
2367          X=0
2368 021460      000000 INT00: .REPT 16.
2369          000020          SETPRI #PRI04
2370                   PUSH      R2
2371                   LET R2 :- #X

```

2372					INLINE <JMP	IODRV>
2373				X=X+2		
2374					.ENDR	
(4)	021460	012700	000200		MOV	#PRI04,R0
(4)	021464	104441			TRAP	C\$SPRI
(3)	021466	010246			MOV	R2,-(SP)
(5)	021470	012702	000000		MOV	#X,R2
(3)	021474	000137	004464		JMP	IODRV
(4)	021500	012700	000200		MOV	#PRI04,R0
(4)	021504	104441			TRAP	C\$SPRI
(3)	021506	010246			MOV	R2,-(SP)
(5)	021510	012702	000002		MOV	#X,R2
(3)	021514	000137	004464		JMP	IODRV
(4)	021520	012700	000200		MOV	#PRI04,R0
(4)	021524	104441			TRAP	C\$SPRI
(3)	021526	010246			MOV	R2,-(SP)
(5)	021530	012702	000004		MOV	#X,R2
(3)	021534	000137	004464		JMP	IODRV
(4)	021540	012700	000200		MOV	#PRI04,R0
(4)	021544	104441			TRAP	C\$SPRI
(3)	021546	010246			MOV	R2,-(SP)
(5)	021550	012702	000006		MOV	#X,R2
(3)	021554	000137	004464		JMP	IODRV
(4)	021560	012700	000200		MOV	#PRI04,R0
(4)	021564	104441			TRAP	C\$SPRI
(3)	021566	010246			MOV	R2,-(SP)
(5)	021570	012702	000010		MOV	#X,R2
(3)	021574	000137	004464		JMP	IODRV
(4)	021600	012700	000200		MOV	#PRI04,R0
(4)	021604	104441			TRAP	C\$SPRI
(3)	021606	010246			MOV	R2,-(SP)
(5)	021610	012702	000012		MOV	#X,R2
(3)	021614	000137	004464		JMP	IODRV
(4)	021620	012700	000200		MOV	#PRI04,R0
(4)	021624	104441			TRAP	C\$SPRI
(3)	021626	010246			MOV	R2,-(SP)
(5)	021630	012702	000014		MOV	#X,R2
(3)	021634	000137	004464		JMP	IODRV
(4)	021640	012700	000200		MOV	#PRI04,R0
(4)	021644	104441			TRAP	C\$SPRI
(3)	021646	010246			MOV	R2,-(SP)
(5)	021650	012702	000016		MOV	#X,R2
(3)	021654	000137	004464		JMP	IODRV
(4)	021660	012700	000200		MOV	#PRI04,R0
(4)	021664	104441			TRAP	C\$SPRI
(3)	021666	010246			MOV	R2,-(SP)
(5)	021670	012702	000020		MOV	#X,R2
(3)	021674	000137	004464		JMP	IODRV
(4)	021700	012700	000200		MOV	#PRI04,R0
(4)	021704	104441			TRAP	C\$SPRI
(3)	021706	010246			MOV	R2,-(SP)
(5)	021710	012702	000022		MOV	#X,R2
(3)	021714	000137	004464		JMP	IODRV
(4)	021720	012700	000200		MOV	#PRI04,R0
(4)	021724	104441			TRAP	C\$SPRI
(3)	021726	010246			MOV	R2,-(SP)

(5)	021730	012702	000024	MOV	#X,R2
(3)	021734	000137	004464	JMP	IODRV
(4)	021740	012700	000200	MOV	#PRI04,R0
(4)	021744	104441		TRAP	C\$SPRI
(3)	021746	010246		MOV	R2,-(SP)
(5)	021750	012702	000026	MOV	#X,R2
(3)	021754	000137	004464	JMP	IODRV
(4)	021760	012700	000200	MOV	#PRI04,R0
(4)	021764	104441		TRAP	C\$SPRI
(3)	021766	010246		MOV	R2,-(SP)
(5)	021770	012702	000030	MOV	#X,R2
(3)	021774	000137	004464	JMP	IODRV
(4)	022000	012700	000200	MOV	#PRI04,R0
(4)	022004	104441		TRAP	C\$SPRI
(3)	022006	010246		MOV	R2,-(SP)
(5)	022010	012702	000032	MOV	#X,R2
(3)	022014	000137	004464	JMP	IODRV
(4)	022020	012700	000200	MOV	#PRI04,R0
(4)	022024	104441		TRAP	C\$SPRI
(3)	022026	010246		MOV	R2,-(SP)
(5)	022030	012702	000034	MOV	#X,R2
(3)	022034	000137	004464	JMP	IODRV
(4)	022040	012700	000200	MOV	#PRI04,R0
(4)	022044	104441		TRAP	C\$SPRI
(3)	022046	010246		MOV	R2,-(SP)
(5)	022050	012702	000036	MOV	#X,R2
(3)	022054	000137	004464	JMP	IODRV

2375

```

2377 .SBTTL CLOCK SERVICE ROUTINE
2378 :++
2379 :UPDATES THE COUNTER AT A RATE OF 16.67 MILLISECONDS PER TICK
2380 :AND UPDATES A SECOND COUNTER WHEN THE FIRST OVERFLOWS.
2381 :--
2382
2383 022060 BGNSRV
2384 022060 CLKTCK: SETPRI #PRI06
      (3) 022060 012700 000300      MOV #PRI06,R0
      (3) 022064 104441      TRAP C$SPRI
2385 022066      IF TICK EQ #0 THEN
      (6) 022066 005737 022134      TST TICK
      (10) 022072 001005      BNE 50223$
2386 022074      LET TICK := #60. ;60 TICKS PER SECOND
      (4) 022074 012737 000074 022134      MOV #60.,TICK
2387 022102      LET TIME := TIME + #1
      (7) 022102 005237 022132      INC TIME
2388 022106      ENDIF
      (4) 022106      50223$:
2389 022106      LET TICK := TICK - #1 ;BACK UP SECOND TIMER
      (7) 022106 005337 022134      DEC TICK
2390 022112      IF CLKTYP EQ #2 THEN
      (6) 022112 023727 002266 000002      CMP CLKTYP,#2
      (10) 022120 001003      BNE 50224$
2391 022122      LET @CLKCSR := #100
      (4) 022122 012777 000100 160142      MOV #100,@CLKCSR
2392 022130      ENDIF
      (4) 022130      50224$:
2393
2394 022130      ENDSRV ;AND EXIT
      (3) 022130      L10021:
      (2) 022130 000002      RTI
2395
2396 022132 000000      TIME: .WORD 0
2397 022134 000000      TICK: .WORD 0
2398 .SBTTL HARDWARE PARAMETER SECTION
2399 022136 BGNMOD
2400
2401 :++
2402 :THIS SECTION INCLUDES THE QUESTIONS WHICH REQUEST THE OPERATOR TO
2403 :FURNISH THE HARDWARE INFORMATION NECESSARY TO BUILD THE HARDWARE
2404 :P-TABLES.
2405 :
2406 :--
2407 022136 BGNHRD
      (3) 022136 000010      .WORD L10022-L$HARD/2
      (3) 022140
2408
2409 022140      GPRMA GETADR,0,0,160000,177516,YES
      (4) 022140 000031      .WORD T$CODE
      (4) 022142 022160      .WORD GETADR
      (4) 022144 160000      .WORD T$LOLIM
      (4) 022146 177516      .WORD T$HILIM
2410 022150      GPRMA GETVEC,2,0,110,770,YES
      (4) 022150 001031      .WORD T$CODE
      (4) 022152 022175      .WORD GETVEC

```

```

(4) 022154 000110 .WORD T$LOIIM
(4) 022156 000770 .WORD T$HILIM
2411 022160 ENDHRD
(2) .EVEN
(3) 022160 L10022:
2412 .NLIST BEX
2413 022160 050114 030461 040440 GETADR: .ASCIZ /LP11 ADDRESS/
2414 022175 111 052116 051105 GETVEC: .ASCIZ /INTERRUPT VECTOR/
2415 .LIST BEX
2416 .EVEN
2417 .SBTTL SOFTWARE PARAMETER SECTION
2418 .
2419 .++
2420 .THIS SECTION INCLUDES THE QUESTIONS WHICH REQUEST THE OPERATOR TO FURNISH
2421 .THE SOFTWARE INFORMATION NECESSARY TO BUILD THE SOFTWARE P-TABLES.
2422 .--
2423 .
2424 022216 BGNSFT
(3) 022216 000010 .WORD L10023-L$SOFT/2
(3) 022220 L$SOFT::
2425 022220 GPRML MGTINT,0,1,YES
(4) 022220 000130 .WORD T$CODE
(4) 022222 022240 .WORD MGTINT
(4) 022224 000001 .WORD 1
2426 022226 GPRMD GETMAX,2,D,377,1,255.,YES
(4) 022226 001052 .WORD T$CODE
(4) 022230 022276 .WORD GETMAX
(4) 022232 000377 .WORD 377
(4) 022234 000001 .WORD T$LOIIM
(4) 022236 000377 .WORD T$HILIM
2427 022240 ENDSFT
(2) .EVEN
(3) 022240 L10023:
2428 .NLIST BEX
2429 022240 052522 020116 040515 MGTINT: .ASCIZ /RUN MANUAL INTERVENTION TESTS/
2430 022276 052501 047524 051104 GETMAX: .ASCIZ /AUTODROP ERROR COUNT/
2431 .LIST BEX
2432 022324 .EVEN
2433 .
2434 .
2435 022324 000020 PATCH: .BLKW 20
2436 022364 LASTAD .EVEN
(2) .EVEN
(4) 022364 000000 .WORD 0
(4) 022366 000000 .WORD 0
(3) 022370 L$LAST::
2437 022370 ENDMOD
2438 000001 .END
  
```

ACTIVE=	020000	855#	1135	1147	1152	1220	1226	1232	1510	1614	2286			
ADR =	000020 G	816#												
ASSEMB=	000010	659	661											
BIN2DA	004252	1069#												
BIT0 =	000001 G	816#												
BIT00 =	000001 G	816#												
BIT01 =	000002 G	816#												
BIT02 =	000004 G	816#												
BIT03 =	000010 G	816#												
BIT04 =	000020 G	816#												
BIT05 =	000040 G	816#												
BIT06 =	000100 G	816#												
BIT07 =	000200 G	816#	1574	1584	2228									
BIT08 =	000400 G	816#												
BIT09 =	001000 G	816#												
BIT11 =	000002 G	816#												
BIT10 =	002000 G	816#												
BIT11 =	004000 G	816#												
BIT12 =	010000 G	816#												
BIT13 =	020000 G	816#	855											
BIT14 =	040000 G	816#	854											
BIT15 =	100000 G	816#	853	1125	1212	1557	2218	2300	2317					
BIT2 =	000004 G	816#												
BIT3 =	000010 G	816#												
BIT4 =	000020 G	816#												
BIT5 =	000040 G	816#												
BIT6 =	000100 G	816#												
BIT7 =	000200 G	816#	1566	1630										
BIT8 =	000400 G	816#												
BIT9 =	001000 G	816#												
BOE =	000400 G	816#												
BUFADD	002314	899#	1249	1250	1281*	1344*	1439*	1623*	1628*	1689*	1709*	1714*	1742*	1753*
		1756*	1758*	1801*	1832*	1873*	1978*	1983*	1986*	1990*	1992*	1995*	1997*	1998*
		2005*	2055*	2076*	2081*	2148*	2149*	2150*	2151*	2152*	2153*	2154*	2155*	2156*
		2157*	2158*	2159*	2160*	2161*	2162*	2165*	2166*	2167*	2169*	2171*	2175*	2236*
		2259*	2263*	2268*	2329*									
BUFCNT	002316	901#	1251	1252	1281*	1344*	1439*	1623*	1628*	1689*	1709*	1714*	1742*	1753*
		1756*	1758*	1801*	1832*	1873*	1978*	1983*	1986*	1990*	1992*	1995*	1997*	1998*
		2005*	2055*	2076*	2081*	2148*	2149*	2150*	2151*	2152*	2153*	2154*	2155*	2156*
		2157*	2158*	2159*	2160*	2161*	2162*	2165*	2166*	2167*	2169*	2171*	2175*	2236*
		2259*	2263*	2268*	2329*									
BUFREP	002320	903#	1253	1281*	1344*	1439*	1623*	1628*	1689*	1709*	1714*	1742*	1753*	1756*
		1758*	1801*	1832*	1873*	1978*	1983*	1986*	1990*	1992*	1995*	1997*	1998*	2005*
		2055*	2076*	2081*	2148*	2149*	2150*	2151*	2152*	2153*	2154*	2155*	2156*	2157*
		2158*	2159*	2160*	2161*	2162*	2165*	2166*	2167*	2169*	2171*	2175*	2236*	2259*
		2263*	2268*	2329*										
CCNT	002250	868#	1698*	2063*										
CHAR	011312	1693*	1695*	1699	1700*	1701*	1702	1703*	1704*	1718#				
CHRGEN	002254	870#												
CK1	006306	1423#												
CLEAN	007242	1504#												
CLKCSR	002272	883#	1416*	1417*	1427*	1430*	1519*	2391*						
CLKENA	002300	886#												
CLKSET	002274	884#												
CLKTCK	022060	2384#												
CLKTYP	002266	878#	1411*	1414*	1425*	1433	1517	1521	2390					

CLKVEC	002276	885#	1419*	1420	1428*	1518	1522												
CLOCKP	002270	882#	1415*	1416	1426*	1427													
COUNT	002246	867#	1749*	1807*	1979*	1999*	2000	2164*	2168										
COUNTD	004460	1073*	1078*	1081	1082*	1083	1090*	1105#											
CR =	000015	G 823#	2141																
CSRERR	003352	971#	1561	2220															
CTLEND	005240	1198	1269#																
CTLLOP	004722	1196#	1268																
CURADD	002516	921#	1130	1131*	1142*	1144	1145*	1249*	2288*										
CURCNT	002716	933#	1129	1136*	1143*	1146*	1219	1251*	1254	1295*	1378*	1511*	2287*						
C\$AU =	000052	659#																	
C\$AUTO=	000061	659#	731																
C\$BRK =	000022	659#																	
C\$BSEG=	000004	659#																	
C\$BSUB=	000002	659#																	
C\$CEFG=	000045	659#																	
C\$CLCK=	000062	659#	1412	1423															
C\$CLEA=	000012	659#	1525																
C\$CLOS=	000035	659#																	
C\$CLP1=	000006	659#																	
C\$CVEC=	000036	659#	1518																
C\$DCLN=	000044	659#	1302																
C\$DODU=	000051	659#																	
C\$DRPT=	000024	659#																	
C\$DU =	000053	659#																	
C\$EDIT=	000003	659#	680																
C\$ERDF=	000055	659#																	
C\$ERHR=	000056	659#	1035	1040	1046	1561	1578	1588	1612	1641	2220	2230	2269	2307					
C\$ERRO=	000060	2324 659#																	
C\$ERSF=	000054	659#																	
C\$ERSO=	000057	659#																	
C\$ESCA=	000010	659#																	
C\$ESEG=	000005	659#																	
C\$ESUB=	000003	659#																	
C\$ETST=	000001	659#	1661	1727	1769	1948	2033	2097	2188	2353									
C\$EXIT=	000032	659#	1348	1440	1632	1716	1761	1875	2009	2083	2177	2207	2210	2331					
C\$GETB=	000026	659#																	
C\$GETW=	000027	659#																	
C\$GMAN=	000043	659#	1368	2255	2277	2299	2303	2316	2320										
C\$GPHR=	000042	659#	1317	1374															
C\$GPLO=	000030	659#																	
C\$GPRI=	000040	659#																	
C\$INIT=	000011	659#	1455																
C\$INLP=	000020	659#																	
C\$MANI=	000050	659#	1357	2205															
C\$MEM =	000031	659#																	
C\$MSG =	000023	659#																	
C\$OPEN=	000034	659#																	
C\$PNTB=	000014	659#																	
C\$PNTF=	000017	659#	1297	1301	1354	1355	1360	1434	1435	2252	2253	2254	2275	2296					
		2297	2298	2301	2302	2314	2315	2318	2319										
C\$PNTS=	000016	659#																	
C\$PNTX=	000015	659#																	
C\$QIO =	000377	659#																	
C\$RDBU=	000007	659#																	

C\$REFG=	000047	659#	1336	1338											
C\$RESE=	000033	659#	1352	1502											
C\$REVI=	000003	659#	680												
C\$RFLA=	000021	659#													
C\$RPT =	000025	659#													
C\$SEFG=	000046	659#													
C\$SPRI=	000041	659#	1342	1437	1501	1524	1595	1606	1622	2374	2384				
C\$SVEC=	000037	659#	1396	1420	1480	1522	1596	1607							
C\$TPRI=	000013	659#													
DATPTH	011314	1689	1719#												
DEL =	000177	824#	1227*	1229*	1230	1262*	1379*	1513*	1615*						
DELCNT	003016	939#													
DFPTBL	002222	716#													
DIAGMC=	000000	659	661												
DIGITS	004462	1075*	1106#												
DONE	011747	1756	1764#												
DOORDY	021354	2318	2348#												
DOORD1	021423	2319	2349#												
DOORSW	021247	2314	2346#												
DOOSWI	003530	975#	2324												
DOOSW1	021324	2315	2347#												
DROPED=	040000	854#	1208	1294	1405	1510	1614								
DROPIT	005314	1053	1294#												
DVSTR	016430	2148	2182#												
EF.CON=	000036	816#													
EF.NEW=	000035	816#													
EF.PWR=	000034	816#													
EF.RES=	000037	816#	1338												
EF.STA=	000040	816#	1336												
END2	010174	1613#	1642	1649											
ERFLG =	000400	1030#													
ERRCOD	002302	887#	1030	1056*	1160*	1204*	1213*	1224*	1231*	1239	1365*	2285*			
ERRFLG	002304	889#	2240*	2257*	2265	2266	2273*	2284*							
ERROR =	100000	853#	1055	1159	1214	1233	1510	1558	1575	1585	1614	2286			
ERRSVC	003056	942#	1161	1243	1281*	1344*	1439*	1623*	1628*	1689*	1709*	1714*	1742*	1753*	
		1756*	1758*	1801*	1832*	1873*	1978*	1983*	1986*	1990*	1992*	1995*	1997*	1998*	
		2005*	2055*	2076*	2081*	2148*	2149*	2150*	2151*	2152*	2153*	2154*	2155*	2156*	
		2157*	2158*	2159*	2160*	2161*	2162*	2165*	2166*	2167*	2169*	2171*	2175*	2236*	
		2259*	2263*	2268*	2329*										
ERRTBL	003060	943#	1033*	1038*	1044*	1052	1298*	1377*	1512*	1559*	1577*	1586*	1610*	1639*	
		2219*	2229*	2270*	2305*	2322*									
ERR11	010504	1588	1657#												
ERR12	010560	1641	1658#												
ERR13	010643	1612	1659#												
EVL =	000004	816#													
E\$END =	002100	659#													
E\$LOAD=	000035	659#	680												
FAKE	005422	1315#	1341												
FF =	000014	822#	2143												
FLAG	002240	864#	1364*	1368	2212*	2251*	2255	2276*	2277	2295*	2299	2303	2313*	2316	
		2320													
FLAGDA	004456	1072*	1081	1084*	1093	1104#									
F\$AU =	000015	659#													
F\$AUTO=	000020	659#	727	731											
F\$BGN =	000040	659#	677	685	727	802	806	1323	1332	1333	1348	1440	1500	1527	
		1530	1541	1632	1638	1647	1661	1663	1668	1683	1716	1727	1729	1732	

1738	1761	1769	1771	1775	1798	1875	1948	1950	1954	1970	2009	2033
2034	2038	2048	2083	2097	2098	2102	2135	2177	2188	2190	2193	2033
2207	2210	2331	2353	2355	2358	2383	2399	2407	2424	2437		2203
659#	1500	1525										
659#												
659#	677	731	802	806	1323	1332	1348	1440	1455	1525	1527	1530
1541	1632	1643	1650	1661	1663	1668	1683	1716	1727	1729	1732	1738
1761	1769	1771	1775	1798	1875	1948	1950	1954	1970	2009	2033	2034
2038	2048	2083	2097	2098	2102	2135	2177	2188	2190	2193	2203	2207
2210	2331	2353	2355	2394	2399	2411	2427	2437				
659#	2407	2411										
659#	716	723										
659#	1333	1455										
659#	1348	1440	1632	1716	1761	1875	2009	2083	2177	2207	2210	2331
659#	677	802	806	1323	1332	1527	1530	1663	1668	1729	1732	1771
1775	1950	1954	2034	2038	2098	2102	2190	2193	2355	2399	2437	
659#												
659#	685	689										
659#												
659#												
659#												
659#	2424	2427										
659#	1638	1643	1647	1650	2358	2383	2394					
659#												
659#	740	749										
659#	1541	1661	1683	1727	1738	1769	1798	1948	1970	2033	2048	2097
2135	2188	2203	2353									
2409	2413#											
2426	2430#											
2410	2414#											
659#												
659#	1228	1346	1568	1599	1609							
659#												
659#												
659#												
659#												
659#												
659#	1368	2255	2277	2299	2303	2316	2320	2409	2410	2425	2426	
659#	1368	2255	2277	2299	2303	2316	2320	2409	2410	2425	2426	
659#	2409	2410										
659#	2426											
659#	1368	2255	2277	2299	2303	2316	2320	2425				
659#												
659#												
659#	2426											
659#	1368	2255	2277	2299	2303	2316	2320	2425				
659#	2409	2410										
659#												
659#	1368	2255	2277	2299	2303	2316	2320	2409	2410	2425	242	

IBE = 010000 G	816#													
IDU = 000040 G	816#													
IER = 020000 G	816#													
IGNORE 007146	1420	1463#	1522											
INDEX 002310	894#													
INHINT 002234	742#	2209												
INTERR 010366	1596	1639#												
INTER1 003574	976#													
INTFAC 010424	1623	1653#												
INTHDL 010416	1607	1649#												
INTLK 020342	2236	2335#												
INTOO 021460	1394	2368#												
IOCTRL 004662	1181#	1281	1344	1439	1623	1628	1689	1709	1714	1742	1753	1756	1758	
	1801	1832	1873	1978	1983	1986	1990	1992	1995	1997	1998	2005	2055	
	2076	2081	2148	2149	2150	2151	2152	2153	2154	2155	2156	2157	2158	
	2159	2160	2161	2162	2165	2166	2167	2169	2171	2175	2236	2259	2263	
	2268	2329												
	1125#	2374												
IODRV 004464														
ISR = 000100 G	816#													
IXE = 004000 G	816#													
ISAU = 000041	659#													
ISAUTO= 000041	659#	727#	731#											
ISCLN = 000041	659#	1500#	1525#											
ISDU = 000041	659#													
ISHRD = 000041	2407#	2411#												
ISINIT= 000041	659#	1333#	1348	1440	1455#									
ISMOD = 000041	659#	677#	802#	806#	1323#	1332#	1527#	1530#	1663#	1668#	1729#	1732#	1771#	
	1775#	1950#	1954#	2034#	2038#	2098#	2102#	2190#	2193#	2355#	2399#	2437#		
ISMSG = 000041	659#													
ISPROT= 000040	659#	685#												
ISPTAB= 000041	659#													
ISPR = 000041	659#													
ISRPT = 000041	659#													
ISSEG = 000041	659#	15 1	1683	1738	1798	1970	2048	2135	2203					
ISSETU= 000041	659#													
ISSFT = 000041	2424#	2427#												
ISSRV = 000041	659#	1638#	1643#	1647#	1650#	2358#	2383#	2394#						
ISSUB = 000041	659#	1541	1683	1738	1798	1970	2048	2135	2203					
ISTST = 000041	659#	1541#	1632	1661#	1683#	1716	1727#	1738#	1761	1769#	1798#	1875	1948#	
	1970#	2009	2033#	2048#	2083	2097#	2135#	2177	2180#	2203#	2207	2210	2331	
	2353#													
JSJMP = 000167	659#													
LF = 030012 G	821#	1752	2142											
LINCNT 002242	865#	1708#	1808#	1994#	2060#	2061#	2067	2074	2079	2256#	2260#	2261	2265	
LOBYTE= 000377	856#	1510												
LOE = 040000 G	816#													
LOT = 000010 G	816#													
LPBUF 002416	915#	1130#	1144#	1385#	1583#									
LPCSR 002322	909#	1057#	1125	1137#	1148#	1153#	1212	1255#	1296#	1384#	1385	1557	1562#	
	1566	1574	1584	1589#	1597#	1605#	1608#	1613#	1630	2218	2221#	2228	2279#	
	2300	2317	2326#											
	992#	1297												
LPDROP 004002	1030#	1281	1344	1439	1623	1628	1689	1709	1714	1742	1753	1756	1758	
LPERR 004050	1801	1832	1873	1978	1983	1986	1990	1992	1995	1997	1998	2005	2055	
	2076	2081	2148	2149	2150	2151	2152	2153	2154	2155	2156	2157	2158	
	2159	2160	2161	2162	2165	2166	2167	2169	2171	2175	2236	2329		

LPINTR	002756		936#	1395*	1396	1480									
LPVEC	002362		912#	1389*	1396	1480	1596	1607							
LSTCNT	002244		866#												
LUNIT	002260		872#	1547*	1550*	1552	1556	1560	1576	1587	1611	1640	1976*	1977	1978
			1983	1986	1990	1992	1995	1997	1998	2005	2216*	2217	2225*	2226	2227
			2241*	2244*	2245	2247	2253	2259	2263	2268	2275	2278	2292*	2293	2294
			2297	2302	2306	2311*	2312	2314	2318	2323					
L\$ACP	002110	G	680#												
L\$APT	002036	G	680#												
L\$AUT	002070	G	680#												
L\$AUTO	002226	G	680	727#											
L\$CCP	002106	G	680#												
L\$CLEA	007232	G	680	1500#											
L\$CO	002032	G	680#												
L\$DEPO	002011	G	680#												
L\$DESC	002152	G	680	702#											
L\$DESP	002076	G	680#												
L\$DEVP	002060	G	680#												
L\$DISP	002132	G	680	698#											
L\$DLY	002116	G	680#	1228	1346	1568	1599	1609							
L\$DTP	002040	G	680#												
L\$DTYP	002034	G	680#												
L\$DUT	002072	G	680#												
L\$DVTY	002212	G	680	703#											
L\$EF	002052	G	680#												
L\$ENVI	002044	G	680#												
L\$ETP	002102	G	680#												
L\$EXP1	002046	G	680#												
L\$EXP4	002064	G	680#												
L\$EXP5	002066	G	680#												
L\$HARD	022140	G	680	2407#											
L\$HIME	002120	G	680#												
L\$HPCP	002016	G	680#												
L\$HPTP	002022	G	680#												
L\$HW	002222	G	680	716#											
L\$IICP	002104	G	680#												
L\$INIT	005456	G	680	333#											
L\$LADP	002026	G	680#												
L\$LAST	022370	G	680	2436#											
L\$LOAD	002100	G	680#												
L\$LUN	002074	G	680#	1034*	1039*	1045*	1188*	1191*	1203	1267*	1297	1315*	1316	1317	1318*
			1373*	1374	1376	1505*	1508	1560*	1576*	1587*	1611*	1640*	2227*	2294*	2306*
			2323*												
L\$MREV	002050	G	680#												
L\$NAME	002000	G	680#												
L\$PRIO	002042	G	680#												
L\$PROT	002122	G	680	685#											
L\$PRT	002112	G	680#												
L\$REPP	002062	G	680#												
L\$REV	002010	G	680#												
L\$SOFT	022220	G	680	2424#											
L\$SPC	002056	G	680#												
L\$SPCP	002020	G	680#												
L\$SPTP	002024	G	680#												
L\$STA	002030	G	680#												
L\$SW	002234	G	680	740#											

[illegible]

PAPSW2	020535	2254	2338#											
PAPTST	020666	2259	2340#											
PATCH	022324	2435#												
PATTER	011352	1691*	1692	1722#										
PLOC	007142	1452#												
PNT	= 001000	816#												
PORSQ	011765	1765#												
PRI	= 002000	816#												
PRINTR	002264	876#	1186	1191	1281*	1344*	1439*	1623*	1628*	1689*	1709*	1714*	1742*	1753*
		1756*	1758*	1801*	1832*	1873*	1978*	1983*	1986*	1990*	1992*	1995*	1997*	1998*
		2005*	2055*	2076*	2081*	2148*	2149*	2150*	2151*	2152*	2157*	2154*	2155*	2156*
		2157*	2158*	2159*	2160*	2161*	2162*	2165*	2166*	2167*	2169*	2171*	2175*	2236*
		2259*	2263*	2268*	2329*									
		816#	1342	1437	1524	1622								
PRI00	= 000000	816#												
PRI01	= 000040	816#												
PRI02	= 000100	816#												
PRI03	= 000140	816#	1606											
PRI04	= 000200	816#	1396	1480	1595	1596	1607	2374						
PRI05	= 000240	816#												
PRI06	= 000300	816#	1420	1522	2384									
PRI07	= 000340	816#	1501											
PRTCHR	011710	1742	1763#											
PRTCTL	013740	1978	2011#											
PTABAD	002262	875#												
QUIET	005246	1281#	1629	1710	1715	1754	1759	1833	1874	2003	2006	2077	2082	2163
		2173	2176	2330										
		972#	1578	2230										
RDYERR	003370	1368	1448#	2255	2277	2299	2303	2316	2320					
READY	006752	927#	1140*	1141	1253*	1380*	1514*	2289*						
REPCNT	002616	1360	1446#											
RESET1	006701	1476#	1516	1621										
RESVEC	007150	740#												
SFPTBL	002234	2180#												
SPANUM	016424	2057*	2060	2064	2075*	2086#								
STACHR	014620	828#	1160	1213										
STATER=	000001	918#	1055*	1135*	1147*	1152*	1159*	1208	1214*	1220	1226	1232*	1233*	1294*
STATUS	002456	1405*	1510*	1558*	1575*	1585*	1614*	2286*						
		869#												
STRCNT	002252	659#	669#	680	685	698	702	703	716	727	740	1333	1500	2407
SVCGBL=	000000	2424	2436#											
		659#	666#	680	698	702	703	716	731	740	1035	1040	1046	1228
SVCINS=	000000	1297	1301	1302	1317	1336	1337	1338	1339	1342	1346	1348	1352	1354
		1355	1357	1358	1360	1368	1374	1375	1396	1412	1420	1423	1434	1435
		1437	1440	1455	1480	1501	1502	1518	1522	1524	1525	1561	1568	1578
		1588	1595	1596	1599	1606	1607	1609	1612	1622	1632	1641	1643	1650
		1661	1716	1727	1761	1769	1875	1948	2009	2033	2083	2097	2177	2188
		2205	2206	2207	2210	2220	2230	2252	2253	2254	2255	2269	2275	2277
		2296	2297	2298	2299	2301	2302	2303	2307	2314	2315	2316	2318	2319
		2320	2324	2331	2353	2374	2384	2394	2407	2409	2410	2411	2424	2425
		2426	2427	2436										
		659#	668#											
SVC SUB=	000000	659#	670#	723	731	749	1368	1455	1489	1499	1525	1643	1650	1661
SVC TAG=	000000	1727	1769	1948	2033	2097	2188	2255	2277	2299	2303	2316	2320	2353
		2394	2411	2427										
		659#	667#	1541	1683	1738	1798	1970	2048	2135	2203			
SVC IST=	000000	1030#												
SYM	000037													

SYMD = 000007	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#
	1099#	1131#	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#
	1229#	1232#	1233#	1266#	1267#	1294#	1299#	1318#	1345#	1372#	1373#	1376#	1385#
	1393#	1394#	1400#	1405#	1481#	1482#	1504#	1505#	1508#	1510#	1542#	1556#	1558#
	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#	1605#	1608#	160#	1614#	1639#
	1691#	1698#	1701#	1704#	1708#	1808#	1813#	1820#	1834#	1974#	197#	1999#	2061#
	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#	2219#	2225#	2226#	2229#	2245#
	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#	2387#	2389#	
SYMS = 000007	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#
	1099#	1131#	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#
	1229#	1232#	1233#	1266#	1267#	1294#	1299#	1318#	1345#	1372#	1373#	1376#	1385#
	1393#	1394#	1400#	1405#	1481#	1482#	1504#	1505#	1508#	1510#	1542#	1556#	1558#
	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#	1605#	1608#	1610#	1614#	1639#
	1691#	1698#	1701#	1704#	1708#	1808#	1813#	1820#	1834#	1974#	1977#	1999#	2061#
	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#	2219#	2225#	2226#	2229#	2245#
	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#	2387#	2389#	
SSLSYM- 010000	659#	723#	731#	749#	1368#	1455#	1525#	1643#	1650#	1661#	1727#	1769#	1948#
	2033#	2097#	2188#	2255#	2277#	2299#	2303#	2316#	2320#	2353#	2394#	2411#	2427#
TABLDA 004444	1071	1103#											
TABLE1 014210	1981	2028#											
TABLE2 014244	1988	2029#											
TABSTR 014622	2057	2088#											
TICK 022134	2385	2386#	2389#	2397#									
TIME 022132	2387#	2396#											
TIMOUT= 000002	829#	1231											
TXERR 003627	977#	1035											
TXNOIN 003701	979#	1046											
TSARGC= 000001	680#	1297#	1301#	1354#	1355#	1360#	1434#	1435#	2252#	2253#	2254#	2275#	2296#
	2297#	2298#	2301#	2302#	2314#	2315#	2318#	2319#					
TS CODE= 001052	1368#	2255#	2277#	2299#	2303#	2316#	2320#	2409#	2410#	2425#	2426#		
TSERRN= 000012	659#	1035#	1040#	1046#	1561#	1578#	1588#	1612#	1641#	2220#	2230#	2269#	2307#
	2324#												
TSEXCP= 000000	2409#	2410#	2426#										
TSFLAG= 000040	1348#	1440#	1632#	1716#	1761#	1875#	2009#	2083#	2177#	2207#	2210#	2331#	
TSGMAN= 000000	659#												
TSHILI= 000377	2409#	2410#	2426#										
TSLAST= 000001	659#	2436#											
TSLOLI= 000001	2409#	2410#	2426#										
TSLSYM= 010000	659#	723	731	749	1455	1525	1643	1650	1661	1727	1769	1948	2033
	2097	2188	2353	2394	2411	2427							
TSLTNO= 000010	2436#												
TSNEST= 000000	659#	677#	685#	689#	716#	723#	727#	731#	740#	749#	802#	806#	1323#
	1332#	1333#	1455#	1500#	1525#	1527#	1530#	1541#	1638#	1643#	1647#	1650#	1661#
	1663#	1668#	1683#	1727#	1729#	1732#	1738#	1769#	1771#	1775#	1798#	1948#	1950#
	1954#	1970#	2033#	2034#	2038#	2048#	2097#	2098#	2102#	2135#	2188#	2190#	2193#
	2203#	2353#	2355#	2358#	2383#	2394#	2399#	2407#	2411#	2424#	2427#	2437#	
TSNSO = 000010	677#	802	806#	1323	1332#	1527	1530#	1663	1668#	1729	1732#	1771	1775#
	1950	1954#	2034	2038#	2098	2102#	2190	2193#	2355	2358#			
TSNS1 = 000000	685#	689	716#	723	727#	731	740#	749	1333#	1455	1500#	1525	1541#
	1661	1683#	1727	1738#	1769	1798#	1948	1970#	2033	2048#	2097	2135#	2188
	2203#	2353	2383#	2394	2399#	2437							
	1638#	1643	1647#	1650	2407#	2411	2424#	2427					
TSNS2 = 000005	659#												
TSPTNU= 000000	659#												
TS SAVL= 177777	659#												
TSSEGL= 177777	659#												
TS SUBN= 000000	659#	1541#	1683#	1738#	1798#	1970#	2048#	2135#	2203#				

[illegible]

X3	014067	2017#	2029											
X4	014101	2018#	2029											
X5	014113	2019#	2029											
X6	014125	2020#	2029											
X7	014137	2021#	2029											
X8	014151	2022#	2029											
X9	014163	2023#	2029											
ZNUM	016422	2179#												
ZN1	016450	2151	2183#											
ZN2	016453	2154	2184#											
ZN3	016462	2157	2185#											
ZN4	016476	2160	2186#											
\$BGNLE=	177777	661#												
\$BRJMP=	177777	661#												
		1129	1138	1141	1149	1156	1186	1189	1197	1208	1212	1215	1219	1220
		1225	1226	1230	1235	1239	1244	1254	1300	1316	1319	1345	1347	1353
		1373	1406	1413	1424	1433	1479	1483	1505	1515	1517	1521	1557	1566
		1567	1569	1574	1584	1598	1600	1630	1631	1691	1692	1694	1698	1705
		1708	1711	1712	1746#	1747	1749	1751	1755	1760#	1808	1813	1815	1820
		1822	1835	1975#	1976	1982	1984	1989	1991	1994	1996	2000	2007	2008#
		2063	2065	2067	2070	2079	2164	2168	2170	2174	2209	2216	2218	2223
		2225	2228	2232	2261	2265	2266	2272	2292	2300	2304	2309	2311	2317
		2321	2327	2385	2390									
\$ERFLG- 000400		661#	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1056#	1057#	1070#	1071#	1072#
		1073#	1075#	1077#	1078#	1082#	1083#	1084#	1086#	1089#	1090#	1094#	1097#	1099#
		1130#	1131#	1135#	1136#	1137#	1140#	1142#	1143#	1144#	1145#	1146#	1147#	1148#
		1152#	1153#	1159#	1160#	1187#	1188#	1190#	1191#	1203#	1204#	1213#	1214#	1224#
		1227#	1229#	1231#	1232#	1233#	1249#	1250#	1251#	1252#	1253#	1255#	1262#	1266#
		1267#	1294#	1295#	1296#	1298#	1299#	1315#	1318#	1343#	1345#	1364#	1365#	1366#
		1372#	1373#	1376#	1377#	1378#	1379#	1380#	1384#	1385#	1389#	1393#	1394#	1395#
		1400#	1405#	1411#	1414#	1415#	1416#	1417#	1419#	1425#	1426#	1427#	1428#	1430#
		1438#	1477#	1478#	1481#	1482#	1504#	1505#	1508#	1510#	1511#	1512#	1513#	1514#
		1519#	1542#	1556#	1558#	1559#	1560#	1562#	1567#	1575#	1576#	1577#	1583#	1585#
		1586#	1587#	1589#	1597#	1598#	1605#	1608#	1610#	1611#	1613#	1614#	1615#	1627#
		1639#	1640#	1642#	1649#	1691#	1693#	1695#	1697#	1698#	1699#	1701#	1702#	1704#
		1706#	1707#	1708#	1713#	1747#	1748#	1749#	1750#	1752#	1757#	1802#	1803#	1807#
		1808#	1809#	1813#	1814#	1820#	1821#	1827#	1828#	1834#	1872#	1974#	1976#	1977#
		1979#	1981#	1985#	1988#	1994#	1999#	2004#	2057#	2060#	2061#	2062#	2063#	2064#
		2066#	2068#	2069#	2074#	2075#	2080#	2137#	2138#	2139#	2140#	2141#	2142#	2143#
		2144#	2164#	2212#	2213#	2216#	2217#	2219#	2221#	2225#	2226#	2227#	2229#	2240#
		2245#	2251#	2256#	2257#	2260#	2262#	2267#	2270#	2273#	2276#	2278#	2279#	2284#
		2285#	2286#	2287#	2288#	2289#	2292#	2293#	2294#	2295#	2305#	2306#	2311#	2312#
		2313#	2322#	2323#	2326#	2328#	2374#	2386#	2387#	2389#	2391#			
\$F\$AND= 000310		661#	1052	1076	1081	1093	1125	1129	1141	1186	1197	1208	1212	1219
		1220	1226	1230	1239	1254	1300	1316	1353	1433	1479	1517	1521	1557
		1566	1574	1584	1630	1692	1982	1989	2000	2067	2168	2209	2218	2228
		2261	2266	2300	2317	2385	2390							
\$F\$BAD= 000401		661#	1030	1033	1034	1038	1039	1044	1045	1052	1055	1056	1057	1070
		1071	1072	1073	1075	1076	1077	1078	1081	1082	1083	1084	1086	1089
		1090	1093	1094	1097	1099	1125	1129	1130	1131	1135	1136	1137	1140
		1141	1142	1143	1144	1145	1146	1147	1148	1152	1153	1159	1160	1186
		1187	1188	1190	1191	1197	1203	1204	1208	1212	1213	1214	1219	1220
		1224	1226	1227	1229	1230	1231	1232	1233	1239	1249	1250	1251	1252
		1253	1254	1255	1262	1266	1267	1294	1295	1296	1298	1299	1300	1315
		1316	1318	1343	1345	1353	1364	1365	1366	1372	1373	1376	1377	1378
		1379	1380	1384	1385	1389	1393	1394	1395	1400	1405	1411	1414	1415

1416	1417	1419	1425	1426	1427	1428	1430	1433	1438	1477	1478	1479
1481	1482	1504	1505	1508	1510	1511	1512	1513	1514	1517	1519	1521
1542	1556	1557	1558	1559	1560	1562	1566	1567	1574	1575	1576	1577
1583	1584	1585	1586	1587	1589	1597	1598	1605	1608	1610	1611	1613
1614	1615	1627	1630	1639	1640	1642	1649	1691	1692	1693	1695	1697
1698	1699	1701	1702	1704	1706	1707	1708	1713	1747	1748	1749	1750
1752	1757	1802	1803	1807	1808	1809	1813	1814	1820	1821	1827	1828
1834	1872	1974	1976	1977	1979	1981	1982	1985	1988	1989	1994	1999
2000	2004	2057	2060	2061	2062	2063	2064	2066	2067	2068	2069	2074
2075	2080	2137	2138	2139	2140	2141	2142	2143	2144	2164	2168	2209
2212	2213	2216	2217	2218	2219	2221	2225	2226	2227	2228	2229	2240
2245	2251	2256	2257	2260	2261	2262	2266	2267	2270	2273	2276	2278
2279	2284	2285	2286	2287	2288	2289	2292	2293	2294	2295	2300	2305
2306	2311	2312	2313	2317	2322	2323	2326	2328	2374	2385	2386	2387
2389	2390	2391										

\$F\$BLA= 000170
 \$F\$CAS= 000150
 \$F\$DEC= 000220
 \$F\$DO = 000340
 \$F\$FAL= 000405
 \$F\$G00= 000400

661#												
661#												
661#	1075	1091	1345	1347	1567	1569	1598	1600	1994	1996		
661#	1076	1226	1316	1479	1630	1982	1989	2067				
661#	1030											
661#	1030	1033	1034	1038	1039	1044	1045	1052	1055	1056	1057	1070
1071	1072	1073	1075	1076	1077	1078	1081	1082	1083	1084	1086	1089
1090	1093	1094	1097	1099	1125	1129	1130	1131	1135	1136	1137	1140
1141	1142	1143	1144	1145	1146	1147	1148	1152	1153	1159	1160	1186
1187	1188	1190	1191	1197	1203	1204	1208	1212	1213	1214	1219	1220
1224	1226	1227	1229	1230	1231	1232	1233	1239	1249	1250	1251	1252
1253	1254	1255	1262	1266	1267	1294	1295	1296	1298	1299	1300	1315
1316	1318	1343	1345	1353	1364	1365	1366	1372	1373	1376	1377	1378
1379	1380	1384	1385	1389	1393	1394	1395	1400	1405	1411	1413	1414
1415	1416	1417	1419	1424	1425	1426	1427	1428	1430	1433	1438	1477
1478	1479	1481	1482	1504	1505	1508	1510	1511	1512	1513	1514	1517
1519	1521	1542	1556	1557	1558	1559	1560	1562	1566	1567	1574	1575
1576	1577	1583	1584	1585	1586	1587	1589	1597	1598	1605	1608	1610
1611	1613	1614	1615	1627	1630	1639	1640	1642	1649	1691	1692	1693
1695	1697	1698	1699	1701	1702	1704	1706	1707	1708	1713	1747	1748
1749	1750	1752	1757	1802	1803	1807	1808	1809	1813	1814	1820	1821
1827	1828	1834	1872	1974	1976	1977	1979	1981	1982	1985	1988	1989
1994	1999	2000	2004	2057	2060	2061	2062	2063	2064	2066	2067	2068
2069	2074	2075	2080	2137	2138	2139	2140	2141	2142	2143	2144	2164
2168	2209	2212	2213	2216	2217	2218	2219	2221	2225	2226	2227	2228
2229	2240	2245	2251	2256	2257	2260	2261	2262	2266	2267	2270	2273
2276	2278	2279	2284	2285	2286	2287	2288	2289	2292	2293	2294	2295
2300	2305	2306	2311	2312	2313	2317	2322	2323	2326	2328	2374	2385
2386	2387	2389	2390	2391								

\$F\$IF = 000110

661#	1052	1054	1081	1085	1087	1093	1095	1125	1129	1138	1141	1149
1154	1155	1156	1163	1186	1189	1192	1197	1199	1208	1212	1215	1219
1220	1225	1230	1234	1236	1237	1238	1239	1244	1254	1256	1257	1258
1300	1303	1353	1356	1413	1421	1424	1431	1433	1436	1517	1520	1521
1523	1557	1563	1566	1570	1574	1579	1584	1590	1692	1694	1696	2000
2002	2168	2170	2172	2209	2211	2218	2222	2228	2231	2261	2264	2266
2272	2274	2300	2304	2308	2317	2321	2325	2385	2388	2390	2392	
661#	1373	1406	1505	1515	1691	1698	1705	1708	1711	1712	1747	1749
1751	1755	1808	1813	1815	1820	1822	1835	1976	2007	2067	2065	2164
2174	2216	2223	2225	2232	2292	2309	2311	2327				

\$F\$LOO= 000200
 \$F\$NAM= 000160

661#
 661#

\$F\$NO = 000403

661#	1030	1033	1034	1038	1039	1044	1045	1052	1055	1056	1057	1070
1071	1072	1073	1075	1076	1077	1078	1081	1082	1083	1084	1086	1089
1090	1093	1094	1097	1099	1125	1129	1130	1131	1135	1136	1137	1140
1141	1142	1143	1144	1145	1146	1147	1148	1152	1153	1159	1160	1186
1187	1188	1190	1191	1197	1203	1204	1208	1212	1213	1214	1219	1220
1224	1226	1227	1229	1230	1231	1232	1233	1239	1249	1250	1251	1252
1253	1254	1255	1262	1266	1267	1294	1295	1296	1298	1299	1300	1315
1316	1318	1343	1345	1353	1364	1365	1366	1372	1373	1376	1377	1378
1379	1380	1384	1385	1389	1393	1394	1395	1400	1405	1411	1413	1414
1415	1416	1417	1419	1424	1425	1426	1427	1428	1430	1433	1438	1477
1478	1479	1481	1482	1504	1505	1508	1510	1511	1512	1513	1514	1517
1519	1521	1542	1556	1557	1558	1559	1560	1562	1566	1567	1574	1575
1576	1577	1583	1584	1585	1586	1587	1589	1597	1598	1605	1608	1610
1611	1613	1614	1615	1627	1630	1639	1640	1642	1649	1691	1692	1693
1695	1697	1698	1699	1701	1702	1704	1706	1707	1708	1713	1747	1748
1749	1750	1752	1757	1802	1803	1807	1808	1809	1813	1814	1820	1821
1827	1828	1834	1872	1974	1976	1977	1979	1981	1982	1985	1988	1989
1994	1999	2000	2004	2057	2060	2061	2062	2063	2064	2066	2067	2068
2069	2074	2075	2080	2137	2138	2139	2140	2141	2142	2143	2144	2164
2168	2209	2212	2213	2216	2217	2218	2219	2221	2225	2226	2227	2228
2229	2240	2245	2251	2256	2257	2260	2261	2262	2265	2266	2267	2270
2273	2276	2278	2279	2284	2285	2286	2287	2288	2289	2292	2293	2294
2295	2300	2305	2306	2311	2312	2313	2317	2322	2323	2326	2328	2374
2385	2386	2387	2389	2390	2391							
661#	1052	1076	1081	1093	1125	1129	1141	1186	1197	1208	1212	1219
1220	1226	1230	1239	1254	1300	1316	1353	1433	1479	1517	1521	1557
1566	1574	1584	1630	1692	1982	1989	2000	2067	2168	2209	2218	2228
2261	2266	2300	2317	2385	2390							

\$F\$OR = 000320

\$F\$RTI= 000350
 \$F\$RTN= 000300
 \$F\$SEL= 000140
 \$F\$THE= 000330

661#	1030	1032	1037	1042	1050							
661#	1052	1081	1093	1125	1129	1141	1186	1197	1208	1212	1219	1220
1230	1239	1254	1300	1353	1433	1517	1521	1557	1566	1574	1584	1692
2000	2168	2209	2218	2228	2261	2266	2300	2317	2385	2390		

\$F\$TRU= 000404
 \$F\$UNT= 000130
 \$F\$WHI= 000120

661#	1032	1037	1042									
661#	2059	2079	2258	2265								
661#	1076	1079	1081	1226	1235	1316	1319	1479	1483	1630	1631	1982
1984	1989	1991	2067	2070	2261							

\$F\$YES= 000402

661#	1030	1033	1034	1038	1039	1044	1045	1050	1052	1054	1055	1056
1057	1070	1071	1072	1073	1075	1076	1077	1078	1081	1082	1083	1084
1085	1086	1087	1089	1090	1093	1094	1095	1097	1099	1125	1129	1130
1131	1135	1136	1137	1138	1140	1141	1142	1143	1144	1145	1146	1147
1148	1149	1152	1153	1154	1155	1156	1159	1160	1163	1186	1187	1188
1189	1190	1191	1192	1197	1199	1203	1204	1208	1212	1213	1214	1215
1219	1220	1224	1225	1226	1227	1229	1230	1231	1232	1233	1234	1236
1237	1238	1239	1244	1249	1250	1251	1252	1253	1254	1255	1256	1257
1258	1262	1266	1267	1294	1295	1296	1298	1299	1300	1303	1315	1316
1318	1343	1345	1353	1356	1364	1365	1366	1372	1373	1376	1377	1378
1379	1380	1384	1385	1389	1393	1394	1395	1400	1405	1411	1413	1414
1415	1416	1417	1419	1421	1424	1425	1426	1427	1428	1430	1431	1433
1436	1438	1477	1478	1479	1481	1482	1504	1505	1508	1510	1511	1512
1513	1514	1517	1519	1520	1521	1523	1542	1556	1557	1558	1559	1560
1562	1563	1566	1567	1570	1574	1575	1576	1577	1579	1583	1584	1585
1586	1587	1589	1590	1597	1598	1605	1608	1610	1611	1613	1614	1615
1627	1630	1639	1640	1642	1649	1691	1692	1693	1694	1695	1696	1697
1698	1699	1701	1702	1704	1706	1707	1708	1713	1747	1748	1749	1750

	1752	1757	1802	1803	1807	1808	1809	1813	1814	1820	1821	1827	1828
	1834	1872	1974	1976	1977	1979	1981	1982	1985	1988	1989	1994	1999
	2000	2002	2004	2057	2060	2061	2062	2063	2064	2066	2067	2068	2069
	2074	2075	2080	2137	2138	2139	2140	2141	2142	2143	2144	2164	2168
	2170	2172	2209	2211	2212	2213	2216	2217	2218	2219	2221	2222	2225
	2226	2227	2228	2229	2231	2240	2245	2251	2256	2257	2260	2261	2262
	2264	2266	2267	2270	2272	2273	2274	2276	2278	2279	2284	2285	2286
	2287	2288	2289	2292	2293	2294	2295	2300	2304	2305	2306	2308	2311
	2312	2313	2317	2321	2322	2323	2325	2326	2328	2374	2385	2386	2387
	2388	2389	2390	2391	2392								
\$IFLEV= 177777	661#	1052#	1054#	1081#	1087#	1093#	1095#	1125#	1129#	1141#	1154#	1155#	1163#
	1186#	1192#	1197#	1199#	1208#	1212#	1219#	1220#	1230#	1234#	1236#	1237#	1238#
	1239#	1254#	1256#	1257#	1258#	1300#	1303#	1353#	1356#	1413#	1421#	1424#	1431#
	1433#	1436#	1517#	1520#	1521#	1523#	1557#	1563#	1566#	1570#	1574#	1575#	1584#
	1590#	1692#	1696#	2000#	2002#	2168#	2172#	2209#	2211#	2218#	2222#	2228#	2231#
\$ISK0 = 000001	2261#	2264#	2266#	2274#	2300#	2308#	2317#	2325#	2385#	2388#	2390#	2391#	
	1052#	1054	1081#	1087	1093#	1095	1125#	1163	1186#	1192	1197#	1199	1208#
	1258	1300#	1303	1353#	1356	1413#	1421	1424#	1431	1433#	1436	1517#	1520
	1521#	1523	1557#	1563	1566#	1570	1574#	1579	1584#	1590	1692#	1696	2000#
	2002	2168#	2172	2209#	2211	2218#	2222	2228#	2231	2261#	2264	2266#	2274
	2300#	2308	2317#	2325	2385#	2388	2390#	2392					
\$ISK1 = 000001	1129#	1155	1212#	1238	1239#	1257							
\$ISK2 = 000001	1141#	1154	1219#	1237	1254#	1256							
\$ISK3 = 000001	1220#	1236											
\$ISK4 = 000001	1230#	1234											
\$LO = 177777	1030#	1032#	1037#	1042#									
\$LOCTA= 177777	661#	664#	1030	1032	1037	1042	1050	1052	1054	1075	1076	1079	1081
	1085	1087	1091	1093	1095	1125	1129	1138	1141	1149	1154	1155	1156
	1163	1186	1189	1192	1197	1199	1208	1212	1215	1219	1220	1225	1226
	1230	1234	1235	1236	1237	1238	1239	1244	1254	1256	1257	1258	1300
	1303	1316	1319	1345	1347	1353	1356	1373	1406	1413	1421	1424	1431
	1433	1436	1479	1483	1505	1515	1517	1520	1521	1523	1557	1563	1566
	1567	1569	1570	1574	1579	1584	1590	1598	1600	1630	1631	1691	1692
	1694	1696	1698	1705	1708	1711	1712	1747	1749	1751	1755	1808	1813
	1815	1820	1822	1835	1976	1982	1984	1989	1991	1994	1996	2000	2002
	2007	2059	2063	2065	2067	2070	2079	2164	2168	2170	2172	2174	2209
	2211	2216	2218	2222	2223	2225	2228	2231	2232	2258	2261	2264	2265
	2266	2272	2274	2292	2300	2304	2308	2309	2311	2317	2321	2325	2327
	2385	2388	2390	2392									
\$LSK0 = 000000	1030#	1032	1037	1042									
\$LSTIN= 000000	661#	662#	1030	1033	1034	1037	1038	1039	1042	1044	1045	1050	1052
	1055	1056	1057	1069	1070	1071	1072	1073	1075	1076	1077	1078	1079
	1081	1082	1083	1084	1085	1086	1089	1090	1091	1093	1094	1097	1098
	1099	1125	1129	1130	1131	1135	1136	1137	1138	1140	1141	1142	1143
	1144	1145	1146	1147	1148	1149	1152	1153	1156	1159	1160	1164	1181
	1186	1187	1188	1189	1190	1191	1197	1198	1203	1204	1208	1212	1213
	1214	1215	1219	1220	1224	1225	1226	1227	1229	1230	1231	1232	1233
	1235	1239	1244	1249	1250	1251	1252	1253	1254	1255	1262	1266	1267
	1270	1294	1295	1296	1298	1299	1300	1315	1316	1318	1319	1343	1345
	1347	1353	1364	1365	1366	1372	1373	1376	1377	1378	1379	1380	1384
	1385	1389	1393	1394	1395	1400	1405	1406	1411	1413	1414	1415	1416
	1417	1419	1424	1425	1426	1427	1428	1430	1433	1438	1476	1477	1478
	1479	1481	1482	1483	1484	1504	1505	1508	1510	1511	1512	1513	1514
	1515	1517	1519	1521	1542	1556	1557	1558	1559	1560	1562	1566	1567
	1569	1574	1575	1576	1577	1583	1584	1585	1586	1587	1589	1597	1598
	1600	1605	1608	1610	1611	1613	1614	1615	1627	1630	1631	1639	1640

	1642	1649	1691	1692	1693	1694	1695	1697	1698	1699	1701	1702	1704
	1705	1706	1707	1708	1711	1712	1713	1747	1748	1749	1750	1751	1752
	1755	1757	1802	1803	1807	1808	1809	1813	1814	1815	1820	1821	1822
	1827	1828	1834	1835	1872	1974	1976	1977	1979	1981	1982	1984	1985
	1988	1989	1991	1994	1996	1999	2000	2004	2007	2057	2060	2061	2062
	2063	2064	2065	2066	2067	2068	2069	2070	2074	2075	2079	2080	2137
	2138	2139	2140	2141	2142	2143	2144	2164	2168	2170	2174	2209	2212
	2213	2216	2217	2218	2219	2221	2223	2225	2226	2227	2228	2229	2232
	2240	2245	2251	2256	2257	2260	2261	2262	2265	2266	2267	2270	2271
	2272	2273	2276	2278	2279	2284	2285	2286	2287	2288	2289	2292	2293
	2294	2295	2300	2304	2305	2306	2309	2311	2312	2313	2317	2321	2322
	2323	2326	2327	2328	2374	2385	2386	2387	2389	2390	2391		
\$LSTTA= 000000	661#	663#	1030	1032	1037	1042	1050	1054	1075	1076	1079	1081	1085
	1087	1091	1095	1138	1149	1154	1155	1156	1163	1189	1192	1199	1215
	1225	1226	1234	1235	1236	1237	1238	1244	1256	1257	1258	1303	1316
	1319	1345	1347	1356	1373	1406	1421	1431	1436	1479	1483	1505	1515
	1520	1523	1563	1567	1569	1570	1579	1590	1598	1600	1630	1631	1691
	1694	1696	1698	1705	1708	1711	1712	1747	1749	1751	1755	1808	1813
	1815	1820	1822	1835	1976	1982	1984	1989	1991	1994	1996	2002	2007
	2059	2063	2065	2067	2070	2164	2170	2172	2174	2211	2216	2222	2223
	2225	2231	2232	2258	2261	2264	2265	2272	2274	2292	2304	2308	2309
	2311	2321	2325	2327	2388	2392							
\$NESTL= 177777	661#	1030#	1032	1037	1042	1050#	1052#	1054#	1075#	1076#	1079#	1081#	1085
	1087#	1091#	1093#	1095#	1125#	1129#	1138	1141#	1149	1154#	1155#	1156	1163#
	1186#	1189	1192#	1197#	1199#	1208#	1212#	1215	1219#	1220#	1225	1226#	1230#
	1234#	1235#	1236#	1237#	1238#	1239#	1244	1254#	1256#	1257#	1258#	1300#	1303#
	1316#	1319#	1345#	1347#	1353#	1356#	1373#	1406#	1413#	1421#	1424#	1431#	1433#
	1436#	1479#	1483#	1505#	1515#	1517#	1520#	1521#	1523#	1557#	1563#	1566#	1567#
	1569#	1570#	1574#	1579#	1584#	1590#	1598#	1600#	1630#	1631#	1691#	1692#	1694
	1696#	1698#	1705#	1708#	1711#	1712#	1747#	1749#	1751#	1755#	1808#	1813#	1815#
	1820#	1822#	1835#	1976#	1982#	1984#	1989#	1991#	1994#	1996#	2000#	2002#	2007#
	2059#	2063#	2065#	2067#	2070#	2079#	2164#	2168#	2170	2172#	2174#	2209#	2211#
	2216#	2218#	2222#	2223#	2225#	2228#	2231#	2232#	2258#	2261#	2264#	2265#	2266#
	2272	2274#	2292#	2300#	2304	2308#	2309#	2311#	2317#	2321	2325#	2327#	2355#
	2388#	2390#	2392#										
\$NSKO = 000110	1030#	1032	1037	1042	1050	1052#	1054	1075#	1091	1093#	1095	1125#	1156
	1163	1186#	1189	1192	1197#	1199	1208#	1258	1300#	1303	1316#	1319	1345#
	1347	1353#	1356	1373#	1406	1413#	1421	1424#	1431	1433#	1436	1479#	1483
	1505#	1515	1517#	1520	1521#	1523	1557#	1563	1566#	1570	1574#	1579	1584#
	1590	1598#	1600	1630#	1631	1691#	1712	1747#	1755	1808#	1835	1976#	2007
	2059#	2079	2164#	2174	2209#	2211	2216#	2223	2225#	2232	2258#	2265	2266#
	2272	2274	2292#	2309	2311#	2327	2385#	2388	2390#	2392			
\$NSK1 000110	1076#	1079	1081#	1085	1087	1129#	1138	1155	1212#	1215	1238	1239#	1244
	1257	1567#	1569	1692#	1694	1696	1698#	1705	1708#	1711	1749#	1751	1813#
	1815	1820#	1822	1982#	1984	1989#	1991	1994#	1996	2000#	2002	2063#	2065
	2067#	2070	2168#	2170	2172	2218#	2222	2228#	2231	2261#	2264	2300#	2304
	2308	2317#	2321	2325									
\$NSK2 = 000110	1141#	1149	1154	1219#	1237	1254#	1256						
\$NSK3 = 000110	1220#	1225	1236										
\$NSK4 = 000120	1226#	1235											
\$NSK5 = 000110	1230#	1234											
\$SAVE = 050004	661#	1030#	1050#										
\$SAVE2= 050005	1030#												
\$SAVLE= 177777	661#	1030#	1050#	1075#	1079#	1235#	1319#	1345#	1373#	1483#	1505#	1567#	1598#
	1631#	1691#	1698#	1708#	1751#	1755#	1808#	1813#	1820#	1984#	1991#	1996#	2007#
	2063#	2070#	2164#	2216#	2225#	2292#	2311#						

\$SELLE= 000000
 \$SSKO = 050217

\$SSK1 = 000402
 \$SSK2 = 050005
 \$IAGLE= 177777

\$IAGNU- 050225

\$TEMP - 050224

\$ISKO = 050224

661#	1030#	1032	1037	1042									
1030#	1050	1075#	1079#	1235#	1319#	1345#	1373#	1483#	1505#	1567#	1598#	1631#	
1691#	1698#	1708#	1751#	1755#	1808#	1813#	1820#	1984#	1991#	1996#	2007#	2063#	
2070#	2164#	2216#	2225#	2292#	2311#								
1030#	1050												
1030#	1050												
661#	1030#	1032	1037	1042	1050#	1052#	1054#	1075#	1076#	1079#	1081#	1085#	
1087#	1091#	1093#	1095#	1125#	1129#	1138#	1141#	1149#	1154#	1155#	1156#	1163#	
1186#	1189#	1192#	1197#	1199#	1208#	1212#	1215#	1219#	1220#	1225#	1226#	1230#	
1234#	1235#	1236#	1237#	1238#	1239#	1244#	1254#	1256#	1257#	1258#	1300#	1303#	
1316#	1319#	1345#	1347#	1353#	1356#	1373#	1406#	1413#	1421#	1424#	1431#	1433#	
1436#	1479#	1483#	1505#	1515#	1517#	1520#	1521#	1523#	1557#	1563#	1566#	1567#	
1569#	1570#	1574#	1579#	1584#	1590#	1598#	1600#	1630#	1631#	1691#	1692#	1694#	
1696#	1698#	1705#	1708#	1711#	1712#	1747#	1749#	1751#	1755#	1808#	1813#	1815#	
1820#	1822#	1835#	1976#	1982#	1984#	1989#	1991#	1994#	1996#	2000#	2002#	2007#	
2059#	2063#	2065#	2067#	2070#	2079#	2164#	2168#	2170#	2172#	2174#	2209#	2211#	
2216#	2218#	2222#	2223#	2225#	2228#	2231#	2232#	2258#	2261#	2264#	2265#	2266#	
2272#	2274#	2292#	2300#	2304#	2308#	2309#	2311#	2317#	2321#	2325#	2327#	2385#	
2388#	2390#	2392#											
661#	1030#	1052#	1075#	1076#	1081#	1085#	1093#	1125#	1129#	1138#	1141#	1149#	
1156#	1186#	1189#	1197#	1208#	1212#	1215#	1219#	1220#	1225#	1226#	1230#	1239#	
1244#	1254#	1300#	1316#	1345#	1353#	1373#	1413#	1424#	1433#	1479#	1505#	1517#	
1521#	1557#	1566#	1567#	1574#	1584#	1598#	1630#	1691#	1692#	1694#	1698#	1708#	
1747#	1749#	1808#	1813#	1820#	1976#	1982#	1989#	1994#	2000#	2059#	2063#	2067#	
2164#	2168#	2170#	2209#	2216#	2218#	2225#	2228#	2258#	2261#	2265#	2266#	2272#	
2292#	2300#	2304#	2311#	2317#	2321#	2385#	2390#						
661#	1030#	1032#	1033#	1034#	1037#	1038#	1039#	1042#	1044#	1045#	1050#	1054#	
1055#	1056#	1057#	1070#	1071#	1072#	1073#	1075#	1077#	1078#	1079#	1082#	1083#	
1084#	1085#	1086#	1087#	1089#	1090#	1091#	1094#	1095#	1097#	1099#	1130#	1131#	
1135#	1136#	1137#	1138#	1140#	1142#	1143#	1144#	1145#	1146#	1147#	1148#	1149#	
1152#	1153#	1154#	1155#	1156#	1159#	1160#	1163#	1187#	1188#	1189#	1190#	1191#	
1192#	1199#	1203#	1204#	1213#	1214#	1215#	1224#	1225#	1227#	1229#	1231#	1232#	
1233#	1234#	1235#	1236#	1237#	1238#	1244#	1249#	1250#	1251#	1252#	1253#	1255#	
1256#	1257#	1258#	1262#	1266#	1267#	1294#	1295#	1296#	1298#	1299#	1303#	1315#	
1318#	1319#	1343#	1345#	1347#	1356#	1364#	1365#	1366#	1372#	1373#	1376#	1377#	
1378#	1379#	1380#	1384#	1385#	1389#	1393#	1394#	1395#	1400#	1405#	1406#	1411#	
1414#	1415#	1416#	1417#	1419#	1421#	1425#	1426#	1427#	1428#	1430#	1431#	1436#	
1438#	1477#	1478#	1481#	1482#	1483#	1504#	1505#	1508#	1510#	1511#	1512#	1513#	
1514#	1515#	1519#	1520#	1523#	1542#	1556#	1558#	1559#	1560#	1562#	1563#	1567#	
1569#	1570#	1575#	1576#	1577#	1579#	1583#	1585#	1586#	1587#	1589#	1590#	1597#	
1598#	1600#	1605#	1608#	1610#	1611#	1613#	1614#	1615#	1627#	1631#	1639#	1640#	
1642#	1649#	1691#	1693#	1694#	1695#	1696#	1697#	1698#	1699#	1701#	1702#	1704#	
1705#	1706#	1707#	1708#	1711#	1712#	1713#	1747#	1748#	1749#	1750#	1751#	1752#	
1755#	1757#	1802#	1803#	1807#	1808#	1809#	1813#	1814#	1815#	1820#	1821#	1822#	
1827#	1828#	1834#	1835#	1872#	1974#	1976#	1977#	1979#	1981#	1984#	1985#	1988#	
1991#	1994#	1996#	1999#	2002#	2004#	2007#	2057#	2060#	2061#	2062#	2063#	2064#	
2065#	2066#	2068#	2069#	2070#	2074#	2075#	2079#	2080#	2137#	2138#	2139#	2140#	
2141#	2142#	2143#	2144#	2164#	2170#	2172#	2174#	2211#	2212#	2213#	2216#	2217#	
2219#	2221#	2222#	2223#	2225#	2226#	2227#	2229#	2231#	2232#	2240#	2245#	2251#	
2256#	2257#	2260#	2262#	2264#	2265#	2267#	2270#	2272#	2273#	2274#	2276#	2278#	
2279#	2284#	2285#	2286#	2287#	2288#	2289#	2292#	2293#	2294#	2295#	2304#	2305#	
2306#	2308#	2309#	2311#	2312#	2313#	2321#	2322#	2323#	2325#	2326#	2327#	2328#	
2374#	2386#	2387#	2388#	2389#	2391#	2392#							
1030#	1050	1052#	1054	1075#	1091	1093#	1095	1125#	1156#	1163	1186#	1189#	
1192	1197#	1199	1208#	1258	1300#	1303	1316#	1319	1345#	1347	1353#	1356	
1373#	1406	1413#	1421	1424#	1431	1433#	1436	1479#	1483	1505#	1515	1517#	

	1520	1521#	1523	1557#	1563	1566#	1570	1574#	1579	1584#	1590	1598#	1600
	1630#	1631	1691#	1712	1747#	1755	1808#	1835	1976#	2007	2059#	2079	2164#
	2174	2209#	2211	2216#	2223	2225#	2232	2258#	2265	2266#	2272#	2274	2292#
	2309	2311#	2327	2385#	2388	2390#	2392						
\$TSK1 = 050217	1030#	1042#	1050	1075#	1091	1129#	1138#	1155	1212#	1215#	1238	1239#	1244#
	1257	1316#	1319	1345#	1347	1373#	1406	1479#	1483	1505#	1515	1567#	1569
	1598#	1600	1630#	1631	1691#	1712	1747#	1755	1808#	1835	1976#	2007	2063#
	2065	2067#	2070	2164#	2174	2216#	2223	2225#	2232	2261#	2264	2292#	2309
	2311#	2327											
\$TSK2 = 050222	1030#	1037#	1050	1076#	1079	1081#	1085#	1087	1141#	1149#	1154	1219#	1237
	1254#	1256	1567#	1569	1692#	1694#	1696	1698#	1705	1708#	1711	1749#	1751
	1813#	1815	1820#	1822	1982#	1984	1989#	1991	1994#	1996	2000#	2002	2063#
	2065	2067#	2070	2168#	2170#	2172	2218#	2222	2228#	2231	2300#	2304#	2308
	2317#	2321#	2325										
\$TSK3 = 050155	1030#	1032#	1050	1076#	1079	1220#	1225#	1236	1698#	1705	1708#	1711	1749#
	1751	1813#	1815	1820#	1822	1982#	1984	1989#	1991	1994#	1996		
\$TSK4 = 050040	1030#	1050#	1226#	1235									
\$TSK5 = 050041	1030#	1037	1042	1050	1226#	1235							
\$TSK6 = 050042	1230#	1234											
\$U = 000403	1075#	1345#	1373#	1505#	1567#	1598#	1691#	1698#	1708#	1747#	1749#	1808#	1813#
	1820#	1976#	1994#	2063#	2164#	2216#	2225#	2292#	2311#				
\$SARGC= 000000	661#												
\$SBYTE= 000403	661#	1052#	1076#	1081#	1093#	1125#	1129#	1141#	1186#	1197#	1208#	1212#	1219#
	1220#	1226#	1230#	1239#	1254#	1300#	1316#	1353#	1433#	1479#	1517#	1521#	1557#
	1566#	1574#	1584#	1630#	1692#	1982#	1989#	2000#	2067#	2168#	2209#	2218#	2228#
	2261#	2266#	2300#	2317#	2385#	2390#							
\$SCASE= 000404	661#	1030#	1032#	1037#	1042#								
\$SDST = 000037	661#	2061#											
\$SELOC= 000402	661#	1052#	1054#	1081#	1085	1087#	1093#	1095#	1125#	1129#	1138	1141#	1149
	1154#	1155#	1156	1163#	1186#	1189	1192#	1197#	1199#	1208#	1212#	1215	1219#
	1220#	1225	1230#	1234#	1236#	1237#	1238#	1239#	1244	1254#	1256#	1257#	1258#
	1300#	1303#	1353#	1356#	1413#	1421#	1424#	1431#	1433#	1436#	1517#	1520#	1521#
	1523#	1557#	1563#	1566#	1570#	1574#	1579#	1584#	1590#	1692#	1694	1696#	2000#
	2002#	2168											

[illegible]

ENDTST	1661	1727	1769	1948	2033	2097	2188	2353							
EQUALS	816														
ERRHRD	1035	1040	1046	1561	1578	1588	1612	1641	2220	2230	2269	2307	2324		
EXIF	661#														
EXIFB	661#														
EXIT	1348	1440	1632	1716	1761	1875	2009	2083	2177	2207	2210	2331			
GMANIL	1368	2255	2277	2299	2303	2316	2320								
GPHARD	1317	1374													
GPRMA	2409	2410													
GPRMD	2426														
GPRML	1368#	2255#	2277#	2299#	2303#	2316#	2320#	2425							
HEADER	680														
IF	661#	1052	1081	1093	1125	1129	1141	1186	1197	1208	1212	1219	1220	1230	1239
	1254	1300	1353	1433	1517	1521	1557	1566	1574	1584	1692	2000	2168	2209	2218
	2228	2261	2266	2300	2317	2385	2390								
IFB	661#														
IFCOND	661#	1413	1424												
IF.ERR	661#														
IF.NO.	661#														
INCR	661#	1373	1505	1691	1698	1708	1747	1749	1808	1813	1820	1976	2063	2164	2216
	2225	2292	2311												
INCRB	661#														
INCRU	661#														
INCRUB	661#														
INLINE	661#	1198	2271	2374											
IROUTI	661#														
LASTAD	2436														
LEAVE	661#														
LET	661#	1033	1034	1038	1039	1044	1045	1055	1056	1057	1070	1071	1072	1073	1077
	1078	1082	1083	1084	1086	1089	1090	1094	1097	1099	1130	1131	1135	1136	1137
	1140	1142	1143	1144	1145	1146	1147	1148	1152	1153	1159	1160	1187	1188	1190
	1191	1203	1204	1213	1214	1224	1227	1229	1231	1232	1233	1249	1250	1251	1252
	1253	1255	1262	1266	1267	1294	1295	1296	1298	1299	1315	1318	1343	1364	1365
	1366	1372	1376	1377	1378	1379	1380	1384	1385	1389	1393	1394	1395	1400	1405
	1411	1414	1415	1416	1417	1419	1425	1426	1427	1428	1430	1438	1477	1478	1481
	1482	1504	1508	1510	1511	1512	1513	1514	1519	1542	1556	1558	1559	1560	1562
	1575	1576	1577	1583	1585	1586	1587	1589	1597	1605	1608	1610	1611	1613	1614
	1615	1627	1639	1640	1642	1649	1693	1695	1697	1699	1701	1702	1704	1706	1707
	1713	1748	1750	1752	1757	1802	1803	1807	1809	1814	1821	1827	1828	1834	1872
	1974	1977	1979	1981	1985	1988	1999	2004	2057	2060	2061	2062	2064	2066	2068
	2069	2074	2075	2080	2137	2138	2139	2140	2141	2142	2143	2144	2212	2213	2217
	2219	2221	2226	2227	2229	2240	2245	2251	2256	2257	2260	2262	2267	2270	2273
	2276	2278	2279	2284	2285	2286	2287	2288	2289	2293	2294	2295	2305	2306	2312
	2313	2322	2323	2326	2328	2374	2386	2387	2389	2391					
LOCAL	661#														
LOOP	661#														
MANUAL	1357	2205													
MSBYTE	680#														
MSCHEC	1348#	1440#	1632#	1716#	1761#	1875#	2009#	2083#	2177#	2207#	2210#	2331#			
MSCNTO	1368#	2255#	2277#	2299#	2303#	2316#	2320#	2409#	2410#	2425#	2426#				
MSCOUN	1297#	1301#	1354#	1355#	1360#	1434#	1435#	2252#	2253#	2254#	2275#	2296#	2297#	2298#	2301#
	2302#	2314#	2315#	2318#	2319#										
MSDATA	680#	702#	703#												
MSDECR	689#	723#	731#	749#	802#	1323#	1455#	1525#	1527#	1643#	1650#	1661#	1663#	1727#	1729#
	1769#	1771#	1948#	1950#	2033#	2034#	2097#	2098#	2188#	2190#	2353#	2355#	2394#	2411#	2427#
	2437#														

CZLNAAO LN01 TEST DNMAC X24.07-563 12-JAN-83 08:16 PAGE 21-2 1 8 CZLNAA.P11 12-JAN-83 08:16 CROSS REFERENCE TABLE -- MACRO NAMES SEQ 0099														
MSDEFA	1368#	2255#	2277#	2299#	2303#	2316#	2320#	2409#	2410#	2425#	2426#			
MSENDE	723#	731#	749#	802#	1323#	1455#	1525#	1527#	1643#	1650#	1661#	1663#	1727#	1729#
	1771#	1948#	1950#	2033#	2034#	2097#	2098#	2188#	2190#	2353#	2355#	2394#	2411#	2427#
MSERRI	1035#	1040#	1046#	1561#	1578#	1588#	1612#	1641#	2220#	2230#	2269#	2307#	2324#	2437#
MSEXCP	2409#	2410#	2426#											
MSEXIT	1348#	1440#	1632#	1716#	1761#	1875#	2009#	2083#	2177#	2207#	2210#	2331#		
MSEXSE	1348#	1440#	1632#	1716#	1761#	1875#	2009#	2083#	2177#	2207#	2210#	2331#		
MSEXTJ	1348#	1440#	1632#	1716#	1761#	1875#	2009#	2083#	2177#	2207#	2210#	2331#		
MSGEN	680#	685#	698#	702#	703#	716#	723#	727#	731#	740#	749#	1333#	1368#	1455#
	1525#	1541#	1638#	1643#	1647#	1650#	1661#	1683#	1727#	1738#	1769#	1798#	1948#	1970#
	2048#	2097#	2135#	2188#	2203#	2255#	2277#	2299#	2303#	2316#	2320#	2353#	2358#	2383#
	2407#	2411#	2424#	2427#	2436#									
MSGENB	1368#	2255#	2277#	2299#	2303#	2316#	2320#							
MSGETS	689#	723#	731#	749#	802#	1323#	1455#	1525#	1527#	1643#	1650#	1661#	63#	1727#
	1769#	1771#	1948#	1950#	2033#	2034#	2097#	2098#	2188#	2190#	2353#	2355#	394#	2411#
	2437#													
MSGETT	1348#	1440#	1632#	1716#	1761#	1875#	2009#	2083#	2177#	2207#	2210#	2331#		
MSGNGB	677#	680#	685#	698#	702#	703#	716#	727#	740#	806#	1332#	1333#	1500#	1530#
	1647#	1668#	1732#	1775#	1954#	2038#	2102#	2193#	2358#	2383#	2399#	2407#	2424#	2436#
MSGNIN	680#	698#	702#	703#	716#	731#	740#	1035#	1040#	1046#	1228#	1297#	1301#	1302#
	1336#	1337#	1338#	1339#	1342#	1346#	1348#	1352#	1354#	1355#	1357#	1358#	1360#	1368#
	1375#	1396#	1412#	1420#	1423#	1434#	1435#	1437#	1440#	1455#	1480#	1501#	1502#	1518#
	1524#	1525#	1561#	1568#	1578#	1588#	1595#	1596#	1599#	1606#	1607#	1609#	1612#	1622#
	1641#	1643#	1650#	1661#	1716#	1727#	1761#	1769#	1875#	1948#	2009#	2033#	2083#	2097#
	2188#	2205#	2206#	2207#	2210#	2220#	2230#	2252#	2253#	2254#	2255#	2269#	2275#	2277#
	2297#	2298#	2299#	2301#	2302#	2303#	2307#	2314#	2315#	2316#	2318#	2319#	2320#	2324#
	2353#	2374#	2384#	2394#	2407#	2409#	2410#	2411#	2424#	2425#	2426#	2427#	2436#	
MSGNLS	1368#	2255#	2277#	2299#	2303#	2316#	2320#							
MSGNTA	723#	731#	749#	1455#	1525#	1643#	1650#	1661#	1727#	1769#	1948#	2033#	2097#	2188#
	2394#	2411#	2427#											
MSGNTE	1541#	1683#	1738#	1798#	1970#	2048#	2135#	2203#						
MSHAPT	680#													
MSHNAP	680#													
MSINCR	677#	685#	716#	727#	731#	740#	806#	1035#	1040#	1046#	1297#	1301#	1302#	1317#
	1333#	1336#	1338#	1342#	1348#	1352#	1354#	1355#	1357#	1360#	1368#	1374#	1396#	1412#
	1423#	1434#	1435#	1437#	1440#	1455#	1480#	1500#	1501#	1502#	1518#	1522#	1524#	1525#
	1541#	1561#	1578#	1588#	1595#	1596#	1606#	1607#	1612#	1622#	1632#	1638#	1641#	1647#
	1668#	1683#	1716#	1727#	1732#	1738#	1761#	1769#	1775#	1798#	1875#	1948#	1954#	1970#
	2033#	2038#	2048#	2083#	2097#	2102#	2135#	2177#	2188#	2193#	2203#	2205#	2207#	2210#
	2230#	2252#	2253#	2254#	2255#	2269#	2275#	2277#	2296#	2297#	2298#	2299#	2301#	2302#
	2307#	2314#	2315#	2316#	2318#	2319#	2320#	2324#	2331#	2353#	2358#	2374#	2383#	2384#
	2407#	2424#												
MSLDRO	1317#	1336#	1338#	1342#	1374#	1412#	1423#	1437#	1501#	1518#	1524#	1595#	1606#	1622#
	2384#													
MSMCHI	659#													
MSMCLO	659#													
MSPOP	689#	723#	731#	749#	802#	1323#	1455#	1525#	1527#	1643#	1650#	1661#	1663#	1727#
	1769#	1771#	1948#	1950#	2033#	2034#	2097#	2098#	2188#	2190#	2353#	2355#	2394#	2411#
	2437#													
MSPRIN	1297#	1301#	1354#	1355#	1360#	1434#	1435#	2252#	2253#	2254#	2275#	2296#	2297#	2298#
	2302#	2314#	2315#	2318#	2319#									
MSPUSH	677#	685#	716#	727#	740#	806#	1332#	1333#	1500#	1530#	1541#	1638#	1647#	1668#
	1732#	1738#	1775#	1798#	1954#	1970#	2038#	2048#	2102#	2135#	2193#	2203#	2358#	2383#
	2407#	2424#												
MSPUT	1297#	1301#	1354#	1355#	1360#	1396#	1420#	1434#	1435#	1480#	1522#	1596#	1607#	2252#
	2254#	2275#	2296#	2297#	2298#	2301#	2302#	2314#	2315#	2318#	2319#			

CZLNAAO LN01 TEST DNMAC X24.07-563 12-JAN-83 08:16 PAGE 21-3 J 8															SEQ 0100
CZLNAA.P11 12-JAN-83 08:16 CROSS REFERENCE TABLE -- MACRO NAMES															
MSPUT1	1297#	1301#	1354#	1355#	1360#	1396#	1420#	1434#	1435#	1480#	1522#	1596#	1607#	2252#	2253#
	2254#	2275#	2296#	2297#	2298#	2301#	2302#	2314#	2315#	2318#	2319#				
MSRADI	1368#	2255#	2277#	2299#	2303#	2316#	2320#	2409#	2410#	2425#	2426#				
MSRNRO	1317#	1374#	1412#	1423#											
MSSETS	677#	685#	716#	727#	740#	806#	1332#	1333#	1500#	1530#	1541#	1638#	1647#	1668#	1683#
	1732#	1738#	1775#	1798#	1954#	1970#	2038#	2048#	2102#	2135#	2193#	2203#	2358#	2383#	2399#
	2407#	2424#													
MS SVC	731#	1035	1040	1046	1297#	1301#	1302#	1317#	1336#	1338#	1342#	1348#	1352#	1354#	1355#
	1357#	1360#	1368#	1374#	1396#	1412#	1420#	1423#	1434#	1435#	1437#	1440#	1455#	1480#	1501#
	1502#	1518#	1522#	1524#	1525#	1561	1578	1588	1595#	1596#	1606#	1607#	1612	1622#	1632#
	1641	1661#	1716#	1727#	1761#	1769#	1875#	1948#	2009#	2033#	2083#	2097#	2177#	2188#	2205#
	2207#	2210#	2220	2230	2252#	2253#	2254#	2255#	2269	2275#	2277#	2296#	2297#	2298#	2299#
MS TLAB	2301#	2302#	2303#	2307	2314#	2315#	2316#	2318#	2319#	2320#	2324	2331#	2353#	2374#	2384#
	731#	1035#	1040#	1046#	1297#	1301#	1302#	1317#	1336#	1338#	1342#	1348#	1352#	1354#	1355#
	1357#	1360#	1368#	1374#	1396#	1412#	1420#	1423#	1434#	1435#	1437#	1440#	1455#	1480#	1501#
	1502#	1518#	1522#	1524#	1525#	1561#	1578#	1588#	1595#	1596#	1606#	1607#	1612#	1622#	1632#
	1641#	1661#	1716#	1727#	1761#	1769#	1875#	1948#	2009#	2033#	2083#	2097#	2177#	2188#	2205#
	2207#	2210#	2220#	2230#	2252#	2253#	2254#	2255#	2269#	2275#	2277#	2296#	2297#	2298#	2299#
MS STL	2301#	2302#	2303#	2307#	2314#	2315#	2316#	2318#	2319#	2320#	2324#	2331#	2353#	2374#	2384#
	731#	1035#	1040#	1046#	1297#	1301#	1302#	1317#	1336#	1338#	1342#	1348#	1352#	1354#	1355#
	1357#	1360#	1368#	1374#	1396#	1412#	1420#	1423#	1434#	1435#	1437#	1440#	1455#	1480#	1501#
	1502#	1518#	1522#	1524#	1525#	1561#	1578#	1588#	1595#	1596#	1606#	1607#	1612#	1622#	1632#
	1641#	1661#	1716#	1727#	1761#	1769#	1875#	1948#	2009#	2033#	2083#	2097#	2177#	2188#	2205#
	2207#	2210#	2220#	2230#	2252#	2253#	2254#	2255#	2269#	2275#	2277#	2296#	2297#	2298#	2299#
MS WORD	2301#	2302#	2303#	2307#	2314#	2315#	2316#	2318#	2319#	2320#	2324#	2331#	2353#	2374#	2384#
	680#	698#	1035#	1040#	1046#	1348#	1368#	1440#	1561#	1578#	1588#	1612#	1632#	1641#	1716#
	1761#	1875#	2009#	2083#	2177#	2207#	2210#	2220#	2230#	2255#	2269#	2277#	2299#	2303#	2307#
	2316#	2320#	2324#	2331#	2409#	2410#	2425#	2426#	2436						
OUTPUT	774#	1978	1983	1986	1990	1992	1995	1997	1998	2005	2259	2263	2268		
OUTPUT	754#	1281	1344	1439	1623	1628	1689	1709	1714	1742	1753	1756	1758	1801	1832
	1873	2055	2076	2081	2148	2149	2150	2151	2152	2153	2154	2155	2156	2157	2158
	2159	2160	2161	2162	2165	2166	2167	2169	2171	2175	2236	2329			
POINTE	678														
POP	661#	1098	1164	1270	1484										
PRINTF	1297	1301	1354	1355	1360	1434	1435	2252	2253	2254	2275	2296	2297	2298	2301
	2302	2314	2315	2318	2319										
PUSH	661#	1069	1181	1476	2374										
REDEF	1336	1338													
REPEAT	661#	2059	2258												
RETURN	661#														
RC JTIN	661#														
SA VR14	661#														
SELECT	661#	1030													
SETPRI	1342	1437	1501	1524	1595	1606	1622	2374	2384						
SETVEC	1396	1420	1480	1522	1596	1607									
STARS	1489	1499													
STRUCT	660#	661													
SVC	658#	659													
UNTIL	661#	2079	2265												
UNTILB	661#														
WHILE	661#	1076	1226	1316	1479	1630	1982	1989	2067						
WHILEB	661#														
XFER	1348#	1440#	1632#	1716#	1761#	1875#	2009#	2083#	2177#	2207#	2210#	2331#			
\$ADDON	1030#	1052#	1075#	1076#	1079#	1081#	1085#	1091#	1093#	1125#	1129#	1138#	1141#	1149#	1156#
	1186#	1189#	1197#	1208#	1212#	1215#	1219#	1220#	1225#	1226#	1230#	1235#	1239#	1244#	1254#
	1300#	1316#	1319#	1345#	1347#	1353#	1373#	1406#	1413#	1424#	1433#	1479#	1483#	1505#	1515#

	1517#	1521#	1557#	1566#	1567#	1569#	1574#	1584#	1598#	1600#	1630#	1631#	1691#	1692#	1694#
	1698#	1705#	1708#	1711#	1712#	1747#	1749#	1751#	1755#	1808#	1813#	1815#	1820#	1822#	1835#
	1976#	1982#	1984#	1989#	1991#	1994#	1996#	2000#	2007#	2059#	2063#	2065#	2067#	2070#	2164#
	2168#	2170#	2174#	2209#	2216#	2218#	2223#	2225#	2228#	2232#	2258#	2261#	2265#	2266#	2272#
	2292#	2300#	2304#	2309#	2311#	2317#	2321#	2327#	2385#	2390#					
\$AND	1052#	1076#	1081#	1093#	1125#	1129#	1141#	1186#	1197#	1208#	1212#	1219#	1220#	1226#	1230#
	1239#	1254#	1300#	1316#	1353#	1433#	1479#	1517#	1521#	1557#	1566#	1574#	1584#	1630#	1692#
\$BRANC	1982#	1989#	2000#	2067#	2168#	2209#	2218#	2228#	2261#	2266#	2300#	2317#	2385#	2390#	
	1030#	1032#	1037#	1042#	1052#	1075#	1076#	1079#	1081#	1085#	1091#	1093#	1125#	1129#	1138#
	1141#	1149#	1156#	1186#	1189#	1197#	1208#	1212#	1215#	1219#	1220#	1225#	1226#	1230#	1235#
	1239#	1244#	1254#	1300#	1316#	1319#	1345#	1347#	1353#	1373#	1406#	1413#	1424#	1433#	1479#
	1483#	1505#	1515#	1517#	1521#	1557#	1566#	1567#	1569#	1574#	1584#	1598#	1600#	1630#	1631#
	1691#	1692#	1694#	1698#	1705#	1708#	1711#	1712#	1747#	1749#	1751#	1755#	1808#	1813#	1815#
	1820#	1822#	1835#	1976#	1984#	1991#	1994#	1996#	2007#	2063#	2065#	2067#	2070#	2079#	2164#
	2168#	2170#	2174#	2209#	2216#	2218#	2223#	2225#	2228#	2232#	2261#	2265#	2266#	2272#	2292#
\$BRCOD	2300#	2304#	2309#	2311#	2317#	2321#	2327#	2385#	2390#						
	1075#	1081#	1345#	1373#	1505#	1567#	1598#	1691#	1698#	1708#	1747#	1749#	1808#	1813#	1820#
\$CHECK	1976#	1994#	2063#	2164#	2216#	2225#	2261#	2265#	2292#	2311#					
	1052#	1076#	1081#	1093#	1125#	1129#	1141#	1186#	1197#	1208#	1212#	1219#	1220#	1226#	1230#
	1239#	1254#	1300#	1316#	1353#	1433#	1479#	1517#	1521#	1557#	1566#	1574#	1584#	1630#	1692#
	1982#	1989#	2000#	2067#	2168#	2209#	2218#	2228#	2261#	2266#	2300#	2317#	2385#	2390#	
\$CKBAS	1030#														
\$CKIDB	1747#	1749#	1976#	1994#											
\$CKOP1	1056#	1057#	1070#	1071#	1072#	1073#	1075#	1083#	1086#	1090#	1094#	1097#	1130#	1142#	1143#
	1144#	1148#	1153#	1160#	1187#	1188#	1190#	1191#	1204#	1213#	1224#	1227#	1231#	1249#	1250#
	1251#	1252#	1253#	1255#	1262#	1295#	1296#	1298#	1315#	1343#	1345#	1364#	1365#	1366#	1373#
	1377#	1378#	1379#	1380#	1384#	1389#	1395#	1411#	1414#	1415#	1416#	1417#	1419#	1425#	1426#
	1427#	1428#	1430#	1438#	1477#	1478#	1505#	1511#	1512#	1513#	1514#	1519#	1560#	1562#	1567#
	1576#	1583#	1587#	1589#	1598#	1611#	1613#	1615#	1627#	1640#	1642#	1649#	1691#	1693#	1695#
	1697#	1698#	1699#	1702#	1706#	1707#	1708#	1713#	1747#	1748#	1749#	1750#	1752#	1757#	1802#
	1803#	1807#	1808#	1809#	1813#	1814#	1820#	1821#	1827#	1828#	1872#	1976#	1979#	1931#	1985#
	1988#	1994#	2004#	2057#	2060#	2062#	2063#	2064#	2066#	2068#	2080#	2137#	2138#	2139#	2140#
	2141#	2142#	2143#	2144#	2164#	2212#	2216#	2221#	2225#	2227#	2240#	2251#	2256#	2257#	2262#
	2267#	2273#	2276#	2279#	2284#	2285#	2287#	2288#	2289#	2292#	2294#	2295#	2306#	2311#	2313#
\$CKOP2	2323#	2326#	2328#	2374#	2386#	2391#									
	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#	1099#	1131#
	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#	1229#	1232#	1233#	1266#
	1267#	1294#	1299#	1318#	1345#	1372#	1373#	1376#	1385#	1393#	1394#	1400#	1405#	1481#	1482#
	1504#	1505#	1508#	1510#	1542#	1556#	1558#	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#
	1605#	1608#	1610#	1614#	1639#	1691#	1698#	1701#	1704#	1708#	1808#	1813#	1820#	1834#	1974#
	1977#	1999#	2061#	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#	2219#	2225#	2226#	2229#
	2245#	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#	2387#	2389#		
\$CKR6	2061#														
\$CKSEL	1030#														
\$CMND	1052#	1076#	1081#	1093#	1125#	1129#	1141#	1186#	1197#	1208#	1212#	1219#	1220#	1226#	1230#
	1239#	1254#	1300#	1316#	1353#	1433#	1479#	1517#	1521#	1557#	1566#	1574#	1584#	1630#	1692#
	1982#	1989#	2000#	2067#	2168#	2209#	2218#	2228#	2261#	2266#	2300#	2317#	2385#	2390#	
\$COMPA	1052#	1075#	1076#	1081#	1093#	1125#	1129#	1141#	1186#	1197#	1208#	1212#	1219#	1220#	1226#
	1230#	1239#	1254#	1300#	1316#	1345#	1353#	1373#	1413#	1424#	1433#	1479#	1505#	1517#	1521#
	1557#	1566#	1567#	1574#	1584#	1598#	1630#	1691#	1692#	1698#	1708#	1747#	1749#	1808#	1813#
	1820#	1976#	1982#	1989#	1994#	2000#	2063#	2067#	2164#	2168#	2209#	2216#	2218#	2225#	2228#
	2261#	2266#	2292#	2300#	2311#	2317#	2385#	2390#							
\$DECR	1075#	1345#	1567#	1598#	1994#										
\$DO	1052#	1076#	1081#	1093#	1125#	1129#	1141#	1186#	1197#	1208#	1212#	1219#	1220#	1226#	1230#
	1239#	1254#	1300#	1316#	1353#	1433#	1479#	1517#	1521#	1557#	1566#	1574#	1584#	1630#	1692#
	1982#	1989#	2000#	2067#	2168#	2209#	2218#	2228#	2261#	2266#	2300#	2317#	2385#	2390#	

\$ELSE	1085#	1138#	1149#	1156#	1189#	1215#	1225#	1244#	1694#	2170#	2272#	2304#	2321#		
\$ENDID	1091#	1347#	1406#	1515#	1569#	1600#	1705#	1711#	1712#	1751#	1755#	1815#	1822#	1835#	1996#
\$ERRMS	2007#	2065#	2174#	2223#	2232#	2309#	2327#								
	1030#	1032#	1033#	1034#	1037#	1038#	1039#	1042#	1044#	1045#	1050#	1052#	1054#	1055#	1056#
	1057#	1070#	1071#	1072#	1073#	1075#	1076#	1077#	1078#	1079#	1081#	1082#	1083#	1084#	1085#
	1086#	1087#	1089#	1090#	1091#	1093#	1094#	1095#	1097#	1099#	1125#	1129#	1130#	1131#	1135#
	1136#	1137#	1138#	1140#	1141#	1142#	1143#	1144#	1145#	1146#	1147#	1148#	1149#	1152#	1153#
	1154#	1155#	1156#	1159#	1160#	1163#	1186#	1187#	1188#	1189#	1190#	1191#	1192#	1197#	1199#
	1203#	1204#	1208#	1212#	1213#	1214#	1215#	1219#	1220#	1224#	1225#	1226#	1227#	1229#	1230#
	1231#	1232#	1233#	1234#	1235#	1236#	1237#	1238#	1239#	1244#	1249#	1250#	1251#	1252#	1253#
	1254#	1255#	1256#	1257#	1258#	1262#	1266#	1267#	1294#	1295#	1296#	1298#	1299#	1300#	1303#
	1315#	1316#	1318#	1319#	1343#	1345#	1347#	1353#	1356#	1364#	1365#	1366#	1372#	1373#	1376#
	1377#	1378#	1379#	1380#	1384#	1385#	1389#	1393#	1394#	1395#	1400#	1405#	1406#	1411#	1413#
	1414#	1415#	1416#	1417#	1419#	1421#	1424#	1425#	1426#	1427#	1428#	1430#	1431#	1433#	1436#
	1438#	1477#	1478#	1479#	1481#	1482#	1483#	1504#	1505#	1508#	1510#	1511#	1512#	1513#	1514#
	1515#	1517#	1519#	1520#	1521#	1523#	1542#	1556#	1557#	1558#	1559#	1560#	1562#	1563#	1566#
	1567#	1569#	1570#	1574#	1575#	1576#	1577#	1579#	1583#	1584#	1585#	1586#	1587#	1589#	1590#
	1597#	1598#	1600#	1605#	1608#	1610#	1611#	1613#	1614#	1615#	1627#	1630#	1631#	1639#	1640#
	1642#	1649#	1691#	1692#	1693#	1694#	1695#	1696#	1697#	1698#	1699#	1701#	1702#	1704#	1705#
	1706#	1707#	1708#	1711#	1712#	1713#	1747#	1748#	1749#	1750#	1751#	1752#	1755#	1757#	1802#
	1803#	1807#	1808#	1809#	1813#	1814#	1815#	1820#	1821#	1822#	1827#	1828#	1834#	1835#	1872#
	1974#	1976#	1977#	1979#	1981#	1982#	1984#	1985#	1988#	1989#	1991#	1994#	1996#	1999#	2000#
	2002#	2004#	2007#	2057#	2060#	2061#	2062#	2063#	2064#	2065#	2066#	2067#	2068#	2069#	2070#
	2074#	2075#	2079#	2080#	2137#	2138#	2139#	2140#	2141#	2142#	2143#	2144#	2164#	2168#	2170#
	2172#	2174#	2209#	2211#	2212#	2213#	2216#	2217#	2218#	2219#	2221#	2222#	2223#	2225#	2226#
	2227#	2228#	2229#	2231#	2232#	2240#	2245#	2251#	2256#	2257#	2260#	2261#	2262#	2264#	2265#
	2266#	2267#	2270#	2272#	2273#	2274#	2276#	2278#	2279#	2284#	2285#	2286#	2287#	2288#	2289#
	2292#	2293#	2294#	2295#	2300#	2304#	2305#	2306#	2308#	2309#	2311#	2312#	2313#	2317#	2321#
	2322#	2323#	2325#	2326#	2327#	2328#	2374#	2385#	2386#	2387#	2388#	2389#	2390#	2391#	2392#
\$GENBR	1030#	1037#	1042#	1050#	1052#	1075#	1076#	1079#	1081#	1085#	1091#	1093#	1125#	1129#	1138#
	1141#	1149#	1156#	1186#	1189#	1197#	1208#	1212#	1215#	1219#	1220#	1225#	1226#	1230#	1235#
	1239#	1244#	1254#	1300#	1316#	1319#	1345#	1347#	1353#	1373#	1406#	1413#	1424#	1433#	1479#
	1483#	1505#	1515#	1517#	1521#	1557#	1566#	1567#	1569#	1574#	1584#	1598#	1600#	1630#	1631#
	1691#	1692#	1694#	1698#	1705#	1708#	1711#	1712#	1747#	1749#	1808#	1813#	1815#	1820#	1822#
	1835#	1976#	1982#	1989#	1994#	2000#	2063#	2065#	2067#	2070#	2079#	2164#	2168#	2170#	2174#
	2209#	2216#	2218#	2223#	2225#	2228#	2232#	2261#	2265#	2266#	2272#	2292#	2300#	2304#	2309#
\$GENTA	2311#	2317#	2321#	2327#	2385#	2390#									
	1030#	1032#	1037#	1042#	1050#	1052#	1054#	1075#	1076#	1079#	1081#	1085#	1087#	1091#	1093#
	1095#	1125#	1129#	1138#	1141#	1149#	1154#	1155#	1156#	1163#	1186#	1189#	1192#	1197#	1199#
	1208#	1212#	1215#	1219#	1220#	1225#	1226#	1230#	1234#	1235#	1236#	1237#	1238#	1239#	1244#
	1254#	1256#	1257#	1258#	1300#	1303#	1316#	1319#	1345#	1347#	1353#	1356#	1373#	1406#	1421#
	1431#	1433#	1436#	1479#	1483#	1505#	1515#	1517#	1520#	1521#	1523#	1557#	1563#	1566#	1567#
	1569#	1570#	1574#	1579#	1584#	1590#	1598#	1600#	1630#	1631#	1691#	1692#	1694#	1696#	1698#
	1705#	1708#	1711#	1712#	1747#	1749#	1751#	1755#	1808#	1813#	1815#	1820#	1822#	1835#	1976#
	1982#	1984#	1989#	1991#	1994#	1996#	2000#	2002#	2007#	2059#	2063#	2065#	2067#	2070#	2164#
	2168#	2170#	2172#	2174#	2209#	2211#	2216#	2218#	2222#	2223#	2225#	2228#	2231#	2232#	2258#
	2261#	2264#	2265#	2266#	2272#	2274#	2292#	2300#	2304#	2308#	2309#	2311#	2317#	2321#	2325#
	2327#	2385#	2388#	2390#	2392#										
\$IDCHK	1075#	1345#	1373#	1505#	1567#	1598#	1691#	1698#	1708#	1747#	1749#	1808#	1813#	1820#	1976#
	1994#	2063#	2164#	2216#	2225#	2292#	2311#								
\$IDFIX	1075#	1345#	1373#	1505#	1567#	1598#	1691#	1698#	1708#	1747#	1749#	1808#	1813#	1820#	1976#
	1994#	2063#	2164#	2216#	2225#	2292#	2311#								
\$IF	1052#	1081#	1093#	1125#	1129#	1141#	1186#	1197#	1208#	1212#	1219#	1220#	1230#	1239#	1254#
	1300#	1353#	1433#	1517#	1521#	1557#	1566#	1574#	1584#	1692#	2000#	2168#	2209#	2218#	2228#
	2261#	2266#	2300#	2317#	2385#	2390#									
\$IFBRJ	1079#	1091#	1235#	1319#	1347#	1406#	1483#	1515#	1569#	1600#	1631#	1705#	1711#	1712#	1751#

CZLNAAO LN01 TEST DNMAC X24.07-563 12-JAN-83 08:16 PAGE 21-6
 CZLNAA.P11 12-JAN-83 08:16 CROSS REFERENCE TABLE -- MACRO NAMES

SEQ 0103

\$IFCOD	1755#	1815#	1822#	1835#	1984#	1991#	1996#	2007#	2065#	2070#	2174#	2223#	2232#	2309#	2327#
	1030#	1052#	1076#	1081#	1093#	1125#	1129#	1141#	1186#	1197#	1208#	1212#	1219#	1220#	1226#
	1230#	1239#	1254#	1300#	1316#	1353#	1433#	1479#	1517#	1521#	1557#	1566#	1574#	1584#	1630#
	1692#	1982#	1989#	2000#	2067#	2079#	2168#	2209#	2218#	2228#	2261#	2265#	2266#	2300#	2317#
	2385#	2370#													
\$IFCON	1413#	1424#													
\$IFDEF	1030#	1052#	1076#	1081#	1093#	1125#	1129#	1141#	1186#	1197#	1208#	1212#	1219#	1220#	1226#
	1230#	1239#	1254#	1300#	1316#	1353#	1413	1424	1433#	1479#	1517#	1521#	1557#	1566#	1574#
	1584#	1630#	1692#	1982#	1989#	2000#	2067#	2079#	2168#	2209#	2218#	2228#	2261#	2265#	2266#
	2300#	2317#	2385#	2390#											
\$IFOPR	1030#	1052#	1076#	1081#	1093#	1125#	1129#	1141#	1186#	1197#	1208#	1212#	1219#	1220#	1226#
	1230#	1239#	1254#	1300#	1316#	1353#	1413#	1424#	1433#	1479#	1517#	1521#	1557#	1566#	1574#
	1584#	1630#	1692#	1982#	1989#	2000#	2067#	2079#	2168#	2209#	2218#	2228#	2261#	2265#	2266#
	2300#	2317#	2385#	2390#											
\$INCR	1373#	1505#	1691#	1698#	1708#	1747#	1749#	1808#	1813#	1820#	1976#	2063#	2164#	2216#	2225#
	2292#	2311#													
\$INHRJ	1030#	1052#	1076#	1081#	1093#	1125#	1129#	1141#	1186#	1197#	1208#	1212#	1219#	1220#	1226#
	1230#	1239#	1254#	1300#	1316#	1353#	1413#	1424#	1433#	1479#	1517#	1521#	1557#	1566#	1574#
	1584#	1630#	1692#	1982#	1989#	2000#	2067#	2079#	2168#	2209#	2218#	2228#	2261#	2265#	2266#
	2300#	2317#	2385#	2390#											
\$JLPCN	1075#	1345#	1373#	1505#	1567#	1598#	1691#	1698#	1708#	1747#	1749#	1808#	1813#	1820#	1976#
	1994#	2063#	2164#	2216#	2225#	2292#	2311#								
\$JUMP	1747#	1749#	1976#	1994#											
\$LET	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1056#	1057#	1070#	1071#	1072#	1073#	1077#	1078#
	1082#	1083#	1084#	1086#	1089#	1090#	1094#	1097#	1099#	1130#	1131#	1135#	1136#	1137#	1140#
	1142#	1143#	1144#	1145#	1146#	1147#	1148#	1152#	1153#	1159#	1160#	1187#	1188#	1190#	1191#
	1203#	1204#	1213#	1214#	1224#	1227#	1229#	1231#	1232#	1233#	1249#	1250#	1251#	1252#	1253#
	1255#	1262#	1266#	1267#	1294#	1295#	1296#	1298#	1299#	1315#	1318#	1343#	1364#	1365#	1366#
	1372#	1376#	1377#	1378#	1379#	1380#	1384#	1385#	1389#	1393#	1394#	1395#	1400#	1405#	1411#
	1414#	1415#	1416#	1417#	1419#	1425#	1426#	1427#	1428#	1430#	1438#	1477#	1478#	1481#	1482#
	1504#	1508#	1510#	1511#	1512#	1513#	1514#	1519#	1542#	1556#	1558#	1559#	1560#	1562#	1575#
	1576#	1577#	1583#	1585#	1586#	1587#	1589#	1597#	1605#	1608#	1610#	1611#	1613#	1614#	1615#
	1627#	1639#	1640#	1642#	1649#	1693#	1695#	1697#	1699#	1701#	1702#	1704#	1706#	1707#	1713#
	1748#	1750#	1752#	1757#	1802#	1803#	1807#	1809#	1814#	1821#	1827#	1828#	1834#	1872#	1974#
	1977#	1979#	1981#	1985#	1988#	1999#	2004#	2057#	2060#	2061#	2062#	2064#	2066#	2068#	2069#
	2074#	2075#	2080#	2137#	2138#	2139#	2140#	2141#	2142#	2143#	2144#	2212#	2213#	2217#	2219#
	2221#	2226#	2227#	2229#	2240#	2245#	2251#	2256#	2257#	2260#	2262#	2267#	2270#	2273#	2276#
	2278#	2279#	2284#	2285#	2286#	2287#	2288#	2289#	2293#	2294#	2295#	2305#	2306#	2312#	2313#
	2322#	2323#	2326#	2328#	2374#	2386#	2387#	2389#	2391#						
\$LPCNT	1075#	1345#	1373#	1505#	1567#	1598#	1691#	1698#	1708#	1747#	1749#	1808#	1813#	1820#	1976#
	1994#	2063#	2164#	2216#	2225#	2292#	2311#								
\$MCHIG	661#														
\$MCLOW	661#														
\$OPADD	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#	1099#	1131#
	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#	1229#	1232#	1233#	1266#
	1267#	1294#	1299#	1315#	1345#	1372#	1373#	1376#	1385#	1393#	1394#	1400#	1405#	1481#	1482#
	1504#	1505#	1508#	1510#	1542#	1556#	1558#	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#
	1605#	1608#	1610#	1614#	1639#	1691#	1698#	1701#	1704#	1708#	1747#	1749#	1808#	1813#	1820#
	1834#	1974#	1976#	1977#	1994#	1999#	2061#	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#
	2219#	2225#	2226#	2229#	2245#	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#
	2387#	2387#													
\$OPAND	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#	1099#	1131#
	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#	1229#	1232#	1233#	1266#
	1267#	1294#	1299#	1318#	1345#	1372#	1373#	1376#	1385#	1393#	1394#	1400#	1405#	1481#	1482#
	1504#	1505#	1508#	1510#	1542#	1556#	1558#	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#
	1605#	1608#	1610#	1614#	1639#	1691#	1698#	1701#	1704#	1708#	1747#	1749#	1808#	1813#	1820#

CZLNAAO LN01 TEST DNMAC X24.07-563 12-JAN-83 08:16 PAGE 21-7
 CZLNAA.P11 12-JAN-83 08:16 CROSS REFERENCE TABLE -- MACRO NAMES

SEQ 0104

	1834#	1974#	1976#	1977#	1994#	1999#	2061#	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#
	2219#	2225#	2226#	2229#	2245#	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#
	2387#	2389#													
\$OPCD2	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#	1099#	1131#
	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#	1229#	1232#	1233#	1266#
	1267#	1294#	1299#	1318#	1345#	1372#	1373#	1376#	1385#	1393#	1394#	1400#	1405#	1481#	1482#
	1504#	1505#	1508#	1510#	1542#	1556#	1558#	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#
	1605#	1608#	1610#	1614#	1639#	1691#	1698#	1701#	1704#	1708#	1747#	1749#	1808#	1813#	1820#
	1834#	1974#	1976#	1977#	1994#	1999#	2061#	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#
	2219#	2225#	2226#	2229#	2245#	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#
	2387#	2389#													
\$OPDEF	1030#	1033#	1034#	1037#	1038#	1039#	1042#	1044#	1045#	1050#	1052#	1055#	1056#	1057#	1069#
	1070#	1071#	1072#	1073#	1075#	1076#	1077#	1078#	1079#	1081#	1082#	1083#	1084#	1085#	1086#
	1089#	1090#	1091#	1093#	1094#	1097#	1098#	1099#	1125#	1129#	1130#	1131#	1135#	1136#	1137#
	1138#	1140#	1141#	1142#	1143#	1144#	1145#	1146#	1147#	1148#	1149#	1152#	1153#	1156#	1159#
	1160#	1164#	1181#	1186#	1187#	1188#	1189#	1190#	1191#	1197#	1198#	1203#	1204#	1208#	1212#
	1213#	1214#	1215#	1219#	1220#	1224#	1225#	1226#	1227#	1229#	1230#	1231#	1232#	1233#	1235#
	1239#	1244#	1249#	1250#	1251#	1252#	1253#	1254#	1255#	1262#	1266#	1267#	1270#	1294#	1295#
	1296#	1298#	1299#	1300#	1315#	1316#	1318#	1319#	1343#	1345#	1347#	1353#	1364#	1365#	1366#
	1372#	1373#	1376#	1377#	1378#	1379#	1380#	1384#	1385#	1389#	1393#	1394#	1395#	1400#	1405#
	1406#	1411#	1413#	1414#	1415#	1416#	1417#	1419#	1424#	1425#	1426#	1427#	1428#	1430#	1433#
	1438#	1476#	1477#	1478#	1479#	1481#	1482#	1483#	1484#	1504#	1505#	1508#	1510#	1511#	1512#
	1513#	1514#	1515#	1517#	1519#	1521#	1542#	1556#	1557#	1558#	1559#	1560#	1562#	1566#	1567#
	1569#	1574#	1575#	1576#	1577#	1583#	1584#	1585#	1586#	1587#	1589#	1597#	1598#	1600#	1605#
	1608#	1610#	1611#	1613#	1614#	1615#	1627#	1630#	1631#	1639#	1640#	1642#	1649#	1691#	1692#
	1693#	1694#	1695#	1697#	1698#	1699#	1701#	1702#	1704#	1705#	1706#	1707#	1708#	1711#	1712#
	1713#	1747#	1748#	1749#	1750#	1751#	1752#	1755#	1757#	1802#	1803#	1807#	1808#	1809#	1813#
	1814#	1815#	1820#	1821#	1822#	1827#	1828#	1834#	1835#	1872#	1974#	1976#	1977#	1979#	1981#
	1982#	1984#	1985#	1988#	1989#	1991#	1994#	1996#	1999#	2000#	2004#	2007#	2057#	2060#	2061#
	2062#	2063#	2064#	2065#	2066#	2067#	2068#	2069#	2070#	2074#	2075#	2079#	2080#	2137#	2138#
	2139#	2140#	2141#	2142#	2143#	2144#	2164#	2168#	2170#	2174#	2209#	2212#	2213#	2216#	2217#
	2218#	2219#	2221#	2223#	2225#	2226#	2227#	2228#	2229#	2232#	2240#	2245#	2251#	2256#	2257#
	2260#	2261#	2262#	2265#	2266#	2267#	2270#	2271#	2272#	2273#	2276#	2278#	2279#	2284#	2285#
	2286#	2287#	2288#	2289#	2292#	2293#	2294#	2295#	2300#	2304#	2305#	2306#	2309#	2311#	2312#
	2313#	2317#	2321#	2322#	2323#	2326#	2327#	2328#	2374#	2385#	2386#	2387#	2389#	2390#	2391#
\$OPEQU	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#	1099#	1131#
	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#	1229#	1232#	1233#	1266#
	1267#	1294#	1299#	1318#	1345#	1372#	1373#	1376#	1385#	1393#	1394#	1400#	1405#	1481#	1482#
	1504#	1505#	1508#	1510#	1542#	1556#	1558#	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#
	1605#	1608#	1610#	1614#	1639#	1691#	1698#	1701#	1704#	1708#	1747#	1749#	1808#	1813#	1820#
	1834#	1974#	1976#	1977#	1994#	1999#	2061#	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#
	2219#	2225#	2226#	2229#	2245#	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#
	2387#	2389#													
\$OPEXO	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#	1099#	1131#
	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#	1229#	1232#	1233#	1266#
	1267#	1294#	1299#	1318#	1345#	1372#	1373#	1376#	1385#	1393#	1394#	1400#	1405#	1481#	1482#
	1504#	1505#	1508#	1510#	1542#	1556#	1558#	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#
	1605#	1608#	1610#	1614#	1639#	1691#	1698#	1701#	1704#	1708#	1808#	1813#	1820#	1834#	1974#
	1977#	1999#	2061#	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#	2219#	2225#	2226#	2229#
	2245#	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#	2387#	2389#		
\$OPIDB	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#	1099#	1131#
	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#	1229#	1232#	1233#	1266#
	1267#	1294#	1299#	1318#	1345#	1372#	1373#	1376#	1385#	1393#	1394#	1400#	1405#	1481#	1482#
	1504#	1505#	1508#	1510#	1542#	1556#	1558#	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#
	1605#	1608#	1610#	1614#	1639#	1691#	1698#	1701#	1704#	1708#	1747#	1749#	1808#	1813#	1820#
	1834#	1974#	1976#	1977#	1994#	1999#	2061#	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#

	2219#	2225#	2226#	2229#	2245#	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#
\$OPNAN	2387#	2389#													
	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#	1099#	1131#
	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#	1229#	1232#	1233#	1266#
	1267#	1294#	1299#	1318#	1345#	1372#	1373#	1376#	1385#	1393#	1394#	1400#	1405#	1481#	1482#
	1504#	1505#	1508#	1510#	1542#	1556#	1558#	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#
	1605#	1608#	1610#	1614#	1639#	1691#	1698#	1701#	1704#	1708#	1747#	1749#	1808#	1813#	1820#
	1834#	1974#	1976#	1977#	1994#	1999#	2061#	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#
	2219#	2225#	2226#	2229#	2245#	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#
\$OPNOR	2387#	2389#													
	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#	1099#	1131#
	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#	1229#	1232#	1233#	1266#
	1267#	1294#	1299#	1318#	1345#	1372#	1373#	1376#	1385#	1393#	1394#	1400#	1405#	1481#	1482#
	1504#	1505#	1508#	1510#	1542#	1556#	1558#	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#
	1605#	1608#	1610#	1614#	1639#	1691#	1698#	1701#	1704#	1708#	1747#	1749#	1808#	1813#	1820#
	1834#	1974#	1976#	1977#	1994#	1999#	2061#	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#
	2219#	2225#	2226#	2229#	2245#	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#
\$OPNOT	2387#	2389#													
	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#	1099#	1131#
	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#	1229#	1232#	1233#	1266#
	1267#	1294#	1299#	1318#	1345#	1372#	1373#	1376#	1385#	1393#	1394#	1400#	1405#	1481#	1482#
	1504#	1505#	1508#	1510#	1542#	1556#	1558#	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#
	1605#	1608#	1610#	1614#	1639#	1691#	1698#	1701#	1704#	1708#	1747#	1749#	1808#	1813#	1820#
	1834#	1974#	1976#	1977#	1994#	1999#	2061#	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#
	2219#	2225#	2226#	2229#	2245#	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#
\$OPOR	2387#	2389#													
	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#	1099#	1131#
	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#	1229#	1232#	1233#	1266#
	1267#	1294#	1299#	1318#	1345#	1372#	1373#	1376#	1385#	1393#	1394#	1400#	1405#	1481#	1482#
	1504#	1505#	1508#	1510#	1542#	1556#	1558#	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#
	1605#	1608#	1610#	1614#	1639#	1691#	1698#	1701#	1704#	1708#	1747#	1749#	1808#	1813#	1820#
	1834#	1974#	1976#	1977#	1994#	1999#	2061#	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#
	2219#	2225#	2226#	2229#	2245#	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#
\$OPRID	2387#	2389#													
	1747#	1749#	1976#	1994#											
\$OPROT	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#	1099#	1131#
	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#	1229#	1232#	1233#	1266#
	1267#	1294#	1299#	1318#	1345#	1372#	1373#	1376#	1385#	1393#	1394#	1400#	1405#	1481#	1482#
	1504#	1505#	1508#	1510#	1542#	1556#	1558#	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#
	1605#	1608#	1610#	1614#	1639#	1691#	1698#	1701#	1704#	1708#	1747#	1749#	1808#	1813#	1820#
	1834#	1974#	1976#	1977#	1994#	1999#	2061#	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#
	2219#	2225#	2226#	2229#	2245#	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#
	2387#	2389#													
\$OPRO	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1056#	1057#	1070#	1071#	1072#	1073#	1075#	1077#
	1078#	1082#	1083#	1084#	1086#	1089#	1090#	1094#	1097#	1099#	1130#	1131#	1135#	1136#	1137#
	1140#	1142#	1143#	1144#	1145#	1146#	1147#	1148#	1152#	1153#	1159#	1160#	1187#	1188#	1190#
	1191#	1203#	1204#	1213#	1214#	1224#	1227#	1229#	1231#	1232#	1233#	1249#	1250#	1251#	1252#
	1253#	1255#	1262#	1266#	1267#	1294#	1295#	1296#	1298#	1299#	1315#	1318#	1343#	1345#	1364#
	1365#	1366#	1372#	1373#	1376#	1377#	1378#	1379#	1380#	1384#	1385#	1389#	1393#	1394#	1395#
	1400#	1405#	1411#	1414#	1415#	1416#	1417#	1419#	1425#	1426#	1427#	1428#	1430#	1438#	1477#
	1478#	1481#	1482#	1504#	1505#	1508#	1510#	1511#	1512#	1513#	1514#	1519#	1542#	1556#	1558#
	1559#	1560#	1562#	1567#	1575#	1576#	1577#	1583#	1585#	1586#	1587#	1589#	1597#	1598#	1605#
	1608#	1610#	1611#	1613#	1614#	1615#	1627#	1639#	1640#	1642#	1649#	1691#	1693#	1695#	1697#
	1698#	1699#	1701#	1702#	1704#	1706#	1707#	1708#	1713#	1747#	1748#	1749#	1750#	1752#	1757#
	1802#	1803#	1807#	1808#	1809#	1813#	1814#	1820#	1821#	1827#	1828#	1834#	1872#	1974#	1976#
	1977#	1979#	1981#	1985#	1988#	1994#	1999#	2004#	2057#	2060#	2061#	2062#	2063#	2064#	2066#

	2068#	2069#	2074#	2075#	2080#	2137#	2138#	2139#	2140#	2141#	2142#	2143#	2144#	2164#	2212#
	2213#	2216#	2217#	2219#	2221#	2225#	2226#	2227#	2229#	2240#	2245#	2251#	2256#	2257#	2260#
	2262#	2267#	2270#	2273#	2276#	2278#	2279#	2284#	2285#	2286#	2287#	2288#	2289#	2292#	2293#
	2294#	2295#	2305#	2306#	2311#	2312#	2313#	2322#	2323#	2326#	2328#	2374#	2386#	2387#	2389#
	2391#														
\$OPR1	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1056#	1057#	1070#	1071#	1072#	1073#	1077#	1078#
	1082#	1083#	1084#	1086#	1089#	1090#	1094#	1097#	1099#	1130#	1131#	1135#	1136#	1137#	1140#
	1142#	1143#	1144#	1145#	1146#	1147#	1148#	1152#	1153#	1159#	1160#	1187#	1188#	1190#	1191#
	1203#	1204#	1213#	1214#	1224#	1227#	1229#	1231#	1232#	1233#	1249#	1250#	1251#	1252#	1253#
	1255#	1262#	1266#	1267#	1294#	1295#	1296#	1298#	1299#	1315#	1318#	1343#	1364#	1365#	1366#
	1372#	1376#	1377#	1378#	1379#	1380#	1384#	1385#	1389#	1393#	1394#	1395#	1400#	1405#	1411#
	1414#	1415#	1416#	1417#	1419#	1425#	1426#	1427#	1428#	1430#	1438#	1477#	1478#	1481#	1482#
	1504#	1508#	1510#	1511#	1512#	1513#	1514#	1519#	1542#	1556#	1558#	1559#	1560#	1562#	1575#
	1576#	1577#	1583#	1585#	1586#	1587#	1589#	1597#	1605#	1608#	1610#	1611#	1613#	1614#	1615#
	1627#	1639#	1640#	1642#	1649#	1693#	1695#	1697#	1699#	1701#	1702#	1704#	1706#	1707#	1713#
	1748#	1750#	1752#	1757#	1802#	1803#	1807#	1809#	181#	1821#	1827#	1828#	1834#	1872#	1974#
	1977#	1979#	1981#	1985#	1988#	1999#	2004#	2057#	2060#	2061#	2062#	2064#	2066#	2068#	2069#
	2074#	2075#	2080#	2137#	2138#	2139#	2140#	2141#	2142#	2143#	2144#	2212#	2213#	2217#	2219#
	2221#	2226#	2227#	2229#	2240#	2245#	2251#	2256#	2257#	2260#	2262#	2267#	2270#	2273#	2276#
	2278#	2279#	2284#	2285#	2286#	2287#	2288#	2289#	2293#	2294#	2295#	2305#	2306#	2312#	2313#
	2322#	2323#	2326#	2328#	2374#	2386#	2387#	2389#	2391#						
\$OPR2	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1056#	1057#	1070#	1071#	1072#	1073#	1075#	1077#
	1078#	1082#	1083#	1084#	1086#	1089#	1090#	1094#	1097#	1099#	1130#	1131#	1135#	1136#	1137#
	1140#	1142#	1143#	1144#	1145#	1146#	1147#	1148#	1152#	1153#	1159#	1160#	1187#	1188#	1190#
	1191#	1203#	1204#	1213#	1214#	1224#	1227#	1229#	1231#	1232#	1233#	1249#	1250#	1251#	1252#
	1253#	1255#	1262#	1266#	1267#	1294#	1295#	1296#	1298#	1299#	1315#	1318#	1343#	1345#	1364#
	1365#	1366#	1372#	1373#	1376#	1377#	1378#	1379#	1380#	1384#	1385#	1389#	1393#	1394#	1395#
	1400#	1405#	1411#	1414#	1415#	1416#	1417#	1419#	1425#	1426#	1427#	1428#	1430#	1438#	1477#
	1478#	1481#	1482#	1504#	1505#	1508#	1510#	1511#	1512#	1513#	1514#	1519#	1542#	1556#	1558#
	1559#	1560#	1562#	1567#	1575#	1576#	1577#	1583#	1585#	1586#	1587#	1589#	1597#	1598#	1605#
	1608#	1610#	1611#	1613#	1614#	1615#	1627#	1639#	1640#	1642#	1649#	1691#	1693#	1695#	1697#
	1698#	1699#	1701#	1702#	1704#	1706#	1707#	1708#	1713#	1748#	1750#	1752#	1757#	1802#	1803#
	1807#	1808#	1809#	1813#	1814#	1820#	1821#	1827#	1828#	1834#	1872#	1974#	1977#	1979#	1981#
	1985#	1988#	1999#	2004#	2057#	2060#	2061#	2062#	2063#	2064#	2066#	2068#	2069#	2074#	2075#
	2080#	2137#	2138#	2139#	2140#	2141#	2142#	2143#	2144#	2164#	2212#	2213#	2216#	2217#	2219#
	2221#	2225#	2226#	2227#	2229#	2240#	2245#	2251#	2256#	2257#	2260#	2262#	2267#	2270#	2273#
	2276#	2278#	2279#	2284#	2285#	2286#	2287#	2288#	2289#	2292#	2293#	2294#	2295#	2305#	2306#
	2311#	2312#	2313#	2322#	2323#	2326#	2328#	2374#	2386#	2387#	2389#	2391#			
\$OPR2A	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#	1099#	1131#
	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#	1229#	1232#	1233#	1266#
	1267#	1294#	1299#	1318#	1345#	1372#	1373#	1376#	1385#	1393#	1394#	1400#	1405#	1481#	1482#
	1504#	1505#	1508#	1510#	1542#	1556#	1558#	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#
	1605#	1608#	1610#	1614#	1639#	1691#	1698#	1701#	1704#	1708#	1808#	1813#	1820#	1834#	1974#
	1977#	1999#	2061#	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#	2219#	2225#	2226#	2229#
	2245#	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#	2387#	2389#		
\$OPR2B	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#	1099#	1131#
	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#	1229#	1232#	1233#	1266#
	1267#	1294#	1299#	1318#	1345#	1372#	1373#	1376#	1385#	1393#	1394#	1400#	1405#	1481#	1482#
	1504#	1505#	1508#	1510#	1542#	1556#	1558#	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#
	1605#	1608#	1610#	1614#	1639#	1691#	1698#	1701#	1704#	1708#	1808#	1813#	1820#	1834#	1974#
	1977#	1999#	2061#	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#	2219#	2225#	2226#	2229#
	2245#	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#	2387#	2389#		
\$OPSHF	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#	1099#	1131#
	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#	1229#	1232#	1233#	1266#
	1267#	1294#	1299#	1318#	1345#	1372#	1373#	1376#	1385#	1393#	1394#	1400#	1405#	1481#	1482#
	1504#	1505#	1508#	1510#	1542#	1556#	1558#	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#

	1605#	1608#	1610#	1614#	1639#	1691#	1698#	1701#	1704#	1708#	1747#	1749#	1808#	1813#	1820#
	1834#	1974#	1976#	1977#	1994#	1999#	2061#	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#
	2219#	2225#	2226#	2229#	2245#	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#
	2387#	2389#													
\$OPSRE	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#	1099#	1131#
	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#	1229#	1232#	1233#	1266#
	1267#	1294#	1299#	1318#	1345#	1372#	1373#	1376#	1385#	1393#	1394#	1400#	1405#	1481#	1482#
	1504#	1505#	1508#	1510#	1542#	1556#	1558#	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#
	1605#	1608#	1610#	1614#	1639#	1691#	1698#	1701#	1704#	1708#	1808#	1813#	1820#	1834#	1974#
	1977#	1999#	2061#	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#	2219#	2225#	2226#	2229#
\$OPSUB	2245#	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#	2387#	2389#		
	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#	1099#	1131#
	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#	1229#	1232#	1233#	1266#
	1267#	1294#	1299#	1318#	1345#	1372#	1373#	1376#	1385#	1393#	1394#	1400#	1405#	1481#	1482#
	1504#	1505#	1508#	1510#	1542#	1556#	1558#	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#
	1605#	1608#	1610#	1614#	1639#	1691#	1698#	1701#	1704#	1708#	1747#	1749#	1808#	1813#	1820#
	1834#	1974#	1976#	1977#	1994#	1999#	2061#	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#
	2219#	2225#	2226#	2229#	2245#	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#
	2387#	2389#													
\$OPXOR	1033#	1034#	1038#	1039#	1044#	1045#	1055#	1075#	1077#	1078#	1082#	1084#	1089#	1099#	1131#
	1135#	1136#	1137#	1140#	1145#	1146#	1147#	1152#	1159#	1203#	1214#	1229#	1232#	1233#	1266#
	1267#	1294#	1299#	1318#	1345#	1372#	1373#	1376#	1385#	1393#	1394#	1400#	1405#	1481#	1482#
	1504#	1505#	1508#	1510#	1542#	1556#	1558#	1559#	1567#	1575#	1577#	1585#	1586#	1597#	1598#
	1605#	1608#	1610#	1614#	1639#	1691#	1698#	1701#	1704#	1708#	1747#	1749#	1808#	1813#	1820#
	1834#	1974#	1976#	1977#	1994#	1999#	2061#	2063#	2069#	2074#	2075#	2164#	2213#	2216#	2217#
	2219#	2225#	2226#	2229#	2245#	2260#	2270#	2278#	2286#	2292#	2293#	2305#	2311#	2312#	2322#
	2387#	2389#													
\$OR	1052#	1076#	1081#	1093#	1125#	1129#	1141#	1186#	1197#	1208#	1212#	1219#	1220#	1226#	1230#
	1239#	1254#	1300#	1316#	1353#	1433#	1479#	1517#	1521#	1557#	1566#	1574#	1584#	1630#	1692#
	1982#	1989#	2000#	2067#	2168#	2209#	2218#	2228#	2261#	2266#	2300#	2317#	2385#	2390#	
\$RANGE	1030#	1052#	1076#	1081#	1093#	1125#	1129#	1141#	1186#	1197#	1208#	1212#	1219#	1220#	1226#
	1230#	1239#	1254#	1300#	1316#	1353#	1413#	1424#	1433#	1479#	1517#	1521#	1557#	1566#	1574#
	1584#	1630#	1692#	1982#	1989#	2000#	2067#	2079#	2168#	2209#	2218#	2228#	2261#	2265#	2266#
	2300#	2317#	2385#	2390#											
\$SUBON	1050#	1054#	1075#	1079#	1085#	1087#	1091#	1095#	1138#	1149#	1154#	1155#	1156#	1163#	1189#
	1192#	1199#	1215#	1225#	1234#	1235#	1236#	1237#	1238#	1244#	1256#	1257#	1258#	1303#	1319#
	1345#	1347#	1356#	1373#	1406#	1421#	1431#	1436#	1483#	1505#	1515#	1520#	1523#	1563#	1567#
	1569#	1570#	1579#	1590#	1598#	1600#	1631#	1691#	1694#	1696#	1698#	1705#	1708#	1711#	1712#
	1751#	1755#	1808#	1813#	1815#	1820#	1822#	1835#	1984#	1991#	1996#	2002#	2007#	2063#	2065#
	2070#	2079#	2164#	2170#	2172#	2174#	2211#	2216#	2222#	2223#	2225#	2231#	2232#	2264#	2265#
	2272#	2274#	2292#	2304#	2308#	2309#	2311#	2321#	2325#	2327#	2388#	2392#			
\$THEN	1052#	1076#	1081#	1093#	1125#	1129#	1141#	1186#	1197#	1208#	1212#	1219#	1220#	1226#	1230#
	1239#	1254#	1300#	1316#	1353#	1433#	1479#	1517#	1521#	1557#	1566#	1574#	1584#	1630#	1692#
	1982#	1989#	2000#	2067#	2168#	2209#	2218#	2228#	2261#	2266#	2300#	2317#	2385#	2390#	
\$UNTIL2	2079#	2265#													
\$UNTIL3	2079#	2265#													
\$WHILE	1076#	1226#	1316#	1479#	1630#	1982#	1989#	2067#							
\$BASE	1030#														
\$ENDS	1050#														
\$GEN	1030#	1032#	1037#	1042#	1050#	1054#	1075#	1076#	1079#	1081#	1085#	1087#	1091#	1095#	1138#
	1149#	1154#	1155#	1156#	1163#	1189#	1192#	1199#	1215#	1225#	1226#	1234#	1235#	1236#	1237#
	1238#	1244#	1256#	1257#	1258#	1303#	1316#	1319#	1345#	1347#	1356#	1373#	1406#	1421#	1431#
	1436#	1479#	1483#	1505#	1515#	1520#	1523#	1563#	1567#	1569#	1570#	1579#	1590#	1598#	1600#
	1630#	1631#	1691#	1694#	1696#	1698#	1705#	1708#	1711#	1712#	1747#	1749#	1751#	1755#	1808#
	1813#	1815#	1820#	1822#	1835#	1976#	1982#	1984#	1989#	1991#	1994#	1996#	2002#	2007#	2059#
	2063#	2065#	2067#	2070#	2164#	2170#	2172#	2174#	2211#	2216#	2222#	2223#	2225#	2231#	2232#

	2258#	2261#	2264#	2265#	2272#	2274#	2292#	2304#	2308#	2309#	2311#	2321#	2325#	2327#	2380#
	2392#														
\$\$GETS	1032#	1037#	1042#	1050#	1054#	1075#	1079#	1085#	1087#	1091#	1095#	1138#	1149#	1154#	1155#
	1156#	1163#	1189#	1192#	1199#	1215#	1225#	1234#	1235#	1236#	1237#	1238#	1244#	1256#	1257#
	1258#	1303#	1319#	1345#	1347#	1356#	1373#	1406#	1421#	1431#	1436#	1483#	1505#	1515#	1520#
	1523#	1563#	1567#	1569#	1570#	1579#	1590#	1598#	1600#	1631#	1691#	1694#	1696#	1698#	1705#
	1708#	1711#	1712#	1751#	1755#	1808#	1813#	1815#	1820#	1822#	1835#	1984#	1991#	1996#	2002#
	2007#	2063#	2065#	2070#	2079#	2164#	2170#	2172#	2174#	2211#	2216#	2222#	2223#	2225#	2231#
	2232#	2264#	2265#	2272#	2274#	2292#	2304#	2308#	2309#	2311#	2321#	2325#	2327#	2388#	2392#
\$\$GETT	1032#	1037#	1042#	1050#	1085#	1138#	1149#	116#	1189#	1215#	1225#	1244#	1694#	2170#	2272#
	2304#	2321#													
\$\$JLPC	1747#	1749#	1976#	1994#											
\$\$LPCN	1075#	1345#	1373#	1505#	1567#	1598#	1691#	1698#	1708#	1808#	1813#	1820#	2063#	2164#	2216#
	2225#	2292#	2311#												
\$\$POP	1050#	1054#	1075#	1079#	1085#	1087#	1091#	1095#	1138#	1149#	1154#	1155#	1156#	1163#	1189#
	1192#	1199#	1215#	1225#	1234#	1235#	1236#	1237#	1238#	1244#	1256#	1257#	1258#	1303#	1319#
	1345#	1347#	1356#	1373#	1406#	1421#	1431#	1436#	1483#	1505#	1515#	1520#	1523#	1563#	1567#
	1569#	1570#	1579#	1590#	1598#	1600#	1631#	1691#	1694#	1696#	1698#	1705#	1708#	1711#	1712#
	1751#	1755#	1808#	1813#	1815#	1820#	1822#	1835#	1984#	1991#	1996#	2002#	2007#	2063#	2065#
	2070#	2079#	2164#	2170#	2172#	2174#	2211#	2216#	2222#	2223#	2225#	2231#	2232#	2264#	2265#
	2272#	2274#	2292#	2304#	2308#	2309#	2311#	2321#	2325#	2327#	2388#	2392#			
\$\$PUSH	1030#	1052#	1075#	1076#	1079#	1081#	1085#	1093#	1125#	1129#	1138#	1141#	1149#	1156#	1186#
	1189#	1197#	1208#	1212#	1215#	1219#	1220#	1225#	1226#	1230#	1235#	1239#	1244#	1254#	1300#
	1316#	1319#	1345#	1353#	1373#	1413#	1424#	1433#	1479#	1483#	1505#	1517#	1521#	1557#	1566#
	1567#	1574#	1584#	1598#	1630#	1631#	1691#	1692#	1694#	1698#	1708#	1747#	1749#	1751#	1755#
	1808#	1813#	1820#	1976#	1982#	1984#	1989#	1991#	1994#	1996#	2000#	2007#	2059#	2063#	2067#
	2070#	2164#	2168#	2170#	2209#	2216#	2218#	2225#	2228#	2258#	2261#	2266#	2272#	2292#	2300#
	2304#	2311#	2317#	2321#	2385#	2390#									
\$\$SELE	1030#														
\$\$SETS	1030#	1032#	1037#	1042#	1050#	1052#	1075#	1076#	1079#	1081#	1085#	1093#	1125#	1129#	1138#
	1141#	1149#	1156#	1186#	1189#	1197#	1208#	1212#	1215#	1219#	1220#	1225#	1226#	1230#	1235#
	1239#	1244#	1254#	1300#	1316#	1319#	1315#	1353#	1373#	1413#	1424#	1433#	1479#	1483#	1505#
	1517#	1521#	1557#	1566#	1567#	1574#	1584#	1598#	1630#	1631#	1691#	1692#	1694#	1698#	1708#
	1747#	1749#	1751#	1755#	1808#	1813#	1820#	1976#	1982#	1984#	1989#	1991#	1994#	1996#	2000#
	2007#	2059#	2063#	2067#	2070#	2164#	2168#	2170#	2209#	2216#	2218#	2225#	2228#	2258#	2261#
	2266#	2272#	2292#	2300#	2304#	2311#	2317#	2321#	2385#	2390#					
\$\$SETT	1030#	1032#	1037#	1042#	1050#										

. ABS. 022370 000 CON RO REL GBL D

ERRORS DETECTED: 0

CZLNAA,CZLNAA,SEQ/CRF/DOC=SPMACJ/ML,SVC33/ML,CZLNAA.P11
 RUN-TIME: 73 70 6 SECONDS
 RUN-TIME RATIO: 176/149=1.1
 CORE USED: 30K (59 PAGES)

DOCUMENT PAGES: 108