

LPA/AR11

DIAGNOSTIC TEST I
MD-11-DRLPC-A

EP-DRLPC-A-DL

COPYRIGHT © 1978

FICHE 1 OF 1

MAR 1978

digital

MADE IN USA

This microfiche card contains a grid of frames, each displaying diagnostic test data for the MD-11-DRLPC-A system. The data is organized into columns and rows, with some frames showing numerical values and others showing graphical representations like bar charts or waveforms. The frames are arranged in a grid that is approximately 10 columns wide and 15 rows high. The data appears to be organized into sections, with some frames showing a header or title. The overall layout is typical of a microfiche card used for storing and retrieving digital data.

801

ECF:DRP000001

00010000

780223 IDENTIFICATION

DRP10 411

MDR1DRLPCASEQ

00010000

780223
SEQ 0001

PRODUCT CODE: MAINDEC-11-DRLPC-A-D
PRODUCT NAME: LPA/ARI1 DIAGNOSTIC TEST I
DATE: JANUARY 1978
MAINTAINER: DIAGNOSTIC GROUP

COPYRIGHT (C) 1978 DIGITAL EQUIPMENT CORP., MAYNARD, MASS.

THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE WHO ONE WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DEC.

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE IN EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

ABSTRACT

SEQ 0002

THIS PROGRAM IS A LOGIC TEST OF THE AR11 LAB SYSTEM OPTION. MOST FUNCTIONS OF THE OPTION WILL BE TESTED. DUE TO THE FLEXIBILITY OF THE OPTION, THE OPERATOR MAY BE REQUIRED TO SUPPLY OPTION CHARACTERISTICS.

THIS PROGRAM IS A MODIFIED VERSION OF "MD-11-DZARA-[REV]". IT WAS MODIFIED TO ENABLE THE OPERATOR TO CHECK OUT THE AR11 OPTION WHEN IT IS ON THE LPA-11XX I/O BUS. NO RECALING IS NEEDED. SOME TESTS DONE IN THE ORIGINAL DIAGNOSTIC SUCH AS ARBITRATION TESTS, WERE DELETED AS THEY COULD NOT BE CHECKED. IF THIS DIAGNOSTIC DOESN'T FIND A SUSPECTED PROBLEM, YOU MAY HAVE TO RUN "MD-11-DZARA". YOU SHOULD RUN "MD-11-DRLPA" BEFORE RUNNING THIS DIAGNOSTIC. PLEASE READ SECTION 10.

2. REQUIREMENTS

2.1 EQUIPMENT

PDP-11 FAMILY COMPUTER WITH 16K WORDS OF MEMORY
AR11 HEX OPTION MODULE INSTALLED
LPA-11X SYSTEM
TELETYPE (OR EQUIVALENT)

2.2 STORAGE

THIS PROGRAM USES LESS THAN 16K OF MEMORY.

3. LOADING PROCEDURE

PROCEDURE FOR NORMAL BINARY TAPES SHOULD BE FOLLOWED.

4. STARTING PROCEDURE

4.1 CONTROL SWITCH SETTINGS

THIS PROGRAM HAS BEEN MODIFIED TO RUN WITH OR WITHOUT A HARDWARE SWITCH REGISTER.

STANDARD PDP-11 FORMAT

SW 15 = 1	HALT ON ERROR
SW 14 = 1	LOOP ON TEST
SW 13 = 1	INHIBIT ERROR TYPINGS
SW 12 = 1	STORAGE SCOPE CONNECTED
SW 11 = 1	INHIBIT INTERACTIONS
SW 10 = 1	ALL 1'S A TO D TEST JUMPER INSTALLED
SW 09 = 1	LOOP ON ERROR
SW 08 = 1	LOOP ON TEST IN SWR <7:0>

REFER TO 9. FOR SOFTWARE SWITCH REGISTER CONTROL

4.2 STARTING ADDRESS OR ADDRESSES

200 IS THE STARTING ADDRESS OF THE LOGIC TEST.
204 IS THE RESTART ADDRESS OF THE LOGIC TEST.

5. OPERATING PROCEDURE

THE OPERATOR MUST INSERT THE CORRECT INFORMATION IN THE SWITCH REGISTER WHEN REQUESTED BY THE PROGRAM OR AN ERROR WILL OCCUR. ONCE STARTED THE TEST WILL RUN IN ITS NORMAL MANNER WITHOUT OPERATOR INTERVENTION OR SWITCH SELECTION.

6. ERRORS

THIS PROGRAM USES THE DIAGNOSTIC 'SYSMAC' PACKAGE FOR ERROR REPORTING AND TYPEOUT. REFER TO THE "ERROR POINTER TABLE" FOR TYPE AND DESCRIPTION OF ERRORS.

7. RESTRICTIONS

EXTERNAL A TO D START INPUT MUST NOT BE CONNECTED.

8. MISCELLANEOUS

8.1 EXECUTION TIME

THE LOGIC TEST WILL TAKE APPROXIMATELY 4 MINUTES FOR COMPLETION AND WILL TYPE 'END PASS'.

8.2 DEVICE ADDRESS PROGRAM LOCATIONS

LOCATION \$BASE CONTAINS THE AR11 BASE DEVICE ADDRESS <170400>
LOCATION \$VECT1 CONTAINS THE AR11 BASE INTERRUPT VECTOR <340>
LOCATION ADBRL CONTAINS THE AR11 A TO D BR LEVEL <300><6>
LOCATION CKBRL CONTAINS THE AR11 CLOCK BR LEVEL <300><6>
LOCATION VCBRL CONTAINS THE AR11 SCOPE BR LEVEL <200><4>
LOCATION \$FILLS CONTAINS THE TTY FILLER CHARACTER COUNT
LOCATION \$NUIL CONTAINS THE TTY FILLER CHARACTER

*NOTE: IF THESE LOCATIONS ARE CHANGED, THE OPERATOR MUST START THE TEST AGAIN AT LOC. 200. THE PROGRAM WILL USE THE BASE ADDRESS AND VECTOR AND UPDATE THE ACTUAL PROGRAM VALUES.

8.3 MULTIPLE AR11 TESTING

A PROVISION IS MADE FOR TESTING SEQUENTIAL AR11. STARTING AT BUS ADDRESS/VECTOR DEFINED BY \$BASE AND \$VECT1. THE HEADER TYPEOUT WILL INFORM THE OPERATOR OF THE NUMBER OF AR11'S FOUND.

8.4 XXDP/ACT/APT NOTES

THIS PROGRAM IS A CHAINABLE PROGRAM UNDER XXDP/ACT. THE APT HOOKS HAVE BEEN INSTALLED BUT NOT TESTED.

8.5 USER LINK TO I/O DEVICE

A SPECIAL USER LINK HAS BEEN PROVIDED IN ORDER FOR THE OPERATOR TO EXAMINE OR MODIFY LOCATIONS ON THE LPA11-KX I/O BUS. (NOTE: THIS CANNOT BE DONE DIRECTLY.)

PROCEDURE:

1) START THE PROCESSOR AT LOCATION \$UTK:

2) THE DIALOG TO EXAMINE A LOCATION IS AS FOLLOWS:

E OR D "E"
DEVICE ADDR= "OCTAL ADDR"
XXXXXX

WHERE XXXXXX IS THE CONTENTS OF THE SPECIFIED LOC.

3) THE DIALOG TO MODIFY A LOCATION IS AS FOLLOWS:

3) THE DIALOG TO MODIFY A LOCATION IS AS FOLLOWS:

EO1

E OR D
DATA=

"D"
"DATA TO BE DEPOSITED"

4) THE PROGRAM WILL STAY IN THIS LOOP UNTIL THE OPERATOR IS FINISHED. AT THIS TIME THE PROCESSOR SHOULD BE HALTED.

NOTE: THE OPERATORS RESPONSE IS ENCLOSED IN QUOTES.

9. SOFTWARE SWITCH REGISTER OPERATION

 THE PROGRAM SUPPORTS NON-SWITCH REGISTER CPU TYPES.
 A CHANGE IN SWR VALUE IS ACCOMPLISHED BY TYPING A "CTRL G".
 THE RESPONSE WILL BE "SWR = " AND WAIT FOR A NEW VALUE.
 THE OPERATOR NOW INPUTS THE NEW VALUE AND TERMINATES WITH A "CR".

10. LPA11 (SYSTEM) DIAGNOSTIC SUMMARY

 DIAGNOSTICS FOR THE LPA11 ARE WRITTEN AT THREE LEVELS: (1)
 TOTAL PDP-11 SYSTEM, (2) LPA11 SYSTEM; AND, (3) LPA11 OPTIONS.

LEVEL 1, IS DESIGNED TO ISOLATE A FAILURE TO THE LPA11 SYSTEM.
 ALL OPTIONS ON THE PDP-11 ARE EXERCISED.

LEVEL 2 DIAGNOSTICS ISOLATE A FAILURE TO THE INDIVIDUAL OPTION
 WITHIN THE LPA11. THE LEVEL 2 DIAGNOSTIC IS MD-11-DRLPA. WHEN
 THE USER RUNS DRLPA HE CAN GENERALLY TELL WHICH OPTION DIAGNOSTIC
 (LEVEL 3) TO RUN NEXT. M8254 AND BMC-11 ERRORS MAY "LOOK" ALIKE
 AND DRLPA MAY NOT BE ABLE TO DISTINGUISH BETWEEN THEM.
 ARBITRATION ERRORS WILL NOT BE DETECTED BY THIS DIAGNOSTIC.

LEVEL THREE DIAGNOSTICS AID IN DETERMINING IF THE ERROR WAS IN
 FACT ON THE OPTION THE DRLPA SPECIFIED. THE USER MAY "LOOP" ON
 THE ERROR. WITHIN LEVEL THREE, THERE ARE TWO GROUPS OF
 DIAGNOSTICS. THE FIRST GROUP REQUIRES NO "EXTRA" WORK BY THE
 USER IN ORDER TO RUN. GROUP "A" DIAGNOSTICS DO NOT CHECK
 ARBITRATION, AND REQUIRE EXTRA TIME FOR EXECUTION. THE SECOND
 GROUP (GROUP "B") REQUIRES THAT THE USER RECONFIGURE THE PDP-11
 SYSTEM. THIS RECONFIGURATION INVOLVES CABLING THE UNIBUS TO THE
 LPA'S I/O BUS.

THE DIAGNOSTIC FOR THE M8254 FALLS INTO THE GROUP "B" CATEGORY.

G01

THE LPA-11KX DIAGNOSTIC KIT WILL INCLUDE:

SEQ 0006

OPTION -----	GROUP -----	DIAG. # -----	DIAG. TITLE -----
LPA11-KX	LEVEL 2	MD-11-DRLPA	LPA11-K SYSTEM DIAG.
M8254	"B"	MD-11-DRLPN	M8254 (IPBM) DIAG.
AA11-K	A	MD-11-DRLPB	AA11-K DIAG.
	B	MD-11-DZAAC	AA11-K DIAG.
AR11	A	MD-11-DRLPC	LPA/AR11 DIAG. #1
	A	MD-11-DRLPD	LPA/AR11 DIAG. #2
	A	MD-11-DRLPE	LPA/AR11 DIAG. #3
	B	MD-11-DZARA	AR11 DIAG. #1
	B	MD-11-DZARB	AR11 DIAG. #2
	B	MD-11-DZARC	AR11 DIAG. #3
DR11-K	A	MD-11-DRLPF	LPA/DR11-K DIAG.
	B	MD-11-DZDRG	DR11-K DIAG.
KW11-K	A	MD-11-DRLPG	LPA/KW11-K DIAG.
	B	MD-11-DZKWK	KW11-K DIAG.
LPS11	A	MD-11-DRLPH	LPA/LPS11 DIAG. #1
	A	MD-11-DRLPI	LPA/LPS11 DIAG. #2
	A	MD-11-DRLPJ	LPA/LPS11 DIAG. #3
	B	MD-11-DZLPC	LPS11 DIAG. #1
	B	MD-11-DZLPD	LPS11 DIAG. #2
	B	MD-11-DZLPI	LPS11 DIAG. #3
AD11-K	A	MD-11-DRLPK	LPA/AD11-K DIAG.
	B	MD-11-DZADL	AD11-K DIAG.
M8200-YC	B	MD-11-DZLPL	LPA/DMC BASIC MICRO-CPU R/W TEST
	B	MD-11-DZLPM	LPA/DMC JMP+ROM READ TEST

MAINDEC-11-DRLPC-A MACY11 27(654) 15-DEC-77 10:54
DRLPC.P11

SEQ 0007

TABLE OF CONTENTS

64	BASIC DEFINITIONS
177	OPERATIONAL SWITCH SETTINGS
189	TRAP CATCHER
198	STARTING ADDRESS(ES)
202	ACT11 HOOKS
213	APT PARAMETER BLOCK
235	COMMON TAGS
282	APT MAILBOX-ETABLE
350	ERROR POINTER TABLE
551	INITIALIZE THE COMMON TAGS
638	TYPE PROGRAM NAME
645	GET VALUE FOR SOFTWARE SWITCH REGISTER
687	T1 TEST EACH BUS ADDRESS FOR TIMEOUT
712	T2 TEST THAT THE PRESET BUFFER CAN HOLD #0
726	T3 TEST THE COUNTER PRESET BUFFER CAN HOLD #377
740	T4 TEST THAT PRESET BUFFER CAN HOLD #125
754	T5 TEST THAT PRESET BUFFER CAN HOLD #252
768	T6 TEST THAT PRESET BUFFER CAN HOLD A COUNT PATTERN
787	T7 TEST INIT TO CLEAR COUNT PRESET BUFFER WHEN IT IS =-1
804	T10 TEST THAT THE COUNTER CAN HOLD #0
818	T11 TEST THE COUNTER CAN HOLD #377
833	T12 TEST THAT COUNTER CAN HOLD #125
847	T13 TEST THAT COUNTER CAN HOLD #252
861	T14 TEST THAT COUNTER CAN HOLD A COUNT PATTERN
880	T15 TEST INIT TO CLEAR COUNTER WHEN IT IS =-1
897	T16 TEST ENABLE COUNTER (BIT 0) CAN BE SET
911	T17 TEST RATE SELECT (BIT 1) MAY BE SET
925	T20 TEST THAT RATE SELECT (BIT 2) MAY BE SET
939	T21 TEST THAT RATE SELECT (BIT 3) MAY BE SET
953	T22 TEST CLOCK INTERRUPT ENABLE (BIT 6) CAN BE SET
967	T23 TEST MODE (BIT 8) CAN BE SET
981	T24 TEST EXT INTERRUPT ENABLE (BIT 14) CAN BE SET
995	T25 TEST THAT CLK DONE (BIT 7) CAN BE SET
1008	T26 TEST THAT CLK EXT INPUT (BIT 15) CAN BE SET
1021	T27 TEST THAT THE EXT FLAG DOES NOT SET FROM THE OUTSIDE SOURCE
1039	T30 MAINT. COUNT THE COUNTER REGISTER AT RATE 1MHZ
1083	T31 TEST THAT OVERFLOW SET CLK DONE (BIT 7)
1113	T32 MAINT. COUNT THE COUNTER REGISTER AT RATE #100KHZ
1154	T33 MAINT. COUNT THE COUNTER REGISTER AT RATE #10KHZ
1193	T34 MAINT. COUNT THE COUNTER REGISTER AT RATE #1KHZ
1230	T35 MAINT. COUNT THE COUNTER REGISTER AT RATE #100HZ
1267	T36 TEST THAT RESET CLEARS RATE SELECT AND MODE BITS
1284	T37 TEST THAT RESET CLEARS CLK INTERRUPT ENABLE
1301	T40 TEST THAT RESET CLEARS CLK FLAGS
1318	T41 TEST THAT RESET CLEARS COUNTER ENABLE
1339	T42 TEST CLOCK TO COUNT UP AT 1 MHZ
1361	T43 TEST CLOCK TO COUNT UP AT 100KHZ
1383	T44 TEST CLOCK TO COUNT UP AT 10 KHZ
1399	T45 TEST CLOCK TO COUNT UP AT 1KHZ
1414	T46 TEST CLOCK TO COUNT UP AT 100HZ
1429	T47 TEST THAT CLOCK ENABLE DOES NOT CLEAR ON DONE (MODE 1) 1 KHZ
1453	T50 TEST THAT CLOCK ENABLE DOES NOT CLEAR DONE (MODE 1 100HZ)
1476	T51 TEST THAT RESET SETS VC READY BIT
1489	T52 TEST THAT VC MODE BIT 2 CAN BE SET AND CLEARED

MAINDEC-11-DRLPC-A MACY11 27(654) 15-DEC-77 10:54
DRLPC.P11 TABLE OF CONTENTS

SEQ 0008

1513	T53	TEST THAT VC MODE BIT 3 CAN BE SET
1528	T54	TEST THAT VC INTERRUPT ENABLE (BIT 6) CAN BE SET
1543	T55	TEST THAT CHANNEL (BIT 9) CAN BE SET
1558	T56	TEST THAT STORE (BIT 10) CAN BE SET
1572	T57	TEST THAT WRITE THRU (BIT 11) CAN BE SET
1586	T60	TEST THAT ERASE (BIT 12) CAN BE SET
1603	T61	TEST THAT THE X REGISTER CAN BE CLEARED
1617	T62	TEST THAT THE X REGISTER CAN BE LOADED WITH #1777
1631	T63	TEST THAT THE X REGISTER CAN BE LOADED WITH #525
1645	T64	TEST THAT THE X REGISTER CAN BE LOADED WITH #1252
1659	T65	TEST THAT THE X REGISTER CAN HOLD A COUNT PATTERN
1679	T66	TEST THAT THE Y REGISTER CAN BE CLEARED
1693	T67	TEST THAT THE Y REGISTER CAN BE LOADED WITH #1777
1707	T70	TEST THAT THE Y REGISTER CAN BE LOADED WITH #525
1721	T71	TEST THAT THE Y REGISTER CAN BE LOADED WITH #1252
1735	T72	TEST THAT THE Y REGISTER CAN HOLD A COUNT PATTERN
1755	T73	TEST THAT THE X-Y REGISTERS CAN HOLD DIFFERENT DATA
1779	T74	TEST THAT WHEN INTENSIFY BIT IS SET THAT THE VC READY BIT RESETS
1802	T75	TEST THAT VC MODE 1 (INTENSIFY ON X) RESETS THE READY FLAG
1831	T76	TEST THAT VC MODE 2 (INTENSIFY ON Y) RESETS THE READY FLAG
1860	T77	TEST WHEN ERASE IS SET, VC READY BIT RESETS
1889	T100	TEST THAT RESET CLEARS VC MODE BITS
1906	T101	TEST THAT RESET CLEARS INTERRUPT ENABLE, CHANNEL, STORE, WRITE THRU
1923	T102	TEST THAT RESET CLEARS X REGISTER
1940	T103	TEST THAT RESET CLEARS Y REGISTER
1957	T104	DOES EXTERNAL ENABLE (BIT 4) SET
1971	T105	DOES CLOCK OVERFLOW ENABLE (BIT 5) SET
1986	T106	DOES AD INTERRUPT ENABLE (BIT 6) SET
2001	T107	DOES MUX CHANNEL (BIT 8) SET
2016	T110	DOES MUX CHANNEL (BIT 9) SET
2030	T111	DOES MUX CHANNEL (BIT 10) SET
2045	T112	DOES MUX CHANNEL (BIT 11) SET
2060	T113	DOES UNIPOLAR/BIPOLAR (BIT 13) SET
2077	T114	DOES AD DONE (BIT 7) SET AND CLEAR
2120	T115	TEST THAT THE CONVERTED NUMBER = 1777 (SW BIT 10=1)
2149	T116	TEST THAT NO EXTERNAL CONVERSIONS INPUT
2176	T117	TEST THAT CLOCK CAN START A CONVERSION
2204	T120	TEST THAT RESET CLEARS MUX AND UNIPOLAR BITS
2221	T121	TEST THAT RESET CLEARS EXT AND INTERRUPT ENABLE BITS
2237	T122	TEST THAT RESET CLEARS AD DONE
2256	T123	TEST THAT RESET CLEARS AD BUFFER REG
2277	T124	LOAD DIFFERENT NUMBERS INTO DIFFERENT REG.
2327	T125	DETERMINE IF MORE ARII'S ARE TO BE TESTED
2344		END OF PASS ROUTINE
2409		CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
2707		SCOPE HANDLER ROUTINE
2773		ERROR HANDLER ROUTINE
2823		TTY INPUT ROUTINE
2962		READ AN OCTAL NUMBER FROM THE TTY
3001		ERROR MESSAGE TIMEOUT ROUTINE
3049		POWER DOWN AND UP ROUTINES
3100		BINARY TO OCTAL (ASCII) AND TYPE
3177		TYPE ROUTINE
3256		APT COMMUNICATIONS ROUTINE

J01

MAINDEC-11-DRLPC-A MACY11 27(654) 15-DEC-77 10:54
DRLPC.P11 TABLE OF CONTENTS

SEQ 0009

3313 TRAP DECODER
3336 TRAP TABLE

.REM [

LPA.MAC

WELCOME. THIS DIAGNOSTIC IS ONE IN A SERIES OF DIAGNOSTIC
DESIGNED IN ORDER TO AID YOU IN TESTING THE LPA-11XX OPTION.
I HOPE THAT YOU HAVE READ THE DOCUMENTATION SECTION OF THIS
DIAGNOSTIC. IF YOU HAVE, YOU KNOW ABOUT ALL OF THE DIAGNOSTICS
THAT ARE AVAILABLE FOR TESTING THE LPA SYSTEM.

GOOD LUCK !

[
.GLOBL DRLPX2

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100

.REM !

THIS IS A LIST OF TEST DELETED FROM THIS DIAGNOSTIC.
THESE TESTS COULD NOT BE DONE THROUGH THE LPA-11.

TEST FOR PROPER SELECTION OF THE LOW BYTE OPERATION
 TEST FOR PROPER SELECTION OF HIGH BYTE OPERATION
 A TO D PRE-INTERRUPT SETUP
 TEST THAT A TO D INTERRUPTS AT LEVEL INDICATED
 TEST THAT A TO D DOES NOT INTERRUPT AT LEVEL INDICATED
 CLOCK PRE-INTERRUPT SETUP
 SCOPE PRE-INTERRUPT SETUP
 TEST THAT THE CLOCK INTERRUPTS AT LEVEL INDICATED -1
 TEST THAT THE CLOCK DOES NOT INTERRUPT AT LEVEL INDICATED
 TEST THAT THE DISPLAY DOES INTERRUPT AT LEVEL INDICATED
 TEST THAT THE DISPLAY DOES NOT INTERRUPT AT LEVEL INDICATED
 TEST 1MHZ REPEATABILITY
 TEST 100KHZ REPEATABILITY
 TEST 10KHZ REPEATABILITY
 TEST 1KHZ REPEATABILITY
 TEST AD GO (BIT 0) CAN BE SET AND CLEARED

```

;
.TITLE MAINDEC-11-DRLPC-A
;*COPYRIGHT (C) 1978
;*DIGITAL EQUIPMENT CORP.
;*MAYNARD, MASS. 01754
;
;*PROGRAM BY EDWARD C. BADGER
;
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-DZQAC-C2), SEPT 14, 1976.
;
.SBTTL BASIC DEFINITIONS

;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
STACK= 1100
.EQUIV EMT,ERROR ;;BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE ;;BASIC DEFINITION OF SCOPE CALL

;*MISCELLANEOUS DEFINITIONS
HT= 11 ;;CODE FOR HORIZONTAL TAB
LF= 12 ;;CODE FOR LINE FEED
CR= 15 ;;CODE FOR CARRIAGE RETURN
CRLF= 200 ;;CODE FOR CARRIAGE RETURN-LINE FEED
PS= 177776 ;;PROCESSOR STATUS WORD
.EQUIV PS,PSW
STKLMT= 177774 ;;STACK LIMIT REGISTER
PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
DSWR= 177570 ;;HARDWARE SWITCH REGISTER
DDI:P= 177570 ;;HARDWARE DISPLAY REGISTER

;*GENERAL PURPOSE REGISTER DEFINITIONS
RO= %0 ;;GENERAL REGISTER

```

001100

000011
 000012
 000015
 000200
 177776

177774
 177772
 177570
 177570

000000

84	000001	R1=	%1	:: GENERAL REGISTER
85	000002	R2=	%2	:: GENERAL REGISTER
86	000003	R3=	%3	:: GENERAL REGISTER
87	000004	R4=	%4	:: GENERAL REGISTER
88	000005	R5=	%5	:: GENERAL REGISTER
89	000006	R6=	%6	:: GENERAL REGISTER
90	000007	R7=	%7	:: GENERAL REGISTER
91	000006	SP=	%6	:: STACK POINTER
92	000007	PC=	%7	:: PROGRAM COUNTER
93				
94		;*PRIORITY LEVEL DEFINITIONS		
95	000000	PR0=	0	:: PRIORITY LEVEL 0
96	000040	PR1=	40	:: PRIORITY LEVEL 1
97	000100	PR2=	100	:: PRIORITY LEVEL 2
98	000140	PR3=	140	:: PRIORITY LEVEL 3
99	000200	PR4=	200	:: PRIORITY LEVEL 4
100	000240	PR5=	240	:: PRIORITY LEVEL 5
101	000300	PR6=	300	:: PRIORITY LEVEL 6
102	000340	PR7=	340	:: PRIORITY LEVEL 7
103				
104		;*SWITCH REGISTER" SWITCH DEFINITIONS		
105	100000	SW15=	100000	
106	040000	SW14=	40000	
107	020000	SW13=	20000	
108	010000	SW12=	10000	
109	004000	SW11=	4000	
110	002000	SW10=	2000	
111	001000	SW09=	1000	
112	000400	SW08=	400	
113	000200	SW07=	200	
114	000100	SW06=	100	
115	000040	SW05=	40	
116	000020	SW04=	20	
117	000010	SW03=	10	
118	000004	SW02=	4	
119	000002	SW01=	2	
120	000001	SW00=	1	
121		.EQUIV	SW09, SW9	
122		.EQUIV	SW08, SW8	
123		.EQUIV	SW07, SW7	
124		.EQUIV	SW06, SW6	
125		.EQUIV	SW05, SW5	
126		.EQUIV	SW04, SW4	
127		.EQUIV	SW03, SW3	
128		.EQUIV	SW02, SW2	
129		.EQUIV	SW01, SW1	
130		.EQUIV	SW00, SW0	
131				
132		;*DATA BIT DEFINITIONS (BIT00 TO BIT15)		
133	100000	BIT15=	100000	
134	040000	BIT14=	40000	
135	020000	BIT13=	20000	
136	010000	BIT12=	10000	
137	004000	BIT11=	4000	

```

138      002000      BIT10= 2000
139      001000      BIT09= 1000
140      000400      BIT08= 400
141      000200      BIT07= 200
142      000100      BIT06= 100
143      000040      BIT05= 40
144      000020      BIT04= 20
145      000010      BIT03= 10
146      000004      BIT02= 4
147      000002      BIT01= 2
148      000001      BIT00= 1
149      .EQUIV      BIT09,BIT9
150      .EQUIV      BIT08,BIT8
151      .EQUIV      BIT07,BIT7
152      .EQUIV      BIT06,BIT6
153      .EQUIV      BIT05,BIT5
154      .EQUIV      BIT04,BIT4
155      .EQUIV      BIT03,BIT3
156      .EQUIV      BIT02,BIT2
157      .EQUIV      BIT01,BIT1
158      .EQUIV      BIT00,BIT0
159
160      .*BASIC "CPU" TRAP VECTOR ADDRESSES
161      000004      ERRVEC= 4      ;; TIME OUT AND OTHER ERRORS
162      000010      RESVEC= 10     ;; RESERVED AND ILLEGAL INSTRUCTIONS
163      000014      TBITVEC=14     ;; "T" BIT
164      000014      TRTVEC= 14     ;; TRACE TRAP
165      000014      BPTVEC= 14     ;; BREAKPOINT TRAP (BPT)
166      000020      IOTVEC= 20     ;; INPUT/OUTPUT TRAP (IOT) **SCOPE**
167      000024      PWRVEC= 24     ;; POWER FAIL
168      000030      EMTVEC= 30     ;; EMULATOR TRAP (EMT) **ERROR**
169      000034      TRAPVEC=34     ;; "TRAP" TRAP
170      000060      TKVEC= 60      ;; TTY KEYBOARD VECTOR
171      000064      TPVEC= 64      ;; TTY PRINTER VECTOR
172      000240      PIRQVEC=240    ;; PROGRAM INTERRUPT REQUEST VECTOR
173      170400      ABASE=170400
174      000340      AVECT1=340
175      000200      APRIOR=200
176
177      .SBTTL      OPERATIONAL SWITCH SETTINGS
178      .*
179      .*          SWITCH          USE
180      .*          -----
181      .*          15             HALT ON ERROR
182      .*          14             LOOP ON TEST
183      .*          13             INHIBIT ERROR TYPEOUTS
184      .*          12             STORAGE SCOPE CONNECTED
185      .*          11             INHIBIT ITERATIONS
186      .*          10             ALL 1'S JUMPER IS INSTALLED
187      .*          9              LOOP ON ERROR
188      .*          8              LOOP ON TEST IN SWR<7:0>
189      .SBTTL      TRAP CATCHER
190      000000      . = 0
191      .*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"

```

```

192      ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
193      ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
194      . = 174
195      000174 000000      DISREG: .WORD 0      ;; SOFTWARE DISPLAY REGISTER
196      000176 000000      SWREG: .WORD 0      ;; SOFTWARE SWITCH REGISTER
197      .SBTTL STARTING ADDRESS(ES)
198      000200 000137 001672      JMP 2#BEGIN ;; JUMP TO STARTING ADDRESS OF PROGRAM
199      000204 000137 001676      JMP 2#BEGIN1 ;; JUMP TO RESTART ADDRESS
200
201      .SBTTL ACT11 HOOKS
202
203      ;*****
204      ;HOOKS REQUIRED BY ACT11
205      $SVPC=.      ;SAVE PC
206      . = 46
207      000046 000046      $ENDAD      ;; 1) SET LOC. 46 TO ADDRESS OF $ENDAD IN .SEOP
208      . = 52
209      000052 000000      .WORD 0      ;; 2) SET LOC. 52 TO ZERO
210      000210 000210      . = $SVPC      ;; RESTORE PC
211      001000      . = 1000
212      .SBTTL APT PARAMETER BLOCK
213
214      ;*****
215      ;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
216      ;*****
217      . $X=.      ;; SAVE CURRENT LOCATION
218      . = 24      ;; SET POWER FAIL TO POINT TO START OF PROGRAM
219      000024 000200      200      ;; FOR APT START UP
220      . = 44      ;; POINT TO APT INDIRECT ADDRESS PNTR.
221      000044 001000      $APTHDR      ;; POINT TO APT HEADER BLOCK
222      . = $X      ;; RESET LOCATION COUNTER
223      ;*****
224      ;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
225      ;INTERFACE SPEC.
226
227      001000      $APTHD:
228      001000 000000      $HI8TS: .WORD 0      ;; TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
229      001002 001176      $MBADR: .WORD $MAIL      ;; ADDRESS OF APT MAILBOX (BITS 0-15)
230      001004 000010      $TSTM: .WORD 10      ;; RUN TIM OF LONGEST TEST
231      001006 000010      $PASTM: .WORD 10      ;; RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
232      001010 000200      $UNITM: .WORD 200      ;; ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
233      001012 000052      .WORD $ETEND-$MAIL/2 ;; LENGTH MAILBOX-ETABLE(WORDS)

```

.SBTTL COMMON TAGS

```

*****
;THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
;USED IN THE PROGRAM.

```

001100

SCMTAG: . =1100

;; START OF COMMON TAGS

001100 000000

\$STNM: .WORD 0

;CONTAINS THE TEST NUMBER

001102 000

\$SERFLG: .BYTE 0

;CONTAINS ERROR FLAG

001103 000

\$ICNT: .WORD 0

;CONTAINS SUBTEST ITERATION COUNT

001104 000000

\$LPADR: .WORD 0

;CONTAINS SCOPE LOOP ADDRESS

001110 000000

\$LPERR: .WORD 0

;CONTAINS SCOPE RETURN FOR ERRORS

001112 000000

\$ERITL: .WORD 0

;CONTAINS TOTAL ERRORS DETECTED

001114 000

\$ITEMB: .BYTE 0

;CONTAINS ITEM CONTROL BYTE

001115 001

\$ERMAX: .BYTE 1

;CONTAINS MAX. ERRORS PER TEST

001116 000000

\$ERRPC: .WORD 0

;CONTAINS PC OF LAST ERROR INSTRUCTION

001120 000000

\$GDADR: .WORD 0

;CONTAINS ADDRESS OF 'GOOD' DATA

001122 000000

\$BDADR: .WORD 0

;CONTAINS ADDRESS OF 'BAD' DATA

001124 000000

\$GDDAT: .WORD 0

;CONTAINS 'GOOD' DATA

001126 000000

\$BDDAT: .WORD 0

;CONTAINS 'BAD' DATA

001130 000000

.WORD 0

;RESERVED--NOT TO BE USED

001132 000000

.WORD 0

;AUTOMATIC MODE INDICATOR

001134 000

\$AUTOB: .BYTE 0

;INTERRUPT MODE INDICATOR

001135 000

\$INTAG: .BYTE 0

;INTERRUPT MODE INDICATOR

001136 000000

.WORD 0

;ADDRESS OF SWITCH REGISTER

001140 177570

SWR: .WORD DSWR

;ADDRESS OF SWITCH REGISTER

001142 177570

DISPLAY: .WORD DOISP

;ADDRESS OF DISPLAY REGISTER

001144 177560

\$TKS: 177560

;TTY KBD STATUS

001146 177562

\$TKB: 177562

;TTY KBD BUFFER

001150 177564

\$TPS: 177564

;TTY PRINTER STATUS REG. ADDRESS

001152 177566

\$TPB: 177566

;TTY PRINTER BUFFER REG. ADDRESS

001154 000

\$NULL: .BYTE 0

;CONTAINS NULL CHARACTER FOR FILLS

001155 002

\$FILLS: .BYTE 2

;CONTAINS # OF FILLER CHARACTERS REQUIRED

001156 012

\$FILLC: .BYTE 12

;INSERT FILL CHARS. AFTER A "LINE FEED"

001157 000

\$TPFLG: .BYTE 0

;"TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)

001160 000000

\$REGAD: .WORD 0

;CONTAINS THE ADDRESS FROM WHICH (\$REGO) WAS OBTAINED

001162 000000

\$REGO: .WORD 0

;CONTAINS ((\$REGAD)+0)

001164 000000

\$REG1: .WORD 0

;CONTAINS ((\$REGAD)+2)

001166 000000

\$TIMES: 0

;MAX. NUMBER OF ITERATIONS

001170 000000

\$ESCAPE: 0

;ESCAPE ON ERROR ADDRESS

001172 077

\$QUES: .ASCII /?/

;QUESTION MARK

001173 015

\$CRLF: .ASCII <15>

;CARRIAGE RETURN

001174 000012

\$LF: .ASCII <12>

;LINE FEED

.SBTTL APT MAILBOX-ETABLE

```

.EVEN
$MAIL:                ;;APT MAILBOX
$MSGTY: .WORD  AMSGTY  ;;MESSAGE TYPE CODE
$FATAL: .WORD  AFATAL  ;;FATAL ERROR NUMBER

```

288	001202	000000	\$TESTN:	.WORD	ATESTN	:: TEST NUMBER
289	001204	000000	\$PASS:	.WORD	APASS	:: PASS COUNT
290	001206	000000	\$DEVCT:	.WORD	ADEVCT	:: DEVICE COUNT
291	001210	000000	\$UNIT:	.WORD	AUNIT	:: I/O UNIT NUMBER
292	001212	000000	\$MSGAD:	.WORD	AMSGAD	:: MESSAGE ADDRESS
293	001214	000000	\$MSGLG:	.WORD	AMSGLG	:: MESSAGE LENGTH
294	001216		\$ETABLE:			:: APT ENVIRONMENT TABLE
295	001216	000	\$ENV:	.BYTE	AENV	:: ENVIRONMENT BYTE
296	001217	000	\$ENVm:	.BYTE	AENVm	:: ENVIRONMENT MODE BITS
297	001220	000000	\$SWREG:	.WORD	ASWREG	:: APT SWITCH REGISTER
298	001222	000000	\$USWR:	.WORD	AUSWR	:: USER SWITCHES
299	001224	000000	\$CPUOP:	.WORD	ACPUOP	:: CPU TYPE, OPTIONS
300			:: *			BITS 15-11=CPU TYPE
301			:: *			11/04=01, 11/05=02, 11/20=03, 11/40=04, 11/45=05
302			:: *			11/70=06, PDQ=07, Q=10
303			:: *			BIT 10=REAL TIME CLOCK
304			:: *			BIT 9=FLOATING POINT PROCESSOR
305			:: *			BIT 8=MEMORY MANAGEMENT
306	001226	000	\$MAMS1:	.BYTE	AMAMS1	:: HIGH ADDRESS, M.S. BYTE
307	001227	000	\$MTYP1:	.BYTE	AMTYP1	:: MEM. TYPE, BLK#1
308			:: *			MEM. TYPE BYTE -- (HIGH BYTE)
309			:: *			900 NSEC CORE=001
310			:: *			300 NSEC BIPOLAR=002
311			:: *			500 NSEC MOS=003
312	001230	000000	\$MAOR1:	.WORD	AMADR1	:: HIGH ADDRESS, BLK#1
313			:: *			MEM. LAST ADDR.=3 BYTES, THIS WORD AND LOW OF "TYPE" ABOVE
314	001232	000	\$MAMS2:	.BYTE	AMAMS2	:: HIGH ADDRESS, M.S. BYTE
315	001233	000	\$MTYP2:	.BYTE	AMTYP2	:: MEM. TYPE, BLK#2
316	001234	000000	\$MAOR2:	.WORD	AMADR2	:: MEM. LAST ADDRESS, BLK#2
317	001236	000	\$MAMS3:	.BYTE	AMAMS3	:: HIGH ADDRESS, M.S. BYTE
318	001237	000	\$MTYP3:	.BYTE	AMTYP3	:: MEM. TYPE, BLK#3
319	001240	000000	\$MAOR3:	.WORD	AMADR3	:: MEM. LAST ADDRESS, BLK#3
320	001242	000	\$MAMS4:	.BYTE	AMAMS4	:: HIGH ADDRESS, M.S. BYTE
321	001243	000	\$MTYP4:	.BYTE	AMTYP4	:: MEM. TYPE, BLK#4
322	001244	000000	\$MAOR4:	.WORD	AMADR4	:: MEM. LAST ADDRESS, BLK#4
323	001246	000340	\$VECT1:	.WORD	AVECT1	:: INTERRUPT VECTOR#1, BUS PRIORITY#1
324	001250	000000	\$VECT2:	.WORD	AVECT2	:: INTERRUPT VECTOR#2, BUS PRIORITY#2
325	001252	170400	\$BASE:	.WORD	ABASE	:: BASE ADDRESS OF EQUIPMENT UNDER TEST
326	001254	000000	\$DEVm:	.WORD	ADEVm	:: DEVICE MAP
327	001256	000000	\$CDW1:	.WORD	ACDW1	:: CONTROLLER DESCRIPTION WORD#1
328	001260	000000	\$CDW2:	.WORD	ACDW2	:: CONTROLLER DESCRIPTION WORD#2
329	001262	000000	\$DDW0:	.WORD	ADDW0	:: DEVICE DESCRIPTOR WORD#0
330	001264	000000	\$DDW1:	.WORD	ADDW1	:: DEVICE DESCRIPTOR WORD#1
331	001266	000000	\$DDW2:	.WORD	ADDW2	:: DEVICE DESCRIPTOR WORD#2
332	001270	000000	\$DDW3:	.WORD	ADDW3	:: DEVICE DESCRIPTOR WORD#3
333	001272	000000	\$DDW4:	.WORD	ADDW4	:: DEVICE DESCRIPTOR WORD#4
334	001274	000000	\$DDW5:	.WORD	ADDW5	:: DEVICE DESCRIPTOR WORD#5
335	001276	000000	\$DDW6:	.WORD	ADDW6	:: DEVICE DESCRIPTOR WORD#6
336	001300	000000	\$DDW7:	.WORD	ADDW7	:: DEVICE DESCRIPTOR WORD#7
337	001302	000000	\$DDW8:	.WORD	ADDW8	:: DEVICE DESCRIPTOR WORD#8
338	001304	000000	\$DDW9:	.WORD	ADDW9	:: DEVICE DESCRIPTOR WORD#9
339	001306	000000	\$DDW10:	.WORD	ADDW10	:: DEVICE DESCRIPTOR WORD#10
340	001310	000000	\$DDW11:	.WORD	ADDW11	:: DEVICE DESCRIPTOR WORD#11
341	001312	000000	\$DDW12:	.WORD	ADDW12	:: DEVICE DESCRIPTOR WORD#12

E02

MAINDEC-11-DRLPC-A MACY11 27(654) 15-DEC-77 10:54 PAGE 8
DRLPC.P11 APT MAILBOX-ETABLE

SEQ 0017

342 001314 000000 \$DDW13: .WORD ADDW13 ;;DEVICE DESCRIPTOR WORD#13
343 001316 000000 \$DDW14: .WORD ADDW14 ;;DEVICE DESCRIPTOR WORD#14
344 001320 000000 \$DDW15: .WORD ADDW15 ;;DEVICE DESCRIPTOR WORD#15
345
346
347 001322 \$ETEND:
348

349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402

.SBTTL ERROR POINTER TABLE

;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
;*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
;*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;* EM ;:POINTS TO THE ERROR MESSAGE
;* DH ;:POINTS TO THE DATA HEADER
;* DT ;:POINTS TO THE DATA
;* DF ;:POINTS TO THE DATA FORMAT

\$ERRTB:

366	001322	014620	1	EM1	;	A TO D STATUS REGISTER IN ERROR
367	001324	015414		DH1	;	ERRPC ADCS ADSTAT EXPECTED
368	001326	016220		DT1	;	\$ERRPC ADCS \$BDDAT \$GDDAT
369	001330	000000		0		
372	001332	014660	2	EM2	;	A TO d INTERRUPT ERROR
373	001334	015454		DH2	;	ERRPC ADCS
374	001336	016232		DT2	;	\$ERRPC ADCS
375	001340	000000		0		
378	001342	014707	3	EM3	;	CLOCK STATUS REGISTER IN ERROR
379	001344	015472		DH3	;	ERRPC CSR CKSTAT EXPECTED
380	001346	016240		DT3	;	\$ERRPC CSR \$BDDAT \$GDDAT
381	001350	000000		0		
384	001352	014746	4	EM4	;	CLOCK PRESET REGISTER IN ERROR
385	001354	015532		DH4	;	ERRPC CSB CKBUFF EXPECTED
386	001356	016252		DT4	;	\$ERRPC CSB \$BDDAT \$GDDAT
387	001360	000000		0		
390	001362	015005	5	EM5	;	CLOCK INTERRUPT ERROR
391	001364	015572		DH5	;	ERRPC CSR
392	001366	016264		DT5	;	\$ERRPC CSR
393	001370	000000		0		
396	001372	015033	6	EM6	;	CLOCK COUNTER REGISTER IN ERROR
397	001374	015607		DH6	;	ERRPC CSC CKCNTR EXPECTED
398	001376	016272		DT6	;	\$ERRPC CSC \$BDDAT \$GDDAT
399	001400	000000		0		
402	001402	015073	7	EM7	;	CLOCK COUNTED IN ERROR

403	001404	015607	DH6	;ERRPC	CSC	CKCNTR	EXPECTED
404	001406	016272	DT6	;\$ERRPC	CSC	\$BDDAT	\$GDDAT
405	001410	000000	0				
406							
407			; ITEM 10				
408	001412	015122	EM10				
409	001414	015647	DH10	;CLOCK REPEATABILITY FAILED			
410	001416	016272	DT6	;ERRPC	CSC	TIME1	TIME2
411	001420	000000	0	;\$ERRPC	CSC	\$BDDAT	\$GDDAT
412							
413			; ITEM 11				
414	001422	015155	EM11	;VC STATUS REGISTER IN ERROR			
415	001424	015705	DH11	;ERRPC	VCADR	VCSTAT	EXPECTED
416	001426	016304	DT11	;\$ERRPC	VCSTAT	\$BDDAT	\$GDDAT
417	001430	000000	0				
418							
419			; ITEM 12				
420	001432	015211	EM12	;X REGISTER IN ERROR			
421	001434	015745	DH12	;ERRPC	VCXPOS	X POS.	EXPECTED
422	001436	016316	DT12	;\$ERRPC	VCXPOS	\$BDDAT	\$GDDAT
423	001440	000000	0				
424							
425			; ITEM 13				
426	001442	015235	EM13	;Y REGISTER IN ERROR			
427	001444	016006	DH13	;ERRPC	VCYPOS	Y POS.	EXPECTED
428	001446	016330	DT13	;\$ERRPC	VCYPOS	\$BDDAT	\$GDDAT
429	001450	000000	0				
430							
431			; ITEM 14				
432	001452	015261	EM14	;SCOPE INTERRUPT ERROR			
433	001454	016047	DH14	;ERRPC	VCADR		
434	001456	016342	DT14	;\$ERRPC	VCSTAT		
435	001460	000000	0				
436							
437			; ITEM 15				
438	001462	015307	EM15	;DEVICE BUS ERROR			
439	001464	016066	DH15	;ERRPC	BASE ADDRESS	ACTUAL ADDRESS	
440	001466	016350	DT15	;\$ERRPC	ARBADD	\$BDDAT	
441	001470	000000	0				
442							
443			; ITEM 16				
444	001472	015330	EM16	;INCORRECT A/D BUFFER DATA			
445	001474	016116	DH16	;ERRPC	ADDBR	BUFFER	EXPECTED
446	001476	016360	DT16	;\$ERRPC	ADDBR	\$BDDAT	\$GDDAT
447	001500	000000	0				
448							
449			; ITEM 17				
450	001502	015362	EM17	;DUAL REGISTER ADDRESSING			
451	001504	016157	DH17	;ERRPC	BUFADR	READ	EXPECTED
452	001506	016372	DT17	;\$ERRPC	BUFADR	\$BDDAT	\$GDDAT
453	001510	000000	0				
454							
455							
456							

; ADDRESS OF KMC-11 OF LPA-11 THE ADDR FOR KMADD MAY BE

```

457      ;
458      ;
459      ;
460      ;
461      ;
462      ;
463      001512      LPCI:
464      001512      170460      KMADO: .WORD      170460      ;BASE KMC ADDR. MAY BE PATCHED BY USER.
465
466      001514      LPMR:
467      001514      170461      KMAD1: .WORD      170460+1      ;>DO NOT      <;KMC-CSR ADDR
468      001516      LPCO:
469      001516      170462      KMAD2: .WORD      170460+2      ;>PATCH      <;
470      001520      LPSO:
471      001520      170463      KMAD3: .WORD      170460+3      ;>THIS AREA      <
472      001522      LPADL:
473      001522      170464      KMAD4: .WORD      170460+4      ;
474      001524      LPADH:
475      001524      170465      KMAD5: .WORD      170460+5      ;>DO NOT      <
476      001526      LPMS1:
477      001526      170466      KMAD6: .WORD      170460+6      ;>PATCH      <
478      001530      LPMS2:
479      001530      170467      KMAD7: .WORD      170460+7      ;>THIS AREA      <
480
481      001532      000340      VECTOR: .WORD      AVECT1&777      ;BASE VECTOR OF KMC
482      001534      000344      VECTPS: .WORD      4+AVECT1&777      ;VECTR ADDR.+2
483
484      001536      000004      VERSN: .WORD      4      ;CURRENT VERSION NUMBER OF MICROCODE.
485
486      001540      000000      .DVLS: .WORD      0      ;/DEVICE LIST OF I/O ADDR. DEFINED
487      001542      000020      .BLKW      16.      ;/BY INIT.
488
489      001602      000300      ADBRL: 300      ;A TO D BR LEVEL
490      001604      000300      CKBRL: 300      ;CLOCK BR LEVEL
491      001606      000200      VCBRL: 200      ;SCOPE BR LEVEL
492
493      ;PROGRAM WILL CHANGE THE NEXT 16 LOCATIONS
494
495      001610      170400      ADCS: 170400      ;A TO D STATUS REG
496      001612      170402      ADDBR: 170402      ;A TO D BUFFER
497
498      001614      170404      CSR: 170404      ;CLOCK STATUS REGISTER
499      001616      170406      CSB: 170406      ;CLOCK PRESET BUFFER
500
501      001620      170410      VCSTAT: 170410      ;VC STATUS REGISTER
502      001622      170412      VCXREG: 170412      ;VC X AXIS REGISTER
503      001624      170414      VCYREG: 170414      ;VC Y AXIS REGISTER
504
505
506      001626      170416      CSC: 170416      ;CLOCK COUNTER REGISTER
507
508      001630      000340      ADINT: 340      ;A TO D INTERRUPT VECTOR
509      001632      000342      ADINT1: 342
510

```

CHANGED BY THE USER TO REFLECT
A DIFFERENT KMC-11 ADDR. THE
REST OF THE ADDRESSES WILL
BE CHANGED BY THE PROGRAM.

511	001634	000344		KWIV:	344		;CLOCK INTERRUPT VECTOR
512	001636	000346		KWIVS:	346		
513							
514	001640	000350		VCIV:	350		;SCOPE INTERRUPT VECTOR
515	001642	000352		VCIVS:	352		
516							
517	001644	170400		ARBADD:	170400		;CURRENT DEVICE ADDRESS
518	001646	000340		ARBVCT:	340		;CURRENT DEVICE VECTOR
519	001650	000000		NMBEXT:	0		;NUMBER OF ADDITIONAL AR11'S
520	001652	000000		NBEXT:	0		
521	001654	000000		COUNT:	0		
522	001656	000000		DELAY:	0		
523	001660	000000		TEMP:	0		
524	001662	000000		SWITCH:	0		
525	001664	000000		BRLEV1:	0		
526	001666	000000		BRLEV2:	0		
527	001670	000000		STMDAT:	0		
528							
529							
530	001672	005000		BEGIN:	CLR	RO	;CLEAR RO
531	001674	000402		BR	RBEG		
532	001676	012700	177777	BEGIN1:	MOV	*-1,RO	;LOAD RO
533	001702			RBEG:			
534							
535							
536							
537							
538	001702	010046		MOV	RO, -(SP)		
539	001704	010146		MOV	R1, -(SP)		
540	001706	013700	001512	MOV	KMAD0,RO		;GET KMC-11 ADDRESS.
541	001712	012701	001514	MOV	*KMAD1,R1		;GET ADDR. OF ADDR. LIST.
542							
543	001716	005200		645:	INC	RO	;UPDATE ADDR.
544	001720	010021		MOV	RO,(1)+		;WRITE ADDR.
545	001722	020127	001532	CMP	R1,*KMAD7+2		;DONE ALL ADDRESSES?
546	001726	001373		BNE	645		;NO - DO NEXT ADDR.
547	001730	005037	001540	CLR	.DVLS		;CLR ADDR. LIST.
548	001734	012601		MOV	(SP)+,R1		
549	001736	012600		MOV	(SP)+,RO		
550				.SBTTL	INITIALIZE THE COMMON TAGS		
551				;;CLEAR	THE COMMON TAGS (\$CMTAG) AREA		
552	001740	012706	001100	MOV	*\$CMTAG,R6		;FIRST LOCATION TO BE CLEARED
553	001744	005026		CLR	(R6)+		;CLEAR MEMORY LOCATION
554	001746	022706	001140	CMP	*SWR,R6 ; ;DONE?		
555	001752	001374		BNE	-6		;LOOP BACK IF NO
556	001754	012706	001100	MOV	*STACK,SP		;SETUP THE STACK POINTER
557				;;INITIALIZE A FEW VECTORS			
558	001760	012737	016404	MOV	*\$SCOPE,2*10TVEC		;IOT VECTOR FOR SCOPE ROUTINE
559	001766	012737	000340	MOV	*340,2*10TVEC+2		;LEVEL 7
560	001774	012737	016666	MOV	*\$ERROR,2*EMTVEC		;EMT VECTOR FOR ERROR ROUTINE
561	002002	012737	000340	MOV	*340,2*EMTVEC+2		;LEVEL 7
562	002010	012737	021262	MOV	*\$TRAP,2*TRAPVEC		;TRAP VECTOR FOR TRAP CALLS
563	002016	012737	000340	MOV	*340,2*TRAPVEC+2		;LEVEL 7
564	002024	012737	020064	MOV	*\$PWARN,2*PWAVEC		;POWER FAILURE VECTOR

```

565 002032 012737 000340 000026      MOV      #340,2#PWRVEC+2 ;:LEVEL 7
566 002040 013737 013714 013706      MOV      $ENDCT,$EOPCT ;:SETUP END-OF-PROGRAM COUNTER
567 002046 005037 001166              CLR      $TIMES ;:INITIALIZE NUMBER OF ITERATIONS
568 002052 005037 001170              CLR      $ESCAPE ;:CLEAR THE ESCAPE ON ERROR ADDRESS
569 002056 112737 000001 001115      MOV      #1,$SERMAX ;:ALLOW ONE ERROR PER TEST
570 002064 012737 002064 001106      MOV      #,$SLPADR ;:INITIALIZE THE LOOP ADDRESS FOR SCOPE
571 002072 012737 002072 001110      MOV      #,$SLPERR ;:SETUP THE ERROR LOOP ADDRESS
572                                     ;:SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
573                                     ;:EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
574 002100 013746 000004              MOV      2#ERRVEC-(SP) ;:SAVE ERROR VECTOR
575 002104 012737 002140 000004      MOV      66$,$ERRVEC ;:SET UP ERROR VECTOR
576 002112 012737 177570 001140      MOV      #DSWR,SWR ;:SETUP FOR A HARDWARE SWICH REGISTER
577 002120 012737 177570 001142      MOV      #DDISP,DISPLAY ;:AND A HARDWARE DISPLAY REGISTER
578 002126 022777 177777 177004      CMP      #-1,$SWR ;:TRY TO REFERENCE HARDWARE SWR
579 002134 001012                    BNE      67$ ;:BRANCH IF NO TIMEOUT TRAP OCCURRED
580                                     ;:AND THE HARDWARE SWR IS NOT = -1
581 002136 000403                    CR      66$ ;:BRANCH IF NO TIMEOUT
582 002140 012716 002146              MOV      #66$,(SP) ;:SET UP FOR TRAP RETURN
583 002144 000002                    RTI
584 002146 012737 000176 001140 66$: MOV      #SWREG,SWR ;:POINT TO SOFTWARE SWR
585 002154 012737 000174 001142      MOV      #DISPR$G,DISPLAY
586 002162 012637 000004 67$: MOV      (SP)+,2#ERRVEC ;:RESTORE ERROR VECTOR
587
588 002166 005037 001204              CLR      $PASS ;:CLEAR PASS COUNT
589 002172 132737 000200 001217      BITB     #APTSIZE,$ENVM ;:TEST USER SIZE UNDER APT
590 002200 001403                    BEQ      68$ ;:YES,USE NON-APT SWITCH
591 002202 012737 001220 001140      MOV      #SSWREG,SWR ;:NO,USE APT SWITCH REGISTER
592 002210                    68$:
593 002210 012706 001100              MOV      #STACK,SP ;:LOAD STACK
594 002214 012737 002262 000004      MOV      #15,2#4 ;:LOAD BUS ERROR
595 002222 013702 001252              MOV      $BASE,R2 ;:LOAD STARTING ADDRESS
596 002226 005003                    CLR      R3 ;:CLEAR COUNT
597 002230 010237 001670 2$: MOV      R2,$TMDAT
598
599 ;* MOV      2$TMDAT,$GDDAT ;:/READ DEVICE REG $TMDAT,PUT DATA IN $GDDAT.
600 002244 005737 022222              TST      $AERR
601 002250 001004                    BNE      1$
602 002252 062702 000020              ADD      #20,R2 ;:EXIST, UPDATE TEST ADDRESS
603 002256 005203                    INC      R3 ;:UPDATE # OF AR11'S
604 002260 000763                    BR      2$
605 002262 005703 1$: TST      R3 ;:TEST IF FIRST DOES EXIST
606 002264 001001                    BNE      3$ ;:BR
607 002266 000000                    HALT ;:FIRST AR11 DOES NOT EXIST
608                                     ;:CHECK THE PROGRAM DEVICE ADDRESS
609 002270 005303 3$: DEC      R3 ;:ADJUST R3
610 002272 010337 001650              MOV      R3,NMBEXT ;:SAVE THE NUMBER OF ADDITIONAL AR11
611 002276 012737 000006 000004      MOV      #6,2#4 ;:RESET BUS ERROR
612 002304 005037 000006              CLR      2#6
613 002310 013737 001252 001644      MOV      $BASE,ARBADD ;:LOAD FIRST ADDRESS
614 002316 013737 001246 001646      MOV      $VECT1,ARBVCT ;:LOAD FIRST VECTOR
615 002324 013737 001650 001652      MOV      NMBEXT,NBEXT ;:LOAD NUMBER OF AR11'S
616 002332 000240 RBEG1: NOP
617 002334 RBEG2:
618 002334 012702 000232              MOV      #232,R2 ;:LOAD R2

```

```

619 002340 012701 000230      5$: MOV    #230,R1          ;LOAD R1
620 002344 010221      MOV    R2,(R1)+      ;LOAD .+2
621 002346 005021      CLR     (R1)+        ;LOAD HALT
622 002350 010102      MOV    R1,R2        ;LOAD R2
623 002352 005722      TST     (R2)+        ;BUMP R2
624 002354 020227 001002      CMP    R2,#1002    ;TEST FOR LFST
625 002360 001371      BNE     5$           ;BR UNTIL DCNE
626 002362 005700      TST     R0           ;TEST R0
627 002364 001402      BEQ     2$           ;BR IF CLEARED
628 002366 000137 002642      JMP     4$           ;INHIBIT TYP0UT
629 002372 005737 000042      2$: TST     @#42      ;TEST ACT-11 OR DOP
630 002376 001402      BEQ     3$           ;BR IF CLEARED
631 002400 000137 002642      JMP     4$           ;INHIBIT TYP0UT
632 002404
633 002404 104401 002412      3$: TYPE    ,65$          ;;TYPE ASCIZ STRING
634 002410 000415      BR      64$          ;;GET OVER THE ASCIZ
635
636 002444      ;;65$: .ASCIZ  <15><12>/AR-11 DIAGNOSTIC TEST I/
637
638      .SBTTL TYPE PROGRAM NAME
639      ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
640 002444 005227 177777      INC     #-1          ;;FIRST TIME?
641 002450 001044      BNE     66$          ;;BRANCH IF NO
642 002452 022737 013746 000042      CMP    #SENDAD,@#42      ;;ACT-11?
643 002460 001440      BEQ     66$          ;;BRANCH IF YES
644 002462 104401 002530      TYPE    ,67$          ;;TYPE ASCIZ STRING
645 002466 005737 000042      .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
646 002472 001012      TST     @#42          ;;ARE WE RUNNING UNDER XXDP/ACT?
647 002474 123727 001216 000001      BNE     68$          ;;BRANCH IF YES
648 002502 001406      CMPB    $ENV,#1        ;;ARE WE RUNNING UNDER APT?
649 002504 023727 001140 000176      BEQ     68$          ;;BRANCH IF YES
650 002512 001005      CMP     SWR,#SWREG      ;;SOFTWARE SWITCH REG SELECTED?
651 002514 104406      BNE     69$          ;;BRANCH IF NO
652 002516 000403      GTSWR                ;;GET SOFT-SWR SETTINGS
653 002520 112737 000001 001134      BR      69$          ;
654 002526      68$: MOVB     #1,$AUTOB        ;;SET AUTO-MODE INDICATOR
655 002526 000415      69$: BR      66$          ;;GET OVER THE ASCIZ
656
657 002562      ;;67$: .ASCIZ  <CRLF><15><12>/MAINDEC-11-DRLPC-A/<15><12><CRLF>
658 002562 013746 001650      66$: MOV     NMBEXT,-(SP)      ;PUSH ON STACK
659 002566 104403      TYP0S                ;TYPE OCTAL
660 002570 000002      .WORD    2
661 002572 104401 002600      TYPE    ,71$          ;;TYPE ASCIZ STRING
662 002576 000421      BR      70$          ;;GET OVER THE ASCIZ
663
664 002642      ;;71$: .ASCIZ  /(8) ADDITIONAL AR11'S CONNECTED/<15><12>
665      70$:
666 002642 000240      4$: NOP
667 002644 012700 001610      MOV     #ADCS,R0          ;LOAD POINTER
668 002650 013720 001644      10$: MOV    ARBAD0,(R0)+      ;
669 002654 022700 001630      CMP     #ADINT,R0          ;TEST FOR END
670 002660 001373      BNE     10$
671 002662 013720 001646      11$: MOV    ARBVCT,(R0)+      ;LOAD VECTOR
672 002666 022700 001644      CMP     #ARBAD0,R0

```

```

673 002672 001373      BNE      11$
674 002674 012700 001612  MOV     #ADDBR,R0
675 002700 012701 000002  MOV     #2,R1
676 002704 060120      12$:  ADD     R1,(R0)+
677 002706 005721      TST     (R1)+
678 002710 022701 000020  CMP     #20,R1
679 002714 001373      BNE     12$
680 002716 005720      TST     (R0)+
681 002720 012701 000002  MOV     #2,R1
682 002724 060120      13$:  ADD     R1,(R0)+
683 002726 005721      TST     (R1)+
684 002730 022701 000014  CMP     #14,R1
685 002734 001373      BNE     13$
686
687 ;*****
688 ;*TEST 1 TEST EACH BUS ADDRESS FOR TIMEOUT
689 ;*****
689 002736 000004      TST1:  SCOPE
690
691 002740 005037 001540  CLR     .DVLS
692 002744 013737 001610 001126 2$:  MOV     ADCS,$BDDAT ;LOAD WITH BUS ADDRESS TO BE TESTED
693 002752
694
695 ;*      MOV     $GDDAT,$BDDAT ;/ PUT DATA FROM $GDDAT TO DEVICE REG $BDDAT
696
697 002762 005737 022222      TST     $AERR ;TEST ADDRESS
698 002766 001011      BNE     1$
699 002770 023737 001126 001626  CMP     $BDDAT,CSC ;TEST FOR LAST
700 002776 001404      BEQ     3$ ;BR IF DONE
701 003000 062737 000002 001126  ADD     #2,$BDDAT ;MAKE NEXT ADDRESS
702 003006 000761      BR      2$ ;TRY MORE
703 003010
704 003010 000403      3$:  BR      TST2 ;;BR TO NEXT TEST
705
706 003012 104015      1$:  ERROR   15 ;DEVICE BUS ERROR
707 003014 000137 013572  JMP     BYPASS ;DONT TEST ANY MORE
708
709
710 ;*****
711 ;*TEST 2 TEST THAT THE PRESET BUFFER CAN HOLD #0
712 ;*****
713 003020 000004      TST2:  SCOPE
714 003022 012737 000000 001124  MOV     #0,$GDDAT ;LOAD EXPECTED
715
716 ;*      MOV     $GDDAT,$CSB ;/ PUT DATA FROM $GDDAT TO DEVICE REG CSB
717
718 ;*      MOV     $CSB,$BDDAT ;/READ DEVICE REG CSB,PUT DATA IN $BDDAT.
719 003050 023737 001124 001126  CMP     $GDDAT,$BDDAT ;COMPARE
720 003056 001401      BEQ     TST3 ;;BR IF EQUAL
721 003060 104004      ERROR   4 ;ERROR, COUNTER PRESET FAILED TO CLEAR
722
723 ;*****
724 ;*TEST 3 TEST THE COUNTER PRESET BUFFER CAN HOLD #377
725 ;*****
726 003062 000004      TST3:  SCOPE

```

MAINDEC-11-DRLPC-A
DRLPC.P11 T3

MACY11 27(654) 15-DEC-77 10:54 PAGE 16
TEST THE COUNTER PRESET BUFFER CAN HOLD #377

SEQ 0025

```

727 003064 012737 000377 001124      MOV      #377,$GDDAT          ;LOAD EXPECTED
728
729      ;*      MOV      $GDDAT,$CSB      ;/ PUT DATA FROM $GDDAT TO DEVICE REG CSB
730
731      ;*      MOV      $CSB,$BDDAT      ;/READ DEVICE REG CSB,PUT DATA IN $BDDAT.
732 003112 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
733 003120 001401                      BEQ      TST4              ;;BR IF EQUAL
734 003122 104004                      ERROR      4              ;ERROR, COUNTER PRESET FAILED TO LOAD
735
736      ;*****
737      ;*TEST 4      TEST THAT PRESET BUFFER CAN HOLD #125
738      ;*****
739 003124 000004      TST4:  SCOPE
740 003126 012737 000125 001124      MOV      #125,$GDDAT          ;LOAD EXPECTED
741
742      ;*      MOV      $GDDAT,$CSB      ;/ PUT DATA FROM $GDDAT TO DEVICE REG CSB
743
744      ;*      MOV      $CSB,$BDDAT      ;/READ DEVICE REG CSB,PUT DATA IN $BDDAT.
745 003154 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
746 003162 001401                      BEQ      TST5              ;;BR IF EQUAL
747 003164 104004                      ERROR      4              ;ERROR, COUNTER PRESET FAILED TO LOAD
748
749      ;*****
750      ;*TEST 5      TEST THAT PRESET BUFFER CAN HOLD #252
751      ;*****
752 003166 000004      TST5:  SCOPE
753 003170 012737 000252 001124      MOV      #252,$GDDAT          ;LOAD EXPECTED
754
755      ;*      MOV      $GDDAT,$CSB      ;/ PUT DATA FROM $GDDAT TO DEVICE REG CSB
756
757      ;*      MOV      $CSB,$BDDAT      ;/READ DEVICE REG CSB,PUT DATA IN $BDDAT.
758 003216 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
759 003224 001401                      BEQ      TST6              ;;BR IF EQUAL
760 003226 104004                      ERROR      4              ;ERROR, COUNTER PRESET FAILED TO LOAD
761
762      ;*****
763      ;*TEST 6      TEST THAT PRESET BUFFER CAN HOLD A COUNT PATTERN
764      ;*****
765 003230 000004      TST6:  SCOPE
766 003232 012737 003244 001110      MOV      #1$,$LPERR          ;LOAD ERROR SCOPE RETURN
767 003240 005037 001124                      CLR      $GDDAT          ;CLEAR PATTERN
768 003244
769      1$:
770      ;*      MOV      $GDDAT,$CSB      ;/ PUT DATA FROM $GDDAT TO DEVICE REG CSB
771
772      ;*      MOV      $CSB,$BDDAT      ;/READ DEVICE REG CSB,PUT DATA IN $BDDAT.
773 003264 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
774 003272 001401                      BEQ      2$              ;;BR IF EQUAL
775 003274 104004                      ERROR      4              ;PRESET BUFFER FAILED TO HOLD A COUNT PATTERN
776
777 003276 105237 001124      2$:  INCB      $GDDAT          ;UPDATE PATTERN
778 003302 001360                      BNE      1$              ;BR UNTIL DONE
779
780      ;*****

```

```

781 ;*TEST 7 TEST INIT TO CLEAR COUNT PRESET BUFFER WHEN IT IS =-1
782 ;*****
783 003304 000004 ;*ST7: SCOPE
784 003306 012737 000020 001166 MOV #20,$TIMES ;DO 20 ITERATIONS
785 003314 012737 000000 001124 MOV #0,$GDDAT ;LOAD EXPECTED
786 003322 012737 177777 001670 MOV #-1,$TMDAT
787
788 ;* MOV $TMDAT,$CSB ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSB
789 003340 004737 023174 JSR PC,$RESET
790
791 ;* MOV $CSB,$BDDAT ;/READ DEVICE REG CSB,PUT DATA IN $BDDAT.
792 003354 005737 001126 TST $BDDAT
793 003360 001401 BEQ TST10 ;BR IF EQUAL
794 003362 104004 ERROR 4 ;ERROR, INIT FAILED TO cLEAR CSB
795
796 ;*****
797 ;*TEST 10 TEST THAT THE COUNTER CAN HOLD #0
798 ;*****
799 003364 000004 ;*ST10: SCOPE
800 003366 012737 000000 001124 MOV #0,$GDDAT ;LOAD EXPECTED
801
802 ;* MOV $GDDAT,$CSB ;/ PUT DATA FROM $GDDAT TO DEVICE REG CSB
803
804 ;* MOV $CSB,$BDDAT ;/READ DEVICE REG CSC,PUT DATA IN $BDDAT.
805 003414 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE
806 003422 001401 BEQ TST11 ;BR IF EQUAL
807 003424 104006 ERROR 6 ;ERROR, COUNTER FAILED TO CLEAR
808
809 ;*****
810 ;*TEST 11 TEST THE COUNTER CAN HOLD #377
811 ;*****
812 003426 000004 ;*ST11: SCOPE
813 003430 012737 000377 001124 MOV #377,$GDDAT ;LOAD EXPECTED
814
815 ;* MOV $GDDAT,$CSB ;/ PUT DATA FROM $GDDAT TO DEVICE REG CSB
816
817 ;* MOV $CSB,$BDDAT ;/READ DEVICE REG CSC,PUT DATA IN $BDDAT.
818 003456 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE
819 003464 001401 BEQ TST12 ;BR IF EQUAL
820 003466 104006 ERROR 6 ;ERROR, COUNTER FAILED TO LOAD
821
822 ;*****
823 ;*TEST 12 TEST THAT COUNTER CAN HOLD #125
824 ;*****
825 003470 000004 ;*ST12: SCOPE
826 003472 012737 000125 001124 MOV #125,$GDDAT ;LOAD EXPECTED
827
828 ;* MOV $GDDAT,$CSB ;/ PUT DATA FROM $GDDAT TO DEVICE REG CSB
829
830 ;* MOV $CSB,$BDDAT ;/READ DEVICE REG CSC,PUT DATA IN $BDDAT.
831 003520 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE
832 003526 001401 BEQ TST13 ;BR IF EQUAL
833 003530 104006 ERROR 6 ;ERROR, COUNTER FAILED TO LOAD
834

```

```

835
836
837
838
839 003532 000004
840 003534 012737 000252 001124
841
842
843
844
845 003562 023737 001124 001126
846 003570 001401
847 003572 104006
848
849
850
851
852 003574 000004
853 003576 012737 003610 001110
854 003604 005037 001124
855 003610
856
857
858
859
860 003630 023737 001124 001126
861 003636 001401
862 003640 104006
863
864 003642 105237 001124
865 003646 001360
866
867
868
869
870 003650 000004
871 003652 012737 000000 001124
872 003660 012737 177777 001670
873
874
875 003676 004737 023174
876
877
878 003712 005737 001126
879 003716 001401
880 003720 104006
881
882
883
884
885
886 003722 000004
887 003724 012737 000021 001124
888

;*****
;TEST 13 TEST THAT COUNTER CAN HOLD #252
;*****
TST13: SCOPE
MOV #252,$GDDAT ;LOAD EXPECTED
;
MOV $GDDAT,$CSB ;PUT DATA FROM $GDDAT TO DEVICE REG CSB
;
MOV $CSC,$BDDAT ;READ DEVICE REG CSC,PUT DATA IN $BDDAT.
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST14 ;BR IF EQUAL
ERROR 6 ;ERROR, COUNTER FAILED TO LOAD

;*****
;TEST 14 TEST THAT COUNTER CAN HOLD A COUNT PATTERN
;*****
TST14: SCOPE
MOV #1,$LPERR ;LOAD ERROR SCOPE RETURN
CLR $GDDAT ;CLEAR PATTERN
1$:
;
MOV $GDDAT,$CSB ;PUT DATA FROM $GDDAT TO DEVICE REG CSB
;
MOV $CSC,$BDDAT ;READ DEVICE REG CSC,PUT DATA IN $BDDAT.
CMP $GDDAT,$BDDAT ;COMPARE
BEQ 2$ ;BR IF EQUAL
ERROR 6 ;COUNTER FAILED TO HOLD A COUNT PATTERN
2$: INCB $GDDAT ;UPDATE PATTERN
BNE 1$ ;BR UNTIL DONE

;*****
;TEST 15 TEST INIT TO CLEAR COUNTER WHEN IT IS --1
;*****
TST15: SCOPE
MOV #0,$GDDAT ;LOAD EXPECTED
MOV #-1,$TMDAT
;
MOV $TMDAT,$CSB ;PUT DATA FROM $TMDAT TO DEVICE REG CSB
JSR PC,$RESET
;
MOV $CSC,$BDDAT ;READ DEVICE REG CSC,PUT DATA IN $BDDAT.
TST $BDDAT
BEQ TST16 ;BR IF EQUAL
ERROR 6 ;ERROR, INIT FAILED TO CLEAR COUNTER

;*****
;TEST 16 TEST ENABLE COUNTER (BIT 0) CAN BE SET
;*****
TST16: SCOPE
MOV #BIT4!BIT0,$GDDAT ;LOAD EXPECTED

```

```

889      ;*      MOV      $GDDAT,$CSR      ;/ PUT DATA FROM $GDDAT TO DEVICE REG CSR
890
891      ;*      MOV      $CSR,$BDDAT      ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
892      003752  023737  001124  001126      ;*      CMP      $GDDAT,$BDDAT      ;COMPARE
893      003760  001401      BEQ      TST17      ;;BR IF EQUAL
894      003762  104003      ERROR      3      ;ERROR COUNTER ENABLE FAILED TO SET
895
896      ;*****
897      ;*TEST 17      TEST RATE SELECT (BIT 1) MAY BE SET
898      ;*****
899      003764  000004      TST17:  SCOPE
900      003766  012737  000022  001124      MOV      #BIT4!BIT1,$GDDAT      ;LOAD EXPECTED
901
902      ;*      MOV      $GDDAT,$CSR      ;/ PUT DATA FROM $GDDAT TO DEVICE REG CSR
903
904      ;*      MOV      $CSR,$BDDAT      ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
905      004014  023737  001124  001126      ;*      CMP      $GDDAT,$BDDAT      ;COMPARE
906      004022  001401      BEQ      TST20      ;;BR IF EQUAL
907      004024  104003      ERROR      3      ;ERROR, RATE BIT 1 FAILED TO SET
908
909      ;*****
910      ;*TEST 20      TEST THAT RATE SELECT (BIT 2) MAY BE SET
911      ;*****
912      004026  000004      TST20:  SCOPE
913      004030  012737  000024  001124      MOV      #BIT4!BIT2,$GDDAT      ;LOAD EXPECTED
914
915      ;*      MOV      $GDDAT,$CSR      ;/ PUT DATA FROM $GDDAT TO DEVICE REG CSR
916
917      ;*      MOV      $CSR,$BDDAT      ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
918      004056  023737  001124  001126      ;*      CMP      $GDDAT,$BDDAT      ;COMPARE
919      004064  001401      BEQ      TST21      ;;BR IF EQUAL
920      004066  104003      ERROR      3      ;ERROR, RATE BIT 2 FAILED TO SET
921
922      ;*****
923      ;*TEST 21      TEST THAT RATE SELECT (BIT 3) MAY BE SET
924      ;*****
925      004070  000004      TST21:  SCOPE
926      004072  012737  000030  001124      MOV      #BIT4!BIT3,$GDDAT      ;LOAD EXPECTED
927
928      ;*      MOV      $GDDAT,$CSR      ;/ PUT DATA FROM $GDDAT TO DEVICE REG CSR
929
930      ;*      MOV      $CSR,$BDDAT      ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
931      004120  023737  001124  001126      ;*      CMP      $GDDAT,$BDDAT      ;COMPARE
932      004126  001401      BEQ      TST22      ;;BR IF EQUAL
933      004130  104003      ERROR      3      ;ERROR, RATE BIT 3 FAILED TO SET
934
935      ;*****
936      ;*TEST 22      TEST CLOCK INTERRUPT ENABLE (BIT 6) CAN BE SET
937      ;*****
938      004132  000004      TST22:  SCOPE
939      004134  012737  000120  001124      MOV      #BIT6!BIT4,$GDDAT      ;LOAD EXPECTED
940
941      ;*      MOV      $GDDAT,$CSR      ;/ PUT DATA FROM $GDDAT TO DEVICE REG CSR
942

```

MAINDEC-11-DRLPC-A
DRLPC.P11 T22

MACY11 27(654) 15-DEC-77 10:54 PAGE 20
TEST CLOCK INTERRUPT ENABLE (BIT 6) CAN BE SET

SEQ 0029

```

943      ;*      MOV      QCSR,$BDDAT      ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
944 004162 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
945 004170 001401      BEQ      TST23      ;;BR IF EQUAL
946 004172 104003      ERROR      3      ;ERROR, CLOCK INTERRUPT ENABLE FAILED TO SET
947
948      ;*****
949      ;*TEST 23      TEST MODE (BIT 8) CAN BE SET
950      ;*****
951 004174 000004      TST23: SCOPE
952 004176 012737 000420 001124      MOV      #BIT8!BIT4,$GDDAT      ;LOAD EXPECTED
953
954      ;*      MOV      $GDDAT,QCSR      ;/ PUT DATA FROM $GDDAT TO DEVICE REG CSR
955
956      ;*      MOV      QCSR,$BDDAT      ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
957 004224 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
958 004232 001401      BEQ      TST24      ;;BR IF EQUAL
959 004234 104003      ERROR      3      ;ERROR, CSR NOT = 420
960
961      ;*****
962      ;*TEST 24      TEST EXT INTERRUPT ENABLE (BIT 14) CAN BE SET
963      ;*****
964 004236 000004      TST24: SCOPE
965 004240 012737 040020 001124      MOV      #BIT14!BIT4,$GDDAT      ;LOAD EXPECTED
966
967      ;*      MOV      $GDDAT,QCSR      ;/ PUT DATA FROM $GDDAT TO DEVICE REG CSR
968
969      ;*      MOV      QCSR,$BDDAT      ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
970 004266 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
971 004274 001401      BEQ      TST25      ;;BR IF EQUAL
972 004276 104003      ERROR      3      ;ERROR, EXT INTERRUPT ENABLE FAILED TO SET
973
974      ;*****
975      ;*TEST 25      TEST THAT CLK DONE (BIT 7) CAN BE SET
976      ;*****
977 004300 000004      TST25: SCOPE
978 004302 012737 000220 001124      MOV      #BIT7!BIT4,$GDDAT      ;LOAD EXPECTED
979
980      ;*      MOV      $GDDAT,QCSR      ;/ PUT DATA FROM $GDDAT TO DEVICE REG CSR
981
982      ;*      MOV      QCSR,$BDDAT      ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
983 004330 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
984 004336 001401      BEQ      TST26      ;;BR IF EQUAL
985 004340 104003      ERROR      3      ;CLOCK DONE FAILED TO SET
986
987      ;*****
988      ;*TEST 26      TEST THAT CLK EXT INPUT (BIT 15) CAN BE SET
989      ;*****
990 004342 000004      TST26: SCOPE
991 004344 012737 100020 001124      MOV      #BIT15!BIT4,$GDDAT      ;LOAD EXPECTED
992
993      ;*      MOV      $GDDAT,QCSR      ;/ PUT DATA FROM $GDDAT TO DEVICE REG CSR
994
995      ;*      MOV      QCSR,$BDDAT      ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
996 004372 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
997 004400 001401      BEQ      TST27      ;;BR IF EQUAL

```

E03

 MAINDEC-11-DRLPC-A
 DRLPC.P11 T26

 MACY11 27(654) 15-DEC-77 10:54 PAGE 21
 TEST THAT CLK EXT INPUT (BIT 15) CAN BE SET

SEQ 0030

```

997 004402 104003          ERROR 3          ;CLOCK EXT INPUT FAILED TO SET
998          ;*****
999          ;*TEST 27          TEST THAT THE EXT FLAG DOES NOT SET FROM THE OUTSIDE SOURCE
1000          ;*****
1001 004404 000004          ;ST27: SCOPE
1002 004406 012737 000000 001670      MOV      #0,$TMDAT
1003
1004          ;*      MOV      $TMDAT,$CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1005 004424 012737 000020 001124      MOV      #BIT4,$GDDAT      ;LOAD EXPECTED
1006 004432 005037 001660          CLR      TEMP
1007 004436          1$:
1008
1009          ;*      MOV      $CSR,$BDDAT      ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
1010 004446 005737 001126          TST      $BDDAT      ;TEST BIT15
1011 004452 100001          BPL      2$      ;;BR IF CLEARED
1012 004454 104003          ERROR 3          ;ERROR EXT FLG SET IN ERROR
1013 004456 005237 001660          2$:      INC      TEMP
1014 004462 001365          BNE      1$
1015          ;*****
1016          ;*TEST 30          MAINT. COUNT THE COUNTER REGISTER AT RATE 1MHZ
1017          ;*****
1018 004464 000004          ;ST30: SCOPE
1019 004466 012737 000004 001166      MOV      #4,$TIMES      ;;DO 4 ITERATIONS
1020 004474 005037 001670          CLR      $TMDAT
1021
1022          ;*      MOV      $TMDAT,$CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1023
1024          ;*      MOV      $TMDAT,$CSB      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSB
1025 004520 012737 000002 001670      MOV      #2,$TMDAT      ;SET UP 1MHZ RATE
1026
1027          ;*      MOV      $TMDAT,$CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1028 004536 005037 001660          CLR      TEMP      ;CLEAR PATTERN
1029 004542 013737 001660 001124      1$:      MOV      TEMP,$GDDAT      ;LOAD EXPECTED
1030
1031          ;*      MOV      $CSC,$BDDAT      ;/READ DEVICE REG CSC,PUT DATA IN $BDDAT.
1032 004560 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMP
1033 004566 001401          BEQ      2$      ;;BR IF EQUAL
1034 004570 104007          ERROR 7          ;ERROR, CLOCK COUNTER
1035          ;BUFFER COUNTED IN ERROR
1036 004572          2$:
1037
1038          ;*      MOV      $CSR,$BDDAT      ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
1039 004602 105737 001126          TSTB     $BDDAT
1040 004606 100005          BPL      3$      ;;BR IF CLEAR
1041 004610 012737 000022 001124      MOV      #22,$GDDAT      ;LOAD EXPECTED STATUS
1042 004616 104003          ERROR 3          ;CLK DONE SET IN ERROR
1043 004620 000431          BR      TST31      ;;BR TO SCOPE
1044 004622          3$:
1045
1046          ;*      MOV      $CSR,$TMDAT      ;/READ DEVICE REG CSR,PUT DATA IN $TMDAT.
1047 004632 052737 004000 001670      BIS      #BIT11,$TMDAT
1048
1049          ;*      MOV      $TMDAT,$CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1050

```

```

1051      ;*      MOV      @CSR,$TMDAT      ;/READ DEVICE REG CSR,PUT DATA IN $TMDAT.
1052      004660  042737  004000  001670      BIC      #BIT11,$TMDAT
1053
1054      ;*      MOV      $TMDAT,@CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1055      004676  105237  00.660      INCB     TEMP
1056      004702  001317      BNE      1$      ;BRANCH IF NOT FULL COUNT
1057
1058      ;*****
1059      ;*TEST 31      TEST THAT OVERFLOW SET CLK DONE (BIT 7)
1060      ;*****
1061      004704  000004      $ST31:  SCOPE
1062      004706  012737  000000  001670      MOV      #0,$TMDAT      ;CLEAR STATUS
1063
1064      ;*      MOV      $TMDAT,@CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1065      004724  012737  177777  001670      MOV      #-1,$TMDAT      ;LOAD PRESET
1066
1067      ;*      MOV      $TMDAT,@CSB      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSB
1068      004742  012737  000002  001670      MOV      #BIT1,$TMDAT      ;LOAD 1 MHZ. RATE
1069
1070      ;*      MOV      $TMDAT,@CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1071      004760  012737  000222  001124      MOV      #BIT7:BIT4:BIT1,$GDDAT      ;LOAD EXPECTED
1072
1073      ;*      MOV      @CSR,$TMDAT      ;/READ DEVICE REG CSR,PUT DATA IN $TMDAT.
1074      004776  052737  004000  001670      BIS      #BIT11,$TMDAT      ;MAINT COUNT
1075
1076      ;*      MOV      $TMDAT,@CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1077
1078      ;*      MOV      @CSR,$TMDAT      ;/READ DEVICE REG CSR,PUT DATA IN $TMDAT.
1079      005024  042737  004000  001670      BIC      #BIT11,$TMDAT      ;CLEAR BIT
1080
1081      ;*      MOV      $TMDAT,@CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1082
1083      ;*      MOV      @CSR,$BDDAT      ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
1084      005052  105737  001126      TSTB     $BDDAT      ;TEST BIT 7
1085      005056  100401      BMI      TST32      ;BR IF MINUS
1086      005060  104003      ERROR      3      ;ERROR, OVERFLOW FAILED TO SET BIT 7
1087      ;*****
1088      ;*TEST 32      MAINT. COUNT THE COUNTER REGISTER AT RATE #100KHZ
1089      ;*****
1090      005062  000004      $ST32:  SCOPE
1091      005064  012737  000004  001166      MOV      #4,$TIMES      ;;DO 4 ITERATIONS
1092      005072  012737  000000  001670      MOV      #0,$TMDAT      ;CLEAR CLOCK STATUS
1093
1094      ;*      MOV      $TMDAT,@CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1095
1096      ;*      MOV      $TMDAT,@CSB      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSB
1097      005120  005037  001124      CLR      $GDDAT
1098      005124  012737  000004  001670      MOV      #4,$TMDAT      ;LOAD STATUS, 100KHZ RATE
1099
1100      ;*      MOV      $TMDAT,@CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1101      005142  005037  001124      CLR      $GDDAT
1102      005146      1$:
1103
1104      ;*      MOV      @CSC,$BDDAT      ;/READ DEVICE REG CSC,PUT DATA IN $BDDAT.

```

1105	005156	023737	001124	001126		CMP	\$GDDAT,\$BDDAT		;COMPARE
1106	005164	001401				BEG	2\$		;BR IF EQUAL
1107	005166	104007				ERROR	7		;ERROR, CLOCK COUNTER BUFFER
1108									;COUNTED IN ERROR, FAULT IS PROBABLY IN THE
1109									;CLOCK UP COUNT OR RATE SELECTION LOGIC
1110	005170	012737	000012	001654	2\$:	MOV	#10.,COUNT		;LOAD COUNT
1111	005176				3\$:				
1112									
1113					*:	MOV	@CSR,\$TMDAT		; /READ DEVICE REG CSR,PUT DATA IN \$TMDAT.
1114	005206	052737	004000	001670		BIS	#BIT11,\$TMDAT		
1115									
1116					*:	MOV	\$TMDAT,@CSR		; / PUT DATA FROM \$TMDAT TO DEVICE REG CSR
1117									
1118					*:	MOV	@CSR,\$TMDAT		; /READ DEVICE REG CSR,PUT DATA IN \$TMDAT.
1119	005234	042737	004000	001670		BIC	#BIT11,\$TMDAT		
1120									
1121					*:	MOV	\$TMDAT,@CSR		; / PUT DATA FROM \$TMDAT TO DEVICE REG CSR
1122	005252	005337	001654			DEC	COUNT		;DONE
1123	005256	001347				BNE	3\$		;BR IF NOT
1124	005260	105237	001124			INCB	\$GDDAT		;INCREMENT EXPECTED VALUE
1125	005264	001330				BNE	1\$		
1126									
1127									
1128									
1129									
1130	005266	000004							
1131	005270	012737	000004	001166					
1132	005276	012737	000000	001670					
1133									
1134									
1135					*:	MOV	\$TMDAT,@CSR		; / PUT DATA FROM \$TMDAT TO DEVICE REG CSR
1136					*:	MOV	\$TMDAT,@CSB		; / PUT DATA FROM \$TMDAT TO DEVICE REG CSB
1137	005324	012737	000006	001670		MOV	#6,\$TMDAT		;LOAD STATUS. 10KHZ RATE
1138									
1139					*:	MOV	\$TMDAT,@CSR		; / PUT DATA FROM \$TMDAT TO DEVICE REG CSR
1140	005342	005037	001124			CLR	\$GDDAT		
1141	005346				1\$:				
1142									
1143					*:	MOV	@CSC,\$BDDAT		; /READ DEVICE REG CSC,PUT DATA IN \$BDDAT.
1144	005356	023737	001124	001126		CMP	\$GDDAT,\$BDDAT		;COMPARE
1145	005364	001401				BEG	2\$		;BR IF EQUAL
1146	005366	104007				ERROR	7		;ERROR, CLOCK COUNTER BUFFER
1147									;COUNTED IN ERROR, FAULT IS PROBABLY IN THE
1148									;CLOCK UP COUNT OR RATE SELECTION LOGIC
1149	005370	012737	000144	001654	2\$:	MOV	#100.,COUNT		;LOAD COUNT
1150	005376				3\$:				
1151									
1152					*:	MOV	@CSR,\$TMDAT		; /READ DEVICE REG CSR,PUT DATA IN \$TMDAT.
1153	005406	052737	004000	001670		BIS	#BIT11,\$TMDAT		
1154									
1155					*:	MOV	\$TMDAT,@CSR		; / PUT DATA FROM \$TMDAT TO DEVICE REG CSR
1156									
1157					*:	MOV	@CSR,\$TMDAT		; /READ DEVICE REG CSR,PUT DATA IN \$TMDAT.
1158	005434	042737	004000	001670		BIC	#BIT11,\$TMDAT		

H03

MAINDEC-11-DRLPC-A
DRLPC.P11 T33

MACY11 27(654) 15-DEC-77 10:54 PAGE 24
MAINT. COUNT THE COUNTER REGISTER AT RATE #10KHZ

SEQ 0033

```

1159
1160 ;*      MOV      $TMDAT,$CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1161 005452 005337 001654      DEC      COUNT      ; DONE
1162 005456 001347      BNE      3$      ; BR IF NOT
1163 005460 105237 001124      INCB     $GDDAT      ; UPDATE PATTERN
1164 005464 001330      BNE      1$      ; BR IF NOT
1165 ;*****
1166 ;*TEST 34      MAINT. COUNT THE COUNTER REGISTER AT RATE #1KHZ
1167 ;*****
1168 005466 000004      ST34:  SCOPE
1169 005470 012737 000004 001166      MOV      #4,$TIMES      ;;DO 4 ITERATIONS
1170 005476 012737 000000 001670      MOV      #0,$TMDAT      ;CLEAR CLOCK STATUS
1171
1172 ;*      MOV      $TMDAT,$CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1173
1174 ;*      MOV      $TMDAT,$CSB      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSB
1175 005524 012737 000001 001124      MOV      #1,$GDDAT      ;LOAD EXPECTED
1176 005532 012737 000010 001670      MOV      #10,$TMDAT      ;LOAD STATUS, 1 KHZ RATE
1177
1178 ;*      MOV      $TMDAT,$CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1179 005550 012737 001750 001654      MOV      #1000.,COUNT      ;SET UP A COUNTER
1180 005556
1181
1182 ;*      MOV      $CSR,$TMDAT      ;/READ DEVICE REG CSR,PUT DATA IN $TMDAT.
1183 005566 052737 004000 001670      BIS      #BIT11,$TMDAT
1184
1185 ;*      MOV      $TMDAT,$CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1186
1187 ;*      MOV      $CSR,$TMDAT      ;/READ DEVICE REG CSR,PUT DATA IN $TMDAT.
1188 005614 042737 004000 001670      BIC      #BIT11,$TMDAT
1189
1190 ;*      MOV      $TMDAT,$CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1191 005632 005337 001654      DEC      COUNT
1192 005636 001347      BNE      1$      ;BR
1193
1194 ;*      MOV      $CSC,$BDDAT      ;/READ DEVICE REG CSC,PUT DATA IN $BDDAT.
1195 005650 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
1196 005656 001401      BEQ      TST35      ;;BR IF EQUAL
1197 005660 104007      ERROR      7      ;ERROR, CLOCK COUNTER BUFFER
1198 ;COUNTED IN ERROR, FAULT IS PROBABLY IN THE
1199 ;CLOCK UP COUNT OR RATE SELECTION LOGIC
1200
1201 ;*****
1202 ;*TEST 35      MAINT. COUNT THE COUNTER REGISTER AT RATE #100HZ
1203 ;*****
1204 005662 000004      ST35:  SCOPE
1205 005664 012737 000004 001166      MOV      #4,$TIMES      ;;DO 4 ITERATIONS
1206 005672 012737 000000 001670      MOV      #0,$TMDAT      ;CLEAR CLOCK STATUS, 100HZ RATE
1207
1208 ;*      MOV      $TMDAT,$CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1209
1210 ;*      MOV      $TMDAT,$CSB      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSB
1211 005720 012737 000001 001124      MOV      #1,$GDDAT      ;LOAD EXPECTED
1212 005726 012737 000012 001670      MOV      #12,$TMDAT      ;LOAD STATUS, 100 HZ

```

```

1213
1214
1215 005744 012737 023420 001654 ;*      MOV      $TMDAT,$CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1216 005752                                1$:      MOV      #10000.,COUNT      ;SET UP A COUNTER
1217
1218
1219 005762 052737 004000 001670 ;*      MOV      $CSR,$TMDAT      ;/READ DEVICE REG CSR,PUT DATA IN $TMDAT.
1220                                BIS      #BIT11,$TMDAT
1221
1222
1223
1224 006010 042737 004000 001670 ;*      MOV      $TMDAT,$CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1225                                BIC      #BIT11,$TMDAT      ;/READ DEVICE REG CSR,PUT DATA IN $TMDAT.
1226
1227
1228 006026 005337 001654 ;*      MOV      $TMDAT,$CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1229 006032 001347                                DEC      COUNT
1230                                BNE      1$      ;BR
1231
1232
1233 006044 023737 001124 001126 ;*      MOV      $CSR,$BDDAT      ;/READ DEVICE REG CSC,PUT DATA IN $BDDAT.
1234 006052 001401                                CMP      $GDDAT,$BDDAT      ;COMPARE
1235 006054 104007                                BEQ      TST36      ;.BR IF EQUAL
1236                                ERROR      7      ;ERROR, CLOCK COUNTER BUFFER
1237                                ;COUNTED IN ERROR, FAULT IS PROBABLY IN THE
1238                                ;CLOCK UP COUNT OR RATE SELECTION LOGIC
1239
1240
1241
1242
1243
1244
1245 006104 012737 000020 001124 ;*      MOV      $TMDAT,$CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1246 006112 004737 023174                                MOV      #20,$GDDAT
1247                                JSR      PC,$RESET
1248
1249
1250 006126 023737 001124 001126 ;*      MOV      $CSR,$BDDAT      ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
1251 006134 001401                                CMP      $GDDAT,$BDDAT      ;COMPARE
1252 006136 104003                                BEQ      TST37      ;.BR IF EQUAL
1253                                ERROR      3      ;ERROR, RESET FAILED TO CLEAR RATE OR MODE BITS
1254
1255
1256
1257
1258
1259
1260
1261 006166 012737 000020 001124 ;*      MOV      $TMDAT,$CSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1262 006174 004737 023174                                MOV      #20,$GDDAT
1263                                JSR      PC,$RESET
1264
1265
1266 006210 023737 001124 001126 ;*      MOV      $CSR,$BDDAT      ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
1267 006216 001401                                CMP      $GDDAT,$BDDAT      ;COMPARE
1268                                BEQ      TST40      ;.BR IF EQUAL
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500

```

MAINDEC-11-DRLPC-A
DRLPC.P11 T37MACY11 27(654) 15-DEC-77 10:54 PAGE 26
TEST THAT RESET CLEARS CLK INTERRUPT ENABLE

SEQ 0035

```

1267 006220 104003          ERROR 3          ;ERROR, RESET FAILED TO CLEAR CLK INT ENABLE
1268
1269
1270 ;*****
1271 ;*TEST 40          TEST THAT RESET CLEARS CLK FLAGS
1272 ;*****
1273 006222 000004          ST40: SCOPE
1274 006224 012737 000002 001166          MOV #2,$TIMES          ;;DO 2 ITERATIONS
1275 006232 012737 100200 001670          MOV #BIT7!BIT15,$TMDAT          ;SET CLK FLAGS
1276
1277 ;*          MOV $TMDAT,$CSR          ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1278 006250 012737 000020 001124          MOV #20,$GDDAT
1279 006256 004737 023174          JSR PC,$RESET
1280
1281 ;*          MOV $CSR,$BDDAT          ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
1282 006272 023737 001124 001126          CMP $GDDAT,$BDDAT
1283 006300 001401          BEQ TST41          ;;BR IF EQUAL
1284 006302 104003          ERROR 3          ;ERROR, RESET FAILED TO CLEAR CLK FLAGS
1285
1286 ;*****
1287 ;*TEST 41          TEST THAT RESET CLEARS COUNTER ENABLE
1288 ;*****
1289 006304 000004          ST41: SCOPE
1290 006306 012737 000002 001166          MOV #2,$TIMES          ;;DO 2 ITERATIONS
1291 006314 012737 000000 001670          MOV #0,$TMDAT          ;CLEAR COUNTER
1292
1293 ;*          MOV $TMDAT,$CSB          ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSB
1294 006332 012737 000001 001670          MOV #BIT0,$TMDAT          ;LOAD COUNTER ENABLE
1295
1296 ;*          MOV $TMDAT,$CSR          ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
1297 006350 012737 000020 001126          MOV #20,$BDDAT
1298 006356 004737 023174          JSR PC,$RESET
1299
1300 ;*          MOV $CSR,$BDDAT          ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
1301 006372 023737 001124 001126          CMP $GDDAT,$BDDAT
1302 006400 001401          BEQ TST42          ;;BR IF EQUAL
1303 006402 104003          ERROR 3          ;ERROR, RESET FAILED TO CLEAR COUNTER ENABLE
1304
1305 ;*****
1306 ;*TEST 42          TEST CLOCK TO COUNT UP AT 1 MHZ
1307 ;*****
1308 006404 000004          ST42: SCOPE
1309 006406 012737 000020 001166          MOV #20,$TIMES          ;;DO 20 ITERATIONS
1310 006414 012737 000003 014610          MOV #3,RATE          ;SELECT MODE 0, 1MHZ.. GO
1311 006422 012737 000222 001124          MOV #BIT7!BIT4!BIT1,$GDDAT
1312 006430 004737 014002          JSR PC,UPCNT
1313
1314 ;*          MOV $CSR,$BDDAT          ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
1315 006444 023737 001124 001126          CMP $GDDAT,$BDDAT          ;COMPARE
1316 006452 001401          BEQ 1$          ;;BR IF EQUAL
1317 006454 104003          ERROR 3          ;ERROR, 1MHZ RATE FAILED TO SET DONE
1318 006456 012737 000000 001124 1$: MOV #0,$GDDAT
1319
1320 ;*          MOV $CSC,$BDDAT          ;/READ DEVICE REG CSC,PUT DATA IN $BDDAT.

```

K03

MAINDEC-11-DRLPC-A
DRLPC.P11 T42MACY11 27(654) 15-DEC-77 10:54 PAGE 27
TEST CLOCK TO COUNT UP AT 1 MHZ

SEQ 0036

```

1321 006474 023737 001124 001126      CMP      $GDDAT,$BDDAT
1322 006502 001401      BEQ      TST43      ;;BR IF EQUAL
1323 006504 104006      ERROR    6      ;IN MODE 0 CLOCK COUNTER WAS
1324                                     ;LOADED ON CLK OVERFLOW
1325
1326      ;*****
1327      ;*TEST 43      TEST CLOCK TO COUNT UP AT 100KHZ
1328      ;*****
1329 006506 000004      TST43:  SCOPE
1330 006510 012737 000020 001166      MOV      #20,$TIMES      ;;DO 20 ITERATIONS
1331 006516 012737 000005 014610      MOV      #5,RATE      ;SELECT MODE 0, 100KHZ., GO
1332 006524 012737 000224 001124      MOV      #BIT7!BIT4!BIT2,$GDDAT
1333 006532 004737 014002      JSR      PC,UPCNT
1334
1335      ;*      MOV      @CSR,$BDDAT      ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
1336 006546 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
1337 006554 001401      BEQ      1$      ;;BR IF EQUAL
1338 006556 104003      ERROR    3      ;ERROR, 100KHZ. RATE FAILED TO SET DONE
1339 006560 012737 000000 001124 1$:  MOV      #0,$GDDAT
1340
1341      ;*      MOV      @CSC,$BDDAT      ;/READ DEVICE REG CSC,PUT DATA IN $BDDAT.
1342 006576 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
1343 006604 001401      BEQ      TST44      ;;BR IF EQUAL
1344 006606 104006      ERROR    6      ;IN MODE 0 CLOCK COUNTER WAS
1345                                     ;LOADED ON CLK OVERFLOW
1346
1347      ;*****
1348      ;*TEST 44      TEST CLOCK TO COUNT UP AT 10 KHZ
1349      ;*****
1350 006610 000004      TST44:  SCOPE
1351 006612 012737 000020 001166      MOV      #20,$TIMES      ;;DO 20 ITERATIONS
1352 006620 012737 000007 014610      MOV      #7,RATE      ;SELECT MODE 0, 10KHZ., GO
1353 006626 012737 000226 001124      MOV      #BIT7!BIT4!BIT2!BIT1,$GDDAT
1354 006634 004737 014002      JSR      PC,UPCNT
1355
1356      ;*      MOV      @CSR,$BDDAT      ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
1357 006650 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
1358 006656 001401      BEQ      TST45      ;;BR IF EQUAL
1359 006660 104007      ERROR    7      ;ERROR, 10 KHZ. FAILED TO SET DONE
1360
1361      ;*****
1362      ;*TEST 45      TEST CLOCK TO COUNT UP AT 1KHZ
1363      ;*****
1364 006662 000004      TST45:  SCOPE
1365 006664 012737 000005 001166      MOV      #5,$TIMES      ;;DO 5 ITERATIONS
1366 006672 012737 000011 014610      MOV      #11,RATE      ;SELECT MODE 0, 1 KHZ, GO
1367 006700 012737 000230 001124      MOV      #BIT7!BIT4!BIT3,$GDDAT
1368 006706 004737 014002      JSR      PC,UPCNT
1369
1370      ;*      MOV      @CSR,$BDDAT      ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
1371 006722 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
1372 006730 001401      BEQ      TST46      ;;BR IF EQUAL
1373 006732 104007      ERROR    7      ;ERROR, 1KHZ FAILED TO SET DONE

```

```

1375
1376
1377
1378
1379 006734 000004
1380 006736 012737 000005 001166
1381 006744 012737 000013 014610
1382 006752 012737 000232 001124
1383 006760 004737 014002
1384
1385
1386 006774 023737 001124 001126
1387 007002 001401
1388 007004 104007
1389
1390
1391
1392
1393 007006 000004
1394 007010 012737 000005 001166
1395 007016 012737 000411 014610
1396 007024 012737 000631 001124
1397 007032 004737 014002
1398
1399
1400 007046 023737 001124 001126
1401 007054 001401
1402 007056 104007
1403
1404 007060 012737 000376 001124
1405
1406
1407 007076 023737 001124 001126
1408 007104 001401
1409 007106 104006
1410
1411
1412
1413
1414
1415
1416 007110 000004
1417 007112 012737 000020 001166
1418 007120 012737 000413 014610
1419 007126 012737 000633 001124
1420 007134 004737 014002
1421
1422
1423 007150 023737 001124 001126
1424 007156 001401
1425 007160 104007
1426
1427 007162 012737 000376 001124
1428

```

```

;*****
;TEST 46 TEST CLOCK TO COUNT UP AT 100HZ
;*****
TST46: SCOPE
MOV #5,STIMES ;;DO 5 ITERATIONS
MOV #13,RATE ;;SELECT MODE 0, 100 HZ, GO
MOV #BIT7:BIT4:BIT3:BIT1,$GDDAT ;;LOAD EXPECTED
JSR PC,UPCNT

;* MOV QCSR,$BDDAT ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST47 ;;BR IF EQUAL
ERROR 7 ;ERROR, 100HZ FAILED TO SET DONE

;*****
;TEST 47 TEST THAT CLOCK ENABLE DOES NOT CLEAR ON DONE (MODE 1) 1 KHZ
;*****
TST47: SCOPE
MOV #5,STIMES ;;DO 5 ITERATIONS
MOV #411,RATE ;;SELECT MODE 1, 1KHZ., GO
MOV #631,$GDDAT ;;LOAD EXP
JSR PC,UPCNT

;* MOV QCSR,$BDDAT ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT.
CMP $GDDAT,$BDDAT ;COMPARE
BEQ 1$ ;;BR IF EQUAL
ERROR 7 ;ERROR, 1 KHZ. FAILED TO OVERFLOW
; AND CONTINUE COUNTING

1$: MOV #376,$GDDAT

;* MOV QCSG,$BDDAT ;/READ DEVICE REG CSC,PUT DATA IN $BDDAT.
CMP $GDDAT,$BDDAT ;COMPARE
BEQ TST50 ;;BR IF EQUAL
ERROR 6 ;IN MODE 1, CLOCK COUNTER FAILED
;TO BE RE-LOADED ON CLOCK OVERFLOW

;*****
;TEST 50 TEST THAT CLOCK ENABLE DOES NOT CLEAR DONE (MODE 1 100HZ)
;*****
TST50: SCOPE
MOV #20,STIMES ;;DO 20 ITERATIONS
MOV #413,RATE ;;MODE 1 100HZ GO
MOV #633,$GDDAT ;;LOAD EXPECTED
JSR PC,UPCNT

;* MOV QCSR,$BDDAT ;/READ DEVICE REG CSR,PUT DATA IN $BDDAT
CMP $GDDAT,$BDDAT ;COMPARE
BEQ 1$ ;;BR IF EQUAL
ERROR 7 ;ERROR, 100HZ FAILED TO
; OVERFLOW AND CONTINUE COUNTING

1$: MOV #376,$GDDAT

```

M03

 MAINDEC-11-DRLPC-A
 DRLPC.P11 T50

 MACY11 27(654) 15-DEC-77 10:54 PAGE 29
 TEST THAT CLOCK ENABLE DOES NOT CLEAR DONE (MODE 1 100HZ)

SEQ 0038

```

1429
1430 007200 023737 001124 001126 ;*      MOV      @CSC,$BDDAT      ;/READ DEVICE REG CSC,PUT DATA IN $BDDAT.
1431 007206 001401      CMP      $GDDAT,$BDDAT      ;COMPARE
1432 007210 104006      BEQ      TST51      ;;BR IF EQUAL
1433                                     ;IN MODE 1, CLOCK COUNTER FAILED
1434                                     ;TO BE RE-LOADED ON CLOCK OVERFLOW
1435
1436 ;*****
1437 ;*TEST 51      TEST THAT RESET SETS VC READY BIT
1438 ;*****
1439 007212 000004      TST51:  SCOPE
1440 007214 012737 000200 001124      MOV      @BIT7,$GDDAT      ;LOAD EXPECTED
1441 007222 004737 023174      JSR      PC,$RESET
1442
1443 ;*      MOV      @VCSTAT,$BDDAT      ;/READ DEVICE REG VCSTAT,PUT DATA IN $BDDAT.
1444 007236 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
1445 007244 001401      BEQ      TST52      ;;BR IF SET
1446 007246 104011      ERROR      11      ;RESET FAILED TO SET READY
1447
1448 ;*****
1449 ;*TEST 52      TEST THAT VC MODE BIT 2 CAN BE SET AND CLEARED
1450 ;*****
1451 007250 000004      TST52:  SCOPE
1452 007252 012737 000004 001670      MOV      @BIT2,$TMDAT      ;LOAD DISPLAY STATUS
1453
1454 ;*      MOV      $TMDAT,@VCSTAT      ;/ PUT DATA FROM $TMDAT TO DEVICE REG VCSTAT
1455      MOV      @BIT7!BIT2,$GDDAT      ;LOAD EXPECTED
1456
1457 ;*      MOV      @VCSTAT,$BDDAT      ;/READ DEVICE REG VCSTAT,PUT DATA IN $BDDAT.
1458 007306 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
1459 007314 001401      BEQ      15      ;;BR IF EQUAL
1460 007316 104011      ERROR      11      ;ERROR, VC STATUS NOT = 204
1461 007320 012737 000000 001670 15:  MOV      @0,$TMDAT      ;CLEAR STATUS
1462
1463 ;*      MOV      $TMDAT,@VCSTAT      ;/ PUT DATA FROM $TMDAT TO DEVICE REG VCSTAT
1464 007336 012737 000200 001124      MOV      @BIT7,$GDDAT      ;LOAD EXPECTED
1465
1466 ;*      MOV      @VCSTAT,$BDDAT      ;/READ DEVICE REG VCSTAT,PUT DATA IN $BDDAT.
1467 007354 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
1468 007362 001401      BEQ      TST53      ;;BR IF CLEARED
1469 007364 104011      ERROR      11      ;MODE FAILED TO CLEAR
1470
1471 ;*****
1472 ;*TEST 53      TEST THAT VC MODE BIT 3 CAN BE SET
1473 ;*****
1474 007366 000004      TST53:  SCOPE
1475 007370 012737 000010 001670      MOV      @BIT3,$TMDAT      ;LOAD
1476
1477 ;*      MOV      $TMDAT,@VCSTAT      ;/ PUT DATA FROM $TMDAT TO DEVICE REG VCSTAT
1478      MOV      @BIT7!BIT3,$GDDAT      ;LOAD EXPECTED
1479
1480 ;*      MOV      @VCSTAT,$BDDAT      ;/READ DEVICE REG VCSTAT,PUT DATA IN $BDDAT.
1481 007424 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
1482 007432 001401      BEQ      TST54      ;;BR IF EQUAL
1483 007434 104011      ERROR      11      ;ERROR, VC STATUS NOT = 210

```

```

1483
1484
1485 ;*****
1486 ;*TEST 54 TEST THAT VC INTERRUPT ENABLE (BIT 6) CAN BE SET
1487 ;*****
1488 007436 000004
1489 007440 012737 000100 001670
1490 ;*
1491 007456 012737 000300 001124 ;*
1492 ;*
1493 007474 023737 001124 001126 ;*
1494 007502 001401 ;*
1495 007504 104011 ;*
1496 ;*
1497 ;*****
1498 ;*TEST 55 TEST THAT CHANNEL (BIT 9) CAN BE SET
1499 ;*****
1500 007506 000004
1501 007510 012737 001000 001670
1502 ;*
1503 007526 012737 001200 001124 ;*
1504 ;*
1505 007544 023737 001124 001126 ;*
1506 007552 001401 ;*
1507 007554 104011 ;*
1508 ;*
1509 ;*****
1510 ;*TEST 56 TEST THAT STORE (BIT 10) CAN BE SET
1511 ;*****
1512 007556 000004
1513 007560 012737 002000 001670
1514 ;*
1515 007576 012737 002200 001124 ;*
1516 ;*
1517 007614 023737 001124 001126 ;*
1518 007622 001401 ;*
1519 007624 104011 ;*
1520 ;*
1521 ;*****
1522 ;*TEST 57 TEST THAT WRITE THRU (BIT 11) CAN BE SET
1523 ;*****
1524 007626 000004
1525 007630 012737 004000 001670
1526 ;*
1527 007646 012737 004200 001124 ;*
1528 ;*
1529 007664 023737 001124 001126 ;*
1530 007672 001401 ;*
1531 ;*
1532 ;*****
1533 ;*TEST 58 TEST THAT VC INTERRUPT ENABLE (BIT 6) CAN BE SET
1534 ;*****
1535 ;*
1536 ;*

```

```

1537 007674 104011          ERROR 11          ;ERROR, VC STATUS NOT = 4200
1538 ;*****
1539 ;*TEST 60          TEST THAT ERASE (BIT 12) CAN BE SET
1540 ;*****
1541 007676 000004          TST60: SCOPE
1542 007700 012737 010000 001670      MOV      #BIT12,$TMDAT          ;SET ERASE BIT
1543
1544 ;*      MOV      $TMDAT,$VCSTAT      ;/ PUT DATA FROM $TMDAT TO DEVICE REG VCSTAT
1545 007716 012737 010000 001124      MOV      #BIT12,$GDDAT          ;LOAD EXPECTED
1546
1547 ;*      MOV      $VCSTAT,$BDDAT      ;/READ DEVICE REG VCSTAT,PUT DATA IN $BDDAT.
1548 007734 023737 001124 001126      CMP      $GDDAT,$BDDAT          ;COMPARE
1549 007742 001401          BEQ          15          ;;BR IF SET
1550 007744 104011          ERROR 11          ;ERROR, ERASE BIT FAILED TO SET
1551 007746 005037 001670      15:      CLR      $TMDAT
1552
1553 ;*      MOV      $TMDAT,$VCSTAT      ;/ PUT DATA FROM $TMDAT TO DEVICE REG VCSTAT
1554 ;*****
1555 ;*TEST 61          TEST THAT THE X REGISTER CAN BE CLEARED
1556 ;*****
1557 007762 000004          TST61: SCOPE
1558 007764 012737 000000 001124      MOV      #0,$GDDAT          ;LOAD EXPECTED
1559
1560 ;*      MOV      $GDDAT,$VCXREG      ;/ PUT DATA FROM $GDDAT TO DEVICE REG VCXREG
1561
1562 ;*      MOV      $VCXREG,$BDDAT      ;/READ DEVICE REG VCXREG,PUT DATA IN $BDDAT.
1563 010012 023737 001124 001126      CMP      $GDDAT,$BDDAT          ;COMPARE
1564 010020 001401          BEQ          TST62          ;;BR IF EQUAL
1565 010022 104012          ERROR 12          ;ERROR, VC XREGISTER NOT = 0
1566
1567 ;*****
1568 ;*TEST 62          TEST THAT THE X REGISTER CAN BE LOADED WITH #1777
1569 ;*****
1570 010024 000004          TST62: SCOPE
1571 010026 012737 001777 001124      MOV      #1777,$GDDAT          ;LOAD EXPECTED
1572
1573 ;*      MOV      $GDDAT,$VCXREG      ;/ PUT DATA FROM $GDDAT TO DEVICE REG VCXREG
1574
1575 ;*      MOV      $VCXREG,$BDDAT      ;/READ DEVICE REG VCXREG,PUT DATA IN $BDDAT.
1576 010054 023737 001124 001126      CMP      $GDDAT,$BDDAT          ;COMPARE
1577 010062 001401          BEQ          TST63          ;;BR IF EQUAL
1578 010064 104012          ERROR 12          ;ERROR, VC X REGISTER NOT = 1777
1579
1580 ;*****
1581 ;*TEST 63          TEST THAT THE X REGISTER CAN BE LOADED WITH #525
1582 ;*****
1583 010066 000004          TST63: SCOPE
1584 010070 012737 000525 001124      MOV      #525,$GDDAT          ;LOAD EXPECTED
1585
1586 ;*      MOV      $GDDAT,$VCXREG      ;/ PUT DATA FROM $GDDAT TO DEVICE REG VCXREG
1587
1588 ;*      MOV      $VCXREG,$BDDAT      ;/READ DEVICE REG VCXREG,PUT DATA IN $BDDAT.
1589 010116 023737 001124 001126      CMP      $GDDAT,$BDDAT          ;COMPARE
1590 010124 001401          BEQ          TST64          ;;BR IF EQUAL

```

```

1591 010126 104012 ERROR 12 ;ERROR, VC X REGISTER NOT = 525
1592
1593 ;*****
1594 ;*TEST 64 TEST THAT THE X REGISTER CAN BE LOADED WITH #1252
1595 ;*****
1596 010130 000004
1597 010132 012737 001252 001124 TST64: SCOPE
1598 MOV #1252,$GDDAT ;LOAD EXPECTED
1599 ;* MOV $GDDAT,$VCXREG ;/ PUT DATA FROM $GDDAT TO DEVICE REG VCXREG
1600 ;* MOV $VCXREG,$BDDAT ;/READ DEVICE REG VCXREG,PUT DATA IN $BDDAT.
1601 CMP $GDDAT,$BDDAT ;COMPARE
1602 010160 023737 001124 001126 BEQ TST65 ;;BR IF EQUAL
1603 010166 001401
1604 010170 104012 ERROR 12 ;ERROR, VC X REGISTER NOT = 1252
1605
1606 ;*****
1607 ;*TEST 65 TEST THAT THE X REGISTER CAN HOLD A COUNT PATTERN
1608 ;*****
1609 010172 000004
1610 010174 012737 010206 001110 TST65: SCOPE
1611 010202 005037 001124 MOV #15,$LPERR ;LOAD SCOPE ERROR RETURN
1612 010206 CLR $GDDAT ;CLEAR EXPECTED
1613
1614 ;* MOV $GDDAT,$VCXREG ;/ PUT DATA FROM $GDDAT TO DEVICE REG VCXREG
1615 ;* MOV $VCXREG,$BDDAT ;/READ DEVICE REG VCXREG,PUT DATA IN $BDDAT.
1616 CMP $GDDAT,$BDDAT ;COMPARE
1617 010226 023737 001124 001126 BEQ 25 ;;BR IF EQUAL
1618 010234 001401
1619 010236 104012 ERROR 12 ;VC X REG FAILED TO HOLD A COUNT PATTERN
1620
1621 010240 005237 001124 25: INC $GDDAT ;UPDATE PATTERN
1622 010244 022737 002000 001124 CMP #2000,$GDDAT ;FINISHED?
1623 010252 001355 BNE 15 ;BR IF NOT
1624
1625 ;*****
1626 ;*TEST 66 TEST THAT THE Y REGISTER CAN BE CLEARED
1627 ;*****
1628 010254 000004
1629 010256 012737 000000 001124 TST66: SCOPE
1630 MOV #0,$GDDAT ;LOAD EXPECTED
1631 ;* MOV $GDDAT,$VCYREG ;/ PUT DATA FROM $GDDAT TO DEVICE REG VCYREG
1632 ;* MOV $VCYREG,$BDDAT ;/READ DEVICE REG VCYREG,PUT DATA IN $BDDAT.
1633 CMP $GDDAT,$BDDAT ;COMPARE
1634 010304 023737 001124 001126 BEQ TST67 ;;BR IF EQUAL
1635 010312 001401
1636 010314 104013 ERROR 13 ;ERROR, VC Y REGISTER NOT = 0
1637
1638 ;*****
1639 ;*TEST 67 TEST THAT THE Y REGISTER CAN BE LOADED WITH #1777
1640 ;*****
1641 010316 000004
1642 010320 012737 001777 001124 TST67: SCOPE
1643 MOV #1777,$GDDAT ;LOAD EXPECTED
1644 ;* MOV $GDDAT,$VCYREG ;/ PUT DATA FROM $GDDAT TO DEVICE REG VCYREG

```

```

1645
1646
1647 010346 023737 001124 001126 ;*      MOV      2VCYREG,$BDDAT ;/READ DEVICE REG VCYREG,PUT DATA IN $BDDAT.
1648 010354 001401          CMP      $GDDAT,$BDDAT          ;COMPARE
1649 010356 104013          BEQ      TST70          ;;BR IF EQUAL
1650          ERROR      13          ;ERROR, VC Y REGISTER NOT = 1777
1651
1652          ;*****
1653          ;*TEST 70      TEST THAT THE Y REGISTER CAN BE LOADED WITH #525
1654          ;*****
1655 010360 000004          TST70:  SCOPE
1656 010362 012737 000525 001124          MOV      #525,$GDDAT          ;LOAD EXPECTED
1657
1658          ;*      MOV      $GDDAT,2VCYREG ;/ PUT DATA FROM $GDDAT TO DEVICE REG VCYREG
1659
1660 010410 023737 001124 001126 ;*      MOV      2VCYREG,$BDDAT ;/READ DEVICE REG VCYREG,PUT DATA IN $BDDAT.
1661 010416 001401          CMP      $GDDAT,$BDDAT          ;COMPARE
1662 010420 104013          BEQ      TST71          ;;BR IF EQUAL
1663          ERROR      13          ;ERROR, VC Y REGISTER NOT = 525
1664
1665          ;*****
1666          ;*TEST 71      TEST THAT THE Y REGISTER CAN BE LOADED WITH #1252
1667          ;*****
1668 010422 000004          TST71:  SCOPE
1669 010424 012737 001252 001124          MOV      #1252,$GDDAT          ;LOAD EXPECTED
1670
1671          ;*      MOV      $GDDAT,2VCYREG ;/ PUT DATA FROM $GDDAT TO DEVICE REG VCYREG
1672
1673 010452 023737 001124 001126 ;*      MOV      2VCYREG,$BDDAT ;/READ DEVICE REG VCYREG,PUT DATA IN $BDDAT.
1674 010460 001401          CMP      $GDDAT,$BDDAT          ;COMPARE
1675 010462 104013          BEQ      TST72          ;;BR IF EQUAL
1676          ERROR      13          ;ERROR, VC Y REGISTER NOT = 1252
1677
1678          ;*****
1679          ;*TEST 72      TEST THAT THE Y REGISTER CAN HOLD A COUNT PATTERN
1680          ;*****
1681 010464 000004          TST72:  SCOPE
1682 010466 012737 010500 001110          MOV      #15,$LPERR          ;LOAD SCOPE ERROR RETURN
1683 010474 005037 001124          CLR      $GDDAT          ;CLEAR EXPECTED
1684
1685          ;*      MOV      $GDDAT,2VCYREG ;/ PUT DATA FROM $GDDAT TO DEVICE REG VCYREG
1686
1687 010520 023737 001124 001126 ;*      MOV      2VCYREG,$BDDAT ;/READ DEVICE REG VCYREG,PUT DATA IN $BDDAT.
1688 010526 001401          CMP      $GDDAT,$BDDAT          ;COMPARE
1689 010530 104013          BEQ      25          ;;BR IF EQUAL
1690          ERROR      13          ;VC Y REG FAILED TO HOLD A COUNT PATTERN
1691
1692 010532 005237 001124          25:      INC      $GDDAT          ;UPDATE PATTERN
1693 010536 022737 002000 001124          CMP      #2000,$GDDAT          ;FINISHED?
1694 010544 001355          BNE      15          ;BR IF NOT
1695
1696          ;*****
1697          ;*TEST 73      TEST THAT THE X-Y REGISTERS CAN HOLD DIFFERENT DATA
1698          ;*****

```

```

1699 010546 000004 TST73: SCOPE
1700 010550 012737 001252 001670 MOV #1252,$TMDAT ;LOAD X REGISTER
1701
1702 ;* MOV $TMDAT,$VCXREG ;/ PUT DATA FROM $TMDAT TO DEVICE REG VCXREG
1703 010566 012737 000525 001124 MOV #525,$GDDAT ;LOAD EXPECTED
1704
1705 ;* MOV $GDDAT,$VCYREG ;/ PUT DATA FROM $GDDAT TO DEVICE REG VCYREG
1706
1707 ;* MOV $VCYREG,$BDDAT ;/READ DEVICE REG VCYREG,PUT DATA IN $BDDAT.
1708 010614 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE
1709 010622 001401 BEQ 15 ;;BR IF EQUAL
1710 010624 104013 ERROR 13 ;ERROR, SELECTED Y REGISTER INCORRECTLY
1711
1712 010626 012737 001252 001124 15: MOV #1252,$GDDAT ;LOAD EXPECTED
1713
1714 ;* MOV $VCXREG,$BDDAT ;/READ DEVICE REG VCXREG,PUT DATA IN $BDDAT.
1715 010644 023737 001124 001126 CMP $GDDAT,$BDDAT ;COMPARE
1716 010652 001401 BEQ TST74 ;;BR IF EQUAL
1717 010654 104012 ERROR 12 ;ERROR, SELECTED X REGISTER INCORRECTLY
1718
1719 ;*****
1720 ;*TEST 74 TEST THAT WHEN INTENSIFY BIT IS SET THAT THE VC READY BIT RESETS
1721 ;*****
1722 010656 000004 TST74: SCOPE
1723 ; AND THEN SETS AFTER A DELAY
1724 010660 012700 001000 MOV #1000,R0
1725 010664 012737 000000 001124 MOV #0,$GDDAT ;LOAD EXPECTED
1726 010672 012737 000001 001670 MOV #BIT0,$TMDAT ;INTENSIFY
1727
1728 ;* MOV $TMDAT,$VCSTAT ;/ PUT DATA FROM $TMDAT TO DEVICE REG VCSTAT
1729 010710 15:
1730
1731 ;* MOV $VCSTAT,$BDDAT ;/READ DEVICE REG VCSTAT,PUT DATA IN $BDDAT.
1732 010720 105737 001126 TSTB $BDDAT
1733 010724 100412 BMI TST75 ;;NEXT TEST
1734 010726 005300 DEC R0 ;DELAY
1735 010730 001367 BNE 15 ;LOAD EXPECTED
1736 010732 012737 000200 001124 MOV #BIT7,$GDDAT
1737
1738 ;* MOV $VCSTAT,$BDDAT ;/READ DEVICE REG VCSTAT,PUT DATA IN $BDDAT.
1739 010750 104011 ERROR 11 ;READY FAILED TO SET AFTER A DELAY
1740
1741 ;*****
1742 ;*TEST 75 TEST THAT VC MODE 1 (INTENSIFY ON X) RESETS THE READY FLAG
1743 ;*****
1744 010752 000004 TST75: SCOPE
1745 ; AND THEN SETS IT
1746 010754 012700 001000 MOV #1000,R0 ;SET UP DELAY
1747 010760 012737 000204 001124 MOV #BIT7:BIT2,$GDDAT ;LOAD EXPECTED
1748 010766 012737 000004 001670 MOV #BIT2,$TMDAT ;LOAD MODE 1
1749
1750 ;* MOV $TMDAT,$VCSTAT ;/ PUT DATA FROM $TMDAT TO DEVICE REG VCSTAT
1751
1752 011004 012737 000000 001670 25: MOV #0,$TMDAT ;ADDRESS X AXIS

```

```

1753
1754 011012          1$:
1755
1756          ;*      MOV      2VCSTAT,$BDDAT  ;/READ DEVICE REG VCSTAT,PUT DATA IN $BDDAT.
1757 011022 105737 001126      TSTB      $BDDAT
1758 011026 100416      BMI      TST76          ;;NEXT TEST
1759 011030 005300      DEC      RD              ;DELAY
1760 011032 001367      BNE      1$          ;TEST READY AGAIN
1761 011034 012737 000204 001124      MOV      #BIT7!BIT2,$GDDAT      ;LOAD EXPECTED
1762
1763          ;*      MOV      2VCSTAT,$BDDAT  ;/READ DEVICE REG VCSTAT,PUT DATA IN $BDDAT.
1764 011052 023737 001124 001126      CMP      $GDDAT,$BDDAT
1765 011060 001401      BEQ      TST76          ;;BR IF EQUAL
1766 011062 104011      ERROR      11          ;ERROR, READY FAILED TO SET
1767          ; AFTER MODE 1 OPERATION
1768
1769          ;*****
1770          ;*TEST 76      TEST THAT VC MODE 2 (INTENSIFY ON Y) RESETS THE READY FLAG
1771          ;*****
1772 011064 000004      1ST76: SCOPE
1773          ; AND THEN SETS IT
1774 011066 012700 001000      MOV      #1000,RD          ;SET UP DELAY
1775 011072 012737 000210 001124      MOV      #BIT7!BIT3,$GDDAT      ;LOAD EXPECTED
1776 011100 012737 000010 001670      MOV      #BIT3,$TMDAT      ;LOAD MODE 2
1777
1778          ;*      MOV      $TMDAT,2VCSTAT  ;/ PUT DATA FROM $TMDAT TO DEVICE REG VCSTAT
1779 011116 012737 000000 001670      2$: MOV      #0,$TMDAT      ;ADDRESS Y AXIS
1780
1781          ;*      MOV      $TMDAT,2VCYREG  ;/ PUT DATA FROM $TMDAT TO DEVICE REG VCYREG
1782 011134          1$:
1783
1784          ;*      MOV      2VCSTAT,$BDDAT  ;/READ DEVICE REG VCSTAT,PUT DATA IN $BDDAT.
1785 011144 105737 001126      TSTB      $BDDAT
1786 011150 100416      BMI      TST77          ;;NEXT TEST
1787 011152 005300      DEC      RD              ;DELAY
1788 011154 001367      BNE      1$          ;TEST READY AGAIN
1789 011156 012737 000210 001124      MOV      #BIT7!BIT3,$GDDAT      ;LOAD EXPECTED
1790
1791          ;*      MOV      2VCSTAT,$BDDAT  ;/READ DEVICE REG VCSTAT,PUT DATA IN $BDDAT.
1792 011174 023737 001124 001126      CMP      $GDDAT,$BDDAT
1793 011202 001401      BEQ      TST77          ;;BR IF EQUAL
1794 011204 104011      ERROR      11          ;ERROR, READY FAILED TO SET
1795          ; AFTER MODE 2 OPERATION
1796
1797          ;*****
1798          ;*TEST 77      TEST WHEN ERASE IS SET, VC READY BIT RESETS
1799          ;*****
1800 011206 000004      1ST77: SCOPE
1801 011210 032777 010000 167722      BIT      #BIT12,$SWR          ;TEST BIT 12
1802 011216 001443      BEQ      TST100          ;;BYPASS IF NO STORAGE SCOPE
1803 011220 012700 000010      MOV      #10,RD
1804 011224 005037 001660      CLR      TEMP          ;CLEAR DELAY
1805 011230 012737 002000 001670      MOV      #BIT10,$TMDAT      ;SET STORE MODE
1806

```

```

1807 ;*      MOV      $TMDAT,$VCSTAT ;/ PUT DATA FROM $TMDAT TO DEVICE REG VCSTAT
1808
1809 ;*      MOV      $VCSTAT,$TMDAT ;/READ DEVICE REG VCSTAT,PUT DATA IN $TMDAT.
1810 011256 052737 010000 001670 ;*      BIS      #BIT12,$TMDAT
1811
1812 ;*      MOV      $TMDAT,$VCSTAT ;/ PUT DATA FROM $TMDAT TO DEVICE REG VCSTAT
1813
1814 011274 1$:
1815
1816 ;*      MOV      $VCSTAT,$TMDAT ;/READ DEVICE REG VCSTAT,PUT DATA IN $TMDAT.
1817 011304 105737 001670 ;*      TSTB     $TMDAT
1818 011310 100406 ;*      BMI      TST100 ;;BR IF SET
1819 011312 005337 001660 ;*      DEC      TEMP ;;DELAY
1820 011316 001366 ;*      BNE      1$ ;;BR IF NOT READY
1821 011320 005300 ;*      DEC      RO ;;DECREMENT COUNTER
1822 011322 001364 ;*      BNE      1$ ;;BR IF NOT DONE
1823 011324 104011 ;*      ERROR    11 ;ERROR, ERASE CLEARED READY AND FAILED
1824 ;*      ;TO SET READY AFTER A DELAY
1825 ;*****
1826 ;*TEST 100 TEST THAT RESET CLEARS VC MODE BITS
1827 ;*****
1828 011326 000004 ;*ST100: SCOPE
1829 011330 012737 000002 001166 ;*      MOV      #2,$TIMES ;;DO 2 ITERATIONS
1830 011336 012737 000014 001670 ;*      MOV      #BIT3!BIT2,$TMDAT
1831
1832 ;*      MOV      $TMDAT,$VCSTAT ;/ PUT DATA FROM $TMDAT TO DEVICE REG VCSTAT
1833 011354 012737 000200 001124 ;*      MOV      #BIT7,$GDDAT ;LOAD EXPECTED
1834 011362 004737 023174 ;*      JSR      PC,$RESET
1835
1836 ;*      MOV      $VCSTAT,$BDDAT ;/READ DEVICE REG VCSTAT,PUT DATA IN $BDDAT.
1837 011376 023737 001124 001126 ;*      CMP      $GDDAT,$BDDAT ;COMPARE
1838 011404 001401 ;*      BEQ      TST101 ;;BR IF EQUAL
1839 011406 104011 ;*      ERROR    11 ;ERROR, RESET FAILED TO CLEAR VC STATUS REG
1840
1841 ;*****
1842 ;*TEST 101 TEST THAT RESET CLEARS INTERRUPT ENABLE, CHANNEL, STORE, WRITE THRU
1843 ;*****
1844 011410 000004 ;*ST101: SCOPE
1845 011412 012737 000002 001166 ;*      MOV      #2,$TIMES ;;DO 2 ITERATIONS
1846 011420 012737 007100 001670 ;*      MOV      #BIT11!BIT10!BIT9!BIT6,$TMDAT
1847
1848 ;*      MOV      $TMDAT,$VCSTAT ;/ PUT DATA FROM $TMDAT TO DEVICE REG VCSTAT
1849 011436 012737 000200 001124 ;*      MOV      #BIT7,$GDDAT ;LOAD EXPECTED
1850 011444 004737 023174 ;*      JSR      PC,$RESET
1851
1852 ;*      MOV      $VCSTAT,$BDDAT ;/READ DEVICE REG VCSTAT,PUT DATA IN $BDDAT.
1853 011460 023737 001124 001126 ;*      CMP      $GDDAT,$BDDAT ;COMPARE
1854 011466 001401 ;*      BEQ      TST102 ;;BR IF EQUAL
1855 011470 104011 ;*      ERROR    11 ;ERROR, RESET FAILED TO CLEAR VC STATUS
1856
1857 ;*****
1858 ;*TEST 102 TEST THAT RESET CLEARS X REGISTER
1859 ;*****
1860 011472 000004 ;*ST102: SCOPE

```

```

1861 011474 012737 000002 001166      MOV      #2,$TIMES      ;;DO 2 ITERATIONS
1862 011502 012737 177777 001670      MOV      #-1,$TMDAT
1863
1864      ;*      MOV      $TMDAT,$VCXREG      ;/ PUT DATA FROM $TMDAT TO DEVICE REG VCXREG
1865 011520 012737 000000 001124      MOV      #0,$GDDAT      ;LOAD EXPECTED
1866 011526 004737 023174      JSR      PC,$RESET
1867
1868      ;*      MOV      $VCXREG,$BDDAT      ;/READ DEVICE REG VCXREG,PUT DATA IN $BDDAT.
1869 011542 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
1870 011550 001401      BEQ      TST103      ;;BR IF EQUAL
1871 011552 104011      ERROR      11      ;ERROR, RESET FAILED TO CLEAR VC X REGISTER
1872
1873      ;*****
1874      ;*TEST 103      TEST THAT RESET CLEARS Y REGISTER
1875      ;*****
1876 011554 000004      TST103: SCOPE
1877 011556 012737 000002 001166      MOV      #2,$TIMES      ;;DO 2 ITERATIONS
1878 011564 012737 177777 001670      MOV      #-1,$TMDAT
1879
1880      ;*      MOV      $TMDAT,$VCYREG      ;/ PUT DATA FROM $TMDAT TO DEVICE REG VCYREG
1881 011602 012737 000000 001124      MOV      #0,$GDDAT      ;LOAD EXPECTED
1882 011610 004737 023174      JSR      PC,$RESET
1883
1884      ;*      MOV      $VCYREG,$BDDAT      ;/READ DEVICE REG VCYREG,PUT DATA IN $BDDAT.
1885 011624 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
1886 011632 001401      BEQ      TST104      ;;BR IF EQUAL
1887 011634 104011      ERROR      11      ;ERROR, RESET FAILED TO CLEAR VC Y REGISTER
1888
1889      ;*****
1890      ;*TEST 104      DOES EXTERNAL ENABLE (BIT 4) SET
1891      ;*****
1892 011636 000004      TST104: SCOPE
1893 011640 012737 000020 001124      MOV      #BIT4,$GDDAT      ;LOAD EXPECTED
1894
1895      ;*      MOV      $GDDAT,$ADCS      ;/ PUT DATA FROM $GDDAT TO DEVICE REG ADCS
1896
1897      ;*      MOV      $ADCS,$BDDAT      ;/READ DEVICE REG ADCS,PUT DATA IN $BDDAT.
1898 011666 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
1899 011674 001401      BEQ      TST105      ;;BR IF SET
1900 011676 104001      ERROR      1      ;EXT ENABLE BIT 4 FAILED TO SET
1901
1902      ;*****
1903      ;*TEST 105      DOES CLOCK OVERFLOW ENABLE (BIT 5) SET
1904      ;*****
1905 011700 000004      TST105: SCOPE
1906
1907 011702 012737 000040 001124      MOV      #BIT5,$GDDAT      ;SET BIT 5
1908      ;LOAD EXPECTED
1909      ;*      MOV      $GDDAT,$ADCS      ;/ PUT DATA FROM $GDDAT TO DEVICE REG ADCS
1910
1911      ;*      MOV      $ADCS,$BDDAT      ;/READ DEVICE REG ADCS,PUT DATA IN $BDDAT.
1912 011730 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
1913 011736 001401      BEQ      TST106      ;;BR IF SET
1914 011740 104001      ERROR      1      ;CLOCK OVERFLOW ENABLE FAILED TO SET

```

```

1915
1916
1917
1918
1919 011742 000004
1920
1921 011744 012737 000100 001124
1922
1923
1924
1925
1926 011772 023737 001124 001126
1927 012000 001401
1928 012002 104001
1929
1930
1931
1932
1933 012004 000004
1934
1935 012006 012737 000400 001124
1936
1937
1938
1939
1940 012034 023737 001124 001126
1941 012042 001401
1942 012044 104001
1943
1944
1945
1946
1947 012046 000004
1948
1949 012050 012737 001000 001124
1950
1951
1952
1953
1954 012076 023737 001124 001126
1955 012104 001401
1956 012106 104001
1957
1958
1959
1960 012110 000004
1961
1962 012112 012737 002000 001124
1963
1964
1965
1966
1967 012140 023737 001124 001126
1968 012146 001401

;*****
;TEST 106 DOES AD INTERRUPT ENABLE (BIT 6) SET
;*****
↑ST106: SCOPE
;SET BIT 6
;LOAD EXPECTED
MOV #BIT6,$GDDAT
;PUT DATA FROM $GDDAT TO DEVICE REG ADCS
;MOV $GDDAT,$ADCS
;READ DEVICE REG ADCS,PUT DATA IN $BDDAT.
MOV $ADCS,$BDDAT
CMP $GDDAT,$BDDAT
;COMPARE
BEQ TST107
;BR IF SET
ERROR 1
;AD INTERRUPT ENABLE FAILED TO SET

;*****
;TEST 107 DOES MUX CHANNEL (BIT 8) SET
;*****
↑ST107: SCOPE
;SET BIT 8
;LOAD EXPECTED
MOV #BIT8,$GDDAT
;PUT DATA FROM $GDDAT TO DEVICE REG ADCS
;MOV $GDDAT,$ADCS
;READ DEVICE REG ADCS,PUT DATA IN $BDDAT.
MOV $ADCS,$BDDAT
CMP $GDDAT,$BDDAT
;COMPARE
BEQ TST110
;BR IF SET
ERROR 1
;MUX BIT 8 FAILED TO SET

;*****
;TEST 110 DOES MUX CHANNEL (BIT 9) SET
;*****
↑ST110: SCOPE
;SET BIT 9
;LOAD EXPECTED
MOV #BIT9,$GDDAT
;PUT DATA FROM $GDDAT TO DEVICE REG ADCS
;MOV $GDDAT,$ADCS
;READ DEVICE REG ADCS,PUT DATA IN $BDDAT.
MOV $ADCS,$BDDAT
CMP $GDDAT,$BDDAT
;COMPARE
BEQ TST111
;BR IF EQUAL
ERROR 1
;MUX BIT 9 FAILED TO SET

;*****
;TEST 111 DOES MUX CHANNEL (BIT 10) SET
;*****
↑ST111: SCOPE
;SET BIT 10
;LOAD EXPECTED
MOV #BIT10,$GDDAT
;PUT DATA FROM $GDDAT TO DEVICE REG ADCS
;MOV $GDDAT,$ADCS
;READ DEVICE REG ADCS,PUT DATA IN $BDDAT.
MOV $ADCS,$BDDAT
CMP $GDDAT,$BDDAT
;COMPARE
BEQ TST112
;BR IF EQUAL

```

J04

MAINDEC-11-DRLPC-A
DRLPC.P11 T111MACY11 27(654) 15-DEC-77 10:54 PAGE 39
DOES MUX CHANNEL (BIT 10) SET

SEQ 0048

```

1969 012150 104001          ERROR 1          ;MUX BIT 10 FAILED TO SET
1970
1971      ;*****
1972      ;*TEST 112      DOES MUX CHANNEL (BIT 11) SET
1973      ;*****
1974 012152 000004      †ST112: SCOPE
1975
1976 012154 012737 004000 001124      MOV      #BIT11,$GDDAT      ;SET BIT 11
1977                                ;LOAD EXPECTED
1978      ;*      MOV      $GDDAT,$ADCS      ;/ PUT DATA FROM $GDDAT TO DEVICE REG ADCS
1979
1980      ;*      MOV      $ADCS,$BDDAT      ;/READ DEVICE REG ADCS,PUT DATA IN $BDDAT.
1981 012202 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
1982 012210 001401      BEQ      TST113      ;;BR IF EQUAL
1983 012212 104001      ERROR 1          ;MUX BIT 11 FAILED TO SET
1984
1985      ;*****
1986      ;*TEST 113      DOES UNIPOLAR/BIPOLAR (BIT 13) SET
1987      ;*****
1988 012214 000004      †ST113: SCOPE
1989
1990 012216 012737 020000 001124      MOV      #BIT13,$GDDAT      ;SET BIT 13
1991                                ;LOAD EXPECTED
1992      ;*      MOV      $GDDAT,$ADCS      ;/ PUT DATA FROM $GDDAT TO DEVICE REG ADCS
1993
1994      ;*      MOV      $ADCS,$BDDAT      ;/READ DEVICE REG ADCS,PUT DATA IN $BDDAT.
1995 012244 023737 001124 001126      CMP      $GDDAT,$BDDAT      ;COMPARE
1996 012252 001401      BEQ      TST114      ;;BR IF EQUAL
1997 012254 104001      ERROR 1          ;UNIPOLAR /BIPOLAR BIT FAILED TO SET
1998
1999
2000
2001      ;*****
2002      ;*TEST 114      DOES AD DONE (BIT 7) SET AND CLEAR
2003      ;*****
2004 012256 000004      †ST114: SCOPE
2005
2006      ;*      MOV      $ADDBR,$TMDAT      ;/READ DEVICE REG ADDBR,PUT DATA IN $TMDAT.
2007 012270 013700 001670      MOV      $TMDAT,$R0
2008 012274 012700 000000      MOV      #0,$R0
2009 012300 012737 000001 001670      MOV      #BIT0,$TMDAT
2010
2011      ;*      MOV      $TMDAT,$ADCS      ;/ PUT DATA FROM $TMDAT TO DEVICE REG ADCS
2012 012316 012737 000200 001124      MOV      #BIT7,$GDDAT      ;LOAD EXPECTED
2013 012324
2014
2015      ;*      MOV      $ADCS,$TMDAT      ;/READ DEVICE REG ADCS,PUT DATA IN $TMDAT.
2016 012334 105737 001670      TSTB      $TMDAT
2017 012340 100407      BMI      2$
2018 012342 005200      INC      $R0
2019 012344 001367      BNE      1$
2020
2021      ;*      MOV      $ADCS,$BDDAT      ;/READ DEVICE REG ADCS,PUT DATA IN $BDDAT.
2022 012356 104001      ERROR 1          ;ERROR, A TO D DONE FAILED TO SET

```

K04

MAINDEC-11-DRLPC-A
DRLPC.P11 T114MACY11 27(654) 15-DEC-77 10:54 PAGE 40
DOES AD DONE (BIT 7) SET AND CLEAR

SEQ 0049

```

2023 012360          2$:
2024
2025          ;*      MOV      @ADDBR,$TMDAT      ;/READ DEVICE REG ADDBR,PUT DATA IN $TMDAT.
2026 012370 013700 001670          MOV      $TMDAT,R0
2027 012374 012737 000000 001124          MOV      #0,$GDDAT          ;CLEAR EXPECTED
2028
2029          ;*      MOV      @ADCS,$BDDAT      ;/READ DEVICE REG ADCS,PUT DATA IN $BDDAT.
2030 012412 105737 001126          TSTB      $BDDAT
2031 012416 100001          BPL          3$          ;;BR IF CLEARED
2032 012420 104001          ERROR      1          ;ERROR, DON'T FAILED TO CLEAR UPON
2033                                     ;READING CONVERTED VALUE
2034 012422          3$:
2035
2036          ;*      MOV      @ADCS,$BDDAT      ;/READ DEVICE REG ADCS,PUT DATA IN $BDDAT.
2037 012432 005037 001124          CLR      $GDDAT          ;CLEAR EXPECTED
2038 012436 032737 000001 001126          BIT      #BIT0,$BDDAT
2039 012444 001401          BEQ          TST115          ;;BR IF CLEARED
2040 012446 104001          ERROR      1          ;ERROR, AD GO FAILED TO CLEAR
2041
2042
2043          ;*****
2044          ;*TEST 115      TEST THAT THE CONVERTED NUMBER = 1777 (SW BIT 10=1)
2045          ;*****
2046 012450 000004          †ST115: SCOPE
2047 012452 012737 000000 001670          MOV      #0,$TMDAT          ;INIT
2048
2049          ;*      MOV      $TMDAT,@ADCS      ;/ PUT DATA FROM $TMDAT TO DEVICE REG ADCS
2050
2051          ;*      MOV      @ADCS,$TMDAT      ;/READ DEVICE REG ADCS,PUT DATA IN $TMDAT.
2052 012500 005237 001670          INC      $TMDAT
2053
2054          ;*      MOV      $TMDAT,@ADCS      ;/ PUT DATA FROM $TMDAT TO DEVICE REG ADCS
2055 012514          1$:
2056
2057          ;*      MOV      @ADCS,$TMDAT      ;/READ DEVICE REG ADCS,PUT DATA IN $TMDAT.
2058 012524 105737 001670          TSTB      $TMDAT
2059 012530 100371          BPL          1$
2060 012532 012737 001777 001124          MOV      #1777,$GDDAT          ;LOAD EXPECTED
2061
2062          ;*      MOV      @ADDBR,$BDDAT      ;/READ DEVICE REG ADDBR,PUT DATA IN $BDDAT.
2063 012550 032777 002000 166362          BIT      #BIT10,$SWR          ;TEST BIT 10
2064 012556 001405          BEQ          TST116          ;;BR IF CLEARED
2065 012560 023737 001124 001126          CMP      $GDDAT,$BDDAT          ;COMPARE
2066 012566 001401          BEQ          TST116          ;;BR IF EQUAL
2067 012570 104016          ERROR      16          ;CONVERTED VALUE NOT = 1777
2068                                     ;OPERATOR INFORMED THE PROGRAM THAT THE
2069                                     ; ALL 1'S JUMPER HAD BEEN INSTALLED
2070
2071          ;*****
2072          ;*TEST 116      TEST THAT NO EXTERNAL CONVERSIONS INPUT
2073          ;*****
2074 012572 000004          †ST116: SCOPE
2075 012574 012737 000004 001166          MOV      #4,$TIMES          ;;DO 4 ITERATIONS
2076 012602 012737 000000 001670          MOV      #0,$TMDAT

```

```

2077
2078      012620  012737  000020  001124  ;*      MOV      $TMDAT,ADCS      ;/ PUT DATA FROM $TMDAT TO DEVICE REG ADCS
2079      ;*      MOV      #BIT4,$GDDAT      ;LOAD EXPECTED
2080
2081      012636  013700  001670      ;*      MOV      @ADDBR,$TMDAT      ;/READ DEVICE REG ADDBR,PUT DATA IN $TMDAT.
2082      ;*      MOV      $TMDAT,RO
2083
2084      012652  052737  000020  001670  ;*      MOV      @ADCS,$TMDAT      ;/READ DEVICE REG ADCS,PUT DATA IN $TMDAT.
2085      ;*      BIS      #BIT4,$TMDAT
2086
2087      012670  012700  000000      ;*      MOV      $TMDAT,ADCS      ;/ PUT DATA FROM $TMDAT TO DEVICE REG ADCS
2088      ;*      MOV      #0,RO
2089      1$:      INC      RO
2090      012676  001376      BNE      1$
2091
2092      012710  105737  001126      ;*      MOV      @ADCS,$BDDAT      ;/READ DEVICE REG ADCS,PUT DATA IN $BDDAT.
2093      ;*      TSTB      $BDDAT
2094      ;*      BPL      TST117      ;;BR IF PLUS
2095      012716  104001      ERROR      1      ;ERROR EXTERNAL CONVERSION
2096
2097      ;*****
2098      ;*TEST 117      TEST THAT CLOCK CAN START A CONVERSION
2099      ;*****
2100      012720  000004      TST117: SCOPE
2101      012722  012737  000004  001166      MOV      #4,$TIMES      ;;DO 4 ITERATIONS
2102      012730  012737  000000  001670      MOV      #0,$TMDAT
2103
2104      ;*      MOV      $TMDAT,ADCS      ;/ PUT DATA FROM $TMDAT TO DEVICE REG ADCS
2105
2106      012756  012737  000240  001124  ;*      MOV      $TMDAT,ACSR      ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
2107      ;*      MOV      #BIT7!BITS,$GDDAT      ;LOAD EXPECTED DATA
2108      012764  012737  000003  014610      MOV      #3,RATE      ;LOAD CLOCK RATE
2109
2110      013002  052737  000040  001670  ;*      MOV      @ADCS,$TMDAT      ;/READ DEVICE REG ADCS,PUT DATA IN $TMDAT.
2111      ;*      BIS      #BITS,$TMDAT
2112
2113      013020  004737  014002      ;*      MOV      $TMDAT,ADCS      ;/ PUT DATA FROM $TMDAT TO DEVICE REG ADCS
2114      ;*      JSR      PC,UPCNT      ;ENABLE THE CLOCK
2115      013024  012700  000040      ;*      MOV      #BITS,RO      ;SETUP DELAY
2116      013030  005300      1$:      DEC      RO      ;DELAY
2117      013032  001376      BNE      1$
2118
2119      013044  023737  001124  001126  ;*      MOV      @ADCS,$BDDAT      ;/READ DEVICE REG ADCS,PUT DATA IN $BDDAT.
2120      ;*      CMP      $GDDAT,$BDDAT      ;COMPARE
2121      013052  001401      BEQ      TST120      ;;BR IF EQUAL
2122      013054  104001      ERROR      1      ;CLOCK OVERFLOW FAILED TO START A CONVERSION
2123
2124      ;*****
2125      ;*TEST 120      TEST THAT RESET CLEARS MUX AND UNIPOLAR BITS
2126      ;*****
2127      013056  000004      TST120: SCOPE
2128      013060  012737  000002  001166      MOV      #2,$TIMES      ;;DO 2 ITERATIONS
2129      013066  005037  001124      CLR      $GDDAT
2130      013072  012737  027400  001670      MOV      #BIT13!BIT11!BIT10!BIT9!BIT8,$TMDAT

```

```

2131
2132
2133 013110 004737 023174 ;* MOV $TMDAT,ADCS ;/ PUT DATA FROM $TMDAT TO DEVICE REG ADCS
2134 JSR PC,$RESET
2135
2136 013124 005737 001126 ;* MOV ADCS,$BDDAT ;/READ DEVICE REG ADCS,PUT DATA IN $BDDAT.
2137 013130 001401 TST $BDDAT
2138 013132 104000 BEQ TST121 ;;BR IF CLEARED
2139 ERROR
2140
2141 ;*****
2142 ;*TEST 121 TEST THAT RESET CLEARS EXT AND INTERRUPT ENABLE BITS
2143 ;*****
2144 TST121: SCOPE
2145 013134 000004 MOV #2,$TIMES ;;DO 2 ITERATIONS
2146 013136 012737 000002 001166 MOV #BIT6:BIT4,$TMDAT
2147 013144 012737 000120 001670
2148
2149 ;* MOV $TMDAT,ADCS ;/ PUT DATA FROM $TMDAT TO DEVICE REG ADCS
2150 CLR $GDDAT ;CLEAR EXPECTED
2151 JSR PC,$RESET
2152
2153 ;* MOV ADCS,$BDDAT ;/READ DEVICE REG ADCS,PUT DATA IN $BDDAT.
2154 013202 001401 BEQ TST122 ;;BR IF CLEARED
2155 013204 104001 ERROR 1 ;ERROR, RESET FAILED TO CLEAR ENABLES
2156
2157 ;*****
2158 ;*TEST 122 TEST THAT RESET CLEARS AD DONE
2159 ;*****
2160 TST122: SCOPE
2161 013206 000004 MOV #2,$TIMES ;;DO 2 ITERATIONS
2162 013210 012737 000002 001166 MOV #BIT0,$TMDAT
2163 013216 012737 000001 001670
2164
2165 ;* MOV $TMDAT,ADCS ;/ PUT DATA FROM $TMDAT TO DEVICE REG ADCS
2166 CLR $GDDAT
2167
2168 ;* MOV ADCS,$TMDAT ;/READ DEVICE REG ADCS,PUT DATA IN $TMDAT.
2169 TSTB $TMDAT
2170 013250 105737 001670 BPL -4
2171 013254 100375 JSR PC,$RESET
2172 013256 004737 023174
2173
2174 ;* MOV ADCS,$BDDAT ;/READ DEVICE REG ADCS,PUT DATA IN $BDDAT.
2175 013272 001401 BEQ TST123 ;;BR IF CLEARED
2176 013274 104001 ERROR 1 ;ERROR, RESET FAILED TO CLEAR DONE FLAG
2177
2178 ;*****
2179 ;*TEST 123 TEST THAT RESET CLEARS AD BUFFER REG
2180 ;*****
2181 TST123: SCOPE
2182 013276 000004 MOV #2,$TIMES ;;DO 2 ITERATIONS
2183 013300 012737 000002 001166 MOV #1,$TMDAT ;CONVERT
2184 013306 012737 000001 001670
2185
2186 ;* MOV $TMDAT,ADCS ;/ PUT DATA FROM $TMDAT TO DEVICE REG ADCS
2187 JS:
2188
2189 ;* MOV ADCS,$TMDAT ;/READ DEVICE REG ADCS,PUT DATA IN $TMDAT.
2190 TSTB $TMDAT ;WAIT
2191

```

```

2185 013340 100371          BPL      1$
2186 013342 004737 023174    JSR      PC,$RESET
2187
2188          ;*      MOV      @ADDBR,$BDDAT    ;/READ DEVICE REG ADDBR,PUT DATA IN $BDDAT.
2189 013356 005037 001124          CLR      $GDDAT          ;LOAD EXPECTED
2190 013362 023737 001124 001126    CMP      $GDDAT,$BDDAT    ;COMPARE
2191 013370 001401          BEQ      TST124          ;;BR IF CLEARED
2192 013372 104016          ERROR    16          ;RESET FAILED TO CLEAR AD BUFFER REGISTER
2193          ;*****
2194          ;*TEST 124      LOAD DIFFERENT NUMBERS INTO DIFFERENT REG.
2195          ;*****
2196 013374 000004          TST124: SCOPE
2197 013376 004737 023174    JSR      PC,$RESET
2198 013402 013700 001626    MOV      CSC,RO          ;LOAD STARTING ADDRESS
2199 013406 062700 000002    ADD      #2,RO          ;ADJUST ADDRESS
2200 013412 012701 013566    MOV      #BUFNUM+20,R1      ;LOAD STARTING TABLE ADDRESS
2201 013416 012702 000010    MOV      #8,R2          ;LOAD COUNT
2202 013422 010037 001670 1$:    MOV      RO,$TMDAT
2203 013426 162700 000002    SUB      #2,RO
2204 013432 162737 000002 001670    SUB      #2,$TMDAT
2205 013440 014137 001124    MOV      -(R1),$GDDAT
2206
2207          ;*      MOV      $GDDAT,@$TMDAT    ;/ PUT DATA FROM $GDDAT TO DEVICE REG $TMDAT
2208 013454 005302          DEC      R2          ;DONE ALL
2209 013456 001361          BNE      1$          ;BR IF NOT
2210
2211 013460 013700 001610    MOV      ADCS,RO          ;LOAD STARTING POINTER
2212 013464 012701 013546    MOV      #BUFNUM,R1      ;LOAD STARTING POINTER <EXPECTED>
2213 013470 012702 000010    MOV      #8,R2          ;LOAD # OF REG
2214
2215 013474 011137 001124 3$:    MOV      (R1),$GDDAT          ;READ REG
2216 013500 010037 001670    MOV      RO,$TMDAT
2217
2218          ;*      MOV      @$TMDAT,$BDDAT    ;/READ DEVICE REG $TMDAT,PUT DATA IN $BDDAT.
2219 013514 023737 001124 001126    CMP      $GDDAT,$BDDAT    ;COMPARE
2220 013522 001403          BEQ      4$          ;;BR IF EQUAL
2221 013524 010037 013566    MOV      RO,BUFADR          ;SAVE BUS ADDRESS
2222 013530 104017          ERROR    17          ;INCORRECT DATA, REG. WAS CHANGED IN ERROR
2223 013532 005721 000002 4$:    TST      (R1)+          ;UPDATE POINTERS
2224 013534 062700          ADD      #2,RO
2225 013540 005302          DEC      R2          ;DONE ALL REG
2226 013542 001354          BNE      3$          ;BR IF NOT
2227 013544 000411          BR       TST125          ;;NEXT TEST
2228
2229          ;* TO BE LOADED INTO DIFFERENT REG
2230
2231 013546 027560          BUFNUM: 27560          ;A TO D STATUS
2232 013550 000000          0          ;A TO D BUFFER
2233 013552 140736          140736          ;CLOCK STATUS
2234 013554 000377          377          ;CLOCK PRESET
2235 013556 007214          7214          ;VC STATUS
2236 013560 001252          1252          ;VC X POS
2237 013562 000525          525          ;VC Y POS
2238 013564 000377          377          ;CLOCK COUNTER

```

```

2239
2240 013566 170400          BUFA0R: 170400          ;BUS ADDRESS OF REG IN ERROR
2241
2242
2243
2244
2245 013570 000004          ;*****
2246 013572 005737 001652  ;*TEST 125      DETERMINE IF MORE AR11'S ARE TO BE TESTED
2247 013576 001411          ;*****
2248 013600 062737 000020 001644  ;ST125: SCOPE
2249 013606 062737 000020 001646  BYPASS: TST      NBEXT      ;TEST IF ANY
2250 013614 005337 001652          BEQ      1$      ;BR IF NONE
2251 013620 000413          ADD      #20, ARBADD ;UPDATE DEVICE ADDRESS
2252 013622 013737 001252 001644 1$:      MOV      $BASE, ARBADD ;UPDATE DEVICE VECTOR
2253 013630 013737 001246 001646      MOV      $VECT1, ARBVCT ;ANOTHER ONE?
2254 013636 013737 001650 001652      MOV      NMBEXT, NBEXT ;BR IF ANOTHER
2255 013644 000137 013660          JMP      $EOP      ;RELOAD ADDRESS
2256 013650 012700 177777          BYPASS: MOV      #-1, RD ;RELOAD VECTOR
2257 013654 000137 002334          JMP      RBEG2 ;RELOAD NUMBER
2258          ;DONE
2259          ;TEST ANOTHER UNIT
2260          .SBTTL END OF PASS ROUTINE
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287
2288
2289
2290
2291
2292
013660
013660 000004
013662 005037 001102
013666 005037 001166
013672 005237 001204
013676 042737 100000 001204
013704 005327
013706 000001
013710 003022
013712 012737
013714 000001
013716 013706
013720 104401 013765
013724 013746 001204
013730 104405
013732 104401 013762
013736 013700 000042
013742 001405
013744 000005
013746 004710
013750 000240
013752 000240
013754 000240
013756 000137
013760 013650

```

```

2293 013762 377 377 000 $ENULL: .BYTE -1,-1,0 ;:NULL CHARACTER STRING
2294 013765 015 042412 042116 $ENDMG: .ASCIZ <15><12>/END PASS #/
2295 013772 050040 051501 020123
2296 014000 000043
2297
2298
2299 ;SUBROUTINE TO LOAD -2 INTO THE CLOCK PRESET REGISTER
2300 ; AND LOAD CLOCK RATE INTO CLOCK STATUS REGISTER
2301 ; AND START THE CLOCK. WAIT A PERIOD OF TIME THEN EXIT
2302
2303 014002 012737 000000 001670 UPCNT: MOV #0,$TMDAT ;CLEAR CLOCK STATUS
2304
2305 ;* MOV $TMDAT,$CSR ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
2306 014020 012737 177776 001670 ;* MOV #-2,$TMDAT ;MOVE -2 INT PRESET
2307
2308 ;* MOV $TMDAT,$CSB ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSB
2309 014036 013737 014610 001670 ;* MOV RATE,$TMDAT ;LOAD RATE AND ENABLE CLOCK
2310
2311 ;* MOV $TMDAT,$CSR ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
2312 014054 012737 000000 001656 ;* MOV #0,DELAY
2313 014062
2314 UPCNTA:
2315 ;* MOV $CSR,$TMDAT ;/READ DEVICE REG CSR,PUT DATA IN $TMDAT.
2316 014072 105737 001670 ;* TSTB $TMDAT
2317 014076 100407 BMI UPCNTB ;
2318 014100 022727 000000 000000 ;* CMP #0,#0
2319 014106 062737 000001 001656 ;* ADD #1,DELAY
2320 014114 001362 ;* BNE UPCNTA
2321 014116 000207 UPCNTB: RTS 7 ;EXIT
2322
2323 .SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
2324
2325 ;*****
2326 ;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
2327 ;*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
2328 ;*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
2329 ;*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
2330 ;*REPLACED WITH SPACES.
2331 ;*CALL:
2332 ;* MOV NUM,-(SP) ;:PUT THE BINARY NUMBER ON THE STACK
2333 ;* TYPDS ;:GO TO THE ROUTINE
2334
2335 $TYPDS:
2336 014120 010046 MOV R0,-(SP) ;:PUSH R0 ON STACK
2337 014122 010146 MOV R1,-(SP) ;:PUSH R1 ON STACK
2338 014124 010246 MOV R2,-(SP) ;:PUSH R2 ON STACK
2339 014126 010346 MOV R3,-(SP) ;:PUSH R3 ON STACK
2340 014130 010546 MOV R5,-(SP) ;:PUSH R5 ON STACK
2341 014132 012746 020200 MOV #20200,-(SP) ;:SET BLANK SWITCH AND SIGN
2342 014136 016605 000020 MOV 20(SP),R5 ;:GET THE INPUT NUMBER
2343 014142 100004 BPL 1$ ;:BR IF INPUT IS POS.
2344 014144 005405 NEG R5 ;:MAKE THE BINARY NUMBER POS.
2345 014146 112766 000055 000001 MOVB #'-,1(SP) ;:MAKE THE ASCII NUMBER NEG.
2346 014154 005000 1$: CLR R0 ;:ZERO THE CONSTANTS INDEX

```

```

2347 014156 012703 014334      MOV    $DBLK,R3      ;; SETUP THE OUTPUT POINTER
2348 014162 112723 000040      MOV    #1,(R3)+    ;; SET THE FIRST CHARACTER TO A BLANK
2349 014166 005002      CLR    R2          ;; CLEAR THE BCD NUMBER
2350 014170 016001 014324      MOV    $DTBL(R0),R1  ;; GET THE CONSTANT
2351 014174 160105      SUB    R1,R5        ;; FORM THIS BCD DIGIT
2352 014176 002402      BLT    4$          ;; BR IF DONE
2353 014200 005202      INC    R2          ;; INCREASE THE BCD DIGIT BY 1
2354 014202 000774      BR     3$
2355 014204 060105      4$: ADD    R1,R5        ;; ADD BACK THE CONSTANT
2356 014206 005702      TST    R2          ;; CHECK IF BCD DIGIT=0
2357 014210 001002      BNE    5$          ;; FALL THROUGH IF 0
2358 014212 105716      TSTB   (SP)        ;; STILL DOING LEADING 0'S?
2359 014214 100407      BMI    7$          ;; BR IF YES
2360 014216 106316      5$: ASLB   (SP)        ;; MSD?
2361 014220 103003      BCC    6$          ;; BR IF NO
2362 014222 116663 000001 177777  MOV    1(SP),-1(R3)  ;; YES--SET THE SIGN
2363 014230 052702 000060      BIS    #'0,R2        ;; MAKE THE BCD DIGIT ASCII
2364 014234 052702 000040      6$: BIS    #' ,R2        ;; MAKE IT A SPACE IF NOT ALREADY A DIGIT
2365 014240 110223      MOV    R2,(R3)+    ;; PUT THIS CHARACTER IN THE OUTPUT BUFFER
2366 014242 005720      TST    (R0)+    ;; JUST INCREMENTING
2367 014244 020027 000010      CMP    R0,#10      ;; CHECK THE TABLE INDEX
2368 014250 002746      BLT    2$          ;; GO DO THE NEXT DIGIT
2369 014252 003002      BGT    8$          ;; GO TO EXIT
2370 014254 010502      MOV    R5,R2        ;; GET THE LSD
2371 014256 000764      BR     6$          ;; GO CHANGE TO ASCII
2372 014260 105726      8$: TSTB   (SP)+    ;; WAS THE LSD THE RST NON-ZERO?
2373 014262 100003      BPL    9$          ;; BR IF NO
2374 014264 116663 177777 177776  MOV    -1(SP),-2(R3)  ;; YES--SET THE SIGN FOR TYPING
2375 014272 105013      9$: CLRB   (R3)        ;; SET THE TERMINATOR
2376 014274 012605      MOV    (SP)+,R5    ;; POP STACK INTO R5
2377 014276 012603      MOV    (SP)+,R3    ;; POP STACK INTO R3
2378 014300 012602      MOV    (SP)+,R2    ;; POP STACK INTO R2
2379 014302 012601      MOV    (SP)+,R1    ;; POP STACK INTO R1
2380 014304 012600      MOV    (SP)+,R0    ;; POP STACK INTO R0
2381 014306 104401 014334      TYPE    $DBLK    ;; NOW TYPE THE NUMBER
2382 014312 016666 000002 000004  MOV    2(SP),4(SP)  ;; ADJUST THE STACK
2383 014320 012616      MOV    (SP)+,(SP)
2384 014322 000002      RTI
2385 014324 023420      $DTBL: 10000.
2386 014326 001750      1000.
2387 014330 000144      100.
2388 014332 000012      10.
2389 014334 000004      $DBLK: .BLKW 4
2390      ;; SUBROUTINE TO TEST THE CLOCK REPEATABILITY
2391      ;; FIRST CLEAR CLOCK STATUS AND PRESET BUFFER
2392      ;; THEN ENABLE THE CLOCK TO COUNT AT A RATE.
2393      ;; DECREMENT R0 FOR SOME PERIOD OF TIME, WHEN R0 = 0
2394      ;; SAVE THE COUNTER VALUE AND REPEAT THIS OPERATION AGAIN
2395      ;; THEN COMPARE THE FIRST TIMED VALUE TO THE SECOND TIMED VALUE
2396      ;; <MACHINE AND MEMORY TIMING NOT IMPORTANT>
2397      ;; TO BE WITHIN THE VALUE SPECIFIED BY LOCATION CNTDEV
2398      ;; IF GREATER THAN EXPECTED IT IS AN ERROR.
2399      ;; ALSO TEST THAT THE COUNTER HAS REACHED A MIN. COUNT
2400

```

```

2401 014344 012737 000000 001670 REPEAT: MOV #0,$TMDAT ;STOP THE CLOCK
2402
2403 ;* MOV $TMDAT,$CSR ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
2404
2405 ;* MOV $TMDAT,$CSB ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSB
2406 014372 012537 014610 MOV (R5)+,RATE ;SET UP RATE
2407 014376 012537 014612 MOV (R5)+,CNTDEV ;SET UP CNT. DEV
2408 014402 012537 014614 MOV (R5)+,MINCNT ;SET UP MIN COUNT
2409 014406 012537 014616 MOV (R5)+,CKDLY ;SAVE DELAY
2410 014412 004737 014502 JSR PC,10$ ;DUMMY TO CHARGE THE "CACHE"
2411 014416 004737 014502 JSR PC,10$ ;ENABLE THE CLOCK
2412 014422 010037 001124 MOV RO,$GDDAT ;SAVE FIRST TIME
2413 014426 004737 014502 JSR PC,10$ ;ENABLE THE CLOCK
2414 014432 010037 001126 MOV RO,$BDDAT ;SAVE SECOND TIME
2415 014436 013700 001124 MOV $GDDAT,RO ;GET FIRST TIME AGAIN
2416 014442 163700 001126 SUB $BDDAT,RO ;SUBTRACT SECOND TIME
2417 014446 100001 BPL 3$
2418 014450 005400 NEG RO ;MAGNITUDE OF DIFFERENCE IN RO
2419 014452 023737 001126 014614 3$: CMP $BDDAT,MINCNT ;COMPARE TO MIN. COUNT
2420 014460 002004 BGE 4$ ;BRANCH IF GREATER
2421 014462 013737 014614 001124 MOV MINCNT,$GDDAT ;LOAD $GDDAT FOR TYPE-OUT
2422 014470 000205 RTS R5
2423 014472 005725 4$: TST (R5)+ ;UPDATE THE STACK
2424 014474 020037 014612 CMP RO,CNTDEV ;COMPARE TO DEVIATION
2425 014500 000205 RTS R5
2426
2427 014502 013700 014616 10$: MOV CKDLY,RO ;GET DELAY
2428 014506 013737 014610 001670 MOV RATE,$TMDAT ;LOAD RATE
2429
2430 ;* MOV $TMDAT,$CSR ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
2431 014524 005237 001670 INC $TMDAT ;ENABLE CLOCK
2432
2433 ;* MOV $TMDAT,$CSR ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
2434 014540 005300 1$: DEC RO ;DELAY
2435 014542 001376 BNE 1$
2436
2437 ;* MOV $CSC,$TMDAT ;/READ DEVICE REG CSC,PUT DATA IN $TMDAT.
2438 014554 013700 001670 MOV $TMDAT,RO
2439 014560 012737 000000 001670 MOV #0,$TMDAT ;STOP CLOCK
2440
2441 ;* MOV $TMDAT,$CSR ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSR
2442
2443 ;* MOV $TMDAT,$CSB ;/ PUT DATA FROM $TMDAT TO DEVICE REG CSB
2444 014606 000207 RTS PC ;EXIT
2445
2446 014610 000000 RATE: 0 ;CLOCK RATE
2447 014612 000000 CNTDEV: 0 ;CLOCK DEV.
2448 014614 000000 MINCNT: 0 ;MIN. COUNT
2449 014616 000000 CKDLY: 0
2450 014620 020101 047524 042040 EM1: .ASCIZ /A TO D STATUS REGISTER IN ERROR/
2451 014626 051440 040524 052524
2452 014634 020123 042522 044507
2453 014642 052123 051105 044440
2454 014650 020116 051105 047522

```

2455	014656	000122				
2456	014660	020101	047524	042040	EM2:	.ASCIZ /A TO D INTERRUPT ERROR/
2457	014666	044440	052116	051105		
2458	014674	052522	052120	042440		
2459	014702	051122	051117	000		
2460	014707	103	047514	045503	EM3:	.ASCIZ /CLOCK STATUS REGISTER IN ERROR/
2461	014714	051440	040524	052524		
2462	014722	020123	042522	044507		
2463	014730	052123	051105	044440		
2464	014736	020116	051105	047522		
2465	014744	000122				
2466	014746	046103	041517	020113	EM4:	.ASCIZ /CLOCK PRESET REGISTER IN ERROR/
2467	014754	051120	051505	052105		
2468	014762	051040	043505	051511		
2469	014770	042524	020122	047111		
2470	014776	042440	051122	051117		
2471	015004	000				
2472	015005	103	047514	045503	EM5:	.ASCIZ /CLOCK INTERRUPT ERROR/
2473	015012	044440	052116	051105		
2474	015020	052522	052120	042440		
2475	015026	051122	051117	000		
2476	015033	103	047514	045503	EM6:	.ASCIZ /CLOCK COUNTER REGISTER IN ERROR/
2477	015040	041440	052517	052116		
2478	015046	051105	051040	043505		
2479	015054	051511	042524	020122		
2480	015062	047111	042440	051122		
2481	015070	051117	000			
2482	015073	103	047514	045503	EM7:	.ASCIZ /CLOCK COUNTED IN ERROR/
2483	015100	041440	052517	052116		
2484	015106	042105	044440	020116		
2485	015114	051105	047522	000122		
2486	015122	046103	041517	020113	EM10:	.ASCIZ /CLOCK REPEATABILITY FAILED/
2487	015130	042522	042520	052101		
2488	015136	041101	046111	052111		
2489	015144	020131	040506	046111		
2490	015152	042105	000			
2491						
2492	015155	126	020103	052123	EM11:	.ASCIZ /VC STATUS REGISTER IN ERROR/
2493	015162	052101	051525	051040		
2494	015170	043505	051511	042524		
2495	015176	020122	047111	042440		
2496	015204	051122	051117	000		
2497	015211	130	051040	043505	EM12:	.ASCIZ /X REGISTER IN ERROR/
2498	015216	051511	042524	020122		
2499	015224	047111	042440	051122		
2500	015232	051117	000			
2501	015235	131	051040	043505	EM13:	.ASCIZ /Y REGISTER IN ERROR/
2502	015242	051511	042524	020122		
2503	015250	047111	042440	051122		
2504	015256	051117	000			
2505	015261	123	047503	042520	EM14:	.ASCIZ /SCOPE INTERRUPT ERROR/
2506	015266	044440	052116	051105		
2507	015274	052522	052120	042440		
2508	015302	051122	051117	000		

2509	015307	104	053105	041511	EM15:	.ASCIZ	/DEVICE BUS ERROR/
2510	015314	020105	052502	020123			
2511	015322	051105	047522	000122			
2512							
2513	015330	047111	047503	051122	EM16:	.ASCIZ	"INCORRECT A/D BUFFER DATA"
2514	015336	041505	020124	027501			
2515	015344	020104	052502	043106			
2516	015352	051105	042040	052101			
2517	015360	000101					
2518	015362	044103	047101	042507	EM17:	.ASCIZ	/CHANGED REGISTER IN ERROR/
2519	015370	020104	042522	044507			
2520	015376	052123	051105	044440			
2521	015404	020116	051105	047522			
2522	015412	000122					
2523	015414	051105	050122	020103	DH1:	.ASCIZ	/ERRPC ADCS ADSTAT EXPECTED/
2524	015422	020040	040440	041504			
2525	015430	020123	020040	042101			
2526	015436	052123	052101	042440			
2527	015444	050130	041505	042524			
2528	015452	000104					
2529	015454	051105	050122	020103	DH2:	.ASCIZ	/ERRPC ADCS/
2530	015462	020040	040440	041504			
2531	015470	000123					
2532	015472	051105	050122	020103	DH3:	.ASCIZ	/ERRPC CSR CKSTAT EXPECTED/
2533	015500	020040	041440	051123			
2534	015506	020040	020040	045503			
2535	015514	052123	052101	042440			
2536	015522	050130	041505	042524			
2537	015530	000104					
2538	015532	051105	050122	020103	DH4:	.ASCIZ	/ERRPC CSB CKBUFF EXPECTED/
2539	015540	020040	041440	041123			
2540	015546	020040	020040	045503			
2541	015554	052502	043106	042440			
2542	015562	050130	041505	042524			
2543	015570	000104					
2544	015572	051105	050122	020103	DH5:	.ASCIZ	/ERRPC CSR/
2545	015600	020040	041440	051123			
2546	015606	000					
2547	015607	105	051122	041520	DH6:	.ASCIZ	/ERRPC CSC CKCNTR EXPECTED/
2548	015614	020040	020040	051503			
2549	015622	020103	020040	041440			
2550	015630	041513	052116	020122			
2551	015636	054105	042520	052103			
2552	015644	042105	000				
2553	015647	105	051122	041520	DH10:	.ASCIZ	/ERRPC CSC TIME1 TIME2/
2554	015654	020040	020040	051503			
2555	015662	020103	020040	052040			
2556	015670	046511	030505	020040			
2557	015676	052040	046511	031105			
2558	015704	000					
2559	015705	105	051122	041520	DH11:	.ASCIZ	/ERRPC VCADR VCSTAT EXPECTED/
2560	015712	020040	053040	040503			
2561	015720	051104	020040	053040			
2562	015726	051503	040524	020124			

2563	015734	054105	042520	052103					
2564	015742	042105	000						
2565	015745	105	051122	041520	DH12:	.ASCIZ	/ERRPC	VCXREG	X POS. EXPECTED/
2566	015752	020040	053040	054103					
2567	015760	042522	020107	054040					
2568	015766	050040	051517	020056					
2569	015774	042440	050130	041505					
2570	016002	042524	000104						
2571	016006	051105	050122	020103	DH13:	.ASCIZ	/ERRPC	VCYREG	Y POS. EXPECTED/
2572	016014	020040	041526	051131					
2573	016022	043505	020040	020131					
2574	016030	047520	027123	020040					
2575	016036	054105	042520	052103					
2576	016044	042105	000						
2577	016047	105	051122	041520	DH14:	.ASCIZ	/ERRPC	VCSTAT/	
2578	016054	020040	053040	051503					
2579	016062	040524	000124						
2580	016066	051105	050122	020103	DH15:	.ASCIZ	/ERRPC	BASE	ACTUAL/
2581	016074	020040	041040	051501					
2582	016102	020105	020040	040440					
2583	016110	052103	040525	000114					
2584	016116	051105	050122	020103	DH16:	.ASCIZ	/ERRPC	ADDR	READ EXPECTED/
2585	016124	020040	042101	041104					
2586	016132	020122	020040	051040					
2587	016140	040505	020104	020040					
2588	016146	054105	042520	052103					
2589	016154	042105	000						
2590	016157	105	051122	041520	DH17:	.ASCIZ	/ERRPC	BUFADR	READ EXPECTED/
2591	016164	020040	041040	043125					
2592	016172	042101	020122	020040					
2593	016200	042522	042101	020040					
2594	016206	042440	050130	041505					
2595	016214	042524	000104						
2596						.EVEN			
2597	016220	001116	001610	001126	DT1:	\$ERRPC,ADCS,\$BDDAT,\$GDDAT,0			
2598	016226	001124	000000						
2599	016232	001116	001610	000000	DT2:	\$ERRPC,ADCS,0			
2600	016240	001116	001614	001126	DT3:	\$ERRPC,CSR,\$BDDAT,\$GDDAT,0			
2601	016246	001124	000000						
2602	016252	001116	001616	001126	DT4:	\$ERRPC,CSB,\$BDDAT,\$GDDAT,0			
2603	016260	001124	000000						
2604	016264	001116	001614	000000	DT5:	\$ERRPC,CSR,0			
2605	016272	001116	001626	001126	DT6:	\$ERRPC,CSC,\$BDDAT,\$GDDAT,0			
2606	016300	001124	000000						
2607	016304	001116	001620	001126	DT11:	\$ERRPC,VCSTAT,\$BDDAT,\$GDDAT,0			
2608	016312	001124	000000						
2609	016316	001116	001622	001126	DT12:	\$ERRPC,VCXREG,\$BDDAT,\$GDDAT,0			
2610	016324	001124	000000						
2611	016330	001116	001624	001126	DT13:	\$ERRPC,VCYREG,\$BDDAT,\$GDDAT,0			
2612	016336	001124	000000						
2613	016342	001116	001620	000000	DT14:	\$ERRPC,VCSTAT,0			
2614	016350	001116	001644	001126	DT15:	\$ERRPC,ARBADD,\$BDDAT,0			
2615	016356	000000							
2616	016360	001116	001612	001126	DT16:	\$ERRPC,ADDR,\$BDDAT,\$GDDAT,0			

MAINDEC-11-DRLPC-A MACY11 27(654) 15-DEC-77 10:54 PAGE 51
DRLPC.P11 CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

SEQ 0060

```

2617 016366 001124 000000
2618 016372 001116 013566 001126 DT17: $ERRPC,BUFADR,$BDDAT,$GDDAT,0
2619 016400 001124 000000
2620
2621 .SBTTL SCOPE HANDLER ROUTINE
2622
2623 ;*****
2624 ;THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
2625 ;AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
2626 ;AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
2627 ;THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
2628 ;*SW14=1 LOOP ON TEST
2629 ;*SW11=1 INHIBIT ITERATIONS
2630 ;*SW09=1 LOOP ON ERROR
2631 ;*SW08=1 LOOP ON TEST IN SWR<7:0>
2632 ;*CALL
2633 ;* SCOPE ;;SCOPE=10T
2634
2635 $SCOPE:
2636 016404 104407 CKSWR ;;TEST FOR CHANGE IN SOFT-SWR
2637 016406 104407 CKSWR
2638 016410 032777 040000 162522 1$: BIT #BIT14,$SWR ;;LOOP ON PRESENT TEST?
2639 016416 001114 BNE $OVER ;;YES IF SW14=1
2640 ;*****START OF CODE FOR THE XOR TESTER*****
2641 016420 000416 $XTSTR: BR 6$ ;;IF RUNNING ON THE "XOR" TESTER CHANGE
2642 ;THIS INSTRUCTION TO A "NOP" (NOP=240)
2643 016422 013746 000004 MOV 2$ERRVEC, -(SP) ;;SAVE THE CONTENTS OF THE ERROR VECTOR
2644 016426 012737 016446 000004 MOV 5$, 2$ERRVEC ;;SET FOR TIMEOUT
2645 016434 005737 177060 TST 2$177060 ;;TIME OUT ON XOR?
2646 016440 012637 000004 MOV (SP)+, 2$ERRVEC ;;RESTORE THE ERROR VECTOR
2647 016444 000463 $SVLAD ;;GO TO THE NEXT TEST
2648 016446 022626 5$: CMP (SP)+, (SP)+ ;;CLEAR THE STACK AFTER A TIME OUT
2649 016450 012637 000004 MOV (SP)+, 2$ERRVEC ;;RESTORE THE ERROR VECTOR
2650 016454 000423 BR 7$ ;;LOOP ON THE PRESENT TEST
2651 016456 6$: ;*****END OF CODE FOR THE XOR TESTER*****
2652 016456 032777 000400 162454 BIT #BIT08,$SWR ;;LOOP ON SPEC. TEST?
2653 016464 001404 BEQ 2$ ;;BR IF NO
2654 016466 127737 162446 001102 CMPB 2$SWR,$TSTNM ;;ON THE RIGHT TEST? SWR<7:0>
2655 016474 001465 BEQ $OVER ;;BR IF YES
2656 016476 105737 001103 2$: TSTB $ERFLG ;;HAS AN ERROR OCCURRED?
2657 016502 001421 BEQ 3$ ;;BR IF NO
2658 016504 123737 001115 001103 CMPB $ERMAX,$ERFLG ;;MAX. ERRORS FOR THIS TEST OCCURRED?
2659 016512 101015 BHI 3$ ;;BR IF NO
2660 016514 032777 001000 162416 BIT #BIT09,$SWR ;;LOOP ON ERROR?
2661 016522 001404 BEQ 4$ ;;BR IF NO
2662 016524 013737 001110 001106 7$: MOV $LPERR,$LPADR ;;SET LOOP ADDRESS TO LAST SCOPE
2663 016532 000446 BR $OVER
2664 016534 105037 001103 4$: CLRB $ERFLG ;;ZERO THE ERROR FLAG
2665 016540 005037 001166 CLR $TIMES ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
2666 016544 000415 BR 1$ ;;ESCAPE TO THE NEXT TEST
2667 016546 032777 004000 162364 3$: BIT #BIT11,$SWR ;;INHIBIT ITERATIONS?
2668 016554 001011 BNE 1$ ;;BR IF YES
2669 016556 005737 001204 TST $PASS ;;IF FIRST PASS OF PROGRAM
2670 016562 001406 BEQ 1$ ;;INHIBIT ITERATIONS

```

Address	Hex	Hex	Hex	Hex	Label	Instruction	Comment
2671	016564	005237	001104			INC	SICNT
2672	016570	023737	001166	001104		CMP	\$TIMES,\$SICNT
2673	016576	002024				BGE	\$OVER
2674	016600	012737	000001	001104	1\$:	MOV	#1,\$SICNT
2675	016606	013737	016664	001166		MOV	\$MXCNT,\$TIMES
2676	016614	105237	001102		\$SVLAD:	INCB	\$STNM
2677	016620	113737	001102	001202		MOVB	\$STNM,\$TESTN
2678	016626	011637	001106			MOV	(SP),\$LPADR
2679	016632	011637	001110			MOV	(SP),\$LPERR
2680	016636	005037	001170			CLR	\$ESCAPE
2681	016642	112737	000001	001115		MOVB	#1,\$ERMAX
2682	016650	013777	001102	162264	\$OVER:	MOV	\$STNM,\$DISPLAY
2683	016656	013716	001106			MOV	\$LPADR,(SP)
2684	016662	000002				RTI	
2685	016664	000006			\$MXCNT:	6.	
2686					.SBTTL	ERROR HANDLER ROUTINE	
2687							
2688							
2689							
2690							
2691							
2692							
2693							
2694							
2695							
2696							
2697							
2698							
2699	016666				\$ERROR:		
2700	016666	104407				CKSWR	
2701	016670	105237	001103		7\$:	INCB	\$ERFLG
2702	016674	001775				BEQ	7\$
2703	016676	013777	001102	162236		MOV	\$STNM,\$DISPLAY
2704	016704	005237	001112			INC	\$ERTTL
2705	016710	011637	001116			MOV	(SP),\$ERRPC
2706	016714	162737	000002	001116		SUB	#2,\$ERRPC
2707	016722	117737	162170	001114		MOVB	\$ERRPC,\$ITEMB
2708	016730	032777	020000	162202		BIT	#BIT13,\$SWR
2709	016736	001004				BNE	20\$
2710	016740	004737	017730			JSR	PC,\$ERRTYP
2711	016744	104401	001173			TYPE	\$CRLF
2712	016750				20\$:		
2713	016750	122737	000001	001216		CMPB	#APTENV,\$ENV
2714	016756	001007				BNE	2\$
2715	016760	113737	001114	016772		MOVB	\$ITEMB,21\$
2716	016766	004737	021032			JSR	PC,\$ATY4
2717	016772	000			21\$:	.BYTE	0
2718	016773	000				.BYTE	0
2719	016774	000777			22\$:	BR	22\$
2720	016776	005777	162136		2\$:	TST	\$SWR
2721	017002	100002				BPL	3\$
2722	017004	000000				HALT	
2723	017006	104407				CKSWR	
2724	017010	032777	001000	162122	3\$:	BIT	#BIT09,\$SWR

```

2725 017016 001402          BEQ      4$          ;;BR IF NO
2726 017020 013716 001110    MOV      $LPERR,(SP)    ;;FUDGE RETURN FOR LOOPING
2727 017024 005737 001170    4$:    TST      $ESCAPE    ;;CHECK FOR AN ESCAPE ADDRESS
2728 017030 001402          BEQ      5$          ;;BR IF NONE
2729 017032 013716 001170    MOV      $ESCAPE,(SP)    ;;FUDGE RETURN ADDRESS FOR ESCAPE
2730 017036          5$:    CMP      #SEI:DAD,2#42    ;;ACT-11 AUTO-ACCEPT?
2731 017036 022737 013746 000042    BNE      6$          ;;BRANCH IF NO
2732 017044 001001          BNE      6$          ;;YES
2733 017046 000000          HALT                    ;;YES
2734 017050          6$:    RTI                      ;;RETURN
2735 017050 000002          .SBTTL  TTY INPUT ROUTINE
2736          ;;*****
2737          .ENABL  LSB
2738          ;;*****
2739          ;;SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
2740          ;;ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
2741          ;;SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
2742          ;;WHEN OPERATING IN TTY FLAG MODE.
2743          $CKSWR:  CMP      #SWREG,SWR    ;;IS THE SOFT-SWR SELECTED?
2744          BNE      15$    ;;BRANCH IF NO
2745          TSTB     2$TKS    ;;CHAR THERE?
2746          BPL      15$    ;;IF NO, DON'T WAIT AROUND
2747          MOV      2$TKB,-(SP)    ;;SAVE THE CHAR
2748          BIC      #1C177,(SP)    ;;STRIP-OFF THE ASCII
2749          CMP      #7,(SP)+    ;;IS IT A CONTROL G?
2750          BNE      15$    ;;NO, RETURN TO USER
2751          CMP      $AUTOB,#1    ;;ARE WE RUNNING IN AUTO-MODE?
2752          BEQ      15$    ;;BRANCH IF YES
2753          15$:    TYPE      , $CNTLG    ;;ECHO THE CONTROL-G (↑G)
2754          19$:    TYPE      , $MSWR    ;;TYPE CURRENT CONTENTS
2755          MOV      $WREG,-(SP)    ;;SAVE SWREG FOR TYPEOUT
2756          TYPE      , $MNEW    ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
2757          CLR      -(SP)    ;;PROMPT FOR NEW SWR
2758          CLR      -(SP)    ;;CLEAR COUNTER
2759          TSTB     2$TKS    ;;THE NEW SWR
2760          BPL      7$    ;;CHAR THERE?
2761          MOV      2$TKB,-(SP)    ;;IF NOT TRY AGAIN
2762          BIC      #1C177,(SP)    ;;PICK UP CHAR
2763          7$:    MOV      2$TKB,-(SP)    ;;MAKE IT 7-BIT ASCII
2764          BIC      #1C177,(SP)
2765          9$:    CMP      (SP),#25    ;;IS IT A CONTROL-U?
2766          BNE      10$    ;;BRANCH IF NOT
2767          TYPE      , $CNTLU    ;;YES, ECHO CONTROL-U (↑U)
2768          ADD      #6,SP    ;;IGNORE PREVIOUS INPUT
2769          BR       19$    ;;LET'S TRY IT AGAIN
2770
2771 017162 021627 000025    9$:    CMP      (SP),#25
2772 017166 001005          BNE      10$
2773 017170 104401 017572    TYPE      , $CNTLU
2774 017174 062706 000006    20$:   ADD      #6,SP
2775 017200 000757          BR       19$
2776
2777
2778

```

```

2779 017202 021627 000015      10$: CMP      (SP),#15      ; IS IT A <CR>?
2780 017206 001022              BNE      16$      ; BRANCH IF NO
2781 017210 005766 000004      TST      4(SP)      ; YES, IS IT THE FIRST CHAR?
2782 017214 001403              BEQ      11$      ; BRANCH IF YES
2783 017216 016677 000002 161714 MOV      2(SP),@SWR      ; SAVE NEW SWR
2784 017224 062706 000006      11$: ADD      #6,SP      ; CLEAR UP STACK
2785 017230 104401 001173      14$: TYPE    $CRLF      ; ECHO <CR> AND <LF>
2786 017234 123727 001135 000001 CMPB     $INTAG,#1      ; RE-ENABLE TTY KBD INTERRUPTS?
2787 017242 001003              BNE      15$      ; BRANCH IF NOT
2788 017244 012777 000100 161672 MOV      #100,@STKS      ; RE-ENABLE TTY KBD INTERRUPTS
2789 017252 000002              RTI              ; RETURN
2790 017254 004737 020744      15$: JSR      PC,$TYPEC      ; ECHO CHAR
2791 017260 021627 000060      16$: CMP      (SP),#60      ; CHAR < 0?
2792 017264 002420              BLT      18$      ; BRANCH IF YES
2793 017266 021627 000067      CMP      (SP),#67      ; CHAR > 7?
2794 017272 003015              BGT      18$      ; BRANCH IF YES
2795 017274 042726 000060      BIC      #60,(SP)+      ; STRIP-OFF ASCII
2796 017300 005766 000002      TST      2(SP)      ; IS THIS THE FIRST CHAR
2797 017304 001403              BEQ      17$      ; BRANCH IF YES
2798 017306 006316              ASL      (SP)      ; NO, SHIFT PRESENT
2799 017310 006316              ASL      (SP)      ; CHAR OVER TO MAKE
2800 017312 006316              ASL      (SP)      ; ROOM FOR NEW ONE.
2801 017314 005266 000002      17$: INC      2(SP)      ; KEEP COUNT OF CHAR
2802 017320 056616 177776      BIS      -2(SP),(SP)      ; SET IN NEW CHAR
2803 017324 000707              BR       7$      ; GET THE NEXT ONE
2804 017326 104401 001172      18$: TYPE    $QUES      ; TYPE ?<CR><LF>
2805 017332 000720              BR       20$      ; SIMULATE CONTROL-U
2806
2807 .DSABL LSB
2808
2809 ;*****
2810 ;*****
2811 ;*****
2812 ;*****
2813 ;*****
2814 ;*****
2815 ;*****
2816 ;*****
2817 017334 011646 000004 000002 $RDCHR: MOV      (SP),-(SP)      ; PUSH DOWN THE PC
2818 017336 016666 000004 161574 1$: MOV      4(SP),2(SP)      ; SAVE THE PS
2819 017344 105777 161574      TSTB     @STKS      ; WAIT FOR
2820 017350 100375              BPL      1$      ; A CHARACTER
2821 017352 117766 161570 000004 MOVB     @STKB,4(SP)      ; READ THE TTY
2822 017360 042766 177600 000004 BIC      #1C(177),4(SP)      ; GET RID OF JUNK IF ANY
2823 017366 026627 000004 000023 CMP      4(SP),#23      ; IS IT A CONTROL-S?
2824 017374 001013              BNE      3$      ; BRANCH IF NO
2825 017376 105777 161542      2$: TSTB     @STKS      ; WAIT FOR A CHARACTER
2826 017402 100375              BPL      2$      ; LOOP UNTIL ITS THERE
2827 017404 117746 161536      MOVB     @STKB,-(SP)      ; GET CHARACTER
2828 017410 042716 177600      BIC      #1C177,(SP)      ; MAKE IT 7-BIT ASCII
2829 017414 022627 000021      CMP      (SP)+,#21      ; IS IT A CONTROL-Q?
2830 017420 001366              BNE      2$      ; IF NOT DISCARD IT
2831 017422 000750              BR       1$      ; YES, RESUME
2832 017424 026627 000004 000140 3$: CMP      4(SP),#140      ; IS IT UPPER CASE?

```

```

2833 017432 002407          BLT      4$          ;; BRANCH IF YES
2834 017434 026627 000004 000175      CMP      4(SP),#175      ;; IS IT A SPECIAL CHAR?
2835 017442 003003          BGT      4$          ;; BRANCH IF YES
2836 017444 042766 000040 000004      BIC      #40,4(SP)      ;; MAKE IT UPPER CASE
2837 017452 000002          RTI          ;; GO BACK TO USER
2838                                     *****
2839                                     ; THIS ROUTINE WILL INPUT A STRING FROM THE TTY
2840                                     ; *CALL:
2841                                     ; *
2842                                     ; *      RDLIN
2843                                     ; *      RETURN HERE
2844                                     ; *
2845                                     ; INPUT A STRING FROM THE TTY
2846                                     ; ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
2847                                     ; TERMINATOR WILL BE A BYTE OF ALL 0'S
2848 017454 010346          $RDLIN: MOV      R3, -(SP)      ;; SAVE R3
2849 017456 012703 017562      1$: MOV      #STTYIN, R3      ;; GET ADDRESS
2850 017462 022703 017572      2$: CMP      #STTYIN+8., R3      ;; BUFFER FULL?
2851 017466 101405          BLOS      4$          ;; BR IF YES
2852 017470 104410          ROCHR      ;; GO READ ONE CHARACTER FROM THE TTY
2853 017472 112613          MOVB      (SP)+, (R3)      ;; GET CHARACTER
2854 017474 122713 000177      10$: CMPB     #177, (R3)      ;; IS IT A RUBOUT
2855 017500 001003          BNE      3$          ;; SKIP IF NOT
2856 017502 104401 001172      4$: TYPE     $QUES      ;; TYPE A '?'
2857 017506 000763          BR       1$          ;; CLEAR THE BUFFER AND LOOP
2858 017510 111337 017560      3$: MOVB      (R3), 9$      ;; ECHO THE CHARACTER
2859 017514 104401 017560          TYPE     9$
2860 017520 122723 000015          CMPB      #15, (R3)+      ;; CHECK FOR RETURN
2861 017524 001356          BNE      2$          ;; LOOP IF NOT RETURN
2862 017526 105063 177777          CLRB      -1(R3)      ;; CLEAR RETURN (THE 15)
2863 017532 104401 001174          TYPE     $LF      ;; TYPE A LINE FEED
2864 017536 012603          MOV      (SP)+, R3      ;; RESTORE R3
2865 017540 011646          MOV      (SP), -(SP)      ;; ADJUST THE STACK AND PUT ADDRESS OF THE
2866 017542 016666 000004 000002      MOV      4(SP), 2(SP)      ;; FIRST ASCII CHARACTER ON IT
2867 017550 012766 017562 000004      MOV      #STTYIN, 4(SP)
2868 017556 000002          RTI          ;; RETURN
2869 017560 000          9$: .BYTE      0      ;; STORAGE FOR ASCII CHAR. TO TYPE
2870 017561 000          .BYTE      0      ;; TERMINATOR
2871 017562 000010          $TTYIN: .BLKB      8.      ;; RESERVE 8 BYTES FOR TTY INPUT
2872 017572 052536 005015 000      $CNTLU: .ASCIZ  /↑U/<15><12>      ;; CONTROL "U"
2873 017577 136 006507 000012      $CNTLG: .ASCIZ  /↑G/<15><12>      ;; CONTROL "G"
2874 017604 005015 053523 020122      $MSWR: .ASCIZ  <15><12>/SWR = /
2875 017612 020075 000
2876 017615 040 047040 053505      $MNEW: .ASCIZ  / NEW = /
2877 017622 036440 000040
2878                                     .SBTTL READ AN OCTAL NUMBER FROM THE TTY
2879                                     *****
2880                                     ; THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
2881                                     ; *CHANGE IT TO BINARY.
2882                                     ; *CALL:
2883                                     ; *
2884                                     ; *      RDOCT
2885                                     ; *      RETURN HERE
2886                                     ; *
2887                                     ; READ AN OCTAL NUMBER
2888                                     ; LOW ORDER BITS ARE ON TOP OF THE STACK
2889                                     ; HIGH ORDER BITS ARE IN $HIOCT
2890 017626 011646          $RDOCT: MOV      (SP), -(SP)      ;; PROVIDE SPACE FOR THE
2891 017630 016666 000004 000002      MOV      4(SP), 2(SP)      ;; INPUT NUMBER

```

```

2887 017636 010046      MOV      R0,-(SP)      ;; PUSH R0 ON STACK
2888 017640 010146      MOV      R1,-(SP)      ;; PUSH R1 ON STACK
2889 017642 010246      MOV      R2,-(SP)      ;; PUSH R2 ON STACK
2890 017644 104411      1$:      RDLIN      ;; READ AN ASCII LINE
2891 017646 012600      MOV      (SP)+,R0      ;; GET ADDRESS OF 1ST CHARACTER
2892 017650 005001      CLR      R1      ;; CLEAR DATA WORD
2893 017652 005002      CLR      R2
2894 017654 112046      2$:      MOVB      (R0)+,-(SP)      ;; PICKUP THIS CHARACTER
2895 017656 001412      BEQ      3$      ;; IF ZERO GET OUT
2896 017660 006301      ASL      R1      ;; *2
2897 017662 006102      ROL      R2
2898 017664 006301      ASL      R1      ;; *4
2899 017666 006102      ROL      R2
2900 017670 006301      ASL      R1      ;; *8
2901 017672 006102      ROL      R2
2902 017674 042716 177770 BIC      #1C7,(SP)      ;; STRIP THE ASCII JUNK
2903 017700 062601      ADD      (SP)+,R1      ;; ADD IN THIS DIGIT
2904 017702 000764      BR      2$      ;; LOOP
2905 017704 005726      3$:      TST      (SP)+      ;; CLEAN TERMINATOR FROM STACK
2906 017706 010166 000012 MOV      R1,12(SP)      ;; SAVE THE RESULT
2907 017712 010237 017726 MOV      R2,$SHIOCT
2908 017716 012602      MOV      (SP)+,R2      ;; POP STACK INTO R2
2909 017720 012601      MOV      (SP)+,R1      ;; POP STACK INTO R1
2910 017722 012600      MOV      (SP)+,R0      ;; POP STACK INTO R0
2911 017724 000002      RTI      ;; RETURN
2912 017726 000000      $SHIOCT: .WORD      0      ;; HIGH ORDER BITS GO HERE
2913
2914      .SBTTL  ERROR MESSAGE TYPEOUT ROUTINE
2915
2916      ;; *****
2917      ;; *THIS ROUTINE USES THE "ITEM CONTROL BY"E" ($ITEMB) TO DETERMINE WHICH
2918      ;; *ERROR IS TO BE REPORTED. IT THEN OBTAINS FROM THE "ERROR TABLE" ($ERRTB).
2919      ;; *AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.
2920
2921 017730      $ERRTYP:
2922 017730 104401 001173      TYPE      $SCRLF      ;; "CARRIAGE RETURN" & "LINE FEED"
2923 017734 010046      MOV      R0,-(SP)      ;; SAVE R0
2924 017736 005000      CLR      R0      ;; PICKUP THE ITEM INDEX
2925 017740 153700 001114      BISB      2*$ITEMB,R0
2926 017744 001004      BNE      1$
2927
2928 017746 013746 001116      MOV      $ERRPC,-(SP)      ;; IF ITEM NUMBER IS ZERO, JUST
2929
2930 017752 104402      TYP0C      ;; TYPE THE PC OF THE ERROR
2931 017754 000426      BR      6$      ;; SAVE $ERRPC FOR TYPEOUT
2932 017756 005300      1$:      DEC      R0      ;; ERROR ADDRESS
2933 017760 006300      ASL      R0      ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
2934 017762 006300      ASL      R0      ;; GET OUT
2935 017764 006300      ASL      R0      ;; ADJUST THE INDEX SO THAT IT WILL
2936 017766 062700 001322 ADD      # $ERRTB,R0      ;; WORK FOR THE ERROR TABLE
2937 017772 012037 020002 MOV      (R0)+,2$      ;; FORM TABLE POINTER
2938 017776 001404      BEQ      3$      ;; PICKUP "ERROR MESSAGE" POINTER
2939 020000 104401      TYPE      ;; SKIP TYPEOUT IF NO POINTER
2940 020002 000000      2$:      .WORD      0      ;; TYPE THE "ERROR MESSAGE"
      ;; "ERROR MESSAGE" POINTER GOES HERE

```

```

2941 020004 104401 001173      TYPE      $CRLF      ; "CARRIAGE RETURN" & "LINE FEED"
2942 020010 012037 020020      3$: MOV      (RO)+,4$      ; PICKUP "DATA HEADER" POINTER
2943 020014 001404      BEQ      5$      ; SKIP TYPEOUT IF 0
2944 020016 104401      TYPE      ; TYPE THE "DATA HEADER"
2945 020020 000000      4$: .WORD      0      ; "DATA HEADER" POINTER GOES HERE
2946 020022 104401 001173      TYPE      $CRLF      ; "CARRIAGE RETURN" & "LINE FEED"
2947 020026 011000      5$: MOV      (RO),RO      ; PICKUP "DATA TABLE" POINTER
2948 020030 001004      BNE      7$      ; GO TYPE THE DATA
2949 020032 012600      6$: MOV      (SP)+,RO      ; RESTORE RO
2950 020034 104401 001173      TYPE      $CRLF      ; "CARRIAGE RETURN" & "LINE FEED"
2951 020040 000207      RTS      PC      ; RETURN
2952 020042      7$:      ;
2953 020042 013046      MOV      2(RO)+,-(SP)      ; SAVE 2(RO)+ FOR TYPEOUT
2954 020044 104402      TYPOC      ; GO TYPE--OCTAL ASCII(ALL DIGITS)
2955 020046 005710      TST      (RO)      ; IS THERE ANOTHER NUMBER?
2956 020050 001770      BEQ      6$      ; BR IF NO
2957 020052 104401 020060      TYPE      8$      ; TYPE TWO(2) SPACES
2958 020056 000771      BR      7$      ; LOOP
2959 020060 020040      8$: .ASCIZ      / /      ; TWO(2) SPACES
2960 020064 020064      .EVEN
2961
2962 .SBTTL POWER DOWN AND UP ROUTINES
2963
2964 ;*****
2965 ;POWER DOWN ROUTINE
2966 020064 012737 020230 000024 $PWRDN: MOV      $SILLUP,2$PWRVEC      ; SET FOR FAST UP
2967 020072 012737 000340 000026      MOV      2$PWRVEC+2      ; PRIO:7
2968 020100 010046      MOV      RO,-(SP)      ; PUSH RO ON STACK
2969 020102 010146      MOV      R1,-(SP)      ; PUSH R1 ON STACK
2970 020104 010246      MOV      R2,-(SP)      ; PUSH R2 ON STACK
2971 020106 010346      MOV      R3,-(SP)      ; PUSH R3 ON STACK
2972 020110 010446      MOV      R4,-(SP)      ; PUSH R4 ON STACK
2973 020112 010546      MOV      R5,-(SP)      ; PUSH R5 ON STACK
2974 020114 017746 161020      MOV      2$SWR,-(SP)      ; PUSH 2$SWR ON STACK
2975 020120 010637 020234      MOV      SP,$SAVR6      ; SAVE SP
2976 020124 012737 020136 000024      MOV      $PWRUP,2$PWRVEC      ; SET UP VECTOR
2977 020132 000000      HALT
2978 020134 000776      BR      -2      ; HANG UP
2979
2980 ;*****
2981 ;POWER UP ROUTINE
2982 020136 012737 020230 000024 $PWRUP: MOV      $SILLUP,2$PWRVEC      ; SET FOR FAST DOWN
2983 020144 013706 020234      MOV      $SAVR6,SP      ; GET SP
2984 020150 005037 020234      CLR      $SAVR6      ; WAIT LOOP FOR THE TTY
2985 020154 005237 020234      1$: INC      $SAVR6      ; WAIT FOR THE INC
2986 020160 001375      BNE      1$      ; OF WORD
2987 020162 012677 160752      MOV      (SP)+,2$SWR      ; POP STACK INTO 2$SWR
2988 020166 012605      MOV      (SP)+,R5      ; POP STACK INTO R5
2989 020170 012604      MOV      (SP)+,R4      ; POP STACK INTO R4
2990 020172 012603      MOV      (SP)+,R3      ; POP STACK INTO R3
2991 020174 012602      MOV      (SP)+,R2      ; POP STACK INTO R2
2992 020176 012601      MOV      (SP)+,R1      ; POP STACK INTO R1
2993 020200 012600      MOV      (SP)+,RO      ; POP STACK INTO RO
2994 020202 012737 020064 000024      MOV      $PWRDN,2$PWRVEC      ; SET UP THE POWER DOWN VECTOR

```

```

2995 020210 012737 000340 000026      MOV      #340, @#PWRVEC+2    ;; PRI0:7
2996 020216 104401                      TYPE                      ;; REPORT THE POWER FAILURE
2997 020220 020236      $PWRMG: .WORD    PWRMSG              ;; POWER FAIL MESSAGE POINTER
2998 020222 012716      MOV      (PC)+, (SP)                ;; RESTART AT BEGIN1
2999 020224 001676      $PWRAD: .WORD    BEGIN1              ;; RESTART ADDRESS
3000 020226 000002      RTI                                  ;;
3001 020230 000000      $ILLUP: HALT                          ;; THE POWER UP SEQUENCE WAS STARTED
3002 020232 000776      BR        .-2                        ;; BEFORE THE POWER DOWN WAS COMPLETE
3003 020234 000000      $SAVR6: 0                            ;; PUT THE SP HERE
3004 020236 005015 042522 052123      PWRMSG: .ASCIZ  <15><12>/RESTARTING AFTER A POWER FAILURE/<15><12><12>
3005 020244 051101 044524 043516
3006 020252 040440 052106 051105
3007 020260 040440 050040 053517
3008 020266 051105 043040 044501
3009 020274 052514 042522 005015
3010 020302 000012
3011
3012
3013
3014
3015
3016
3017
3018
3019
3020
3021
3022
3023
3024
3025
3026
3027
3028
3029
3030
3031
3032
3033
3034
3035
3036
3037
3038 020304 017646 000000
3039 020310 116637 000001 020527
3040 020316 112637 020531
3041 020322 062716 000002
3042 020326 000406
3043 020330 112737 000001 020527
3044 020336 112737 000006 020531
3045 020344 112737 000005 020526
3046 020352 010346
3047 020354 010446
3048 020356 010546

.EVEN
.SBTTL  BINARY TO OCTAL (ASCII) AND TYPE
*****
;THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
;OCTAL (ASCII) NUMBER AND TYPE IT.
;$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
;CALL:
;      MOV      NUM, -(SP)          ;; NUMBER TO BE TYPED
;      TYPOS          ;; CALL FOR TYPEOUT
;      .BYTE    N          ;; N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
;      .BYTE    M          ;; M=1 OR 0
;                               ;; 1=TYPE LEADING ZEROS
;                               ;; 0=SUPPRESS LEADING ZEROS
;$STYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
;$TYPOS OR $TYPOC
;CALL:
;      MOV      NUM, -(SP)          ;; NUMBER TO BE TYPED
;      TYPON          ;; CALL FOR TYPEOUT
;$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
;CALL:
;      MOV      NUM, -(SP)          ;; NUMBER TO BE TYPED
;      TYPOC          ;; CALL FOR TYPEOUT
$TYPOS: MOV      @ (SP), -(SP)      ;; PICKUP THE MODE
        MOVB     1 (SP), $OFILL      ;; LOAD ZERO FILL SWITCH
        MOVB     (SP)+, $OMODE+1      ;; NUMBER OF DIGITS TO TYPE
        ADD      #2, (SP)            ;; ADJUST RETURN ADDRESS
        BR       $TYPON
$TYPOC: MOVB     #1, $OFILL          ;; SET THE ZERO FILL SWITCH
        MOVB     #6, $OMODE+1        ;; SET FOR SIX(6) DIGITS
$TYPON: MOVB     #5, $OCNT           ;; SET THE ITERATION COUNT
        MOV      R3, -(SP)           ;; SAVE R3
        MOV      R4, -(SP)           ;; SAVE R4
        MOV      R5, -(SP)           ;; SAVE R5

```

```

3049 020360 113704 020531      MOVB $OMODE+1,R4      ;;GET THE NUMBER OF DIGITS TO TYPE
3050 020364 005404      NEG R4
3051 020366 062704 000006      ADD #6,R4          ;;SUBTRACT IT FOR MAX. ALLOWED
3052 020372 110437 020530      MOVB R4,$OMODE      ;;SAVE IT FOR USE
3053 020376 113704 020527      MOVB $OFILL,R4      ;;GET THE ZERO FILL SWITCH
3054 020402 016605 000012      MOV 12(SP),R5      ;;PICKUP THE INPUT NUMBER
3055 020406 005003      CLR R3          ;;CLEAR THE OUTPUT WORD
3056 020410 006105      1$: ROL R5          ;;ROTATE MSB INTO "C"
3057 020412 000404      BR 3$          ;;GO DO MSB
3058 020414 006105      2$: ROL R5          ;;FORM THIS DIGIT
3059 020416 006105      ROL R5
3060 020420 006105      ROL R5
3061 020422 010503      MOV R5,R3
3062 020424 006103      3$: ROL R3          ;;GET LSB OF THIS DIGIT
3063 020426 105337 020530      DECB $OMODE      ;;TYPE THIS DIGIT?
3064 020432 100016      BPL 7$          ;;BR IF NO
3065 020434 042703 177770      BIC #177770,R3      ;;GET RID OF JUNK
3066 020440 001002      BNE 4$          ;;TEST FOR 0
3067 020442 005704      TST R4          ;;SUPPRESS THIS 0?
3068 020444 001403      BEQ 5$          ;;BR IF YES
3069 020446 005204      4$: INC R4          ;;DON'T SUPPRESS ANYMORE 0'S
3070 020450 052703 000060      BIS #'0,R3      ;;MAKE THIS DIGIT ASCII
3071 020454 052703 000040      5$: BIS #'1,R3      ;;MAKE ASCII IF NOT ALREADY
3072 020460 110337 020524      MOVB R3,$$      ;;SAVE FOR TYPING
3073 020464 104401 020524      TYPE 8$          ;;GO TYPE THIS DIGIT
3074 020470 105337 020526      7$: DECB $OCNT      ;;COUNT BY 1
3075 020474 003347      BGT 2$          ;;BR IF MORE TO DO
3076 020476 002402      BLT 6$          ;;BR IF DONE
3077 020500 005204      INC R4          ;;INSURE LAST DIGIT ISN'T A BLANK
3078 020502 000744      BR 2$          ;;GO DO THE LAST DIGIT
3079 020504 012605      6$: MOV (SP)+,R5      ;;RESTORE R5
3080 020506 012604      MOV (SP)+,R4      ;;RESTORE R4
3081 020510 012603      MOV (SP)+,R3      ;;RESTORE R3
3082 020512 016666 000002 000004      MOV 2(SP),4(SP)      ;;SET THE STACK FOR RETURNING
3083 020520 012616      MOV (SP)+,(SP)
3084 020522 000002      RTI          ;;RETURN
3085 020524 000      8$: .BYTE 0          ;;STORAGE FOR ASCII DIGIT
3086 020525 000      .BYTE 0          ;;TERMINATOR FOR TYPE ROUTINE
3087 020526 000      $OCNT: .BYTE 0      ;;OCTAL DIGIT COUNTER
3088 020527 000      $OFILL: .BYTE 0      ;;ZERO FILL SWITCH
3089 020530 000000      $OMODE: .WORD 0      ;;NUMBER OF DIGITS TO TYPE
3090      .SBTTL TYPE ROUTINE
3091
3092      ;*****
3093      ;ROUTINE TO TYPE ASCII MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
3094      ;THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
3095      ;*NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
3096      ;*NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
3097      ;*NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
3098      ;
3099      ;*CALL:
3100      ;*1) USING A TRAP INSTRUCTION
3101      ;* TYPE ,MESADR      ;;MESADR IS FIRST ADDRESS OF AN ASCII STRING
3102      ;*OR

```

```

3103      ;*      TYPE
3104      ;*      MESADR
3105      ;*
3106
3107      020532  105737  001157      $TYPE:  TSTB      $TPFLG      ;; IS THERE A TERMINAL?
3108      020536  100002                      BPL          1$      ;; BR IF YES
3109      020540  000000                      HALT          ;; HALT HERE IF NO TERMINAL
3110      020542  000430                      BR           3$      ;; LEAVE
3111      020544  010046      1$:      MOV      RD, -(SP)      ;; SAVE RD
3112      020546  017600  000002      MOV      22(SP), RD      ;; GET ADDRESS OF ASCIZ STRING
3113      020552  122737  000001  001216      CMPB      #APTENV, $ENV      ;; RUNNING IN APT MODE
3114      020560  001011                      BNE          62$      ;; NO GO CHECK FOR APT CONSOLE
3115      020562  132737  000100  001217      BITB      #APTSPool, $ENV      ;; SPOOL MESSAGE TO APT
3116      020570  001405                      BEQ          62$      ;; NO GO CHECK FOR CONSOLE
3117      020572  010037  020602      MOV      RD, 61$      ;; SETUP MESSAGE ADDRESS FOR APT
3118      020576  004737  021022      JSR      PC, $ATY3      ;; SPOOL MESSAGE TO APT
3119      020602  000000      61$:      .WORD      0      ;; MESSAGE ADDRESS
3120      020604  132737  000040  001217      62$:      BITB      #APTCSUP, $ENV      ;; APT CONSOLE SUPPRESSED
3121      020612  001003                      BNE          60$      ;; YES, SKIP TYPE OUT
3122      020614  112046      2$:      MOVB      (RD)+, -(SP)      ;; PUSH CHARACTER TO BE TYPED ONTO STACK
3123      020616  001005                      BNE          4$      ;; BR IF IT ISN'T THE TERMINATOR
3124      020620  005726                      TST          (SP)+      ;; IF TERMINATOR POP IT OFF THE STACK
3125      020622  012600      60$:      MOV      (SP)+, RD      ;; RESTORE RD
3126      020624  062716  000002      3$:      ADD      #2, (SP)      ;; ADJUST RETURN PC
3127      020630  000002                      RTI          ;; RETURN
3128      020632  122716  000011      4$:      CMPB      #HT, (SP)      ;; BRANCH IF <HT>
3129      020636  001430                      BEQ          8$      ;;
3130      020640  122716  000200      CMPB      #CRLF, (SP)      ;; BRANCH IF NOT <CRLF>
3131      020644  001006                      BNE          5$      ;;
3132      020646  005726                      TST          (SP)+      ;; POP <CR><LF> EQUIV
3133      020650  104401                      TYPE          ;; TYPE A CR AND LF
3134      020652  001173      $CRLF
3135      020654  105037  021010      CLRB      $CHARCNT      ;; CLEAR CHARACTER COUNT
3136      020660  000755                      BR           2$      ;; GET NEXT CHARACTER
3137      020662  004737  020744      5$:      JSR      PC, $TYPEC      ;; GO TYPE THIS CHARACTER
3138      020666  123726  001156      6$:      CMPB      $FILLC, (SP)+      ;; IS IT TIME FOR FILLER CHARS.?
3139      020672  001350                      BNE          2$      ;; IF NO GO GET NEXT CHAR.
3140      020674  013746  001154      MOV      $NULL, -(SP)      ;; GET # OF FILLER CHARS. NEEDED
3141                      AND THE NULL CHAR.
3142      020700  105366  000001      7$:      DECB      1(SP)      ;; DOES A NULL NEED TO BE TYPED?
3143      020704  002770                      BLT          6$      ;; BR IF NO--GO POP THE NULL OFF OF STACK
3144      020706  004737  020744      JSR      PC, $TYPEC      ;; GO TYPE A NULL
3145      020712  105337  021010      DECB      $CHARCNT      ;; DO NOT COUNT AS A COUNT
3146      020716  000770                      BR           7$      ;; LOOP
3147
3148      ;HORIZONTAL TAB PROCESSOR
3149
3150      020720  112716  000040      8$:      MOVB      #' (SP)      ;; REPLACE TAB WITH SPACE
3151      020724  004737  020744      9$:      JSR      PC, $TYPEC      ;; TYPE A SPACE
3152      020730  132737  000007  021010      BITB      #7, $CHARCNT      ;; BRANCH IF NOT AT
3153      020736  001372                      BNE          9$      ;; TAB STOP
3154      020740  005726                      TST          (SP)+      ;; POP SPACE OFF STACK
3155      020742  000724                      BR           2$      ;; GET NEXT CHARACTER
3156      020744  105777  160200      $TYPEC:  TSTB      2$TPS      ;; WAIT UNTIL PRINTER IS READY

```

```

3157 020750 100375      BPL      $TYPEC
3158 020752 116677 000002 160172      MOV      2(SP), 2$TPB
3159 020760 122766 000015 000002      CMPB     #CR, 2(SP)
3160 020766 001003      BNE      1$
3161 020770 105037 021010      CLRB     $CHARCNT
3162 020774 000406      BR       $TYPEX
3163 020776 122766 000012 000002 1$:      CMPB     #LF, 2(SP)
3164 021004 001402      BEQ      $TYPEX
3165 021006 105227      INCB     (PC)+
3166 021010 000000      $CHARCNT: .WORD 0
3167 021012 000207      $TYPEX: RTS      PC
3168
3169      .SBTTL  APT COMMUNICATIONS ROUTINE
3170
3171      .*****
3172 021014 112737 000001 021260 $ATY1:  MOV      #1, $FFLG
3173 021022 112737 000001 021256 $ATY3:  MOV      #1, $MFLG
3174 021030 000403      BR       $ATYC
3175 021032 112737 000001 021260 $ATY4:  MOV      #1, $FFLG
3176 021040      $ATYC:
3177 021040 010046      MOV      RO, -(SP)
3178 021042 010146      MOV      R1, -(SP)
3179 021044 105737 021256      TSTB     $MFLG
3180 021050 001450      BEQ      5$
3181 021052 122737 000001 001216      CMPB     #APTENV, $ENV
3182 021060 001031      BNE      3$
3183 021062 132737 000100 001217      BITB     #APTSPOOL, $ENV
3184 021070 001425      BEQ      3$
3185 021072 017600 000004      MOV      24(SP), RO
3186 021076 062766 000002 000004      ADD      #2, 4(SP)
3187 021104 005737 001176      1$:      TST      $MSGTYPE
3188 021110 001375      BNE      1$
3189 021112 010037 001212      MOV      RO, $MSGAD
3190 021116 105720      2$:      TSTB     (RO)+
3191 021120 001376      BNE      2$
3192 021122 163700 001212      SUB      $MSGAD, RO
3193 021126 006200      ASR      RO
3194 021130 010037 001214      MOV      RO, $MSGGLT
3195 021134 012737 000004 001176      MOV      #4, $MSGTYPE
3196 021142 000413      BR       5$
3197 021144 017637 000004 021170 3$:      MOV      24(SP), 4$
3198 021152 062766 000002 000004      ADD      #2, 4(SP)
3199 021160 013746 177776      MOV      177776, -(SP)
3200 021164 004737 020532      JSR      PC, $TYPE
3201 021170 000000      4$:      .WORD 0
3202 021172
3203 021172 105737 021260      5$:      TSTB     $FFLG
3204 021176 001416      BEQ      12$
3205 021200 005737 001216      TST      $ENV
3206 021204 001413      BEQ      12$
3207 021206 005737 001176      11$:     TST      $MSGTYPE
3208 021212 001375      BNE      11$
3209 021214 017637 000004 001200      MOV      24(SP), $FATAL
3210 021222 062766 000002 000004      ADD      #2, 4(SP)

;; LOAD CHAR TO BE TYPED INTO DATA REG.
;; IS CHARACTER A CARRIAGE RETURN?
;; BRANCH IF NO
;; YES--CLEAR CHARACTER COUNT
;; EXIT
;; IS CHARACTER A LINE FEED?
;; BRANCH IF YES
;; COUNT THE CHARACTER
;; CHARACTER COUNT STORAGE

;;*****
;; TO REPORT FATAL ERROR
;; TO TYPE A MESSAGE
;; TO ONLY REPORT FATAL ERROR
;; PUSH RO ON STACK
;; PUSH R1 ON STACK
;; SHOULD TYPE A MESSAGE?
;; IF NOT: BR
;; OPERATING UNDER APT?
;; IF NOT: BR
;; SHOULD SPOOL MESSAGES?
;; IF NOT: BR
;; GET MESSAGE ADDR.
;; BUMP RETURN ADDR.
;; SEE IF DONE W/ LAST XMISSION?
;; IF NOT: WAIT
;; PUT ADDR IN MAILBOX
;; FIND END OF MESSAGE
;; SUB START OF MESSAGE
;; GET MESSAGE LGTH IN WORDS
;; PUT LENGTH IN MAILBOX
;; TELL APT TO TAKE MSG.
;; PUT MSG ADDR IN JSR LINKAGE
;; BUMP RETURN ADDRESS
;; PUSH 177776 ON STACK
;; CALL TYPE MACRO
;; SHOULD REPORT FATAL ERROR?
;; IF NOT: BR
;; RUNNING UNDER APT?
;; IF NOT: BR
;; FINISHED LAST MESSAGE?
;; IF NOT: WAIT
;; GET ERROR #
;; BUMP RETURN ADDR.

```

```

3211 021230 005237 001176          INC      $MSGTYPE      ;; TELL APT TO TAKE ERROR
3212 021234 105037 021260          12$:  CLRB      $FFLG      ;; CLEAR FATAL FLAG
3213 021240 105037 021257          CLRB      $LFLG      ;; CLEAR LOG FLAG
3214 021244 105037 021256          CLRB      $MFLG      ;; CLEAR MESSAGE FLAG
3215 021250 012601          MOV      (SP)+,R1      ;; POP STACK INTO R1
3216 021252 012600          MOV      (SP)+,R0      ;; POP STACK INTO R0
3217 021254 000207          RTS      PC      ;; RETURN
3218 021256          000          $MFLG: .BYTE 0      ;; MESSG. FLAG
3219 021257          000          $LFLG: .BYTE 0      ;; LOG FLAG
3220 021260          000          $FFLG: .BYTE 0      ;; FATAL FLAG
3221          021262          .EVEN
3222          000200          APTSIZE=200
3223          000001          APTENV=001
3224          000100          APTSPool=100
3225          000040          APTCSUP=040
3226          .SBTTL TRAP DEC0DER
3227
3228          ;;*****
3229          ;;*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
3230          ;;*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
3231          ;;*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
3232          ;;*GO TO THAT ROUTINE.
3233
3234 021262 010046          $TRAP: MOV      RO, -(SP)      ;; SAVE RO
3235 021264 016600 000002      MOV      2(SP),RO      ;; GET TRAP ADDRESS
3236 021270 005740          TST      -(RO)      ;; BACKUP BY 2
3237 021272 111000          MOV      (RO),RO      ;; GET RIGHT BYTE OF TRAP
3238 021274 006300          ASL      RO      ;; POSITION FOR INDEXING
3239 021276 016000 021316      MOV      $TRPAD(RO),RO      ;; INDEX TO TABLE
3240 021302 000200          RTS      RO      ;; GO TO ROUTINE
3241
3242
3243          ;;THIS IS USE TO HANDLE THE "GETPRI" MACRO
3244
3245 021304 011646          $TRAP2: MOV      (SP), -(SP)      ;; MOVE THE PC DOWN
3246 021306 016666 000004 000002      MOV      4(SP),2(SP)      ;; MOVE THE PSW DOWN
3247 021314 000002          RTI      ;; RESTORE THE PSW
3248
3249          .SBTTL TRAP TABLE
3250
3251          ;;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
3252          ;;*BY THE "TRAP" INSTRUCTION.
3253
3254          ROUTINE
3255          -----
3256 021316 021304          $TRPAD: .WORD      $TRAP2      TRAP+1(104401) TTY TYPEOUT ROUTINE
3257 021320 020532          $TYPE      ;;CALL=TYPE      TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
3258 021322 020330          $TYPOC      ;;CALL=TYPOC      TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
3259 021324 020304          $TYPOS      ;;CALL=TYPOS      TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
3260 021326 020344          $TYPON      ;;CALL=TYPON      TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
3261 021330 014120          $TYPDS      ;;CALL=TYPDS
3262
3263 021332 017122          $GTSWR      ;;CALL=GTSWR      TRAP+6(104406) GET SOFT-SWR SETTING
3264

```

```

3265 021334 017052 $CKSWR ;;CALL=CKSWR TRAP+7(104407) TEST FOR CHANGE IN SOFT-SWR
3266 021336 017334 $RDCHR ;;CALL=RDCHR TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
3267 021340 017454 $RDLIN ;;CALL=RDLIN TRAP+11(104411) TTY TYPEIN STRING ROUTINE
3268 021342 017626 $RDOCT ;;CALL=RDOCT TRAP+12(104412) READ AN OCTAL NUMBER FROM TTY
3269
3270 ;*
3271 ;*THIS SUB CODE IS USED TO INITIALIZE THE LPA-11
3272 ;*FIRST WE WILL LOAD MICROCODE INTO KMC-11
3273 ;*NEXT WE WILL INIT BOTH UPROCESSORS
3274 ;*THEN WE WILL LOAD DEVICE TABLE IN SLAVE UP.
3275 ;*THE ORDER OF LOAD IS DETERMINED BY THE USER.
3276 ;*
3277 ;* CALL= JSR R5,$LPAI
3278 ;* .WORD 0 ;ADDR. OF DEVICE ADDRESS.
3279 ;* ROUTINES REQUIRED: .LOADLP
3280 ;* PROGRAMS REQUIRED: DRLPX2
3281 ;*
3282 ;*
3283 ;* ;RETURNS WITH $AERR=1 IF SLAVE
3284 ;* ;MICRO SAYS AN ADDR. DOES NOT EXSIST. IN THE LIST.
3285 ;*
3286 021344 $LPAI:
3287 021344 013746 000004 MOV 4,-(SP)
3288
3289 021350 000413 BR 31$ ;FIELD DOES NOT HAVE A BUS SWITCH TO
3290 ;WORRY ABOUT,SO WE WILL UNCONDITIONALLY
3291 ;BRANCH AROUND THE NEXT CODE THAT
3292 ;WORKS BASED ON A BUS SWITCH.
3293 ;CODE LEFT IN HERE FOR IN HOUSE
3294 ;PERSONAL WHO MAY PATCH THIS BRANCH
3295 ;INSTRUCTION TO A <NOP> OCTAL <240>
3296 ;IN ORDER TO RUN PROGRAM WITH A SWITCH.
3297
3298 ;NOTE THIS "SWITCH" IS A PIECE OF INHOUSE
3299 ;TEST EQUIPMENT ONLY IT CONNECTS
3300 ;THE UNIBUS TO THE I/O BUS FOR
3301 ;CERTAIN TESTING.
3302 021352 012737 021376 000004 MOV #30$,4
3303 021360 005237 170000 INC 170000
3304 021364 104401 021372 TYPE 65$ ;;TYPE ASCIZ STRING
3305 021370 000401 BR 64$ ;;GET OVER THE ASCIZ
3306 65$:
3307 021374 64$:
3308 021374 000401 BR 31$
3309 021376 022626 30$: CMP (SP)+,(SP)+
3310 021400 012637 000004 31$: MOV (SP)+,4
3311 021404 005037 022222 CLR $AERR ;ALL THIS JUNK MUST BE REMOVED!!
3312 021410 004537 022224 JSR R5,$LOAD ;LOAD MICRO-CODE.
3313 021414 000000G .WORD DRLPX2 ;FILE "DRLPX2.OBJ"
3314
3315 021416 052777 040000 160066 BIS #BIT14,$KMA00 ;ISSUE KMC+DMC INIT.
3316
3317 021424 1$:
3318 ;"HANGS" HERE THEN KMC-11 ERROR.

```

3319	021424	010146				MOV	R1, -(SP)	
3320	021426	005001				CLR	R1	
3321	021430	005201			25:	INC	R1	;STALL FOR DMC-UP
3322	021432	001376				BNE	25	
3323	021434	012777	104000	160050		MOV	#BIT15!BIT11, @KMADO	;SET RUN, AND ENABLE ARBITRATION.
3324	021442	105201			255:	INCB	R1	
3325	021444	001376				BNE	255	
3326								
3327	021446	032777	000040	160036		BIT	#BITS, @KMADO	;SLAVE READY? (READING IPBM SR)
3328	021454	001401				BEQ	35	
3329								;FATAL LPA-11 ERROR SLAVE NOT READY.
3330	021456	104000				ERROR		
3331								
3332	021460	012777	000004	160030	35:	MOV	#4, @KMAD2	;READ FAST PATH
3333	021466				45:			
3334	021466	004537	023134			JSR	R5, \$TOUT	; -TOUT-CHECK FOR TIMEOUT
3335								
3336	021472	104000				ERROR		; /TIME-OUT ERROR
3337								; /WE FAILED TO COMPLETE
3338								; /CURRENT OPERATION.
3339								; /CONTINUES IN THIS LOOP
3340								; /WOULD MAKE US "HANG" HERE
3341								
3342	021474	000774				BR	45	
3343								
3344								; /RETURNS HERE-FROM-TIMED OUT.
3345	021476	122777	000377	160012		CMPB	#377, @KMAD2	;WAIT TILL KMC DONE COMMAND.
3346	021504	001370				BNE	45	
3347	021506	122777	000377	160006		CMPB	#377, @KMAD4	; IF FAST PATH=377 THEN ERROR.
3348	021514	001001				BNE	355	
3349	021516	104000				ERROR		; IPBM ERROR (SLAVE SIDE)
3350								; YOU MUST RUN IPBM DIAGNOSTIC.
3351								
3352	021520	122777	000004	157774	355:	CMPB	#4, @KMAD4	; IS THIS THE CORRECT VERSION OF MICRO-CODE?
3353	021526	001543				BEQ	55	; YES-CONTINUE.
3354	021530	005227	177777			INC	#-1	
3355	021534	001140				BNE	55	
3356	021536	005227	177777			INC	#-1	
3357	021542	001135				BNE	55	
3358	021544	104401	021552			TYPE	675	; ;TYPE ASCIZ STRING
3359	021550	000440				BR	665	; ;GET OVER THE ASCIZ
3360					665:	.ASCIZ	<200>"W A R N I N G THIS PROGRAM WAS DESIGNED TO RUN WITH VERSION 4"	
3361	021652							
3362	021652	104401	021660			TYPE	695	; ;TYPE ASCIZ STRING
3363	021656	000430				BR	685	; ;GET OVER THE ASCIZ
3364					685:	.ASCIZ	<200>"MICRO-CODE. ANOTHER VERSION CODE WAS DETECTED."	
3365	021740							
3366	021740	104401	021746			TYPE	715	; ;TYPE ASCIZ STRING
3367	021744	000434				BR	705	; ;GET OVER THE ASCIZ
3368					705:	.ASCIZ	<200>"THIS MAY OR MAYNOT CAUSE FALSE ERROR TO BE REPORTED."<200><200>	
3369	022036							
3370								
3371	022036	112737	177777	022170	55:	MOVB	#0-1, 115	; DAC CODE FOR SLAVE.
3372	022044	012501				MOV	(5)+, R1	; GET NEXT DEVICE ADDR.

3373	022046	021127	000000	6\$:	CMP	(R1), #0	; TERM REACHED?
3374	022052	001444			BEQ	10\$	
3375	022054	105237	022170		INCB	11\$	
3376	022060	113777	022170	157434	MOVB	11\$, 2KMAD4	; FIFO DATA
3377	022066	004737	022172		JSR	PC, 20\$	; ISSUE SEND
3378	022072	112177	157424		MOVB	(P1)+, 2KMAD4	; SEND LOW BYTE OF DEVICE ADDR TO SLAVE.
3379	022076	004737	022172		JSR	PC, 20\$	; ISSUE SEND
3380	022102	112177	157414		MOVB	(R1)+, 2KMAD4	; SEND HIGH BYTE OF DEVICE ADDR. TO SLAVE.
3381	022106	004737	022172		JSR	PC, 20\$	
3382							
3383	022112	032777	000002	157372	7\$:	BIT	#BIT1, 2KMAD0
3384	022120	001374			BNE	7\$	; WAIT FOR FIFO DATA
3385	022122	112777	000002	157366	MOVB	#2, 2KMAD2	; =1 NO DATA. =0 DATA.
3386							; READ FIFO.
3387	022130			8\$:			
3388	022130	004537	023134		JSR	R5, \$TOUT	; -TOUT-CHECK FOR TIMEOUT
3389							
3390	022134	104000			ERROR		; /TIME-OUT ERROR
3391							; /WE FAILED TO COMPLETE
3392							; /CURRENT OPERATION.
3393							; /CONTINUES IN THIS LOOP
3394							; /WOULD MAKE US "HANG" HERE
3395							
3396	022136	000774			BR	8\$	
3397							
3398							; /RETURNS HERE-FROM-TIMED OUT.
3399	022140	122777	000377	157350	CMPB	#377, 2KMAD2	; WAIT FOR READ.
3400	022146	001370			BNE	8\$	
3401	022150	105777	157346		TSTB	2KMAD4	; WAS A ZERO RETURNED?
3402	022154	001734			BEQ	6\$	; YES GET NEXT ADDR.
3403							; SLAVE WILL RETURN CODE 0 IF
3404	022156	005237	022222		INC	\$AERR	; DEV PRESENT. ELSE
3405							; EXIT \$AERR=1 IF SLAVE GIVES ERROR.
3406	022162	005041			CLR	-(1)	; GET RID OF REFERENCE TO BAD ADDR.
3407	022164	012601		10\$:	MOV	(SP)+, R1	
3408	022166	000205			RTS	R5	; RETURN ALL ADDR. CHECKED.
3409							
3410	022170	000000		11\$:	.WORD	0	; HOLDS DAC CODE PLUS OFFSET
3411							; TO SLAVES ADDR. TABLE.
3412							
3413	022172	112777	000003	157316	20\$:	MOVB	#3, 2KMAD2
3414	022200			21\$:			; ISSUE FIFO WRITE
3415	022200	004537	023134		JSR	R5, \$TOUT	; -TOUT-CHECK FOR TIMEOUT
3416							
3417	022204	104000			ERROR		; /TIME-OUT ERROR
3418							; /WE FAILED TO COMPLETE
3419							; /CURRENT OPERATION.
3420							; /CONTINUES IN THIS LOOP
3421							; /WOULD MAKE US "HANG" HERE
3422							
3423	022206	000774			BR	21\$	
3424							
3425							; /RETURNS HERE-FROM-TIMED OUT.
3426	022210	122777	000377	157300	CMPB	#377, 2KMAD2	; KMC CODE WILL RETURN A "377"

```

3427 022216 001370      BNE      21$      ;WHEN DONE COMMAND.
3428 022220 000207      RTS      PC
3429
3430 022222 000000      $AERR: .WORD 0      ;=0 IF ADDR. LIST OK,=1 IF BAD.
3431
3432      ;*
3433      ;* THIS SUB CODE USED TO LOAD MICRO-CODE INTO LPA-11.
3434      ;* CALL = JSR      R5,$LOAD
3435      ;*      .WORD XX      ;ADDR. OF MICRO CODE.
3436      ;*      ;RETURNS HERE
3437      ;* NOTE: MICRO CODE FILE MUST END IN -1 DATA.
3438      ;*
3439
3440 022224 010446      $LOAD: MOV      R4,-(SP)      ;SAVE R4.
3441 022226 010046      MOV      R0,-(SP)      ;SAVE R0.
3442 022230 012500      1$: MOV      (5)+,R0      ;GET PROG. ADDR.
3443 022232 005077 157254      CLR      @KMAD0      ;CLEAR CSR
3444 022236 005077 157260      CLR      @KMAD4      ;CLEAR CRAM ADDR.
3445 022242 052777 002000 157242 2$: BIS      #2000,@KMAD0      ;SELECT CRAM.
3446 022250 012077 157252      MOV      (0)+,@KMAD6      ;WRITE DATA.
3447 022254 052777 020000 157230      BIS      #20000,@KMAD0      ;SET CRAM WRITE
3448 022262 005077 157224      CLR      @KMAD0      ;DISABLE CRAM.
3449 022266 005277 157230      INC      @KMAD4      ;UPDATE CRAM ADDR.
3450 022272 021027 177777      CMP      (0),#-1      ;ALL DONE?
3451 022276 001361      BNE      2$      ;NO LOOP.
3452 022300 005077 157216      CLR      @KMAD4      ;CLEAR CRAM ADDR.
3453 022304 016500 177776      MOV      -2(5),R0      ;GET MICRO CODE ADDR.
3454
3455 022310 052777 002000 157174 3$: BIS      #2000,@KMAD0      ;SELECT CRAM
3456 022316 022077 157204      CMP      (R0)+,@KMAD6      ;DATA OK?
3457 022322 001013      BNE      5$      ;NO - REPORT AN ERROR.
3458 022324 021027 177777      CMP      (0),#-1      ;ALL DONE?
3459 022330 001405      BEQ      4$      ;YES - EXIT
3460 022332 005077 157154      CLR      @KMAD0      ;NO - DESELECT CRAM.
3461 022336 005277 157160      INC      @KMAD4      ;UPDATE CRAM ADDR.
3462 022342 000762      BR      3$
3463
3464 022344 012600      4$: MOV      (SP)+,R0      ;RESTORE R0
3465 022346 012604      MOV      (SP)+,R4      ;RESTORE R4
3466 022350 000205      RTS      R5      ;EXIT
3467
3468 022352      5$:      ;COME HERE ON LOAD ERROR
3469 022352 005745      TST      -(5)
3470 022354 105204      INCB      R4      ;UPDATE ERROR COUNTER.
3471 022356 100324      BPL      1$      ;IF NOT TOO MANY, TRY AGAIN.
3472 022360 000000      HALT      1$      ;MICRO CODE LOAD ERROR.
3473
3474 022362 000722      BR      1$      ;KMC-11 FAULT. YOU COULD TRY
3475      ;TO PRESS CONTINUE TO GIVE IT
3476      ;ANOTHER CHANCE, BUT I DOUBT
3477      ;THAT THAT WOULD WORK. SINCE I'VE
3478      ;ALREADY GIVEN IT 177 (OCTAL) CHANCES.
3479      ;TRY RUNNING THE KMC-11 DIAGNOSTIC.
3480

```

```

3481
3482
3483
3484
3485
3486
3487
3488 022364 010046
3489 022366 012500
3490 022370 052700 000340
3491 022374 004737 022646
3492 022400 010037 022472
3493 022404 010077 157112
3494 022410 112777 000005 157100
3495 022416 004737 022646
3496 022422 011537 022474
3497 022426 112577 157070
3498
3499 022432 112777 000005 157056
3500 022440 004737 022646
3501 022444 111537 022476
3502 022450 112577 157046
3503 022454 112777 000005 157034
3504 022462 004737 022646
3505 022466 012600
3506 022470 000205
3507 022472 000000
3508 022474 000000
3509 022476 000000
3510
3511
3512
3513
3514
3515
3516
3517
3518
3519
3520 022500 010046
3521 022502 012500
3522 022504 052700 000300
3523 022510 004737 022646
3524 022514 110077 157002
3525 022520 112777 000005 156770
3526 022526 004737 022646
3527 022532 010037 022642
3528 022536
3529 022536 004537 023134
3530
3531 022542 104000
3532
3533
3534

; *THIS ROUTINE ISSUES A WRITE COMMAND TO THE LPA-11
; *
; *      CALL = JSR      RS,$TLKW
; *              .WORD    0              ;OFFSET OF DEVICE ADDR.
; *              .WORD    0              ;DATA TO BE WRITTEN
; *
$TLKW: MOV      RO, -(SP)      ;SAVE RO
      MOV      (5)+, RO      ;GET DEVICE OFFSET
      BIS      #340, RO      ;ADD WRITE CODE.
      JSR      PC, $LPW      ;WAIT FOR FAST PATH READY
      MOV      RO, W1
      MOV      RO, $KMAD4
      MOVB     #5, $KMAD2      ;ISSUE FAST PATH WRITE
      JSR      PC, $LPW      ;WAIT FOR RDY
      MOV      (5), W2
      MOVB     (5)+, $KMAD4    ;WRITE LOW BYTE DATA.
      MOVB     #5, $KMAD2      ;FP WRITE
      JSR      PC, $LPW
      MOVB     (5), W3
      MOVB     (5)+, $KMAD4    ;WRITE HIGH BYTE
      MOVB     #5, $KMAD2
      JSR      PC, $LPW
      MOV      (SP)+, RO
      RTS      RS              ;EXIT DONE.
W1:    0
W2:    0
W3:    0

; *THIS ROUTINE ISSUES A READ COMMAND TO THE LPA-11
; *
; *      CALL = JSR      RS,$TLKR
; *              .WORD    0              ;OFFSET OF DEVICE
; *              .WORD    0              ;RETURNS HERE
; *      *DATA IN WORD $DATR
; *
$TLKR: MOV      RO, -(SP)      ;SAVE RO
      MOV      (5)+, RO      ;GET OFFSET
      BIS      #300, RO      ;ADD READ CODE
      JSR      PC, $LPW      ;WAIT TILL READY
      MOVB     RO, $KMAD4
      MOVB     #5, $KMAD2      ;ISSUE WRITE FP
      JSR      PC, $LPW
      MOV      RO, RD1
      JSR      RS, $TOUT      ; -TOUT-CHECK FOR TIMEOUT
      ERROR
      ; /TIME-OUT ERROR
      ; /WE FAILED TO COMPLETE
      ; /CURRENT OPERATION.
      ; /CONTINUES IN THIS LOOP

```

3535									; /WOULD MAKE US "HANG" HERE
3536									
3537	022544	000774			BR		1\$		
3538									
3539									; /RETURNS HERE-FROM-TIMED OUT.
3540	022546	032777	000040	156736	BIT	#BITS, QKMADO			; FAST PATH GOT DATA?
3541	022554	001370			BNE	1\$			
3542	022556	112777	000004	156732	MOVB	#4, QKMAO2			; ISSUE FAST PATH READ
3543	022564	004737	022646		JSR	PC, SLPW			
3544	022570	117737	156726	022644	MOVB	QKMAO4, \$DATR			; GET LOW BYTE
3545	022576								
3546	022576	004537	023134		JSR	R5, \$TOUT			; -TOUT-CHECK FOR TIMEOUT
3547									
3548	022602	104000			ERROR				; /TIME-OUT ERROR
3549									; /WE FAILED TO COMPLETE
3550									; /CURRENT OPERATION.
3551									; /CONTINUES IN THIS LOOP
3552									; /WOULD MAKE US "HANG" HERE
3553									
3554	022604	000774			BR		2\$		
3555									
3556									; /RETURNS HERE-FROM-TIMED OUT.
3557	022606	032777	000040	156676	BIT	#BITS, QKMADO			; FAST PATH READY?
3558	022614	001370			BNE	2\$			
3559	022616	112777	000004	156672	MOVB	#4, QKMAO2			; ISSUE FAST PATH READ
3560	022624	004737	022646		JSR	PC, SLPW			
3561	022630	117737	156666	022645	MOVB	QKMAO4, \$DATR+1			; SAVE HIGH BYTE
3562	022636	012600			MOV	(SP)+, R0			
3563	022640	000205			RTS	R5			
3564	022642	000000							
3565	022644	000000							
3566									
3567									: THIS ROUTINE WAITS FOR KMC-CODE TO BECOME READY AS WELL
3568									: AS FAST PATH TO BE READ.
3569									:
3570									: CALL = JSR PC, SLPW
3571									:
3572									: IT WILL TIME OUT IF TOO MUCH TIME IS TAKEN BY
3573									: THE MICRO-PROCESSORS AND REPORT AN ERROR, THEN HALT.
3574									:
3575									
3576	022646	010146			\$LPW:	MOV	R1, -(SP)		; SAVE R1
3577	022650	005001				CLR	R1		
3578	022652	122777	000377	156636	1\$:	CMPB	#377, QKMAO2		; FINISHED INSTRUCTION?
3579	022660	001403				BEQ	2\$		
3580	022662	005201				INC	R1		; TIME OUT?
3581	022664	001372				BNE	1\$		
3582	022666	000411				BR	10\$		
3583									
3584	022670	032777	000020	156614	2\$:	BIT	#BIT4, QKMADO		; FAST PATH READ?
3585	022676	001403				BEQ	3\$		
3586	022700	005201				INC	R1		; NO - TIME OUT?
3587	022702	001372				BNE	2\$		
3588	022704	000402				BR	10\$		; YES - REPORT AN ERROR

```

3589
3590 022706 012601
3591 022710 000207
3592
3593 022712
3594 022712 104401 022720
3595 022716 000407
3596
3597 022736
3598
3599 022736 000000
3600 022740 000776
3601
3602
3603
3604
3605
3606
3607
3608
3609
3610
3611
3612
3613
3614
3615 022742 010046
3616 022744 010146
3617
3618 022746 012700 001540
3619 022752 005001
3620 022754 005710
3621 022756 001421
3622 022760 027520 000000
3623 022764 001402
3624 022766 005201
3625 022770 000771
3626
3627 022772 010137 023010
3628 022776 005725
3629 023000 013537 023012
3630 023004 004537 022364
3631 023010 000000
3632 023012 000000
3633 023014 012601
3634 023016 012600
3635 023020 000205
3636 023022 017520 000000
3637 023026 005010
3638 023030 004537 021344
3639 023034 001540
3640 023036 000755
3641
3642

3$: MOV (SP)+,R1 ;RESTORE R1
RTS PC ;EXIT

10$: TYPE 65$ ;TYPE ASCIZ STRING
BR 64$ ;GET OVER THE ASCIZ
;65$: .ASCIZ <200>#LPA-11 FAULT#
64$:

11$: HALT ;LPA-11 FAULT RUN LPA-11
BR 11$ ;DIAGNOSTICS.

; *
; * THIS ROUTINE PROVIDES THE LINKAGE FROM USER CODE TO
; * A DEVICE ADDRESS ON THE I/O BUSS FOR WRITE ONLY.
; *
; * FIRST WE WILL DETERMINE IF THE ADDRESS HAS BEEN USED
; * BEFORE. IF NOT WE HAVE TO INITIALIZE THE LPA WITH
; * THAT ADDRESS.
; * WHEN THE ADDR. IS KNOWN BY THE LPA, DO THE OUTPUT BY
; * STLKW
; *

$OUTLP: MOV RO,-(SP) ;SAVE RO
MOV R1,-(SP) ;SAVE R1

MOV #.DVLS,RO ;PROGRAM DEFINED LIST.
CLR R1
1$: TST (0) ;TERMINATOR REACHED?
BEQ 10$ ;YES NEXT STEP.
CMP 2(5),(0)+ ;MATCH WITH ADDR IN LIST?
BEQ 2$
INC R1
BR 1$

2$: MOV R1,3$ ;SAVE OFFSET, DEVICE KNOWN.
TST (5)+
MOV 2(5)+,4$ ;GET DATA TO BE WRITTEN
JSR R5,$STLKW ;DO WRITE
3$: .WORD 0 ;DEVICE OFFSET
4$: .WORD 0 ;DATA TO BE WRITTEN.
MOV (SP)+,R1
MOV (SP)+,RO
RTS R5
10$: MOV 2(5),(0)+ ;SAVE ADDR.
CLR (0)
JSR R5,$LPAI
.WORD .DVLS
BR 2$

; *

```

```

3643      ; *THIS ROUTINE PROVIDES THE LINKAGE FROM USER CODE
3644      ; *TO A DEVICE ADDR. ON THE I/O BUSS FOR READ ONLY.
3645      ; *
3646      ; *FIRST WE WILL DETERMINE IF THE ADDRESS HAS BEEN
3647      ; *USED BEFORE. IF NOT, WE HAVE TO INITIALIZE THE LPA
3648      ; *WITH THE NEW ADDR.
3649      ; *WHEN THE ADDR IS KNOWN WE CAN DO OUTPUT THROUGH
3650      ; *$TLKR
3651      ; *
3652      ; *      CALL THROUGH      MOVEI      DATA,ADDR.
3653      ; *      WHICH EQUALS:
3654      ; *      JSR      R5,$INLP
3655      ; *      .WORD    XX      ADDR OF DEVICE
3656      ; *      .WORD    YY      ADDR TO $TORE READ DATA.
3657      023040 010046      $INLP:  MOV      R0,-(SP)      ;SAVE R0
3658      023042 010146      MOV      R1,-(SP)      ;SAVE R1
3659
3660      023044 012700 001540      MOV      #.DVLS,R0      ;PROG DEFINED ADDR. LIST.
3661      023050 005001      CLR      R1
3662      023052 005710      1$:      TST      (0)      ;EOL REACHED?
3663      023054 001420      BEQ      10$      ;YES - DEFINE NEW ADDR.
3664
3665      023056 027520 000000      CMP      @($),(0)+      ;ADDR. MATCH?
3666      023062 001402      BEQ      2$
3667      023064 005201      INC      R1
3668      023066 000771      BR      1$
3669
3670      023070 010137 023102      2$:      MOV      R1,3$      ;SAVE LIST OFFSET
3671      023074 005725      TST      ($)+
3672      023076 004537 022500      JSR      R5,$TLKR      ;GO READ DEVICE
3673
3674      023102 000000      $OFS=.  .WORD    0      ;OFFSET OF DEVICE
3675      3$:
3676      023104 013735 022644      MOV      $DATA,@($)+      ;STORE DATA.
3677      023110 012601      MOV      (SP)+,R1      ;RESTORE R1
3678      023112 012600      MOV      (SP)+,R0      ;RESTORE R2
3679      023114 000205      RTS      R5      ;EXIT
3680
3681      023116 017520 000000      10$:  MOV      @($),(0)+
3682      023122 005010      CLR      (0)
3683      023124 004537 021344      JSR      R5,$LPAI
3684      023130 001540      .WORD    .DVLS
3685      023132 000756      BR      2$
3686
3687      ; *$STOUT ROUTINE USED TO WATCH IF
3688      ; *      WE'RE IN A LOOP TOO-LONG
3689      ; *      CALL= JSR R5, $STOUT
3690      ; *      ERROR X ;RETURNS HERE ON TIMEOUT
3691      ; *      BR
3692      ; *      ;RETURNS HERE NO ERROR
3693      ; *
3694
3695      023134 020537 023170      $STOUT: CMP      R5,$$AD      ;SAME ADDR?
3696      023140 001405      BEQ      1$

```

```

3697 023142 010537 023170      MOV    R5,$$AD      ;NO-SAVE THIS ADDR.
3698 023146 005037 023172      CLR    $CNT      ;CLR CNT AT ADDR.
3699 023152 000403              BR      2$
3700 023154 005237 023172      1$: INC    $CNT      ;OVERFLOW?
3701 023160 100402              BMI    3$      ;YES-ERROR RETURN
3702 023162 062705 000004      2$: ADD    #4,R5      ;NO-NON ERROR RETURN
3703 023166 000205              3$: RTS    R5      ;RETURN.
3704
3705 023170 000000      $$AD: .WORD 0      ;CONTAINS LOOP ADDR.
3706 023172 000000      $CNT: .WORD 0      ;# OF TIMES AT ADDR.
3707
3708      ;*
3709      ;* THIS ROUTINE REPLACES WHAT THE USER WOULD ORDINARILY
3710      ;* USE FOR A RESET. FIRST WE DO A RESET INSTRUCTION.
3711      ;* THEN WE CLR ".DVLST" WHICH FORCES US TO RESET BOTH THE
3712      ;* KMC AND DMC AS SOON AS A DEVICE IS REFERENCED.
3713      ;*
3714      ;*      CALL=JSR      PC,$RESET      ;REPLACES "RESET INSTRUCTION
3715      ;*      ;RETURNS HERE.
3716      ;*
3717 023174 000005      $RESET: RESET      ;RESET THE WORLD.
3718
3719      ;*      MOV    2$,$1$      ;/READ DEVICE REG 2$,PUT DATA IN 1$.
3720 023206 005737 022222      TST    $AERR      ;IF NO ERROR,LOOP
3721 023212 001004              BNE    10$      ;THERE WAS AN ERROR.
3722 023214 062737 000002 023230      ADD    #2,2$      ;UPDATE DEVICE ADDR.
3723      ;YOU SEE ,WE HAVE TO PROTECT OUR SELF!
3724      ;IF 2$ CONTAINED A VALID ADDR,WE
3725      ;MUST KEEP TRYING UNTIL WE GENERATE
3726      ;AN INVALID ADDR.
3727 023222 000764              BR      $RESET
3728 023224
3729 023224 000207      10$: RTS    PC
3730 023226 000000      1$: .WORD 0      ;JUNK LOC.
3731 023230 160000      2$: .WORD 160000      ;DUMB ADDR. FORCES INIT OF DMC/KMC.
3732
3733      ;
3734      ;SDELAY- ROUTINE TO GIVE A MINOR DELAY.
3735      ;IS NOT TIME DEPENDENT CODE SENCE
3736      ;NOT USED TO GET SPECIFIC TIME BUT
3737      ;JUST A LITTLE DELAY.
3738      ;
3739      ;
3740      ;THAT IS,UNLESS A REAL TIME CLOCK IS PRESENT!
3741      ;THEN WE'LL GENERATE A TIME BETWEEN 16MS TO 32 MS
3742      ;
3743      ;
3744      ;CALL= JSR PC, SDELAY
3745      ;
3746 023232      SDELAY:
3747 023232 005737 023314      TST    RTCCSR      ;CLOCK PRESENT?
3748 023236 100016              BPL    10$
3749 023240 012737 000002 023304      MOV    #2,TIME
3750 023246 052777 000115 000040      BIS    #15,RTCCSR      ;START CLOCK

```

3751	023254	005037	177776		CLR	PS	
3752	023260	005737	023304	1\$:	TST	TIME	
3753	023264	001375			BNE	1\$	
3754	023266	005077	000022		CLR	RTCCSR	; STOP CLOCK
3755							
3756	023272	000207			RTS PC		
3757	023274	105237	023304	10\$:	INCB	TIME	
3758	023300	001375			BNE	10\$	
3759	023302	000207			RTS	PC	
3760							
3761	023304	000000		TIME:	.WORD	0	
3762							
3763	023306	005337	023304	CLKINT:	DEC	TIME	
3764	023312	000002			RTI		
3765	023314	000000		RTCCSR:	.WORD	0	; CLOCK CSR IF USED.
3766							
3767							
3768							
3769							
3770							
3771							
3772							
3773							
3774							
3775							
3776							
3777	023316			\$UTK:	CLR	.DVLS	
3778	023316	005037	001540				
3779	023322			21\$:	TYPE	65\$	:: TYPE ASCIZ STRING
3780	023322	104401	023330		BR	64\$	:: GET OVER THE ASCIZ
3781	023326	000405					
3782				:: 65\$:	.ASCIZ	<200>#E OR D?#	
3783	023342			64\$:			
3784	023342	105777	155576	1\$:	TSTB	2\$TKS	
3785	023346	100375			BPL	1\$	
3786	023350	117737	155572		MOVB	2\$TKB, 20\$	; GET INPUT
3787	023356	104401	023472		TYPE	20\$	; ECHO, NEXT MESSAGE.
3788	023362	142737	000240		BICB	#240, 20\$	; STRIP PARITY, LC
3789	023370	104412			RDOCT		; GET ADDR.
3790	023372	012637	023470		MOV	(SP)+, 14\$	
3791	023376	123727	023472		CMPB	20\$, #10	; DEPOSIT?
3792	023404	001411	000104		BEQ	10\$	
3793							
3794	023406	004537	023040		JSI	R5, \$INLP	; GET DATA
3795	023412	023470		2\$:	.WORD	14\$	
3796	023414	023426			.WORD	5\$	
3797							
3798	023416	013746	023426		MOV	5\$, -(SP)	:: SAVE 5\$ FOR TYPEOUT
3799	023422	104402			TYPOC		:: GO TYPE--OCTAL ASCII(ALL DIGITS)
3800	023424	000736			BR	21\$	; LOOP.
3801	023426	000000		5\$:	.WORD	0	
3802							
3803	023430			10\$:			
3804	023430	104401	023436		TYPE	.67\$	:: TYPE ASCIZ STRING

3805	023434	000404			BR	66\$	;;GET OVER THE ASCIZ
3806					;;67\$:	.ASCIZ	<200>*DATA= #
3807	023446				66\$:	RDOCT	
3808	023446	104412				MOV	(SP)+,13\$
3809	023450	012637	023466				
3810							
3811	023454	004537	022742		11\$:	JSR	R5,\$OUTLP ;OUTPUT ROUTINE.
3812	023460	023470			12\$:	.WORD	14\$;DEVICE ADDR.
3813	023462	023466				.WORD	13\$;DATA
3814	023464	000716				BR	21\$
3815							
3816	023466	000000			13\$:	.WORD	0
3817	023470	000000			14\$:	.WORD	0
3818	023472	100001	042504	044526	20\$:	.ASCIZ	<1><200>*DEVICE ADDR= #
3819	023500	042503	040440	042104			
3820	023506	036522	000040				
3821						.EVEN	
3822							
3823							
3824							
3825							
3826							
3827							
3828							
3829							
3830							
3831							
3832							
3833							
3834							
3835							
3836							
3837							
3838							
3839							
3840							
3841							
3842							
3843							
3844							
3845	023512	012537	023522		\$PUTS:	MOV	(5)+,1\$;GET ADDR OF ADDR. OF A/D
3846	023516	004537	023040			JSR	R5,\$INLP
3847	023522	000000			1\$:	.WORD	0
3848	023524	023620				.WORD	10\$
3849	023526	113777	023102	155772		MOVB	\$OFS,2KMA06
3850	023534	113777	023102	155766		MOVB	\$OFS,2KMA07
3851	023542	013737	023522	023562		MOV	1\$,2\$
3852	023550	062737	000002	023562		ADD	#2,2\$
3853	023556	004537	023040			JSR	R5,\$INLP
3854	023562	000000			2\$:	.WORD	0
3855	023564	023620				.WORD	10\$
3856	023566	113777	023102	155724		MOVB	\$OFS,2KMA03
3857	023574	152777	000340	155724		BISB	#340,2KMA06
3858	023602	152777	000300	155720		BISB	#300,2KMA07

THIS ROUTINE LOOKS THROUGH CURENT .DVLS FOR A/D ADDR.
IF UNFOUND GENERATES IT. THIS ROUTINE'S WHOLE PURPOSE IS
TO SET UP THE USER PROGRAM TO LINK TO FILE "DRLPX2" FOR
SAMPLE TAKING PURPOSES.
TO TAKE SAMPLES, THE USER PROGRAM MUST SET UP
A/D CSR IN BSEL 4, AND 5.
(2) HE MUST CALL THIS ROUTINE:
JSR R5,\$PUTS ;CALL SET UP ROUTINE.
.WORD ADCSR ;ADDR. OF A/D CSR.
;RETURNS HERE ;KMC BSEL 3,6,7 PERMINENTLY SET UP
;(UNTILL ONE DOES A RESET)

(3)THE USER MUST PUT CODE 006 INTO KMC REG 2 TO
START CONVERSION CAUTION*DO WITH MOVB INSTR.!

(4)MONITOR KMC REG 2 FOR CODE 377 (DRLPX2 IS DONE)

(5)READ KMC REG 4,5 FOR A/D RESULT.

(6) TO TAKE MORE SAMPLES, SIMPLY PUT A/D CSR INTO
BSEL 4,5 AND CODE 6 INTO BSEL 2.

MAINDEC-11-DRLPC-A MACY11 27(654) 15-DEC-77 10:54 PAGE 74
DRLPC.P11 TRAP TABLE

SEQ 0083

3859	023610	152777	000300	155702	BISB	#300,2KMA03
3860	023616	000205			RTS	R5
3861	023620	000000			10\$: .WORD	0
3862						
3863		000001			.END	

MAINDEC-11-DRLPC-A MACY11 27(654) 15-DEC-77 10:54 PAGE 75
DRLPC.P11 CROSS REFERENCE TABLE

SEQ 0084

MAINDEC-11-DRLPC-A MACY11 27(654)
DRLPC.P11 CROSS REFERENCE TABLE

[illegible]

EM17	5362	450	2518#												
EM2	014660	372	2456#												
EM3	014707	378	2460#												
EM4	014746	384	2466#												
EM5	015005	390	2472#												
EM6	015033	396	2476#												
EM7	015073	402	2482#												
ERRVEC=	000004	161#	574	575*	586*	2643	2644*	2646*	2649*						
GNS	=***** U	194	635	656	663	3257	3258	3259	3260	3261	3263	3265	3266	3267	
		3268	3306	3360	3364	3368	3596	3782	3806						
GTSWR =	104406	651	3263#												
HT	= 000011	71#	3128	3169											
IOTVEC=	000020	166#	558*	559*											
KM300	001512	464#	540	3315*	3323*	3327	3383	3443*	3445*	3447*	3448*	3455*	3460*	3540	
		3557	3584												
KMAD1	001514	467#	541												
KMAD2	001516	469#	3332*	3345	3385*	3399	3413*	3426	3494*	3499*	3503*	3525*	3542*	3559*	
		3578													
KMAD3	001520	471#	3856*	3859*											
KMAD4	001522	473#	3347	3352	3376*	3378*	3380*	3401	3444*	3449*	3452*	3461*	3493*	3497*	
		3502*	3524*	3544	3561										
KMAD5	001524	475#													
KMAD6	001526	477#	3446*	3456	3849*	3857*									
KMAD7	001530	479#	545	3850*	3858*										
KWIV	001634	511#													
KWIVS	001636	512#													
LF	= 000012	72#	3163	3169											
LPADH	001524	474#													
LPADL	001522	472#													
LPCI	001512	463#													
LPC0	001516	468#													
LPMR	001514	466#													
LPMS1	001526	476#													
LPMS2	001530	478#													
LPS0	001520	470#													
MINCNT	014614	2408*	2419	2421	2448*										
NBEXT	001652	520#	615*	2246	2250*	2254*									
NMBEXT	001650	519#	610*	615	658	2254									
PC	=%000007	92#	789*	875*	1246*	1262*	1278*	1297*	1312*	1333*	1354*	1369*	1383*	1397*	
		1420*	1440*	1834*	1850*	1866*	1882*	2114*	2133*	2149*	2168*	2186*	2197*	2273*	
		2276*	2286*	2291	2410*	2411*	2413*	2444*	2710*	2716*	2790*	2951*	2998	3118*	
		3137*	3144*	3151*	3165*	3167*	3200*	3217*	33						

K07

MAINDEC-11-DRLPC-A
DRLPC.P11MACY11 27(654)
CROSS REFERENCE TABLE

15-DEC-77 10:54 PAGE 79

SEQ 0088

PSW = 177776	76*													
PWRMSG 020236	2997	3004*												
PWRVEC= 000024	167*	564*	565*	2966*	2967*	2976*	2982*	2994*	2995*					
RATE 014610	1310*	1331*	1352*	1367*	1381*	1395*	1418*	2108*	2309	2406*	2428	2446*		
RBEG 001702	531	533*												
RBEG1 002332	616*													
RBEG2 002334	617*	2257												
ROCHR = 104410	2849	3266*												
RDLIN = 104411	2890	3267*												
RDOCT = 104412	3268*	3789	3808											
RD1 022642	3527*	3564*												
REPEAT 014344	2401*													
RESVEC= 000010	162*													
RTCCSR 023314	3747	3750*	3754*	3765*										
RO =%000000	83*	530*	532*	538	540*	543*	544	549*	626	667*	668*	669	671*	
	672	674*	676*	680	682*	1724*	1734*	1746*	1759*	1774*	1787*	1803*	1821*	
	2007*	2008*	2018*	2026*	2082*	2088*	2089*	2115*	2116*	2198*	2199*	2202	2203*	
	2211*	2216	2221	2224*	2256*	2283*	2286	2336	2346*	2350	2366	2367	2380*	
	2412	2414	2415*	2416*	2418*	2424	2427*	2434*	2438*	2887	2891*	2894	2910*	
	2923	2924*	2925*	2932*	2933*	2934*	2935*	2936*	2937	2942	2947*	2949*	2953	
	2955	2968	2993*	3111	3112*	3117	3122	3125*	3177	3185*	3189	3190	3192*	
	3193*	3194	3216*	3234	3235*	3236	3237*	3238*	3239*	3240*	3441	3442*	3453*	
	3456	3464*	3488	3489*	3490*	3492	3493	3505*	3520	3521*	3522*	3524	3527	
	3562*	3615	3618*	3634*	3657	3660*	3678*							
R1 =%000001	84*	539	541*	545	548*	619*	620*	621*	622	675*	676	677	678	
	681*	682	683	684	2200*	2205	2212*	2215	2223	2337	2350*	2351	2355	
	2379*	2888	2892*	2896*	2898*	2900*	2903*	2906	2909*	2969	2992*	3178	3215*	
	3319	3320*	3321*	3324*	3372*	3373	3378	3380	3407*	3576	3577*	3580*	3586*	
	3590*	3616	3619*	3624*	3627	3633*	3658	3661*	3667*	3670	3677*			
R2 =%000002	85*	595*	597	602*	618*	620	622*	623	624	2201*	2208*	2213*	2225*	
	2338	2349*	2353*	2356	2363*	2364*	2365	2370*	2378*	2889	2893*	2897*	2899*	
	2901*	2907	2908*	2970	2991*									
R3 =%000003	86*	596*	603*	605	609*	610	2339	2347*	2348*	2362*	2365*	2374*	2375*	
	2377*	2845	2846*	2847	2850*	2851	2855	2857	2859*	2861*	2971	2990*	3046	
	3055	3061*	3062*	3065*	3070*	3071*	3072	3081*						
R4 =%000004	87*	2972	2989*	3047	3049*	3050*	3051*	3052	3053*	3067	3069*	3077*	3080*	
	3440	3465*	3470*											
R5 =%000005	88*	600*	696*	717*	719*	730*	732*	743*	745*	756*	758*	771*	773*	
	789*	792*	803*	805*	816*	818*	830*	832*	843*	845*	858*	860*	875*	
	878*	890*	892*	903*	905*	916*	918*	929*	931*	942*	944*	955*	957*	
	968*	970*	981*	983*	993*	995*	1005*	1010*	1023*	1025*	1028*	1032*	1039*	
	1047*	1050*	1052*	1055*	1065*	1068*	1071*	1074*	1077*	1079*	1082*	1084*	1095*	
	1097*	1101*	1105*	1114*	1117*	1119*	1122*	1135*	1137*	1140*	1144*	1153*	1156*	
	1158*	1161*	1173*	1175*	1179*	1183*	1186*	1188*	1191*	1195*	1209*	1211*	1215*	
	1219*	1222*	1224*	1227*	1231*	1245*	1249*	1261*	1265*	1277*	1281*	1293*	1296*	
	1300*	1315*	1321*	1336*	1342*	1357*	1372*	1386*	1400*	1407*	1423*	1430*	1443*	
	1454*	1457*	1463*	1466*	1477*	1480*	1491*	1494*	1505*	1508*	1519*	1522*	1532*	
	1535*	1545*	1548*	1554*	1561*	1563*	1574*	1576*	1587*	1589*	1600*	1602*	1615*	
	1617*	1632*	1634*	1645*	1647*	1658*	1660*	1671*	1673*	1686*	1688*	1703*	1706*	
	1708*	1715*	1729*	1732*	1739*	1751*	1757*	1764*	1779*	1782*	1785*	1792*	1808*	
	1810*	1813*	1817*	1833*	1837*	1849*	1853*	1865*	1869*	1881*	1885*	1896*	1898*	
	1910*	1912*	1924*	1926*	1938*	1940*	1952*	1954*	1965*	1967*	1979*	1981*	1993*	
	1995*	2007*	2012*	2016*	2022*	2026*	2030*	2037*	2050*	2052*	2055*	2058*	2063*	
	2079*	2082*	2085*	2088*	2093*	2105*	2107*	2111*	2114*	2120*	2133*	2136*	2148*	

```

SWREG      000176
SW0        = 000001
SW00       = 000001
SW01       = 000002
SW02       = 000004
SW03       = 000010
SW04       = 000020
SW05       = 000040
SW06       = 000100
SW07       = 000200
SW08       = 000400
SW09       = 001000
SW1        = 000002
SW10       = 002000
SW11       = 004000
SW12       = 010000
SW13       = 020000
SW14       = 040000
SW15       = 100000
SW2        = 000004
SW3        = 000010
SW4        = 000020
SW5        = 000040
SW6        = 000100
SW7        = 000200

```

SW8 = 000400	122#							
SW9 = 001000	121#							
TBITVE= 000014	163#							
TEMP 001660	523#	1006*	1013*	1028*	1029	1055*	1804*	1819*
TIME 023304	3749*	3752	3757*	3761#	3763*			
TKVEC = 000060	170#							
TPVEC = 000064	171#							
TRAPVE= 000034	169#	562*	563*					
TRTVEC= 000014	164#							
TST1 002736	689#							
TST10 003364	793	799#						
TST100 011326	1802	1818	1828#					
TST101 011410	1838	1844#						
TST102 011472	1854	1860#						
TST103 011554	1870	1876#						
TST104 011636	1886	1892#						
TST105 011700	1899	1905#						
TST106 011742	1913	1919#						
TST107 012004	1927	1933#						
TST11 003426	806	812#						
TST110 012046	1941	1947#						
TST111 012110	1955	1960#						
TST112 012152	1968	1974#						
TST113 012214	1982	1988#						
TST114 012256	1996	2004#						
TST115 012450	2039	2046#						
TST116 012572	2064	2066	2074#					
TST117 012720	2094	2100#						
TST12 003470	819	826#						
TST120 013056	2121	2127#						
TST121 013134	2137	2143#						
TST122 013206	2152	2158#						
TST123 013276	2171	2176#						
TST124 013374	2191	2196#						
TST125 013570	2227	2245#						
TST13 003532	833	839#						
TST14 003574	846	852#						
TST15 003650	870#							
TST16 003722	879	886#						
TST17 003764	893	899#						
TST2 003020	704	713#						
TST20 004026	906	912#						
TST21 004070	919	925#						
TST22 004132	932	938#						
TST23 004174	945	951#						
TST24 004236	958	964#						
TST25 004300	971	977#						
TST26 004342	984	989#						
TST27 004404	996	1001#						
TST3 003062	720	726#						
TST30 004464	1018#							
TST31 004704	1043	1061#						
TST32 005062	1085	1090#						
TST33 005266	1130#							

[illegible]

MAINDEX-11-DRLPC A MACY11 27(654)
DRLPC.P11 CROSS REFERENCE TABLE

DRLPC.P11

CROSS REFERENCE TABLE

[illegible]

	1857#	1873#	1889#	1902#	1916#	1930#	1944#	1957#	1971#	1985#	2001#	2043#	2071#
\$OCNT 020526	2097#	2124#	2140#	2155#	2173#	2193#	2242#						
\$OFs = 023102	3045#	3074#	3087#										
\$OMoDE 020530	3673#	3849	3850	3856									
\$OUTLP 022742	3040#	3044#	3049	3052*	3063*	3089#							
	696	717	730	743	756	771	789	803	816	830	843	858	875
	890	903	916	929	942	955	968	981	993	1005	1023	1025	1028
	1050	1055	1065	1068	1071	1077	1082	1095	1097	1101	1117	1122	1135
	1137	1140	1156	1161	1173	1175	1179	1186	1191	1209	1211	1215	1222
	1227	1245	1261	1277	1293	1296	1454	1463	1477	1491	1505	1519	1532
	1545	1554	1561	1574	1587	1600	1615	1632	1645	1658	1671	1686	1703
	1706	1729	1751	1779	1782	1808	1813	1833	1849	1865	1881	1896	1910
	1924	1938	1952	1965	1979	1993	2012	2050	2055	2079	2088	2105	2107
	2114	2133	2148	2163	2181	2208	2306	2309	2312	2404	2406	2431	2434
	2442	2444	3615#	3811									
	2639	2655	2663	2673	2682#								
\$OVER 016650	289#	588#	2271*	2272*	2280	2293	2669	2686					
\$PASS 001204	231#												
\$PASTM 001006	3845#												
\$PUTS 023512	2999#												
\$PWRAD 020224	564	2966#	2994										
\$PWRDN 020064	2997#												
\$PWRMG 020220	2976	2982#											
\$PWRUP 020136	277#	2736	2804	2853	2869	3169							
\$QUES 001172	2817#	3266											
\$ROCHR 017334	3269												
\$RDOEC= ***** U	2845#	3267											
\$RDLIN 017454	2885#	3268											
\$RDOCT 017626	2838#												
\$RDSZ = 000010	271#												
\$REGAD 001160	273#												
\$REGO 001162	274#												
\$REG1 001164	789	875	1246	1262	1278	1297	1440	1834	1850	1866	1882	2133	2149
\$RESET 023174	2168	2186	2197	3717#	3727								
\$RTNAD 013760	2292#												
\$R2A = ***** U	3269												
\$SAD 023170	3695	3697*	3705#										
\$SAVRE= ***** U	3269												
\$SAVR6 020234	2975#	2983	2984*	2985*	3003#								
\$SCOPE 016404	558	2635#											
\$SETUP= 000137	442#	557	558	560	562	564	566	567	568	570	641	644	2269
	2636	2700	2723	2731	2741	2875							
	442#												
\$STUP = 177777	2647	2676#											
\$SVLAD 016614	205#	210											
\$SVPC = 000210	30#	63	180	181	182	193	184	185	186	187	275	276	277
\$SWR = 165400	567	568	570	571	690	714	727	740	753	766	784	800	813
	827	840	853	871	887	900	913	926	939	952	965	978	990
	1002	1019	1062	1091	1131	1169	1205	1241	1257	1273	1289	1309	1330
	1351	1366	1380	1394	1417	1439	1451	1474	1488	1502	1516	1529	1542
	1558	1571	1584	1597	1610	1629	1642	1655	1668	1681	1700	1723	1745
	1773	1801	1829	1845	1861	1877	1893	1906	1920	1934	1948	1961	1975
	1989	2005	2047	2075	2101	2128	2144	2159	2177	2197	2246	2264	2270
	2285	2291	2293	2627	2628	2629	2630	2631	2638	2650	2652	2653	2656

```
SSWREG 001220
SSWRMK= 000000
$TESIN 001202
$TIMES 001166
```

STKB	001146
STK:	001144
STLKR	022500
STLKW	022364
STMDAT	001670

STN = 000126

```
STOUT      023134
STPB       001152
STPFLG     001157
STPS       001150
STRAP      021262
STRAP2     021304
STRP =     000013
STRPAD     021316
$STM       001004
```

2657	2658	2665	2666	2667	2679	2682	2685	2692	2693	2694	2695	2704
2708	2720	2724	2736	3000								
297#	591											
187	188	2631	2632	2654								
288#	2677*											
275#	567*	784*	1019*	1091*	1131*	1169*	1205*	1241*	1257*	1273*	1289*	1309*
1330*	1351*	1366*	1380*	1394*	1417*	1829*	1845*	1861*	1877*	2075*	2101*	2128*
2144*	2159*	2177*	2270*	2665*	2672	2675*	2685					
264#	2739	2750	2767	2821	2827	3786						
263#	2739	2748	2764	2788*	2819	2825	3784					
3520#	3672											
3488#	3630											
527#	597*	600	786*	789	872*	875	1002*	1005	1020*	1023	1025*	1028
1047*	1050	1052*	1055	1062*	1065*	1068*	1071	1074*	1077	1079*	1082	1092*
1095	1097	1098*	1101	1114*	1117	1119*	1122	1132*	1135	1137*	1140	1153*
1156	1158*	1161	1170*	1173	1175	1176*	1179	1183*	1186	1188*	1191	1206*
1209	1211	1212*	1215	1219*	1222	1224*	1227	1242*	1245	1258*	1261	1274*
1277	1290*	1293*	1296	1451*	1454	1460*	1463	1474*	1477	1488*	1491	1502*
1505	1516*	1519	1529*	1532	1542*	1545	1551*	1554	1700*	1703	1726*	1729
1748*	1751	1752*	1776*	1779*	1782	1805*	1808	1810*	1813	1817	1830*	1833
1846*	1849	1862*	1865	1878*	1881	2007	2009*	2012	2016	2026	2047*	2050
2052*	2055	2058	2076*	2079	2082	2085*	2088	2102*	2105	2107	2111*	2114
2130*	2133	2145*	2148	2160*	2163	2166	2178*	2181	2184	2202*	2204*	2208
2216*	2219	2303*	2306*	2309*	2312	2316	2401*	2404	2406	2428*	2431*	2434
2438	2439*	2442	2444									
30#	63	686	690#	704	710	714#	720	723	727#	733	736	740#
746	749	753#	759	762	766#	780	784#	793	796	800#	806	809
813#	819	823	827#	833	836	840#	846	849	853#	867	871#	879
883	887#	893	896	900#	906	909	913#	919	922	926#	932	935
939#	945	948	952#	958	961	965#	971	974	978#	984	986	990#
996	998	1002#	1015	1019#	1043	1058	1062#	1085	1087	1091#	1127	1131#
1165	1169#	1196	1201	1205#	1232	1237	1241#	1250	1253	1257#	1266	1269
1273#	1282	1285	1289#	1301	1305	1309#	1322	1326	1330#	1343	1347	1351#
1358	1362	1366#	1373	1376	1380#	1387	1390	1394#	1408	1413	1417#	1431
1435	1439#	1444	1447	1451#	1467	1470	1474#	1481	1484	1488#	1495	1498
1502#	1509	1512	1516#	1523	1525	1529#	1536	1538	1542#	1554	1558#	1564
1567	1571#	1577	1580	1584#	1590	1593	1597#	1603	1606	1610#	1625	1629#
1635	1638	1642#	1648	1651	1655#	1661	1664	1668#	1674	1677	1681#	1696
1700#	1716	1719	1723#	1733	1741	1745#	1758	1765	1769	1773#	1786	1793
1797	1801#	1802	1818	1825	1829#	1838	1841	1845#	1854	1857	1861#	1870
1873	1877#	1886	1889	1893#	1899	1902	1906#	1913	1916	1920#	1927	1930
1934#	1941	1944	1948#	1955	1957	1961#	1968	1971	1975#	1982	1985	1989#
1996	2001	2005#	2039	2043	2047#	2064	2066	2071	2075#	2094	2097	2101#
2121	2124	2128#	2137	2140	2144#	2152	2155	2159#	2171	2173	2177#	2191
2193	2197#	2227	2242	2246#								
3334	3388	3415	3529	3546	3695#							
266#	3158*	3169										
270#	3107	3169										
265#	3156	3169										
562	3234#											
3245#	3256											
3249#	3258#	3259#	3260#	3261#	3262#	3263	3264#	3265	3266#	3267#	3268#	3269#
3239	3256#											
230#												

MAINDEC-11-DRLPC-A MACY11 27(654)
DRLPC.P11 CROSS REFERENCE TABLE

DRLPC.P11 CROSS REFERENCE TABLE

[illegible]

COMMEN	173#														
ENDCOM	173#														
ERROR	67#	706	721	734	747	760	775	794	807	820	834	847	862	880	894
	907	920	933	946	959	972	985	997	1012	1034	1042	1086	1107	1146	1197
	1233	1251	1267	1283	1302	1317	1323	1338	1344	1359	1374	1388	1402	1409	1425
	1432	1445	1459	1468	1482	1496	1510	1524	1537	1550	1565	1578	1591	1604	1619
	1636	1649	1662	1675	1690	1710	1717	1739	1766	1794	1823	1839	1855	1871	1887
	1900	1914	1928	1942	1956	1969	1983	1997	2022	2032	2040	2067	2095	2122	2138
	2153	2172	2192	2222	3330	3336	3349	3390	3417	3531	3548				
ESCAPE	173#														
GETPRI	173#														
GETSWR	173#														
MOVEI	20#	644#													
	903	598	717	730	743	756	771	790	803	816	830	843	858	876	890
	916	929	942	955	968	981	993	1007	1030	1036	1044	1050	1072	1077	
	1082	1102	1111	1117	1141	1150	1156	1180	1186	1193	1216	1222	1229	1247	1263
	1279	1298	1313	1319	1334	1340	1355	1370	1384	1398	1405	1421	1428	1441	1455
	1464	1478	1492	1506	1520	1533	1546	1561	1574	1587	1600	1615	1632	1645	1658
	1671	1686	1706	1713	1729	1737	1754	1762	1782	1790	1808	1814	1835	1851	1867
	1883	1896	1910	1924	1938	1952	1965	1979	1993	2005	2013	2020	2023	2028	2034
	2050	2055	2061	2080	2083	2091	2109	2118	2134	2150	2164	2169	2181	2187	2217
	2313	2436	3718												
MOVEM	19#	693	715	728	741	754	768	787	801	814	828	841	855	873	888
	901	914	927	940	953	966	979	991	1003	1021	1023	1026	1048	1053	1063
	1066	1069	1075	1080	1093	1095	1099	1115	1120	1133	1135	1138	1154	1159	1171
	1173	1177	1184	1189	1207	1209	1213	1220	1225	1243	1259	1275	1291	1294	1452
	1461	1475	1489	1503	1517	1530	1543	1552	1559	1572	1585	1598	1612	1630	1643
	1656	1669	1683	1701	1704	1727	1749	1777	1780	1806	1811	1831	1847	1863	1879
	1894	1908	1922	1936	1950	1963	1977	1991	2010	2048	2053	2077	2086	2103	2105
	2112	2131	2146	2161	2179	2206	2304	2307	2310	2402	2404	2429	2432	2440	2442
MULT	173#														
NEWTST	173#	686	710	723	736	749	762	780	796	809	823	836	849	867	883
	896	909	922	935	948	961	974	986	998	1015	1058	1087	1127	1165	1201
	1237	1253	1269	1285	1305	1326	1347	1362	1376	1390	1413	1435	1447	1470	1484
	1498	1512	1525	1538	1554	1567	1580	1593	1606	1625	1638	1651	1664	1677	1696
	1719	1741	1769	1797	1825	1841	1857	1873	1889	1902	1916	1930	1944	1957	1971
	1985	2001	2043	2071	2097	2124	2140	2155	2173	2193	2242				
POP	173#	2376	2908	2987	2988	3215	3216								
PUSH	173#	2335	2887	2968	2974	3176	3178	3199							
REPORT	173#														
SCOPE	68#	689	713	726	739	752	765	783	799	812	826	839	852	870	886
	899	912	925	938	951	964	977	989	1001	1018	1061	1090	1130	1168	1204
	1240	1256	1272	1288	1308	1329	1350	1365	1379	1393	1416	1438	1450	1473	1487
	1501	1515	1528	1541	1557	1570	1583	1596	1609	1628	1641	1654	1667	1680	1699
	1722	1744	1772	1800	1828	1844	1860	1876	1892	1905	1919	1933	1947	1960	1974
	1988	2004	2046	2074	2100	2127	2143	2158	2176	2196	2245	2268			
SETPRI	173#														
SETTRA	3249#	3258	3259	3260	3261	3263	3265	3266	3267	3268					
SETUP	173#	550													
SKIP	173#	704	720	733	746	759	774	793	806	819	833	846	861	879	893
	906	919	932	945	958	971	984	996	1011	1033	1040	1043	1085	1106	1145
	1196	1232	1250	1266	1282	1301	1316	1322	1337	1343	1358	1373	1387	1401	1408
	1424	1431	1444	1458	1467	1481	1495	1509	1523	1536	1549	1564	1577	1590	1603
	1618	1635	1648	1661	1674	1689	1709	1716	1733	1758	1760	1765	1786	1788	1793
	1802	1818	1820	1822	1838	1854	1870	1886	1899	1913	1927	1941	1955	1968	1982

	1996	2031	2039	2064	2066	2094	2121	2137	2152	2171	2191	2220	2227		
SLASH	173#														
SPACE	173#														
STARS	173#	203	214	216	223	236	280	283	686	688	710	712	723	725	736
	738	749	751	762	764	780	782	796	798	809	811	823	825	836	838
	849	851	867	869	883	885	896	898	909	911	922	924	935	937	948
	950	961	963	974	976	986	968	998	1000	1015	1017	1058	1060	1087	1089
	1127	1129	1165	1167	1201	1203	1237	1239	1253	1255	1269	1271	1285	1287	1305
	1307	1326	1328	1347	1349	1362	1364	1376	1378	1390	1392	1413	1415	1435	1437
	1447	1449	1470	1472	1484	1486	1498	1500	1512	1514	1525	1527	1538	1540	1554
	1556	1567	1569	1580	1582	1593	1595	1606	1608	1625	1627	1638	1640	1651	1653
	1664	1666	1677	1679	1696	1698	1719	1721	1741	1743	1769	1771	1797	1799	1825
	1827	1841	1843	1857	1859	1873	1875	1889	1891	1902	1904	1916	1918	1930	1932
	1944	1946	1957	1959	1971	1973	1985	1987	2001	2003	2043	2045	2071	2073	2097
	2099	2124	2126	2140	2142	2155	2157	2173	2175	2193	2195	2242	2244	2260	2325
	2623	2688	2738	2741	2809	2838	2877	2916	2964	2980	3015	3092	3171	3228	
SWRSU	173#	572#													
TOUT	489#	3333	3387	3414	3528	3545									
TRMTRP	3249#														
TYPBIN	173#														
TYPDEC	173#	2280													
TYPNAM	173#	637													
TYPNUM	173#														
TYPOCS	173#														
TYPOCT	173#	2759	2928	2952	3798										
TYPTX1	173#	632	661	3304	3358	3362	3366	3593	3779	3804					
\$CAL	30#	3269													
\$DMAST	30#														
\$DMDT	30#														
\$MMAST	30#														
\$SCMRE	234#	273	274												
\$SCMTM	234#														
\$SESCA	173#														
\$SNEWT	173#														
	896	686	710	723	736	749	762	780	796	809	823	836	849	867	883
	1237	909	922	935	948	961	974	986	998	1015	1058	1087	1127	1165	1201
	1498	1253	1269	1285	1305	1326	1347	1362	1376	1390	1413	1435	1447	1470	1484
	1719	1512	1525	1538	1554	1567	1580	1593	1606	1625	1638	1651	1664	1677	1696
	1985	1741	1769	1797	1825	1841	1857	1873	1889	1902	1916	1930	1944	1957	1971
	2001	2001	2043	2071	2097	2124	2140	2155	2173	2193	2242				
\$SET	3249#	3258	3259	3260	3261	3263	3265	3266	3267	3268					
\$SETM	588#														
\$SKIP	173#	704	720	733	746	759	793	806	819	833	846	879	893	906	919
	932	945	958	971	984	996	1043	1085	1196	1232	1250	1266	1282	1301	1322
	1343	1358	1373	1387	1408	1431	1444	1467	1481	1495	1509	1523	1536	1564	1577
	1590	1603	1635	1648	1661	1674	1716	1733	1758	1765	1786	1793	1802	1818	1838
	1854	1870	1886	1899	1913	1927	1941	1955	1968	1982	1996	2039	2064	2066	2094
	2121	2137	2152	2171	2191	2227									
.EQUAT	30#	63													
.HEADE	30#	53													
.KMADR	17#	455													
.KSI5	22#	533													
.LOADL	25#	3432													
.LPAIN	22#	3270													
.PUTCS	24#	3825													

.RESET	22#	3707
.SETUP	30#	442
.SWRHI	30#	176
.SWRLO	188#	
.UTK	29#	3767
.SACT1	30#	201
.SAPT8	30#	281#
.SAPTH	30#	212
.SAPTY	30#	3169
.SCATC	30#	188
.SCMTA	30#	234
.SEOP	30#	2258
.SERRC	30#	2686
.SERRT	30#	2914
.SINLP	28#	3642
.SMMAC	18#	
.SOUTL	27#	3603
.SPARM	30#	
.SPOWE	30#	2962
.SRODC	30#	2875
.SREAD	30#	2736
.SSAVE	30#	
.SSCOP	30#	2621
.SSPAC	30#	
.SSWDO	30#	
.STLKW	26#	3481
.STOUT	489#	3686
.STRAP	30#	3226
.STYPD	30#	2323
.STYPE	30#	3090
.STYPO	30#	3013

K08

 MAINDEC-11-DRLPC-A MACY11 27(654) 15-DEC-77 10:54 PAGE 92
 DRLPC.P11 CROSS REFERENCE TABLE

SEQ 0101

ADD	602	676	682	701	2199	2224	2248	2249	2319	2355	2775	2784	2903	2936	3041
ASL	3051	3126	3186	3198	3210	3702	3722	3852							
ASLB	2798	2799	2800	2896	2898	2900	2933	2934	2935	3238					
ASR	2360														
BCC	3193														
BEQ	2361														
	590	627	630	642	648	700	720	733	746	759	774	793	806	819	833
	846	861	879	893	906	919	932	945	958	971	984	996	1033	1106	1145
	1196	1232	1250	1266	1282	1301	1316	1322	1337	1343	1358	1373	1387	1401	1408
	1424	1431	1444	1458	1467	1481	1495	1509	1523	1536	1549	1564	1577	1590	1603
	1618	1635	1648	1661	1674	1689	1709	1716	1765	1793	1802	1838	1854	1870	1886
	1899	1913	1927	1941	1955	1968	1982	1996	2039	2064	2066	2121	2137	2152	2171
	2191	2220	2247	2284	2653	2655	2657	2661	2670	2702	2725	2728	2755	2782	2797
	2895	2938	2943	2956	3068	3116	3129	3164	3180	3184	3204	3206	3328	3353	3374
	3402	3459	3579	3585	3621	3623	3663	3666	3696	3792					
BGE	2420	2673													
BGT	2275	2369	2794	2835	3075										
BHI	2659														
BIC	1052	1079	1119	1158	1188	1224	2272	2751	2768	2795	2822	2828	2836	2902	3065
BICB	3788														
BIS	1047	1074	1114	1153	1183	1219	1810	2085	2111	2363	2364	2802	3070	3071	3315
	3445	3447	3455	3490	3522	3750									
BISB	2925	3857	3858	3859											
BIT	1801	2038	2063	2638	2652	2660	2667	2708	2724	3327	3383	3540	3557	3584	
BITB	589	3115	3120	3152	3183										
BLOS	2848														
BLT	2352	2368	2792	2833	3076	3143									
BMI	1085	1733	1758	1786	1818	2017	2317	2359	3701						
BNE	546	555	579	601	606	625	640	646	650	670	673	679	685	698	778
	865	1014	1056	1123	1125	1162	1164	1192	1228	1623	1694	1735	1760	1788	1820
	1822	2019	2090	2117	2209	2226	2320	2357	2435	2639	2668	2709	2714	2732	2747
	2753	2773	2780	2787	2824	2830	2852	2858	2926	2948	2986	3066	3114	3121	3123
	3131	3139	3153	3160	3182	3188	3191	3208	3322	3325	3346	3348	3355	3357	3384
	3400	3427	3451	3457	3541	3558	3581	3587	3721	3753	3758				
BPL	1011	1040	2031	2059	2094	2167	2185	2343	2373	2417	2721	2749	2765	2820	2826
	3064	3108	3157	3471	3748	3785									
BR	531	581	604	634	652	655	662	702	704	1043	2227	2251	2354	2371	2641
	2647	2650	2663	2666	2719	2776	2803	2805	2831	2854	2904	2931	2958	2978	3002
	3042	3057	3078	3110	3136	3146	3155	3162	3174	3196	3289	3305	3308	3342	3359
	3363	3367	3396	3423	3462	3474	3537	3554	3582	3588	3595	3600	3625	3640	3668
	3685	3699	3727	3781	3800	3805	3814								
CLR	530	547	553	567	568	588	596	612	621	691	767	854	1006	1020	1028
	1097	1101	1140	1551	1611	1682	1804	2037	2129	2148	2163	2189	2269	2270	2346
	2349	2665	2680	2762	2763	2892	2893	2924	2984	3055	3311	3320	3406	3443	3444
	3448	3452	3460	3577	3619	3637	3661	3682	3698	3751	3754	3778			
CLRB	2375	2664	2859	3135	3161	3212	3213	3214							
CMP	545	554	578	624	641	649	669	672	678	684	699	719	732	745	758
	773	805	818	832	845	860	892	905	918	931	944	957	970	983	995
	1032	1105	1144	1195	1231	1249	1265	1281	1300	1315	1321	1336	1342	1357	1372
	1386	1400	1407	1423	1430	1443	1457	1466	1480	1494	1508	1522	1535	1548	1563
	1576	1589	1602	1617	1622	1634	1647	1660	1673	1688	1693	1708	1715	1764	1792
	1837	1853	1869	1885	1898	1912	1926	1940	1954	1967	1981	1995	2065	2120	2190
	2219	2318	2367	2419	2424	2648	2672	2731	2746	2752	2772	2779	2791	2793	2823
	2829	2832	2834	2847	3309	3373	3450	3456	3458	3622	3665	3695			

CMPB	647	2654	2658	2713	2754	2786	2851	2857	3113	3128	3130	3138	3159	3163	3181
DEC	3345	3347	3352	3399	3426	3578	3791	1787	1819	1821	2116	2208	2225	2250	2273
DECB	609	1122	1161	1191	1227	1734	1759								
EMT	2434	2932	3763												
HALT	3063	3074	3142	3145											
INC	67														
INC	194	607	2722	2733	2977	3001	3109	3472	3599						
INC	543	603	639	1013	1621	1692	2018	2052	2089	2271	2353	2431	2671	2704	2801
	2985	3069	3077	3211	3303	3321	3354	3356	3404	3449	3461	3580	3586	3624	3667
INC	3700														
INC	777	864	1055	1124	1163	2676	2701	3165	3324	3375	3470	3757			
INC	68														
INC	198	199	628	631	707	2255	2257	2291							
INC	600	696	717	719	730	732	743	745	756	758	771	773	789	792	803
INC	805	816	818	830	832	843	845	858	860	875	878	890	892	903	905
INC	916	918	929	931	942	944	955	957	968	970	981	983	993	995	1005
INC	1010	1023	1025	1028	1032	1039	1047	1050	1052	1055	1065	1068	1071	1074	1077
INC	1079	1082	1084	1095	1097	1101	1105	1114	1117	1119	1122	1135	1137	1140	1144
INC	1153	1156	1158	1161	1173	1175	1179	1183	1186	1188	1191	1195	1209	1211	1215
INC	1219	1222	1224	1227	1231	1245	1246	1249	1261	1262	1265	1277	1278	1281	1293
INC	1296	1297	1300	1312	1315	1321	1333	1336	1342	1354	1357	1369	1372	1383	1386
INC	1397	1400	1407	1420	1423	1430	1440	1443	1454	1457	1463	1466	1477	1480	1491
INC	1494	1505	1508	1519	1522	1532	1535	1545	1548	1554	1561	1563	1574	1576	1587
INC	1589	1600	1602	1615	1617	1632	1634	1645	1647	1658	1660	1671	1673	1686	1688
INC	1703	1706	1708	1715	1729	1732	1739	1751	1757	1764	1779	1782	1785	1792	1808
INC	1810	1813	1817	1833	1834	1837	1849	1850	1853	1865	1866	1869	1881	1882	1885
INC	1896	1898	1910	1912	1924	1926	1938	1940	1952	1954	1965	1967	1979	1981	1993
INC	1995	2007	2012	2016	2022	2026	2030	2037	2050	2052	2055	2058	2063	2079	2082
INC	2085	2088	2093	2105	2107	2111	2114	2120	2133	2136	2148	2149	2152	2163	2166
INC	2168	2171	2181	2184	2186	2189	2197	2208	2219	2286	2306	2309	2312	2316	2404
INC	2406	2410	2411	2413	2431	2434	2438	2442	2444	2710	2716	2790	3118	3137	3144
INC	3151	3200	3312	3334	3377	3379	3381	3388	3415	3491	3495	3500	3504	3523	3526
INC	3529	3543	3546	3560	3630	3638	3672	3683	3720	3794	3811	3846	3853		
INC	532	538	539	540	541	544	548	549	552	556	558	559	560	561	562
INC	563	564	565	566	570	571	574	575	576	577	582	584	585	586	591
INC	593	594	595	597	610	611	613	614	615	618	619	620	622	658	667
INC	668	671	674	675	681	692	714	727	740	753	766	784	785	786	800
INC	813	827	840	853	871	872	887	900	913	926	939	952	965	978	990
INC	1002	1005	1019	1025	1029	1041	1062	1065	1068	1071	1091	1092	1098	1110	1131
INC	1132	1137	1149	1169	1170	1175	1176	1179	1205	1206	1211	1212	1215	1241	1242
INC	1245	1257	1258	1261	1273	1274	1277	1289	1290	1293	1296	1309	1310	1311	1318
INC	1330	1331	1332	1339	1351	1352	1353	1366	1367	1368	1380	1381	1382	1394	1395
INC	1396	1404	1417	1418	1419	1427	1439	1451	1454	1460	1463	1474	1477	1488	1491
INC	1502	1505	1516	1519	1529	1532	1542	1545	1558	1571	1584	1597	1610	1629	1642
INC	1655	1668	1681	1700	1703	1712	1724	1725	1726	1736	1746	1747	1748	1752	1761
INC	1774	1775	1776	1779	1789	1803	1805	1829	1830	1833	1845	1846	1849	1861	1862
INC	1865	1877	1878	1881	1893	1907	1921	1935	1949	1962	1976	1990	2007	2008	2009
INC	2012	2026	2027	2047	2060	2075	2076	2079	2082	2088	2101	2102	2107	2108	2115
INC	2128	2130	2144	2145	2159	2160	2177	2178	2198	2200	2201	2202	2205	2211	2212
INC	2213	2215	2216	2221	2232	2253	2254	2256	2276	2280	2283	2303	2306	2309	2312
INC	2336	2337	2338	2339	2340	2341	2342	2347	2350	2370	2376	2377	2378	2379	2380
INC	2382	2383	2401	2406	2407	2408	2409	2412	2414	2415	2421	2427	2428	2438	2439
INC	2643	2644	2646	2649	2662	2674	2675	2678	2679	2682	2683	2703	2705	2726	2729
INC	2759	2783	2788	2817	2818	2845	2846	2861	2862	2863	2864	2885	2886	2887	2888

MOV

	2889	2891	2906	2907	2908	2909	2910	2923	2928	2937	2942	2947	2949	2953	2966
	2967	2968	2969	2970	2971	2972	2973	2974	2975	2976	2982	2983	2987	2988	2989
	2990	2991	2992	2993	2994	2995	2998	3038	3046	3047	3048	3054	3061	3079	3080
	3081	3082	3083	3111	3112	3117	3125	3140	3177	3178	3185	3189	3194	3195	3197
	3199	3209	3215	3216	3234	3235	3239	3245	3246	3287	3302	3310	3319	3323	3332
	3372	3407	3440	3441	3442	3446	3453	3464	3465	3488	3489	3492	3493	3496	3505
	3520	3521	3527	3562	3576	3590	3615	3616	3618	3627	3629	3633	3634	3636	3657
	3658	3660	3670	3676	3677	3678	3681	3697	3749	3790	3798	3809	3845	3851	
MOVB	569	653	2345	2348	2362	2365	2374	2677	2681	2707	2715	2750	2767	2821	2827
	2850	2855	2894	3039	3040	3043	3044	3045	3049	3052	3053	3072	3122	3150	3158
	3172	3173	3175	3237	3371	3376	3378	3380	3385	3413	3494	3497	3499	3501	3502
	3503	3524	3525	3542	3544	3559	3561	3786	3849	3850	3856				
NEG	2344	2418	3050												
NOP	616	666	2287	2288	2289										
RESET	2285	3717													
ROL	2897	2899	2901	3056	3058	3059	3060	3062							
RTI	583	2384	2684	2735	2789	2837	2865	2911	3000	3084	3127	3247	3764		
rTS	2321	2422	2425	2444	2951	3167	3217	3240	3408	3428	3466	3506	3563	3591	3635
	3679	3703	3729	3756	3759	3860									
SUB	2203	2204	2351	2416	2706	3192									
TRAP	3249	3258	3259	3260	3261	3263	3265	3266	3267	3268					
TST	600	605	623	626	629	645	677	680	683	697	792	878	1010	2136	2223
	2246	2356	2366	2423	2645	2669	2720	2727	2781	2796	2905	2955	3067	3124	3132
	3154	3187	3205	3207	3236	3469	3620	3628	3662	3671	3720	3747	3752		
TSTB	1039	1084	1732	1757	1785	1817	2016	2030	2058	2093	2166	2184	2316	2358	2372
	2656	2748	2764	2819	2825	3107	3156	3179	3190	3203	3401	3784			
.ASCII	277	278													
.ASCII2	279	636	657	664	2294	2450	2456	2460	2466	2472	2476	2482	2486	2492	2497
	2501	2505	2509	2513	2518	2523	2529	2532	2538	2544	2547	2553	2559	2565	2571
	2577	2580	2584	2590	2669	2670	2671	2673	2659	3004	3307	3361	3365	3369	3597
	3783	3807	3818												
.ASECT	14														
.BLKB	2868														
.BLKW	487	2389													
.BYTE	243	244	249	250	258	259	267	268	269	270	295	296	306	307	314
	315	317	318	320	321	2293	2717	2718	2866	2867	3085	3086	3087	3088	3218
	3219	3220													
.DSABL	2806														
.ENABL	30	2739													
.END	3863														
.ENDC	58	67	159	173	184	186	187	188	199	204	208	210	215	217	224
	237	241	243	271	275	276	277	281	284	306	314	317	320	323	324
	325	326	327	328	329	330	331	332	333	334	335	336	337	338	339
	340	341	342	343	344	345	349	442	484	550	556	557	560	562	564
	566	567	568	570	572	593	636	641	643	649	655	657	664	687	688
	689	690	705	711	712	713	714	721	724	725	726	727	734	737	738
	739	740	747	750	751	752	753	760	763	764	765	766	775	781	782
	783	784	785	794	797	798	799	800	807	810	811	812	813	820	824
	825	826	827	834	837	838	839	840	847	850	851	852	853	862	868
	869	870	871	880	884	885	886	887	894	897	898	899	900	907	910
	911	912	913	920	923	924	925	926	933	936	937	938	939	946	949
	950	951	952	953	962	963	964	965	972	975	976	977	978	985	987
	988	989	990	997	999	1000	1001	1002	1012	1016	1017	1018	1019	1020	1034
	1041	1044	1059	1060	1061	1062	1086	1088	1089	1090	1091	1092	1107	1128	1129

	1130	1131	1132	1146	1166	1167	1168	1169	1170	1197	1202	1203	1204	1205	1206
	1233	1238	1239	1240	1241	1242	1251	1254	1255	1256	1257	1258	1267	1270	1271
	1272	1273	1274	1283	1286	1287	1288	1289	1290	1302	1306	1307	1308	1309	1310
	1317	1323	1327	1328	1329	1330	1331	1338	1344	1348	1349	1350	1351	1352	1359
	1363	1364	1365	1366	1367	1374	1377	1378	1379	1380	1381	1388	1391	1392	1393
	1394	1395	1402	1409	1414	1415	1416	1417	1418	1425	1432	1436	1437	1438	1439
	1445	1448	1449	1450	1451	1459	1468	1471	1472	1473	1474	1482	1485	1486	1487
	1488	1496	1499	1500	1501	1502	1510	1513	1514	1515	1516	1524	1526	1527	1528
	1529	1537	1539	1540	1541	1542	1550	1555	1556	1557	1558	1565	1568	1569	1570
	1571	1578	1581	1582	1583	1584	1591	1594	1595	1596	1597	1604	1607	1608	1609
	1610	1613	1626	1627	1628	1629	1636	1639	1640	1641	1642	1649	1652	1653	1654
	1655	1662	1665	1666	1667	1668	1675	1678	1679	1680	1681	1690	1697	1698	1699
	1700	1710	1717	1720	1721	1722	1723	1734	1742	1743	1744	1745	1759	1761	1766
	1770	1771	1772	1773	1787	1789	1794	1798	1799	1800	1801	1803	1819	1821	1823
	1826	1827	1828	1829	1830	1839	1842	1843	1844	1845	1846	1855	1858	1859	1860
	1861	1862	1871	1874	1875	1876	1877	1878	1887	1890	1891	1892	1893	1900	1903
	1904	1905	1906	1914	1917	1918	1919	1920	1928	1931	1932	1933	1934	1942	1945
	1946	1947	1948	1956	1958	1959	1960	1961	1969	1972	1973	1974	1975	1983	1986
	1987	1988	1989	1997	2002	2003	2004	2005	2032	2040	2044	2045	2046	2047	2065
	2067	2072	2073	2074	2075	2076	2095	2098	2099	2100	2101	2102	2122	2125	2126
	2127	2128	2129	2138	2141	2142	2143	2144	2145	2153	2156	2157	2158	2159	2160
	2172	2174	2175	2176	2177	2178	2192	2194	2195	2196	2197	2221	2238	2243	2244
	2245	2246	2261	2263	2264	2266	2269	2275	2278	2279	2283	2285	2291	2293	2294
	2297	2326	2624	2627	2632	2638	2640	2651	2654	2655	2656	2658	2660	2667	2671
	2676	2678	2682	2685	2686	2689	2692	2701	2705	2710	2711	2712	2720	2731	2735
	2736	2739	2740	2742	2770	2806	2810	2838	2839	2846	2848	2851	2853	2869	2875
	2878	2880	2913	2917	2932	2961	2965	2974	2975	2981	2987	2988	2998	3000	3004
	3016	3093	3122	3172	3173	3176	3203	3218	3229	3235	3238	3257	3258	3259	3260
	3261	3262	3263	3264	3265	3266	3267	3268	3269	3307	3337	3344	3361	3365	3369
	3391	3398	3418	3425	3532	3539	3549	3556	3597	3767	3783	3807			
.EQUIV	67	68	76	121	122	123	124	125	126	127	128	129	130	149	150
.EVEN	151	152	153	154	155	156	157	158							
	284	636	657	664	2596	2960	3011	3221	3307	3361	3365	3369	3597	3783	3807
.GLOBL	3821														
.IF	14														
	54	65	131	159	183	185	186	187	188	197	203	206	208	214	216
	223	236	240	242	271	275	276	277	280	281	283	306	314	317	320
	323	324	325	326	327	328	329	330	331	332	333	334	335	336	337
	338	339	340	341	342	343	344	345	349	442	481	550	551	556	558
	560	562	564	566	567	568	570	588	635	640	641	642	644	647	656
	663	686	688	690	704	710	712	714	720	723	725	727	733	736	738
	740	746	749	751	753	759	762	764	766	774	780	782	784	785	793
	796	798	800	806	809	811	813	819	823	825	827	833	836	838	840
	846	849	851	853	861	867	869	871	879	883	885	887	893	896	898
	900	906	909	911	913	919	922	924	926	932	935	937	939	945	948
	950	952	958	961	963	965	971	974	976	978	984	986	988	990	996
	998	1000	1002	1011	1015	1017	1019	1020	1033	1040	1043	1058	1060	1062	1085
	1087	1089	1091	1092	1106	1127	1129	1131	1132	1145	1165	1167	1169	1170	1196
	1201	1203	1205	1206	1232	1237	1239	1241	1242	1250	1253	1255	1257	1258	1266
	1269	1271	1273	1274	1282	1285	1287	1289	1290	1301	1305	1307	1309	1310	1316
	1322	1326	1328	1330	1331	1337	1343	1347	1349	1351	1352	1358	1362	1364	1366
	1367	1373	1376	1378	1380	1381	1387	1390	1392	1394	1395	1401	1408	1413	1415
	1417	1418	1424	1431	1435	1437	1439	1444	1447	1449	1451	1458	1467	1470	1472
	1474	1481	1484	1486	1488	1495	1498	1500	1502	1509	1512	1514	1516	1523	1525

.IFF

1527	1529	1536	1538	1540	1542	1549	1554	1556	1558	1564	1567	1569	1571	1577
1580	1582	1584	1590	1593	1595	1597	1603	1606	1608	1610	1618	1625	1627	1629
1635	1638	1640	1642	1648	1651	1653	1655	1661	1664	1666	1668	1674	1677	1679
1681	1689	1696	1698	1700	1709	1716	1719	1721	1723	1733	1741	1743	1745	1758
1760	1765	1769	1771	1773	1786	1788	1793	1797	1799	1801	1802	1818	1820	1822
1825	1827	1829	1830	1838	1841	1843	1845	1846	1854	1857	1859	1861	1862	1870
1873	1875	1877	1878	1886	1889	1851	1893	1899	1902	1904	1906	1913	1916	1918
1920	1927	1930	1932	1934	1941	1944	1946	1948	1955	1957	1959	1961	1968	1971
1973	1975	1982	1985	1987	1989	1996	2001	2003	2005	2031	2039	2043	2045	2047
2064	2066	2071	2073	2075	2076	2094	2097	2099	2101	2102	2121	2124	2126	2128
2129	2137	2140	2142	2144	2145	2152	2155	2157	2159	2160	2171	2173	2175	2177
2178	2191	2193	2195	2197	2220	2227	2242	2244	2246	2260	2261	2262	2263	2264
2265	2266	2268	2274	2277	2279	2283	2285	2291	2293	2294	2325	2623	2626	2631
2637	2638	2650	2652	2653	2654	2656	2657	2658	2667	2669	2677	2679	2684	2685
2686	2688	2691	2701	2704	2708	2710	2711	2713	2720	2724	2731	2735	2736	2738
2740	2741	2742	2770	2809	2810	2838	2846	2847	2851	2852	2868	2869	2875	2877
2880	2892	2916	2931	2947	2964	2974	2975	2980	2987	2988	2996	2998	3000	3004
3015	3092	3113	3171	3173	3176	3203	3218	3228	3234	3238	3249	3258	3259	3260
3261	3262	3263	3265	3266	3267	3268	3269	3306	3336	3342	3360	3364	3368	3390
3396	3417	3423	3531	3537	3548	3554	3596	3767	3782	3806				
65	183	185	187	188	204	208	210	215	217	224	237	240	243	271
281	284	556	640	642	687	688	689	690	705	711	712	713	714	721
724	725	726	727	734	737	738	739	740	747	750	751	752	753	760
763	764	765	766	774	781	782	783	784	794	797	798	799	800	807
810	811	812	813	820	824	825	826	827	834	837	838	839	840	847
850	851	852	853	861	868	869	870	871	880	884	885	886	887	894
897	898	899	900	907	910	911	912	913	920	923	924	925	926	933
936	937	938	939	946	949	950	951	952	959	962	963	964	965	972
975	976	977	978	985	987	988	989	990	997	999	1000	1001	1002	1011
1016	1017	1018	1019	1033	1040	1044	1059	1060	1061	1062	1086	1088	1089	1090
1091	1106	1128	1129	1130	1131	1145	1166	1167	1168	1169	1197	1202	1203	1204
1205	1233	1238	1239	1240	1241	1251	1254	1255	1256	1257	1267	1270	1271	1272
1273	1283	1286	1287	1288	1289	1302	1306	1307	1308	1309	1316	1323	1327	1328
1329	1330	1337	1344	1348	1349	1350	1351	1359	1363	1364	1365	1366	1374	1377
1378	1379	1380	1388	1391	1392	1393	1394	1401	1409	1414	1415	1416	1417	1424
1432	1436	1437	1438	1439	1445	1448	1449	1450	1451	1458	1468	1471	1472	1473
1474	1482	1485	1486	1487	1488	1496	1499	1500	1501	1502	1510	1513	1514	1515
1516	1524	1526	1527	1528	1529	1537	1539	1540	1541	1542	1549	1555	1556	1557
1558	1565	1568	1569	1570	1571	1578	1581	1582	1583	1584	1591	1594	1595	1596
1597	1604	1607	1608	1609	1610	1618	1626	1627	1628	1629	1636	1639	1640	1641
1642	1649	1652	1653	1654	1655	1662	1665	1666	1667	1668	1675	1678	1679	1680
1681	1689	1697	1698	1699	1700	1709	1717	1720	1721	1722	1723	1734	1742	1743
1744	1745	1759	1760	1766	1770	1771	1772	1773	1787	1788	1794	1798	1799	1800
1801	1803	1819	1820	1822	1826	1827	1828	1829	1839	1842	1843	1844	1845	1855
1858	1859	1860	1861	1871	1874	1875	1876	1877	1887	1890	1891	1892	1893	1900
1903	1904	1905	1906	1914	1917	1918	1919	1920	1928	1931	1932	1933	1934	1942
1945	1946	1947	1948	1956	1958	1959	1960	1961	1969	1972	1973	1974	1975	1983
1986	1987	1988	1989	1997	2002	2003	2004	2005	2031	2040	2044	2045	2046	2047
2065	2067	2072	2073	2074	2075	2095	2098	2099	2100	2101	2122	2125	2126	2127
2128	2138	2141	2142	2143	2144	2153	2156	2157	2158	2159	2172	2174	2175	2176
2177	2192	2194	2195	2196	2197	2220	2228	2243	2244	2245	2246	2261	2265	2269
2274	2277	2293	2326	2624	2651	2654	2655	2658	2685	2689	2691	2705	2731	2736
2739	2742	2810	2812	2817	2838	2839	2848	2852	2869	2878	2917	2932	2961	2965
2981	2996	3016	3093	3172	3229	3235	3336	3342	3390	3396	3417	3423	3531	3537

.IFT	3548	3554	664	2666	2711	2812	2817	2896	2912	2913	3307	3361	3365	3369	3597
	636	657													
.IFTF	3783	3807	664	2664	2710	2757	2810	2813	2892	2896	2912	3307	3361	3365	3369
	636	657													
.IIF	3597	3783	3807												
	53	58	63	180	181	182	184	187	188	194	280	284	557	560	566
	567	568	570	571	641	2263	2269	2270	2281	2293	2297	2627	2628	2629	2630
	2631	2632	2636	2665	2666	2682	2685	2686	2692	2693	2694	2695	2700	2723	2731
	2736	2739	2760	2861	2869	2875	2929	2954	3169	3257	3258	3259	3260	3261	3263
.IRP	3265	3266	3267	3268	3799										
	442	686	710	723	736	749	762	780	796	809	823	836	849	867	883
	896	909	922	935	948	961	974	986	998	1015	1058	1087	1127	1165	1201
	1237	1253	1269	1285	1305	1326	1347	1362	1376	1390	1413	1435	1447	1470	1484
	1498	1512	1525	1538	1554	1567	1580	1593	1606	1625	1638	1651	1664	1677	1696
	1719	1741	1769	1797	1825	1841	1857	1873	1889	1902	1916	1930	1944	1957	1971
	1985	2001	2043	2071	2097	2124	2140	2155	2173	2193	2242	2336	2376	2637	2887
.LIST	2908	2968	2974	2987	2988	3177	3178	3199	3215	3216					
	14	30	173	187	194	271	273	274	275	281	284	442	572	600	636
	641	644	657	664	686	690	696	710	714	717	719	723	727	730	732
	736	740	743	745	749	753	756	758	762	766	771	773	780	784	789
	792	796	800	803	805	809	813	816	818	823	827	830	832	836	840
	843	845	849	853	858	860	867	871	875	878	883	887	890	892	896
	900	903	905	909	913	916	918	922	926	929	931	935	939	942	944
	948	952	955	957	961	965	968	970	974	978	981	983	986	990	993
	995	998	1002	1005	1010	1015	1019	1023	1025	1028	1032	1039	1047	1050	1052
	1055	1058	1062	1065	1068	1071	1074	1077	1079	1082	1084	1087	1091	1095	1097
	1101	1105	1114	1117	1119	1122	1127	1131	1135	1137	1140	1144	1153	1156	1158
	1161	1165	1169	1173	1175	1179	1183	1186	1188	1191	1195	1201	1205	1209	1211
	1215	1219	1222	1224	1227	1231	1237	1241	1245	1249	1253	1257	1261	1265	1269
	1273	1277	1281	1285	1289	1293	1296	1300	1305	1309	1315	1321	1326	1330	1336
	1342	1347	1351	1357	1362	1366	1372	1376	1380	1386	1390	1394	1400	1407	1413
	1417	1423	1430	1435	1439	1443	1447	1451	1454	1457	1463	1466	1470	1474	1477
	1480	1484	1488	1491	1494	1498	1502	1505	1508	1512	1516	1519	1522	1525	1529
	1532	1535	1538	1542	1545	1548	1554	1558	1561	1563	1567	1571	1574	1576	1580
	1584	1587	1589	1593	1597	1600	1602	1606	1610	1615	1617	1625	1629	1632	1634
	1638	1642	1645	1647	1651	1655	1658	1660	1664	1668	1671	1673	1677	1681	1686
	1688	1696	1700	1703	1706	1708	1715	1719	1723	1729	1732	1739	1741	1745	1751
	1757	1764	1769	1773	1779	1782	1785	1792	1797	1801	1808	1810	1813	1817	1825
	1829	1833	1837	1841	1845	1849	1853	1857	1861	1865	1869	1873	1877	1881	1885
	1889	1893	1896	1898	1902	1906	1910	1912	1916	1920	1924	1926	1930	1934	1938
	1940	1944	1948	1952	1954	1957	1961	1965	1967	1971	1975	1979	1981	1985	1989
	1993	1995	2001	2005	2007	2012	2016	2022	2026	2030	2037	2043	2047	2050	2052
	2055	2058	2063	2071	2075	2079	2082	2085	2088	2093	2097	2101	2105	2107	2111
	2114	2120	2124	2128	2133	2136	2140	2144	2148	2152	2155	2159	2163	2166	2171
	2173	2177	2181	2184	2189	2193	2197	2208	2219	2242	2246	2269	2285	2306	2309
	2312	2316	2404	2406	2431	2434	2438	2442	2444	2631	2731	2838	3249	3257	3258
	3259	3260	3261	3262	3263	3264	3265	3266	3267	3268	3269	3307	3361	3365	3369
.MACRO	3597	3720	3783	3807											
	17	18	19	20	22	24	25	26	27	28	29	30	188	234	489
.MCALL	588	3249													
.NLIST	30	173	281	572	644										
	14	30	173	187	194	271	273	274	275	281	284	442	572	600	636
	641	644	657	664	686	690	696	710	714	717	719	723	727	730	732
	736	740	743	745	749	753	756	758	762	766	771	773	780	784	789

	792	796	800	803	805	809	813	816	818	823	827	830	832	836	840
	843	845	849	853	858	860	867	871	875	878	883	887	890	892	896
	900	903	905	909	913	916	918	922	926	929	931	935	939	942	944
	948	952	955	957	961	965	968	970	974	978	981	983	986	990	993
	995	998	1002	1005	1010	1015	1019	1023	1025	1028	1032	1039	1047	1050	1052
	1055	1058	1062	1065	1068	1071	1074	1077	1079	1082	1084	1087	1091	1095	1097
	1101	1105	1114	1117	1119	1122	1127	1131	1135	1137	1140	1144	1153	1156	1158
	1161	1165	1169	1173	1175	1179	1183	1186	1188	1191	1195	1201	1205	1209	1211
	1215	1219	1222	1224	1227	1231	1237	1241	1245	1249	1253	1257	1261	1265	1269
	1273	1277	1281	1285	1289	1293	1296	1300	1305	1309	1315	1321	1326	1330	1336
	1342	1347	1351	1357	1362	1366	1372	1376	1380	1386	1390	1394	1400	1407	1413
	1417	1423	1430	1435	1439	1443	1447	1451	1454	1457	1463	1466	1470	1474	1477
	1480	1484	1488	1491	1494	1498	1502	1505	1508	1512	1516	1519	1522	1525	1529
	1532	1535	1538	1542	1545	1548	1554	1558	1561	1563	1567	1571	1574	1576	1580
	1584	1587	1589	1593	1597	1600	1602	1606	1610	1615	1617	1625	1629	1632	1634
	1638	1642	1645	1647	1651	1655	1658	1660	1664	1668	1671	1673	1677	1681	1686
	1688	1696	1700	1703	1706	1708	1715	1719	1723	1729	1732	1739	1741	1745	1751
	1757	1764	1769	1773	1779	1782	1785	1792	1797	1801	1808	1810	1813	1817	1825
	1829	1833	1837	1841	1845	1849	1853	1857	1861	1865	1869	1873	1877	1881	1885
	1889	1893	1896	1898	1902	1906	1910	1912	1916	1920	1924	1926	1930	1934	1938
	1940	1944	1948	1952	1954	1957	1961	1965	1967	1971	1975	1979	1981	1985	1989
	1993	1995	2001	2005	2007	2012	2016	2022	2026	2030	2037	2043	2047	2050	2052
	2055	2058	2063	2071	2075	2079	2082	2085	2088	2093	2097	2101	2105	2107	2111
	2114	2120	2124	2128	2133	2136	2140	2144	2148	2152	2155	2159	2163	2166	2171
	2173	2177	2181	2184	2189	2193	2197	2208	2219	2242	2246	2269	2285	2306	2309
	2312	2316	2404	2406	2431	2434	2438	2442	2444	2631	2731	2838	3249	3257	3258
	3259	3260	3261	3262	3263	3264	3265	3266	3267	3268	3269	3307	3361	3365	3369
	3597	3720	3783	3807											
	234	349													
.PAGE	14		30												
.PSECT	1	14													
.REM															
.REPT	194	273													
.SBTTL	63	176	188	197	201	212	234	281	349	550	637	644	686	710	723
	736	749	762	780	796	809	823	836	849	867	883	896	909	922	935
	948	961	974	986	998	1015	1058	1087	1127	1165	1201	1237	1253	1269	1285
	1305	1326	1347	1362	1376	1390	1413	1435	1447	1470	1484	1498	1512	1525	1538
	1554	1567	1580	1593	1606	1625	1638	1651	1664	1677	1696	1719	1741	1769	1797
	1825	1841	1857	1873	1889	1902	1916	1930	1944	1957	1971	1985	2001	2043	2071
	2097	2124	2140	2155	2173	2193	2242	2258	2323	2621	2686	2736	2875	2914	2962
	3013	3090	3169	3226	3249										
.TITLE	53														
.WORD	194	195	196	209	228	229	230	231	232	233	242	245	246	247	248
	251	252	253	254	255	256	257	260	261	262	271	273	274	286	287
	288	289	290	291	292	293	297	298	299	312	316	319	322	323	324
	325	326	327	328	329	330	331	332	333	334	335	336	337	338	339
	340	341	342	343	344	464	467	469	471	473	475	477	479	481	482
	484	486	600	660	696	717	719	730	732	743	745	756	758	771	773
	789	792	803	805	816	818	830	832	843	845	858	860	875	878	890
	892	903	905	916	918	929	931	942	944	955	957	968	970	981	983
	993	995	1005	1010	1023	1025	1028	1032	1039	1047	1050	1052	1055	1065	1068
	1071	1074	1077	1079	1082	1084	1095	1097	1101	1105	1114	1117	1119	1122	1135
	1137	1140	1144	1153	1156	1158	1161	1173	1175	1179	1183	1186	1188	1191	1195
	1209	1211	1215	1219	1222	1224	1227	1231	1245	1249	1261	1265	1277	1281	1293
	1296	1300	1315	1321	1336	1342	1357	1372	1386	1400	1407	1423	1430	1443	1454

1457	1463	1466	1477	1480	1491	1494	1505	1508	1519	1522	1532	1535	1545	1548
1554	1561	1563	1574	1576	1587	1589	1600	1602	1615	1617	1632	1634	1645	1647
1658	1660	1671	1673	1686	1688	1703	1706	1708	1715	1729	1732	1739	1751	1757
1764	1779	1782	1785	1792	1808	1810	1813	1817	1833	1837	1849	1853	1865	1869
1881	1885	1896	1898	1910	1912	1924	1926	1938	1940	1952	1954	1965	1967	1979
1981	1993	1995	2007	2012	2016	2022	2026	2030	2037	2050	2052	2055	2058	2063
2079	2082	2085	2088	2093	2105	2107	2111	2114	2120	2133	2136	2148	2152	2163
2166	2171	2181	2184	2189	2208	2219	2274	2277	2292	2306	2309	2312	2316	2404
2406	2431	2434	2438	2442	2444	2912	2940	2945	2997	2999	3089	3119	3166	3201
3256	3313	3410	3430	3565	3631	3632	3639	3674	3684	3705	3706	3720	3730	3731
3761	3765	3795	3796	3801	3812	3813	3816	3817	3847	3848	3854	3855	3861	

000000

ERRORS DETECTED: 0

F09

MAINDEC-11-DRLPC-A MACY11 27(654) 15-DEC-77 10:54 PAGE 100
DRLPC.P11

SEQ 0109

*DRLPC,DRLPC/SOL/CRF=DRLPA.MAC,DRLPC
RUN-TIME: 35 23 3 SECONDS
CORE USED: 40K