

DV11

DEVICE ROUTINE (MPG)
MD-11-DTDUA-A

EP-DTDUA-A-DL-A
COPYRIGHT © 1976
FICHE 1 OF 1

NOV 1976
digital
MADE IN U.S.A.

.REM %

IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DTDUA-A
PRODUCT NAME: DULL DEVICE ROUTINE FOR MP3
DATE: JULY 1976
MAINTAINER: SYSTEMS RELIABILITY
AUTHOR: C. E. HARPER

COPYRIGHT (C) 1976
DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.

THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DEC.

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

C01

MAINDEC-11-DTQDA-A DUII DEVICE ROUTINE FOR MPG
DTQDA.P11 REVISION HISTORY

MACY11 27(732) 24-SEP-76 14:10 PAGE 2

SEQ 0031

4444

.SBTTL REVISION HISTORY

: JUL 76 DTQDA-A INITIAL RELEASE

49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104

000000'

.SBTTL STANDARD DEVICE ROUTINE TABLE & CONSTANT AREAS

.TITLE MAINDEC-11-DTUA-A D11 DEVICE ROUTINE FOR MPG

;REVISION "A"

;FILENAME OF "TDUAA.MPG" ON MPG/XXDP MEDIA

;MACY11: DTUA',DTUA'/CRF:SYM/DOC=DTUA'.P11

;LNKX11: DTUA'.MPG/B:0+DTUA'/E

;PAPER TAPE: PUNCH DTUA'.MPG/FILE:ELEV

.CSECT D11

.DSABL GBL

 ;THE FOLLOWING TABLE IS IN THE STANDARDIZED FORMAT REQUIRED
 ;TO INTERFACE WITH MPG.

 LOCZ: .WORD DVREND-.
 DFLGWD: .WORD 0

 ;DEVICE ROUT SIZE IN BYTES
 ;DEVICE ROUT FLAGWORD

 WAITMD= 100000
 BRKFLG= 200
 WRIERR= 100
 RDIDSC= 40
 RDIERR= 20
 WRTERM= 10
 RDTERM= 4
 WRBSY= 2
 RDBSY= 1

 ; 'NOWAIT' FLAG
 ; BREAK INST FLAG
 ; WRITE INT ERROR FLAG
 ; READ INT DATA SET CHG ERR
 ; READ INT ERROR FLAG
 ; DO WRITE TERMINATION
 ; DO READ TERMINATION
 ; WRITE BUSY
 ; READ BUSY

 SYNC: .WORD SYNCB
 SCNT: .WORD NSYNC

 ;CURRENT SYNC CHARACTER
 ;SYNC CHAR COUNT
 ;INTERFACE WORD # 3 (NOT USED)
 ;INTERFACE WORD # 4 (NOT USED)
 ;INTERFACE WORD # 5 (NOT USED)
 ;INTERFACE WORD # 6 (NOT USED)

 SIZE: .WORD 0
 ERR1: .WORD 0
 DREGAD: .WORD 160010
 IVCTAD: .WORD 300
 RDPSWD: .WORD 240
 WRPSWD: .WORD 240
 HSKEEP-.
 REPORT-.
 KILL-.
 DATAER-.
 TOUTER-.

 ;# OF BYTES TRANSFERRED / UNIMAP FLG
 ;ERROR ON LAST I/O INDICATOR
 ;FIRST DEVICE REGISTER ADR
 ;INTERRUPT VECTOR ADR
 ;READ INT PROC STATUS WORD (BR 5)
 ;WRITE INT PROC STATUS WORD (BR 5)
 ;HOUSEKEEPING ROUT REL ADR
 ;REPORT ROUT REL ADR
 ;KILL ROUT REL ADR
 ;DATA ERROR COUNTER REL ADR
 ;TIME OUT ERROR ROUT REL ADR
 ;I/O BUSY BRANCH ADR
 ;DEVICE ERROR BRANCH ADR
 ;USER MODE PRINT ROUTINE BRANCH ADR
 ;CMND MODE PRINT ROUTINE BRANCH ADR
 ;CONVERT BINARY TO ASCII ROUT BR ADR
 ;CONVERT BINARY TO DECIMAL ASCII BR ADR

 CIOBSY: .WORD 0
 CUPGER: .WORD 0
 ULIST: .WORD 0
 CLIST: .WORD 0
 BINASC: .WORD 0
 BTASLZ: .WORD 0

E01

MAINDEC-11-DTQUA-A DUL1 DEVICE ROUTINE FOR MPG MACY11 27(732) 24-SEP-76 14:10 PAGE 3-1
 DTQUA.P11 STANDARD DEVICE ROUTINE TABLE & CONSTANT AREAS

SEQ 0033

105	000062'	000000		DECASC:	.WORD	0	: CONVERT PACKED DECIMAL TO ASCII BR ADR
106	000064'	000000		CSYSEW:	.WORD	0	: MPG SYSTEM FLAGWORD ADR
107	000066'	000000		SETVEC:	.WORD	0	: SET INT VECT ROUT BR ADR
108	000070'	000000		CLRVEC:	.WORD	0	: CLEAR INT VECTOR ROUT BR ADR
109	000072'	000000		TSTVEC:	.WORD	0	: TEST INT VECTOR ROUT BR ADR
110	000074'	000000		RTNINT:	.WORD	0	: RETURN FROM INT ROUT BR ADR
111	000076'	000000		GETBYT:	.WORD	0	: GET DATA BYTE ROUT BR ADR
112	000100'	000000		PUTBYT:	.WORD	0	: PUT DATA BYTE ROUT BR ADR
113	000102'	000014			.WORD	DVREGS-	: ADR OF DEVICE REGISTER NAMES
114	000104'	000050			.WORD	DVCMDS-	: ADR OF DEVICE FUNCTIONS
115	000106'	000234			.WORD	DVPKTE-	: ADR OF PACK TBL EXTENSION
116	000110'	000552			.WORD	DVMVTE-	: ADR OF MODEL VECTOR TBL EXTEN.
117	000112'	000720			.WORD	DVCPT-	: ADR OF COMPILER TBL EXTEN.
118	000114'	001172			.WORD	DVIWST-	: ADR OF DEV INTERFACE WD SYM TBL
119							
120							
121	000116'	041522	051123	DVREGS:	.ASCII	/RCSR/	: VALID DEVICE REGISTER NAMES &
122	000122'	000000			.WORD	0	: THEIR POSITIONS RELATIVE TO
123	000124'	041122	043125		.ASCII	/RBUF/	: THE DEVICE REGISTERS BASE ADDRESS.
124	000130'	000002			.WORD	2	
125	000132'	041524	051123		.ASCII	/TCSR/	
126	000136'	000004			.WORD	4	
127	000140'	041124	043125		.ASCII	/TBUF/	
128	000144'	000006			.WORD	6	
129	000146'	041520	051123		.ASCII	/PCSR/	
130	000152'	000002			.WORD	2	
131		000154'		DVREGS=	.		
132							
133	000154'	120	001	DVCMDS:	.BYTE	120,001	: VALID DEVICE FUNCTIONS
134	000156'	003270	001		.WORD	READ-	: FLAG BYTE:
135	000160'	130	001		.BYTE	130,001	: BIT 7 = NPR DEV
136	000162'	003434			.WORD	WRITE-	: BIT 3 = MASSBUS DEV
137	000164'	160	001		.BYTE	160,001	: BIT 0 = 2 WORDS FOR ADR
138	000166'	003450			.WORD	BREAK-	: (18 BIT ADRES.
139	000170'	376	000		.BYTE	376,0	
140	000172'	002224			.WORD	NOWAIT-	
141	000174'	375	000		.BYTE	375,0	
142	000176'	002154			.WORD	WAIT-	
143	000200'	374	000		.BYTE	374,0	
144	000202'	001412			.WORD	REPORT-	
145	000204'	373	000		.BYTE	373,0	
146	000206'	001406			.WORD	REPORT-	
147	000210'	372	000		.BYTE	372,0	
148	000212'	002556			.WORD	RESET-	
149	000214'	371	000		.BYTE	371,0	
150	000216'	002356			.WORD	CALL-	
151	000220'	370	000		.BYTE	370,0	
152	000222'	002404			.WORD	LISTEN-	
153	000224'	367	000		.BYTE	367,0	
154	000226'	002346			.WORD	ANSWER-	
155	000230'	366	000		.BYTE	366,0	
156	000232'	002464			.WORD	HANGUP-	
157	000234'	365	000		.BYTE	365,0	
158	000236'	002434			.WORD	SEND-	
159	000240'	364	000		.BYTE	364,0	
160	000242'	002420			.WORD	REC'-	

F01

MAINDEC-11-DTDA-A DUII DEVICE ROUTINE FOR MPG MACY11 27(732) 24-SEP-76 14:10 PAGE 3-2
 DTDA.A.P11 STANDARD DEVICE ROUTINE TABLE & CONSTANT AREAS

SEQ 0034

161	000244'	363	000		.BYTE	363,0
162	000246'	002734			.WORD	MODE-
163	000250'	362	000		.BYTE	362,0
164	000252'	002542			.WORD	STRIP-
165	000254'	361	000		.BYTE	361,0
166	000256'	002546			.WORD	NSTRIP-
167	000260'	360	000		.BYTE	360,0
168	000262'	002552			.WORD	FOUPLX-
169	000264'	357	000		.BYTE	357,0
170	000266'	002562			.WORD	HOUPLX-
171	000270'	356	000		.BYTE	356,0
172	000272'	002572			.WORD	NORMAL-
173	000274'	355	000		.BYTE	355,0
174	000276'	002602			.WORD	SYSTST-
175	000300'	354	000		.BYTE	354,0
176	000302'	002612			.WORD	EVEN-
177	000304'	353	000		.BYTE	353,0
178	000306'	002616			.WORD	ODD-
179	000310'	352	000		.BYTE	352,0
180	000312'	002630			.WORD	NOPAR-
181	000314'	351	000		.BYTE	351,0
182	000316'	002750			.WORD	BITS-
183	000320'	350	000		.BYTE	350,0
184	000322'	003074			.WORD	PRESET-
185	000324'	347	000		.BYTE	347,0
186	000326'	002140			.WORD	GENPAR-
187	000330'	346	000		.BYTE	346,0
188	000332'	002074			.WORD	CVSYNC-
189	000334'	345	000		.BYTE	345,0
190	000336'	002306			.WORD	READY-
191	000340'	177777			.WORD	177777
192						
193	000342'	047516	040527	052111	DVPKTE: .ASCII	/NOWAIT/
194	000350'	376	000		.BYTE	376,0
195	000352'	020040	040527	052111	.ASCII	/ WAIT/
196	000360'	375	000		.BYTE	375,0
197	000362'	052123	052101	051525	.ASCII	/STATUS/
198	000370'	374	000		.BYTE	374,0
199	000372'	047503	047125	051524	.ASCII	/COUNTS/
200	000400'	373	000		.BYTE	373,0
201	000402'	051103	051505	052105	.ASCII	/CRESET/
202	000410'	372	000		.BYTE	372,0
203	000412'	020040	040503	046114	.ASCII	/ CALL/
204	000420'	371	000		.BYTE	371,0
205	000422'	044514	052123	047105	.ASCII	/LISTEN/
206	000430'	370	000		.BYTE	370,0
207	000432'	047101	053523	051105	.ASCII	/ANSWER/
208	000440'	367	000		.BYTE	367,0
209	000442'	040510	043516	050125	.ASCII	/HANGUP/
210	000450'	366	000		.BYTE	366,0
211	000452'	020040	042523	042116	.ASCII	/ SEND/
212	000460'	365	000		.BYTE	365,0
213	000462'	020040	042522	053103	.ASCII	/ RECV/
214	000470'	364	000		.BYTE	364,0
215	000472'	020040	047515	042504	.ASCII	/ MODE/
216	000500'	363	000		.BYTE	363,0

;TABLE TERMINATOR

;PACK TABLE EXTENSION

217	000502'	051440	051124	050111	.ASCII	/STRIP/
218	000510'	362	000		.BYTE	362,0
219	000512'	051516	051124	050111	.ASCII	/NSTRIP/
220	000520'	361	000		.BYTE	361,0
221	000522'	042106	050125	054114	.ASCII	/FDUPLX/
222	000530'	360	000		.BYTE	360,0
223	000532'	042110	050125	054114	.ASCII	/HDUPLX/
224	000540'	357	000		.BYTE	357,0
225	000542'	047516	046522	046101	.ASCII	/NORMAL/
226	000550'	356	000		.BYTE	356,0
227	000552'	054523	052123	052123	.ASCII	/SYSTST/
228	000560'	355	000		.BYTE	355,0
229	000562'	020040	053105	047105	.ASCII	/EVEN/
230	000570'	354	000		.BYTE	354,0
231	000572'	020040	047440	042104	.ASCII	/ODD/
232	000600'	353	000		.BYTE	353,0
233	000602'	047040	050117	051101	.ASCII	/NOPAR/
234	000610'	352	000		.BYTE	352,0
235	000612'	020040	044502	051524	.ASCII	/BITS/
236	000620'	351	000		.BYTE	351,0
237	000622'	051120	051505	052105	.ASCII	/PRESET/
238	000630'	350	000		.BYTE	350,0
239	000632'	042507	050116	051101	.ASCII	/GENPAR/
240	000640'	347	000		.BYTE	347,0
241	000642'	053103	054523	041516	.ASCII	/CVSYNC/
242	000650'	346	000		.BYTE	346,0
243	000652'	051040	040505	054504	.ASCII	/READY/
244	000660'	345	000		.BYTE	345,0
245						
246	000662'	000376	001330		DVMVTE: .WORD	376,MSFMT1-LOCZ
247	000666'	000375	001330		.WORD	375,MSFMT1-LOCZ
248	000672'	000374	001330		.WORD	374,MSFMT1-LOCZ
249	000676'	000373	001330		.WORD	373,MSFMT1-LOCZ
250	000702'	000372	001330		.WORD	372,MSFMT1-LOCZ
251	000706'	000371	001330		.WORD	371,MSFMT1-LOCZ
252	000712'	000370	001330		.WORD	370,MSFMT1-LOCZ
253	000716'	000367	001330		.WORD	367,MSFMT1-LOCZ
254	000722'	000366	001330		.WORD	366,MSFMT1-LOCZ
255	000726'	000365	001330		.WORD	365,MSFMT1-LOCZ
256	000732'	000364	001330		.WORD	364,MSFMT1-LOCZ
257	000736'	000363	001327		.WORD	363,MSFMT2-LOCZ
258	000742'	000362	001330		.WORD	362,MSFMT1-LOCZ
259	000746'	000361	001330		.WORD	361,MSFMT1-LOCZ
260	000752'	000360	001330		.WORD	360,MSFMT1-LOCZ
261	000756'	000357	001330		.WORD	357,MSFMT1-LOCZ
262	000762'	000356	001330		.WORD	356,MSFMT1-LOCZ
263	000766'	000355	001330		.WORD	355,MSFMT1-LOCZ
264	000772'	000354	001330		.WORD	354,MSFMT1-LOCZ
265	000776'	000353	001330		.WORD	353,MSFMT1-LOCZ
266	001002'	000352	001330		.WORD	352,MSFMT1-LOCZ
267	001006'	000351	001327		.WORD	351,MSFMT2-LOCZ
268	001012'	000350	001330		.WORD	350,MSFMT1-LOCZ
269	001016'	000347	001324		.WORD	347,MSFMT3-LOCZ
270	001022'	000346	001324		.WORD	346,MSFMT3-LOCZ
271	001026'	000345	001330		.WORD	345,MSFMT1-LOCZ
272						

;MODEL VECTOR TABLE EXTEN.

				: COMPILER TABLE EXTENSION		
273				:		
274				:		
275	001032'	003	376	DVCPTE:	.BYTE	3,376 ;NO WAIT
276	001034'	004537	000012		.WORD	4537,10.
277	001040'	003	375		.BYTE	3,375 ;WAIT
278	001042'	004537	000012		.WORD	4537,10.
279	001046'	004	374		.BYTE	4,374 ;STATUS
280	001050'	004537	000012	001C02	.WORD	4537,10.,1002
281	001056'	004	373		.BYTE	4,373 ;COUNTS
282	001060'	004537	000012	001001	.WORD	4537,10.,1001
283	001066'	003	372		.BYTE	3,372 ;CONTROL RESET
284	001070'	004537	000012		.WORD	4537,10.
285	001074'	003	371		.BYTE	3,371 ;CALL
286	001076'	004537	000012		.WORD	4537,10.
287	001102'	003	370		.BYTE	3,370 ;LISTEN
288	001104'	004537	000012		.WORD	4537,10.
289	001110'	003	367		.BYTE	3,367 ;ANSWER
290	001112'	004537	000012		.WORD	4537,10.
291	001116'	003	366		.BYTE	3,366 ;HANG UP
292	001120'	004537	000012		.WORD	4537,10.
293	001124'	003	365		.BYTE	3,365 ;SEND
294	001126'	004537	000012		.WORD	4537,10.
295	001132'	003	364		.BYTE	3,364 ;RECEIVE
296	001134'	004537	000012		.WORD	4537,10.
297	001140'	004	363		.BYTE	4,363 ;MODE V
298	001142'	004537	000012	000000	.WORD	4537,10.,0
299	001150'	003	362		.BYTE	3,362 ;STRIP
300	001152'	004537	000012		.WORD	4537,10.
301	001156'	003	361		.BYTE	3,361 ;NO STRIP
302	001160'	004537	000012		.WORD	4537,10.
303	001164'	003	360		.BYTE	3,360 ;FULL DUPLEX
304	001166'	004537	000012		.WORD	4537,10.
305	001172'	003	357		.BYTE	3,357 ;HALF DUPLEX
306	001174'	004537	000012		.WORD	4537,10.
307	001200'	003	356		.BYTE	3,356 ;NORMAL MODE
308	001202'	004537	000012		.WORD	4537,10.
309	001206'	003	355		.BYTE	3,355 ;SYSTEM TEST MODE
310	001210'	004537	000012		.WORD	4537,10.
311	001214'	003	354		.BYTE	3,354 ;EVEN PARITY
312	001216'	004537	000012		.WORD	4537,10.
313	001222'	003	353		.BYTE	3,353 ;ODD PARITY
314	001224'	004537	000012		.WORD	4537,10.
315	001230'	003	352		.BYTE	3,352 ;NO PARITY
316	001232'	004537	000012		.WORD	4537,10.
317	001236'	004	351		.BYTE	4,351 ;BITS V
318	001240'	004537	000012	000000	.WORD	4537,10.,0
319	001246'	003	350		.BYTE	3,350 ;PRESET
320	001250'	004537	000012		.WORD	4537,10.
321	001254'	005	347		.BYTE	5,347 ;GENERATE PARITY V AT V
322	001256'	004537	000012	000000	.WORD	4537,10.,0,2
	001264'	000002				
323	001266'	005	346		.BYTE	5,346 ;CONVERT SYNC V AT V
324	001270'	004537	000012	000000	.WORD	4537,10.,0,2
	001276'	000002				
325	001300'	003	345		.BYTE	3,345 ;READY
326	001302'	004537	000012		.WORD	4537,10.

J01

MAINDEC-11-DTDUA-A DUII DEVICE ROUTINE FOR MPG MACY11 27(732) 24-SEP-76 14:10 PAGE 3-6
 DTDUA.P11 STANDARD DEVICE ROUTINE TABLE & CONSTANT AREAS

SEG 0038

383	001422'	000000	MISCNT: .WORD	0	;MISC. CMND COUNT
384	001424'	000000	PARCNT: .WORD	0	;PARITY ERRORS COUNT
385	001426'	000000	FRMCNT: .WORD	0	;FRAMING ERRORS COUNT
386	001430'	000000	OVRCNT: .WORD	0	;OVERRUN ERRORS COUNT
387	001432'	000000	DSCCNT: .WORD	0	;DATA SET CHANGE ERRORS COUNT
388	001434'	000000	DNACNT: .WORD	0	;DATA NOT AVAILABLE ERRORS COUNT
389	001436'	000000	TOECNT: .WORD	0	;TIMEOUT ERRORS COUNT
390	001440'	000000	DATAER: .WORD	0	;DATA ERRORS COUNT
391	001442'	000000	RDICNT: .WORD	0	;READ INTERRUPTS COUNT
392	001444'	000000	WRICNT: .WORD	0	;WRITE INTERRUPTS COUNT
393					
394	001446'		HSKPEN=	.	
395					
396	000000		XXXX=	0	;VALUE TO BF TAILORED BY DEV ROUT
397					
398	000200		CACHE=	200	;SYSTEM FLDWD BIT DEF.
399					
400	000021		CNTNUM=	HSKPEN-COUNTS/2	;# OF STATISTICAL COUNT WORDS
401					
402	000026		SYNCB=	026	;PRESET SYNC CHARACTER
403					
404	000005		NSYNC=	5	;PRESET # OF SYNC CHARACTERS
405					
406	001446'	037026	PCSRV: .WORD	ISYNCM+BITSB+PARENB+SYNCB	;PCSR REGISTER BASE VALUE
407					
408					
409	001450'		PATCH: .REPT	20.	;PATCH AREA
410			.WORD	0	
411			.ENDR		

.SBTTL DEVICE REGISTER NAME EQUATES

;DEVICE REGISTER NAME EQUATES RELATIVE TO RCSR AND
;BIT NAME EQUATES FOR THEIR BITS.

413					
414					
415					
416					
417					
418					
419	000000	RCSR=	0		;RECEIVER CONTROL & STATUS
420					
421	100000		DSC	= 100000	;DATA SET CHANGE
422	040000		RING	= 40000	;RING
423	020000		CTS	= 20000	;CLEAR TO SEND
424	010000		CARRIER	= 10000	;CARRIER
425	001000		DSR	= 1000	;DATA SET READY
426	000400		STRSYN	= 400	;STRIP SYNC
427	000100		RINTEN	= 100	;RECEIVER INTERRUPT ENABLE
428	000040		DSCIE	= 40	;DATA SET CHANGE INT ENABLE
429	000020		SCHSYN	= 20	;SEARCH SYNC
430	000004		RQTS	= 4	;REQUEST TO SEND
431	000002		DTR	= 2	;DATA TERMINAL READY
432					
433	000002	RBUF=	2		;RECEIVER DATA BUFFER
434					
435	100000		RXER	= 100000	;RECEIVER ERROR
436	040000		OVR	= 40000	;OVERRUN ERROR
437	020000		FRM	= 20000	;FRAMING ERROR
438	010000		PAR	= 10000	;PARITY ERROR
439					
440	000002	PCSR=	2		;PARAMETER CONTROL
441					
442	030000		MODEBT	= 30000	;MODE BITS
443	030000		ISYNCH	= 30000	;INTERNAL SYNCHRONOUS MODE
444	020000		ESYNCH	= 20000	;EXTERNAL SYNCHRONOUS MODE
445	000000		ISOCHM	= 00000	;ISOCRONOUS MODE
446	006000		WDLENG	= 6000	;WORD LENGTH BITS
447	006000		BITS8	= 6000	;8 BITS
448	004000		BITS7	= 4000	;7 BITS
449	002000		BITS6	= 2000	;6 BITS
450	000000		BITS5	= 0000	;5 BITS
451	001000		PARENB	= 1000	;PARITY ENABLE (0 = NO PARITY)
452	000400		PARSEN	= 400	;PARITY SENSE (0 = ODD, 1 = EVEN)
453					
454	000004	TCSR=	4		;TRANSMITTER CONTROL & STATUS
455					
456	100000		DNA	= 100000	;DATA NOT AVAILABLE
457	014000		MAINTM	= 14000	;MAINT. MODE BITS
458	000400		MSTRST	= 400	;MASTER RESET
459	000100		TINTEN	= 100	;TRANSMITTER INTERRUPT ENABLE
460	000040		TDNAIE	= 40	;DNA INTERRUPT ENABLE
461	000020		TSEND	= 20	;TRANSMITTER SEND
462	000010		HLFDPX	= 10	;HALF DUPLEX
463	000001		BRK	= 1	;BREAK
464					
465	000006	TBUF=	6		;TRANSMITER DATA BUFFER

.SBTTL DUI1 SUPPORT ROUTINES ENTERED FROM MPG

;DEVICE ROUTINE HOUSEKEEPING

```

;JSR    R5,HSKEEP      S/R CALL
;WORD   0 OR 1          0 = DO HSKP PER OPSW
;                     1 = UNCOND. DO HSKP
;R2 = PROG'S OPSW
;DESTROYS R0,R1
;SET UP FIRST WD ADR
;SET UP # OF WORDS
;UNCONDITIONALLY DO HSKP?
;N,Y-10$
;OPSW SPECIFY DON'T HSKP COUNTS?
;Y,N-10$
;REMOVE THEM FROM LOOP COUNT
;HSKP ALL NECESSARY AREAS
;INITIALIZE SYNC CHARACTER
;INITIALIZE SYNC CHAR COUNT
;INITIALIZE PCSR REG VALUE
;SET PARITY CLEAR MASK TO 8 BITS
;SET PARITY BIT POSITION TO 8 BITS
;EXIT IN-LINE

```

;DUI1 REPORT ROUTINE (ALSO "STATUS" AND "COUNTS")

```

;JSR    R5,REPORT      S/R CALL
;WORD   FLGWD          FLAGWORD
;                     BIT 15 = CMND MODE CALL
;                     BIT  9 = PROG STMT CALL
;                     BIT  1 = DO STATUS REPORT
;                     BIT  0 = DO COUNTS REPORT

```

```

REPORT: JSR    R0,SAVREG      ;SAVE REG'S R0 - R5
        JSR    PC,SUPTAD     ;SET UP PROG TBL ADR IN R3
        MOV    (R5),R4       ;GET FLAGWORD
        BIT    #2,R4         ;GOING TO DO STATUS DISPLAY?
        BEQ    5$            ;Y,N-5$
        JSR    R5,STSTAT     ;GO STORE STATUS REG'S
        .WORD   CSTAT-       ;DISPLAYING CNTS AT END OF
        BIT    #177776,R4    ;PROG PASS? (Y,N-15$)
        BNE    15$           ;SET UP ADR OF CNTS
        MOV    PC,R0         ;GET # OF CNT WORDS
        ADD    #COUNTS-.,R0 ;THIS CNT WORD = 0?
        MOV    #CNTNUM,R1    ;Y,N-15$
        TST    (R0)+         ;DECR WORD CNT
        BNE    15$           ;CK'ED ALL WORDS? (Y,N-10$)
        DEC    R1
        BNE    10$

```

```

467
468
469
470
471
472
473
474
475
476
477
478
479 001520' 010700      HSKEEP: MOV    PC,R0
480 001522' 062700      177610    ADD    #HSKPST-.,R0
481 001526' 012701      000046    MOV    #HSKPEN-HSKPST/2,R1
482 001532' 005725      TST    (R5)+
483 001534' 001005      BNE    10$
484 001536' 032702      000004    BIT    #HSKPEP,R2
485 001542' 001402      BEQ    10$
486 001544' 162701      000021    SUB    #CNTNUM,R1
487 001550' 005020      10$:    CLR    (R0)+
488 001552' 005301      DEC    R1
489 001554' 001375      BNE    10$
490 001556' 012767      000026    176220  ICONS: MOV    #SYNCB,SYNC
491 001564' 012767      000005    176214    MOV    #NSYNC,SCNT
492 001572' 012767      037026    177646    MOV    #ISYNCR+BITS8+PAREN8+SYNCB,PCSRV
493 001600' 012767      177400    177566    MOV    #177400,CMASK
494 001606' 005067      177564    CLR    PARB
495 001612' 000205      RTS    R5
496
497
498
499
500
501
502
503
504
505
506
507 001614' 004067      004116    REPORT: JSR    R0,SAVREG
508 001620' 004767      004144    JSR    PC,SUPTAD
509 001624' 011504      MOV    (R5),R4
510 001626' 032704      000002    BIT    #2,R4
511 001632' 001403      BEQ    5$
512 001634' 004567      004150    JSR    R5,STSTAT
513 001640' 177506      .WORD   CSTAT-
514 001642' 032704      177776    5$:    BIT    #177776,R4
515 001646' 001012      BNE    15$
516 001650' 010700      MOV    PC,R0
517 001652' 062700      177532    ADD    #COUNTS-.,R0
518 001656' 012701      000021    MOV    #CNTNUM,R1
519 001662' 005720      10$:    TST    (R0)+
520 001664' 001003      BNE    15$
521 001666' 005301      DEC    R1
522 001670' 001374      BNE    10$

```

523	001672'	000512		BR	DVREX	;GO TO EXIT -- ALL CNTS ARE 0'S
524	001674'	004767	004130	15\$: JSR	PC,DISUNM	;DISPLAY DEVICE I.D.
525	001700'	032704	000002	BIT	#2,R4	;DOING STATUS DISPLAY?
526	001704'	001445		BEQ	DISCNT	;Y,N-DISCNT
527	001706'	010700		MOV	PC,R0	;SET UP ADR OF REG'S AT
528	001710'	062700	177422	ADD	#R1STAT-.,R0	;LAST READ INT
529	001714'	012701	000003	MOV	#3,R1	;SET UP # OF REG'S
530	001720'	005720		20\$: TST	(R0)+	;ALL REG'S = 0?
531	001722'	001003		BNE	30\$	;N,Y-40\$
532	001724'	005301		DEC	R1	
533	001726'	001374		BNE	20\$	
534	001730'	000407		BR	40\$	
535	001732'	004567	004220	30\$: JSR	R5,PRINT	;ISSUE 'AT LAST READ INT' MSG
536	001736'	004341		.WORD	LRIMSG-	
537	001740'	000021		.WORD	17.	
538	001742'	004567	004106	JSR	R5,DISPST	;DISPLAY STATUS AT LAST READ INT
539	001746'	177364		.WORD	R1STAT-	
540	001750'	005767	177364	40\$: TST	WIRCSR	;WR INT REG STORAGE = 0'S?
541	001754'	001003		BNE	60\$	;N,Y-70\$
542	001756'	005767	177362	TST	WITCSR	
543	001762'	001407		BEQ	70\$	
544	001764'	004567	004166	60\$: JSR	R5,PRINT	;ISSUE 'AT LAST WRITE INT' MSG
545	001770'	004330		.WORD	LWIMSG-	
546	001772'	000022		.WORD	18.	
547	001774'	004567	004054	JSR	R5,DISPST	;DISPLAY STATUS AT LAST WRITE INT
548	002000'	177340		.WORD	W1STAT-	
549	002002'	004567	004150	70\$: JSR	R5,PRINT	;ISSUE 'CURRENTLY' MSG
550	002006'	004334		.WORD	CURMSG-	
551	002010'	000012		.WORD	10.	
552	002012'	004567	004036	JSR	R5,DISPST	;DISPLAY CURRENT STATUS
553	002016'	177330		.WORD	CSTAT-	
554	002020'	032704	000001	DISCNT: BIT	#1,R4	;DISPLAY COUNTS?
555	002024'	001431		BEQ	RPTEND	;Y,N-RPTEND
556	002026'	012700	000021	MOV	#CNTNUM,R0	;SET UP # OF WORDS
557	002032'	010701		MOV	PC,R1	;SET UP ADR OF CNTS
558	002034'	062701	177350	ADD	#COUNTS-.,R1	
559	002040'	010702		MOV	PC,R2	;SET UP TBL ADR
560	002042'	062702	000066	ADD	#REPTBL-.,R2	
561	002046'	012267	000012	RPTLP: MOV	(R2)+,RPTBAS	;MOV MSG ADR TO S/R LINKAGE
562	002052'	004067	003660	JSR	R0,SAVREG	;SAVE ALL REG'S
563	002056'	011100		MOV	(R1),R0	;GET CURRENT COUNT
564	002060'	004577	175772	JSR	R5,ABINASC	;CONVERT IT TO ASCII
565	002064'	000000		RPTBAS: .WORD	XXXX	
566	002066'	004067	003660	JSR	R0,RESREG	;RESTORE REG'S
567	002072'	005721		TST	(R1)+	;POINT AT NXT CNT
568	002074'	005300		DEC	R0	;DONE ALL WORDS?
569	002076'	001363		BNE	RPTLP	;Y,N-RPTLP
570	002100'	004567	004052	JSR	R5,PRINT	;GO ISSUE COUNTS MSG
571	002104'	004324		.WORD	CNTSMG-	
572	002106'	000360		.WORD	CNTSEN-CNTSMG	
573	002110'	004567	004042	RPTEND: JSR	R5,PRINT	;ISSUE "END OF REPORT" MSG
574	002114'	004240		.WORD	RENDMG-	
575	002116'	177763		.WORD	-13.	
576	002120'	004067	003626	DVREX: JSR	R0,RESREG	;RESTORE REGISTERS
577	002124'	005725		TST	(R5)+	;SET UP RETURN POINT
578	002126'	000205		RTS	R5	;EXIT IN-LINE

```

579
580
581 002130' 004360      REPTBL: .WORD BCMRD-RPTBAS
582 002132' 004366      .WORD BCMRD+6-RPTBAS
583 002134' 004402      .WORD BCMWR-RPTBAS
584 002136' 004410      .WORD BCMWR+6-RPTBAS
585 002140' 004435      .WORD CMDCRD-RPTBAS
586 002142' 004450      .WORD CMDCWR-RPTBAS
587 002144' 004464      .WORD CMOBRK-RPTBAS
588 002146' 004501      .WORD CMDCMS-RPTBAS
589 002150' 004527      .WORD CNTPAR-RPTBAS
590 002152' 004544      .WORD CNTFRM-RPTBAS
591 002154' 004561      .WORD CNTOVR-RPTBAS
592 002156' 004576      .WORD CNTDSC-RPTBAS
593 002160' 004615      .WORD CNTDNA-RPTBAS
594 002162' 004632      .WORD CNTTOE-RPTBAS
595 002164' 004650      .WORD CNTDER-RPTBAS
596 002166' 004702      .WORD CNTRDI-RPTBAS
597 002170' 004716      .WORD CNTWRI-RPTBAS
598
599
600
601
602
603
604
605

```

;TIMEOUT ERROR ROUTINE

```

606 002172' 005267 177174      TOUTER: INC      TOCNT
607 002176' 026727 177170 000010  CMP      TOCNT,#8.
608 002204' 001401      BEQ      10$
609 002206' 000205      RTS      R5
610 002210' 004067 003522      10$: JSR      R0,SAVREG
611 002214' 005267 177216      INC      TOCNT
612 002220' 004767 003544      JSR      PC,SUPTAD
613 002224' 004567 003560      JSR      R5,STSTAT
614 002230' 177116      .WORD    CSTAT-
615 002232' 004567 000024      JSR      R5,KILL
616 002236' 042713 000010      BIC      #WT4IOT,(R3)
617 002242' 004567 003014      JSR      R5,ERRCS
618 002246' 001520      .WORD    IJTO-ERMBAS
619 002250' 004067 003476      JSR      R0,RESREG
620 002254' 012605      MOV      (SP)+,R5
621 002256' 000177 175566      JMP      @CUPGER

```

S/R CALL

```

;ADD 1 TO TIMEOUT CNTR
;EIGHTH TIME THRU ON THIS I/O?
;N,Y-10$
;EXIT BACK TO MPG
;SAVE ALL REGISTERS
;ADD 1 TO TIMEOUT ERROR CNTR
;SET UP RCSR & PROG TBL ADR'S
;STORE CURRENT STATUS

;RESET I.E.'S & VECTORS
;RESET WAITING FOR I/O FLAG
;ISSUE TIMEOUT ERROR MSG

;RESTORE REGISTERS
;REMOVE RETURN ADR
;GO TO ERROR EXIT

```

:FILL USER PROGRAM ROUTINE

002262
002266
002272
002274
002300
002302
002306
002312
002320
002322
002326
002330
002336
002342
002350

016701 175536
032711 000140
001407
004567 002674
000404
042711 000160
004767 002604
032761 000140 000004 10\$
001410
004567 002676
000405
042761 000140 000004
004767 002600
042767 000003 175432 20\$
000205

KILL:

MOV
BIT
BEQ
JSR
BR
BIC
JSP
BIT
BEQ
JSR
BR
BIC
JSR
BIC
RTE

:JSR RS,KILL S/P CALL
 :R3 = PROG TBL ADR
 :DESTROYS R0,R1

DREGAD,R1
 @RINTEN+DSCIE,(R1)
 10\$
 RS,TRVECT
 10\$
 @RINTEN+SCHSYC+DSCIE,(R1)
 PC,RINTV
 @TINTEN+TDNAIE,(CSR(R1))
 20\$
 RS,TWVECT
 20\$
 @TINTEN+TDNAIE,(CSR(R1))
 PC,RWINTV
 @ROBSY+WRBSY,DFLWMC
 RS

:GET RCSR ADR
 :READ INT ENABLES SET
 :Y,N-10\$
 :IS READ VECTOR SET FOR ME?
 :Y,N-10\$
 :RESET R0 INT ENABLES & SPC- SYNC
 :RESET READ'S INT VECTOR
 :WRITE INT ENABLES SET
 :Y,N-20\$
 :IS WRITE VECTOR SET FOR ME?
 :Y,N-20\$
 :RESET WR INT ENABLES
 :RESET WRITE'S INT VECTOR
 :RESET THE BUSY FLAGS
 :EXIT IN-LINE

```

649 .SBTTL D11 NON I/O FUNCTION ROUTINES
650
651 ;"WAIT" FUNCTION ROUTINE
652
653 ;JSR RS,WAIT FUNCTION CALL
654
655 002352' 042767 100000 175422 WAIT: BIC #WAITMD,DFLGWD ;RESET THE "NOWAIT" FLAG
656 002360' 004767 003404 JSR PC,SUPTAD ;GET PROG TBL ADR IN R3
657 002364' 052713 000010 BIS #WT4IOT,(R3) ;SET WAITING FOR I/O TERM
658 002370' 032767 000003 175404 BIT #RDBSY+WRBSY,DFLGWD ;READ OR WRITE STILL BUSY?
659 002376' 001402 BEQ 10$ ;Y,N-10$
660 002400' 004577 175442 JSR RS,DCIOBSY ;WAIT FOR I/O TO COMPLETE
661 002404' 042713 000010 10$: BIC #WT4IOT,(R3) ;RESET WAITING FOR I/O TERM
662 002410' 004767 002206 JSP PC,CKBSY ;WAIT IF D11 IS BUSY & DC TERMINATION
663 002414' 000205 RTS R5 ;EXIT IN-LINE
664
665 ;"NOWAIT" FUNCTION ROUTINE
666
667 ;JSR RS,NOWAIT FUNCTION CALL
668
669 002416' 052767 100000 175356 NOWAIT: BIS #WAITMD,DFLGWD ;SET THE "NOWAIT" FLAG
670 002424' 000205 RTS R5 ;EXIT IN-LINE
671
672 ;"CVSYNC" FUNCTION ROUTINE
673
674 ;JSR RS,CVSYNC FUNCTION CALL
675 ;.WORD ADR DATA ADDRESS
676 ;.WORD CNT BYTE COUNT
677
678 002426' 012500 CVSYNC: MOV (RS)+,R0 ;GET THE DATA ADDRESS
679 002430' 012501 MOV (RS)+,R1 ;GET THE BYTE COUNT
680 002432' 016703 175346 MOV SYNC,R3 ;GET THE SYNC CHAR
681 002436' 046703 176732 BIC CMASK,R3 ;SAVE ONLY PERTINENT BITS
682 002442' 112002 10$: MOVB (R0)+,R2 ;GET THE DATA BYTE
683 002444' 046702 176724 BIC CMASK,R2 ;SAVE ONLY PERTINENT BITS
684 002450' 020203 CMP R2,R3 ;DATA BYTE = SYNC BYTE?
685 002452' 001002 BNE 20$ ;Y,N-20$
686 002454' 105160 177777 COMB -1(R0) ;COMPLEMENT THE DATA BYTE
687 002460' 005301 20$: DEC R1 ;DECR THE BYTE COUNT
688 002462' 001367 BNE 10$ ;DONE ALL BYTES? (Y,N-10$)
689 002464' 000205 RTS R5 ;EXIT TO USER PROG

```

694
 695
 696
 697
 698
 699
 700
 701
 702
 703
 704
 705
 706
 707
 708
 709
 710
 711
 712
 713
 714
 715
 716
 717
 718
 719
 720
 721
 722
 723
 724
 725
 726
 727

; "GENPAR" FUNCTION ROUTINE

				JSR R5, GENPAR	FUNCTION CALL
				..WORD ADDR	DATA ADDRESS
				..WORD CNT	BYTE COUNT
GENPAR:	MOV	(R5)+, R0			: GET THE DATA ADDRESS
	MOV	(R5)+, R1			: GET THE BYTE COUNT
10\$:	MOVB	(R0), R2			: GET THE DATA BYTE
	BIC	CMASK, R2			: SAVE ONLY PERTINENT BITS
	BIT	#PAREN, PCSRV			: IS PARITY BEING USED?
	BEQ	50\$			: Y, N-50\$
	MOV	R2, R4			: MOVE BYTE TO WORK REG
	CLR	R3			: CLEAR ACCUMULATOR REG
20\$:	ASR	R4			: SHIFT OUT LSB
	BEQ	30\$			: ANY BITS LEFT? (Y, N-30\$)
	ADC	R3			: ADD CARRY BIT TO BIT CNT
	BR	20\$			: GO SHIFT SOME MORE
30\$:	ADC	R3			: DON'T FORGET LAST CARRY
	BIT	#PARSEN, PCSRV			: PARITY = ODD PARITY?
	BNE	40\$			: Y, N-40\$
	BIT	#1, R3			: ODD # OF BITS?
	BNE	50\$			: N, Y-50\$
	BIS	PARB, R2			: SET IN THE PARITY BIT
	BR	50\$			: GO STORE THE BYTE
40\$:	BIT	#1, R3			: EVEN # OF BITS?
	BEQ	50\$			: N, Y-50\$
	BIS	PARB, R2			: SET IN THE PARITY BIT
50\$:	MOVB	R2, (R0)+			: STORE THE MODIFIED DATA BYTE
	DEC	R1			: DECR BYTE COUNT
	BNE	10\$			: DONE ALL BYTES? (Y, N-10\$)
	RTS	P5			: EXIT TO USER PROG

.SBTTL DUII NON-INTERRUPT I/O FUNCTION ROUTINES

;"CALL" AND "ANSWER" FUNCTION ROUTINES

;JSR RS,CALL FUNCTION CALL
;JSR RS,ANSWER FUNCTION CALL

```

739 002574' 052777 000002 175222 CALL: BIS #DTR, DREGAD ;SET DATA TERMINAL RDY IN RCSP
740 002574' 032777 001000 175214 10$: BIT #DSR, DREGAD ;DATA SET RDY = 1?
741 002610' 001003 BNE NINTEX ;N.Y-NINTEX
742 002612' 004577 175230 JSR RS, DCI0BSY ;RELEASE CONTROL FOR 1 POLLING LOOP
743 002616' 000771 BR 10$ ;GO CK FOR DATA SET RDY AGAIN
744 002620' 005267 176576 NINTEX: INC MISCNT ;ADD 1 TO MISC. CMND COUNT
745 002624' 000205 RTS RS ;EXIT TO USER PROG

```

;"LISTEN" FUNCTION ROUTINE

;JSR RS,LISTEN FUNCTION CALL

```

751 002626' 032777 040000 175170 LISTEN: BIT #RING, DREGAD ;IS THE RING BIT SET?
752 002634' 001371 BNE NINTEX ;N.Y-NINTEX
753 002636' 004577 175204 JSR RS, DCI0BSY ;RELEASE CONTROL FOR 1 POLLING LOOP
754 002642' 000771 BR LISTEN ;GO CK RING AGAIN

```

;"READY" FUNCTION ROUTINE

;JSR RS,READY FUNCTION CALL

```

761 002644' 032777 010000 175152 READY: BIT #CARRIER, DREGAD ;IS THE CARRIER UP YET?
762 002652' 001362 BNE NINTEX ;N.Y-NINTEX
763 002654' 004577 175166 JSR RS, DCI0BSY ;RELEASE CONTROL FOR 1 POLLING LOOP
764 002660' 000771 BR READY ;GO CK CARRIER AGAIN

```

;"RCV" FUNCTION ROUTINE

;JSR RS,RCV FUNCTION CALL

```

771 002662' 042777 000004 175134 RCV: BIC #RQTS, DREGAD ;RESET REQUEST TO SEND IN RCSR
772 002670' 000753 BR NINTEX ;GO TO EXIT

```

;"SEND" FUNCTION ROUTINE

;JSR RS,SEND FUNCTION CALL

```

779 002672' 052777 000004 175124 SEND: BIS #RQTS, DREGAD ;SET REQUEST TO SEND IN RCSR
780 002700' 032777 020000 175116 70$: BIT #CTS, DREGAD ;IS CLEAR TO SEND SET?
781 002706' 001344 BNE NINTEX ;N.Y-NINTEX
782 002710' 004577 175132 JSR RS, DCI0BSY ;RELEASE CONTROL FOR 1 POLLING LOOP
783 002714' 000771 BR 70$ ;GO CK CLEAR TO SEND AGAIN

```

```

785                                     ;"HANGUP" FUNCTION ROUTINE
786
787                                     ;JSR    R5,HANGUP          FUNCTION CALL
788
789 002716' 042777 000004 175100 HANGUP: BIC    #RQTS, DREGAD      ;RESET REQ TO SEND IN RCSR
790 002724' 012700 000017          MOV    #15., R0              ;INITIALIZE LOOP COUNT
791 002730' 012701 000522          MOV    #522, R1              ;INIT 1 MS COUNTER
792 002734' 032777 000200 175122          BIT    #CACHE, DCSYSFW    ;CPU HAVE A CACHE MEM?
793 002742' 001402          BEQ    60$                          ;Y, N-60$
794 002744' 012701 002126          MOV    #2126, R1              ;INCREASE 1 MS COUNTER
795 002750' 005301          60$:    DEC    R1                    ;DECR 1 MS COUNTER
796 002752' 001376          BNE    60$                          ;EXHAUSTED CNTR? (Y, N-60$)
797 002754' 005300          DEC    R0                            ;DECR LOOP COUNT
798 002756' 001364          BNE    50$                          ;CNT = 0? (Y, N-50$)
799 002760' 042777 000002 175036          BIC    #DTR, DREGAD      ;LOWER DATA TERMINAL RDY
800 002766' 000714          BR     NINTX                          ;GO TO EXIT
801
802                                     ;"CRESET" FUNCTION ROUTINE
803
804                                     ;JSR    R5,CRESET          FUNCTION CALL
805
806
807 002770' 016704 175030          CRESET: MOV    DREGAD, R4        ;GET RCSR ADR
808 002774' 052764 000400 000004          BIS    #MSTRT, TCSR(R4)   ;SET THE MASTER CLEAR BIT
809 003002' 012700 000024          MOV    #20., R0              ;SET UP DELAY COUNT
810 003006' 005300          10$:    DEC    R0                    ;DELAY FOR A FEW
811 003010' 001376          BNE    10$                          ;MICROSECONDS
812 003012' 000205          RTS    R5                            ;EXIT TO USER PROG
813
814                                     ;"STRIP" FUNCTION ROUTINE
815
816                                     ;JSR    R5,STRIP          FUNCTION CALL
817
818
819 003014' 052777 000400 175002 STRIP: BIS    #STRSYN, DREGAD      ;SET STRIP SYNC IN RCSR
820 003022' 000205          RTS    R5                            ;EXIT TO USER PROG
821
822                                     ;"NSTRIP" FUNCTION ROUTINE
823
824                                     ;JSR    R5,NSTRIP          FUNCTION CALL
825
826
827
828 003024' 042777 000400 174772 NSTRIP: BIC    #STRSYN, DREGAD      ;RESET STRIP SYNC BIT IN RCSR
829 003032' 000205          RTS    R5                            ;EXIT TO USER PROG
830
831                                     ;"FDOPLX" FUNCTION ROUTINE
832
833                                     ;JSR    R5,FDOPLX          FUNCTION CALL
834
835
836
837 003034' 016704 174764          FDOPLX: MOV    DREGAD, R4        ;GET RCSR ADR
838 003040' 042764 000010 000004          BIC    #HLFDPX, TCSR(R4)   ;RESET THE HALF DUPLEX BIT IN TCSR
839 003046' 000205          RTS    R5                            ;EXIT TO USER PROG

```

```

841                                     ;"HDXPLX" FUNCTION ROUTINE
842
843                                     ;JSR    R5,HDXPLX          FUNCTION CALL
844
845 003050' 016704 174750 HDUPLX: MOV    DREGAD,R4          ;GET RCSR ADR
846 003054' 052764 000010 000004 BIS    #HLFDPX,TCSR(R4) ;SET THE HALF DUPLEX BIT IN TCSR
847 003062' 000205 RTS      R5          ;EXIT TO USER PROG
848
849
850                                     ;"NORMAL" FUNCTION ROUTINE
851
852                                     ;JSR    R5,NORMAL        FUNCTION CALL
853
854 003064' 016704 174734 NORMAL: MOV    DREGAD,R4          ;GET RCSR ADR
855 003070' 042764 014000 000004 BIC    #MAINTM,TCSR(R4) ;SET MAINT MODE BITS TO NORMAL IN TCSR
856 003076' 000205 RTS      R5          ;EXIT TO USER PROG
857
858
859                                     ;"SYSTST" FUNCTION ROUTINE
860
861                                     ;JSR    R5,SYSTST        FUNCTION CALL
862
863 003100' 016704 174720 SYSTST: MOV    DREGAD,R4          ;GET RCSR ADR
864 003104' 052764 014000 000004 BIS    #MAINTM,TCSR(R4) ;SET MAINT MODE BITS TO SYS TEST IN TCSR
865 003112' 000205 RTS      R5          ;EXIT TO USER PROG
866
867
868                                     ;"EVEN" FUNCTION ROUTINE
869
870                                     ;JSR    R5,EVEN          FUNCTION CALL
871
872 003114' 052767 001400 176324 EVEN: BIS    #PARENB+PARSEN,PCSRV ;SET PAR ENB & PAR SEN SEL IN PCSRV
873 003122' 000412 BR      LDPCSR          ;GO LOAD PCSRV REG & EXIT
874
875
876                                     ;"ODD" FUNCTION ROUTINE
877
878                                     ;JSR    R5,ODD          FUNCTION CALL
879
880 003124' 052767 001000 176314 ODD:  BIS    #PARENB,PCSRV      ;SET PARITY ENABLE IN PCSRV BASE
881 003132' 042767 000400 176306 BIC    #PARSEN,PCSRV      ;RESET PAR SEN SEL TO ODD
882 003140' 000403 BR      LDPCSR          ;GO LOAD PCSRV REG & EXIT
883
884
885                                     ;"NOPAR" FUNCTION ROUTINE
886
887                                     ;JSR    R5,NOPAR        FUNCTION CALL
888
889 003142' 042767 001400 176276 NOPAR: BIC    #PARENB+PARSEN,PCSRV ;RESET PARITY BITS IN PCSRV BASE
890 003150' 116767 174630 176270 LDPCSR: MOV    SYNC,PCSRV      ;MOVE CURR SYNC CHAR TO PCSRV BASE
891 003156' 016704 174642 MOV    DREGAD,R4          ;GET RCSR ADR
892 003162' 016764 176260 000002 MOV    PCSRV,PCSR(R4)      ;LOAD PCSRV WITH NEW BASE VALUE
893 003170' 012700 000310 MOV    #200.,R0          ;SET UP LOOP CNT
894 003174' 005300 10$: DEC    R0          ;DELAY A
895 003176' 001376 BNE    10$          ;BIT
896 003200' 000205 RTS      R5          ;EXIT TO USER PROG

```

```

898                                     ;"MODE" FUNCTION ROUTINE
899
900                                     ;JSR    R5,MODE
901                                     ;.WORD  CODE
902                                     FUNCTION CALL
903                                     MODE SELECT CODE (0, 2, OR 3)
904
903 003202' 004767 001502          MODE: JSR    PC,STMADR          ;STORE USER STMT ADR
904 003206' 012500                  MOV    (R5)+,R0              ;GET MODE SELECT CODE
905 003210' 012701 030000          MOV    #ISYNCR,R1             ;SET UP FOR MODE 3 (INT. SYNC)
906 003214' 020027 000003          CMP    R0,#3                  ;CODE TOO HIGH?
907 003220' 101016                  BHI    MODERR                 ;N,Y-MODERR
908 003222' 001407                  BEQ    MODCOM                  ;IS IT A 3? (N,Y-MODCOM)
909 003224' 012701 020000          MOV    #ESYNCR,R1             ;SET UP FOR MODE 2 (EXT. SYNC)
910 003230' 020027 000001          CMP    R0,#1                  ;IS IT A 1?
911 003234' 001410                  BEQ    MODERR                 ;N,Y-MODERR
912 003236' 101001                  BHI    MODCOM                  ;IS IT A 2? (N,Y-MODCOM)
913 003240' 005001                  CLR    R1                     ;SET UP MODE 0 (ISOCRONOUS)
914 003242' 042767 030000 176176 MODCOM: BIC    #MODEBT,PCSRV     ;RESET MODE BITS IN PCSR BASE
915 003250' 050167 176172          BIS    R1,PCSRV              ;SET IN NEW MODE SELECT BITS
916 003254' 000735                  BR     LDPCSR                 ;GO LOAD PCSR REG & EXIT
917
918 003256' 004567 002000          MODERR: JSR    R5,ERRCS          ;REPORT INVALID MODE SELECT CODE
919 003262' 001577                  .WORD  IVMODE-ERMBAS
920 003264' 000434                  BR     NIEREX                 ;GO TO ERROR EXIT
921
922                                     ;"BITS" FUNCTION ROUTINE
923
924                                     ;JSR    R5,BITS
925                                     ;.WORD  CODE
926                                     FUNCTION CALL
927                                     BITS SELECT CODE (5 - 8)
928
928 003266' 004767 001416          BITS: JSR    PC,STMADR          ;STORE USER STMT ADR
929 003272' 012500                  MOV    (R5)+,R0              ;GET THE BITS SELECT CODE
930 003274' 162700 000005          SUB    #5,R0                  ;ADJ IT DOWNWARD
931 003300' 020027 000003          CMP    R0,#3                  ;IS IT A VALID CODE?
932 003304' 101021                  BHI    BITERR                 ;Y,N-BITERR
933 003306' 006300                  ASL    R0                     ;CONVERT IT
934 003310' 010046                  MOV    R0,-(SP)               ;TO A
935 003312' 006300                  ASL    R0                     ;TABLE
936 003314' 062600                  ADD    (SP)+,R0              ;DISPLACEMENT
937 003316' 060700                  ADD    PC,R0                 ;ADD IN THE START ADR OF
938 003320' 062700 000046          ADD    #BITTBL-,R0            ;THE BIT CODE TABLE
939 003324' 042767 006000 176114 MODCOM: BIC    #WDLNG,PCSRV     ;RESET CURR BITS IN PCSR BASE
940 003332' 052067 176110          BIS    (R0)+,PCSRV            ;SET IN THE NEW BITS
941 003336' 012067 176032          MOV    (R0)+,CMASK            ;STORE THIS CODE'S PARITY CLR MASK
942 003342' 011067 176030          MOV    (R0),PARB             ;STORE ITS PARITY BIT POSITION
943 003346' 000700                  BR     LDPCSR                 ;GO LOAD PCSR REG & EXIT
944
945 003350' 004567 001706          BITERR: JSR    R5,ERRCS          ;REPORT INV BIT SELECT CODE
946 003354' 001622                  .WORD  IVBITS-ERMBAS
947 003356' 005267 176056          NIEREX: INC    DATAER          ;ADD 1 TO DATA ERROR CNT
948 003362' 000177 174462          JMP     @CUPGER                ;GO TO MPG'S ERR RETURN POINT
949
950 003366' 000000 177740 000040 BITTBL: .WORD  BITS5,177740,000040 ;5 BITS - PCSR BITS, BIT CLR MASK.
951 003374' 002000 177700 000100          .WORD  BITS6,177700,000100 ;6 BITS  PARITY BIT POSITION
952 003402' 004000 177600 000200          .WORD  BITS7,177600,000200 ;7 BITS
953 003410' 006000 177400 000000          .WORD  BITS8,177400,000000 ;8 BITS

```

MAINDEC-11-DTUA-A DU11 DEVICE ROUTINE FOR MPG
 DTDJAA.P11 DU11 NON-INTERRUPT I/O FUNCTION ROUTINES

MACY11 27(732) 24-SEP-76 14:10 PAGE 6-4

SEQ 0050

954
 955
 956
 957
 958
 959
 960
 961
 962
 963
 964
 965

;"PRESET" FUNCTION ROUTINE

;JSR R5,PRESET FUNCTION CALL

PRESET:	JSR	R5,ICONS	;GO INITIALIZE ALL CONSTANTS
	MOV	DREGAD,R4	;GET RCSR ADR
	BIC	#MAINTM+HLFDPX+BRK,TCSR(R4)	;SET NORM MODE, FULL DUPLX IN TCSR
	JSR	R5,LDPCSR	;LOAD THE PCSR REG
	SIS	#STRSYN,(R4)	;SET STRIP SYNC BIT IN PCSR
	RTS	R5	;EXIT TO USER PROG

000004

003416' 004567 176134
 003422' 016704 174376
 003426' 042764 014011
 003434' 004567 177510
 003440' 052714 000400
 003444' 000205

1007
1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057

; "WRITE" AND "BREAK" FUNCTION ROUTINES

```

;JSR    R5,WRITE    FUNCTION CALL
;JSR    R5,BREAK    FUNCTION CALL
;.WORD  ADR          (NOT USED)
;.WORD  ADR          DATA ADDRESS (BITS 0 - 15)
;.WORD  CNT          BYTE COUNT
;.WORD  DEV          (NOT USED)

WRITE: JSR    PC,CKWBSY    ;GO CK IF WRITE IS BUSY
      INC    WRCNT        ;ADD 1 TO WRITE CMND COUNT
      BIC    #BRKFLG,DFLGWD ;RESET THE BREAK FLAG
      BR     WRBRCM       ;GO TO WRITE/BREAK COMMON POINT

BREAK: JSR    PC,CKWBSY    ;GO CK IF WRITE IS BUSY
      INC    BRKCN        ;ADD 1 TO BREAK CMND COUNT
      BIS    #BRKFLG,DFLGWD ;SET THE BREAK FLAG

WRBRCM: JSR    PC,CKWBSY    ;GO CK IF WRITE IS BUSY
      TST    (R5)+        ;BYPASS MSW OF ADR
      MOV    (R5)+,WRADR   ;STORE THE WRITE DATA ADR
      MOV    (R5)+,WRBCNT  ;STORE THE WRITE BYTE COUNT
      TST    (R5)+        ;BYPASS UNUSED WORD
      BIC    #WRTERM+WRIERR,DFLGWD ;MSKP INTERRUPT FLAGS
      CLR    ERR          ;CLEAR THE ERROR INDICATOR
      CLR    PTOCNT(R3)   ;RESET THE TIMEOUT COUNTERS
      CLR    TOCNT
      CLR    WRSIZE       ;INITIALIZE # OF BYTES WRITTEN
      CLR    PADCNT       ;RESET THE PAD CHAR CNT
      MOV    IVCTAD,50$   ;GET INT VECTOR BASE ADR
      ADD    #4,50$       ;POINT IT AT WRITE'S VECTOR
      MOV    WRPSWD,60$   ;GET WRITE PSW
      JSR    R5,SETVEC    ;GO SET UP WRITE'S INT VECTOR
      .WORD  XXXX         ;INT VECTOR ADR
      .WORD  XXXX         ;PSW
      .WORD  DUWINT-      ;REL INT ROUT ADR
      CLR    ISCNT        ;RESET THE SYNC COUNT
      BIT    #MODEBT,PCSRV ;IN ISOCHRONOUS MODE?
      BEQ    70$         ;N,Y-70$
      MOV    SCNT,ISCNT   ;INITIALIZE INT'S SYNC CHAR CNT
      BIC    #BRK,TCSR(R4) ;RESET THE BREAK BIT IN TCSR
      BIT    #BRKFLG,DFLGWD ;DOING A BREAK INST?
      BEQ    80$         ;Y,N-80$
      BIS    #BRK,TCSR(R4) ;SET THE BREAK BIT IN TCSR
      BIS    #TSEND,TCSR(R4) ;SET THE SEND BIT
      BIS    #WRBSY,DFLGWD ;SET WRITE'S BUSY FLAG
      BIS    #WT4IOT,(R3) ;SET WAITING FOR I/O TERM
      BIS    #TINTEN+TDNAIE,TCSR(R4) ;SET BOTH INT ENABLES
      BR     RDWREX       ;GO CK WAIT/NOWAIT FLAG
50$: .WORD  XXXX
60$: .WORD  XXXX
70$: BIC    #BRK,TCSR(R4)
80$: BIS    #TSEND,TCSR(R4)

```

.SBTTL DUI1 READ INTERRUPT SERVICE ROUTINE

;RECEIVER INTERRUPT ENTRY POINT

```

1059
1060
1061
1062
1063
1064
1065 004060' 004067 001652      DURINT: JSR    RD, SAVREG      ;SAVE REGISTERS RD THRU RS
1066 004064' 004567 001720      JSR    R5, STSTAT      ;GO STORE ALL DEV REGS
1067 004070' 175242      .WORD    R1STAT-
1068 004072' 005267 175344      INC     RDICNT      ;ADD 1 TO READ INTERRUPT COUNT
1069 004076' 004767 001666      JSR    PC, SUPTAD      ;SET UP PROG TBL & RCSR ADRS
1070 004102' 005767 175260      TST     RDSIZE      ;FIRST INT ON READ?
1071 004106' 001005      BNE     10$      ;Y, N-10$
1072 004110' 042767 100000 175214 BIC     #DSC, RIRCSR      ;IGNORE DATA SET CHG ON 1ST TIME
1073 004116' 052714 000040      BIS     #DSCIE, (R4)      ;SET DSC INT ENABLE
1074 004122' 016701 175206      10$: MOV     RIRBUF, R1      ;GET STORED RBUF REG
1075 004126' 005767 175200      TST     RIRCSR      ;DATA SET CHG INT?
1076 004132' 100453      BMI     DSCERR      ;N, Y-DSCERR
1077 004134' 032701 170000      BIT     #RXER+OVR+FRM+PAR, R1 ;ANY ERRORS IN STORED RBUF WORD?
1078 004140' 001055      BNE     RDERR      ;N, Y-RDERR
1079 004142' 005767 175212      TST     RDBCNT      ;DATA BYTE CNT = 0?
1080 004146' 001417      BEQ     RDRBSY      ;N, Y-RDRBSY
1081 004150' 016700 175202      MOV     RDADR, RD      ;GET CURR RD DATA ADR
1082 004154' 004777 173720      JSR    PC, @PUTBYT      ;STORE DATA BYTE IN MEM
1083 004160' 010067 175172      MOV     RD, RDADR      ;STORE NEW RD DATA ADR
1084 004164' 005267 175216      INC     BYRD+2      ;ADD 1 TO TOTAL BYTES
1085 004170' 005567 175210      ADC     BYRD      ;READ COUNTER
1086 004174' 005267 175166      INC     RDSIZE      ;ADD 1 TO THIS MSG'S SIZE
1087 004200' 005367 175154      DEC     RDBCNT      ;DECR THE DATA BYTE COUNT
1088 004204' 001022      BNE     INTEX      ;BYTE CNT = 0? (Y, N-INTEX)
1089
1090 004206' 042767 000001 173566 RDRBSY: BIC     #RDRBSY, DFLGWD      ;RESET READ BUSY FLAG
1091 004214' 052767 000004 173560      BIS     #RDTERM, DFLGWD      ;SET DO READ TERMINATION FLAG
1092 004222' 042714 000160      BIC     #RINTEN+DSCIE+SCHSYN, (R4) ;RESET SEARCH SYNC & INT ENB FOR RD
1093 004226' 032764 000100 000004      BIT     #TINTEN, TCSR(R4)      ;IS WRITE INT ENABLE SET?
1094 004234' 001404      BEQ     CLRWTF      ;Y, N-CLRWTF
1095 004236' 032767 000002 173536      BIT     #WRBSY, DFLGWD      ;IS WRITE BUSY?
1096 004244' 001002      BNE     INTEX      ;N, Y-INTEX
1097 004246' 042713 000010      CLRWTF: BIC     #WT4IOT, (R3)      ;RESET WAITING FOR I/O TERM
1098 004252' 004067 001474      INTEX: JSR    RD, RESREG      ;RESTORE REGISTERS RD THRU RS
1099 004256' 000177 173612      JMP     @RINTINT      ;EXIT FROM INTERRUPT
1100
1101 004262' 052767 000040 173512 DSCERR: BIS     #RDIDSC, DFLGWD      ;SET DATA SET CHANGE ERROR FLG
1102 004270' 005267 175136      INC     DSCCNT      ;ADD 1 TO DSC ERROR CNTR
1103 004274' 052767 000020 173500 RDERR: BIS     #RDIERR, DFLGWD      ;SET THE READ INTERRUPT ERR FLAG
1104 004302' 032701 040000      BIT     #OVR, R1      ;IS THERE AN OVERRUN ERROR?
1105 004306' 001402      BEQ     RDE1      ;Y, N-RDE1
1106 004310' 005267 175114      INC     OVRCNT      ;ADD 1 TO OVR ERROR CNTR
1107 004314' 032701 020000      RDE1: BIT     #FRM, R1      ;IS THERE A FRAMING ERROR?
1108 004320' 001402      BEQ     RDE2      ;Y, N-RDE2
1109 004322' 005267 175100      INC     FRMCNT      ;ADD 1 TO FRM ERROR CNTR
1110 004326' 032701 010000      RDE2: BIT     #PAR, R1      ;IS THERE A PARITY ERROR?
1111 004332' 001725      BEQ     RDRBSY      ;Y, N-RDRBSY
1112 004334' 005267 175064      INC     PARCNT      ;ADD 1 TO PAR ERROR CNTR
1113 004340' 000722      BR      RDRBSY      ;GO TERMINATE THE READ

```

```

1115          .SBTTL  DU11 WRITE INTERRUPT SERVICE ROUTINE
1116
1117
1118          ;TRANSMITTER INTERRUPT ENTRY POINT
1119
1120
1121 004342' 004067 001370      DUWINT: JSR    RD, SAVREG      ;SAVE REGISTERS RD THRU RS
1122 004346' 005267 175072      INC    WRICNT      ;ADD 1 TO WRITE INTERRUPT COUNT
1123 004352' 004767 001412      JSR    PC, SUPTAD      ;SET UP PROG TBL & RCSR ADRS
1124 004356' 016467 000004 174760  MOV    TCSR(R4), WITCSR      ;STORE CURRENT TCSR CONTENTS
1125 004364' 011467 174750      MOV    (R4), WIRCSR      ;STORE RCSR ALSO
1126 004370' 005767 174750      TST    WITCSR      ;DNA SET IN STORED TCSR?
1127 004374' 100476      BMI    DNAERR      ;N.Y-DNAERR
1128 004376' 005767 174776      TST    ISCNT      ;SENDING SYNC CHARACTERS?
1129 004402' 001406      BEQ    WXDATA      ;Y.N-WXDATA
1130 004404' 116764 173374 000006  MOVB   SYNC, TBUF(R4)      ;LOAD ANOTHER SYNC CHAR
1131 004412' 005367 174762      DEC    ISCNT      ;DECR SYNC CHAR CNT
1132 004416' 000423      BR      WINCBC      ;GO ADD 1 TO BYTE COUNT
1133
1134 004420' 005767 174740      WXDATA: TST    WRBCNT      ;ANY MORE DATA BYTES TO SEND?
1135 004424' 001427      BEQ    WCKPAD      ;Y.N-WCKPAD
1136 004426' 012701 000377      MOV    #377, R1      ;PRESET TO THE BREAK DATA
1137 004432' 032767 000200 173342  BIT    #BRKFLG, DFLGWD      ;DOING A BREAK INST?
1138 004440' 001006      BNE    10$      ;N.Y-10$
1139 004442' 016700 174714      MOV    WRADR, RD      ;GET CURRENT DATA ADR
1140 004446' 004777 173424      JSR    PC, @GETBYT      ;GET NEXT DATA BYTE IN R1
1141 004452' 010067 174704      MOV    RD, WRADR      ;STORE NEXT DATA BYTE ADR
1142 004456' 005367 174702      10$: DEC    WRBCNT      ;DECR THE DATA BYTE COUNT
1143 004462' 110164 000006      MOVB   R1, TBUF(R4)      ;LOAD THE DATA BYTE
1144 004466' 005267 174720      WINCBC: INC    BYWR+2      ;ADD 1 TO TOTAL BYTES
1145 004472' 005567 174712      ADC     BYWR      ;WRITTEN COUNT
1146 004476' 005267 174666      INC    WRSIZE      ;ADD 1 TO THIS MSG'S SIZE
1147 004502' 000663      BR      INTEX      ;GO TO INT EXIT
1148
1149 004504' 005767 174672      WCKPAD: TST    PADCNT      ;ALREADY SENT A PAD CHAR?
1150 004510' 001005      BNE    WRRBSY      ;N.Y-WRRBSY
1151 004512' 005064 000006      CLR    TBUF(R4)      ;LOAD A BYTE OF 0'S
1152 004516' 005267 174650      INC    PADCNT      ;ADD 1 TO PAD CNT
1153 004522' 000761      BR      WINCBC      ;GO INCR BYTE COUNTS
1154 004524' 042767 000002 173250  WRRBSY: BIC    #WRRBSY, DFLGWD      ;RESET WRITE BUSY FLAG
1155 004532' 052767 000010 173242  BIS    #WRTERR, DFLGWD      ;SET DO WRITE TERMINATION FLAG
1156 004540' 042764 000161 000004  BIC    #TSEND+TINTEN+TDNAIE+BRK, TCSR(R4) ;RESET SEND, WR INT ENB, & BRK
1157 004546' 042714 000004      BIC    #RQTS, (R4)      ;RESET REQ TO SEND
1158 004552' 032714 000100      BIT    #RINTEN, (R4)      ;READ INT ENABLE SET?
1159 004556' 001633      BEQ    CLRWTF      ;N.Y-CLRWTF
1160 004560' 032767 000001 173214  BIT    #RDBSY, DFLGWD      ;IS READ BUSY?
1161 004566' 001627      BEQ    CLRWTF      ;Y.N-CLRWTF
1162 004570' 000630      BR      INTEX      ;GO TO INT EXIT
1163
1164 004572' 005267 174636      DNAERR: INC    DNACNT      ;ADD 1 TO DNA ERROR CNTR
1165 004576' 052767 000100 173176  BIS    #WRIERR, DFLGWD      ;SET THE WRITE INT ERROR FLAG
1166 004604' 000747      BR      WRRBSY      ;GO TERMINATE THE WRITE

```

.SBTTL SUBROUTINES FOR DU11 FUNCTION ROUTINES

```

1168
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184 004606' 012700 000001 CKRBSY: MOV #1,R0 ;SET UP CK READ FLAG
1185 004612' 000405 BR CKCOM ;GO TO COMMON POINT
1186
1187 004614' 012700 100000 CKWBSY: MOV #100000,R0 ;SET UP CK WRITE FLAG
1188 004620' 000402 BR CKCOM ;GO TO COMMON POINT
1189
1190 004622' 012700 100001 CKBSY: MOV #100001,R0 ;SET UP CK RD & WR FLAGS
1191
1192 004626' 004767 001136 CKCOM: JSR PC,SUPTAD ;SET UP PROG TBL & RCSR ADR'S
1193 004632' 105700 10$ TSTB R0 ;CHECK FOR READ INT ENABLE?
1194 004634' 001403 BEQ 20$ ;Y,N-20$
1195 004636' 032714 000100 BIT #RINTEN,(R4) ;READ INT ENABLE ON?
1196 004642' 001006 BNE 30$ ;N,Y-30$
1197 004644' 005700 20$ TST R0 ;CHECK FOR WRITE INT ENABLE?
1198 004646' 100007 BPL 40$ ;Y,N-40$
1199 004650' 032764 000140 000004 BIT #TINTEN+TDNAIE,TCSR(R4) ;WRITE INT ENABLES SET?
1200 004656' 001403 BEQ 40$ ;Y,N-40$
1201 004660' 004577 173162 30$ JSR R5,ACIOBSY ;RELEASE CONTROL
1202 004664' 000762 10$ BR 10$ ;GO CK AGAIN
1203 004666' 032767 000014 173106 40$ BIT #RDTERM+WRTerm,DFLGWD ;HAVE TO PROCESS PREV TERMINATION?
1204 004674' 001405 BEQ STMADR ;Y,N-STMADR
1205 004676' 010046 MOV R0,-(SP) ;SAVE RD/WR CK FLAGS
1206 004700' 004767 000020 JSR PC,PROCTM ;GO PROCESS TERMINATION
1207 004704' 012600 MOV (SP)+,R0 ;RESTORE RD/WR FLAGS
1208 004706' 000751 BR 10$ ;GO RECHECK INT ENABLE
1209 004710' 010567 174440 STMADR: MOV R5,OBJADR ;SAVE CURR USER STMT ADR
1210 004714' 162767 000004 174432 SUB #4,OBJADR
1211 004722' 000207 RTS PC ;EXIT IN-LINE

```

:PROCESS TERMINATION OF PREVIOUS I/O FUNCTION

```

:JSR    PC,PROCTM      S/R CALL
:R3 = PROG TABLE ADR
:DESTROYS R0

```

1221	004724	010146		PROCTM:	MOV	R1,-(SP)	:SAVE R1 & R2
1222	004726	010246			MOV	R2,-(SP)	
1223	004730	032767	000004 173044	10\$:	BIT	#RDTERM,DFLGWD	:NEED TO DO READ TERMINATION?
1224	004736	001433			BEQ	20\$	:Y,N-20\$
1225	004740	042767	000004 173034		BIC	#RDTERM,DFLGWD	:RESET READ'S PROC TERM FLAG
1226	004746	016767	174414 173044		MOV	RDSIZE,SIZE	:STORE # OF BYTES READ
1227	004754	004767	000136		JSR	PC,RINTV	:RESET READ'S INT VECTOR
1228	004760	032767	000020 173014		BIT	#RDIERR,DFLGWD	:WAS THERE A READ INT ERROR?
1229	004766	001417			BEQ	20\$	:Y,N-20\$
1230	004770	032767	000040 173004		BIT	#RDIDSC,DFLGWD	:WAS IT A DATA SET CHG?
1231	004776	001404			BEQ	14\$	:Y,N-14\$
1232	005000	004567	000274		JSR	RS,ERRRIS	:REPORT DSC ERROR ON READ
1233	005004	001436			.WORD	DSCMSG-ERMBAS	
1234	005006	000403			BR	16\$	
1235	005010	004567	000264	14\$:	JSR	RS,ERRRIS	:GO RESET ERROR FLGS
1236	005014	001406			.WORD	RXFERR-ERMBAS	:GO ISSUE READ XFER ERROR MSG WITH
1237	005016	042767	000060 172756	16\$:	BIC	#RDIERR+RDIDSC,DFLGWD	:READ'S INT STATUS
1238	005024	000426			BR	30\$	:RESET READ INT ERR FLAGS
1239	005026	032767	000010 172746	20\$:	BIT	#WATERM,DFLGWD	:GO TO EROR POINT
1240	005034	001425			BEQ	PROCEX	:NEED TO DO WRITE TERMINATION?
1241	005036	042767	000010 172736		BIC	#WATERM,DFLGWD	:Y,N-PROCEX
1242	005044	016767	174320 172746		MOV	WRSIZE,SIZE	:RESET WRITE'S PROC TERM FLAG
1243	005052	004767	000064		JSR	PC,RWINTV	:STORE # OF BYTES WRITTEN
1244	005056	032767	000100 172716		BIT	#WRIERR,DFLGWD	:RESET WRITE'S INT VECTOR
1245	005064	001411			BEQ	PROCEX	:WAS THERE A WRITE INT ERROR?
1246	005066	004567	000224		JSR	RS,ERRRIS	:Y,N-PROCEX
1247	005072	001467			.WORD	WXFERR-ERMBAS	:GO ISSUE WRITE XFER ERROR MSG WITH
1248	005074	042767	000100 172700		BIC	#WRIERR,DFLGWD	:WRITE'S INT STATUS
1249	005102	004577	172742	30\$:	JSR	RS,OCUPGER	:RESET WRITE INT ERR FLAG
1250	005106	000710			BR	10\$	:GO TO MPG ERR RETN POINT
1251	005110	012602		PROCEX:	MOV	(SP)+,R2	:GO CK FOR ANOTHER TERMINATION
1252	005112	012601			MOV	(SP)+,R1	:RESTORE R1 & R2
1253	005114	000207			R'S	PC	:EXIT IN-LINE

C03

MAINDEC-11-DTDUA-A DUII DEVICE ROUTINE FOR MPG
 DTDUA.P11 SUBROUTINES FOR DUII FUNCTION ROUTINES

MACY11 27(732) 24-SEP-76 14:10 PAGE 10-2

SEQ 0037

```

1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268 005116' 004567 000052 RRINTV: JSR R5,TRVECT ;GO CK IF I HAVE VECTOR CONTROL
1269 005122' 000406 BR 20$ ;BR IF I DON'T
1270 005124' 016767 172676 000004 MOV IVCTAD,10$ ;GET READ INT VECT ADR
1271 005132' 004577 172732 JSR R5,2CLAVEC ;GO HAVE MPG CLEAR IT
1272 005136' 000000 10$: .WORD XXXX
1273 005140' 000207 20$: RTS PC ;EXIT IN-LINE
1274
1275 005142' 004567 000056 RWINTV: JSR R5,TWVECT ;GO CK IF I HAVE VECTOR CONTROL
1276 005146' 000411 BR 40$ ;BR IF I DON'T
1277 005150' 016767 172652 000012 MOV IVCTAD,30$ ;GET READ INT VECT ADR
1278 005156' 062767 000004 000004 ADD #4,30$ ;POINT IT AT WRITE'S VECTOR
1279 005164' 004577 172700 JSR R5,2CLAVEC ;GO HAVE MPG CLEAR IT
1280 005170' 000000 30$: .WORD XXXX
1281 005172' 000207 40$: RTS PC ;EXIT IN-LINE
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295 005174' 016767 172626 000010 TRVECT: MOV IVCTAD,10$ ;GET READ INT VECT ADR
1296 005202' 016346 000004 MOV PFWADR(R3),-(SP) ;STORE FLGWD ADR TO IDENTIFY ME
1297 005206' 004577 172660 JSR R5,2TSTVEC ;DO I HAVE VECTOR CONTROL?
1298 005212' 000000 10$: .WORD XXXX ; MPG WILL TELL ME SINCE I CAN'T
1299 005214' 176644 .WORD DURINT- ; GET AT LOWER MEM IF MEM MGMNT
1300 005216' 000401 BR 20$ ;BR IF I DONT'T HAVE CNTRL
1301 005220' 005725 TST (R5)+ ;BYPASS BR INST IN S/R CALL
1302 005222' 000205 20$: RTS R5 ;EXIT IN-LINE
1303
1304 005224' 016767 172576 000016 TWVECT: MOV IVCTAD,30$ ;GET INT VECT BASE ADR
1305 005232' 062767 000004 000010 ADD #4,30$ ;POINT IT AT WRITE'S VECTOR
1306 005240' 016346 000004 MOV PFWADR(R3),-(SP) ;STORE FLGWD ADR TO IDENTIFY ME
1307 005244' 004577 172622 JSR R5,2TSTVEC ;DO I HAVE VECTOR CONTROL?
1308 005250' 000000 30$: .WORD XXXX ; MPG WILL TELL ME SINCE I CAN'T
1309 005252' 177070 .WORD DUWINT- ; GET AT LOWER MEM IF MEM MGMNT
1310 005254' 000401 BR 40$ ;BR IF I DONT'T HAVE CNTRL
1311 005256' 005725 TST (R5)+ ;BYPASS BR INST IN S/R CALL
1312 005260' 000205 40$: RTS R5 ;EXIT IN-LINE

```

1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369

;ERROR INFORMATION DISPLAY S/R

```

;JSR    RS,ERRCS      S/R CALL FOR CURR STATUS
;          ,ERRRIS      S/R CALL FOR READ INT STATUS
;          ,ERRWIS      S/R CALL FOR WRITE INT STATUS
;          .WORD MSGADR-ERMBAS REL ADR OF ERROR MSG
;R3 = PROG TABLE ADR
;DESTROYS R0,R1,R2

ERRCS: MOV    #CSTAT-ERSTAD,ERSTAD ;STORE ADRS OF CURR STATUS
      MOV    #CSTAT-EBSBAS,EBSTAT ;GO TO COMMON POINT
      BR

ERRRIS: MOV    #R1STAT-ERSTAD,ERSTAD ;STORE ADRS OF LAST READ
      MOV    #R1STAT-EBSBAS,EBSTAT ;INT STATUS
      BR      ;GO TO COMMON POINT

ERRWIS: MOV    #W1STAT-ERSTAD,ERSTAD ;STORE ADRS OF LAST WRITE
      MOV    #W1STAT-EBSBAS,EBSTAT ;INT STATUS

ERRCOM: MOV    (R5)+,ERMBAS ;STORE MSG ADR
      MOV    #1,ERRI ;SET THE ERROR INDICATOR
      BIT    #DOERCK+PRONER,POPSW(R3) ;ERROR CHECKING OR PRINTING INHIBITED?
      BNE    ERREX ;Y,N-ERREX
      MOV    R4,-(SP) ;SAVE R4 & R5
      MOV    R5,-(SP)
      CLR    R4 ;SET USER MODE PRINT FLAG
      JSR    PC,DISUMM ;DISPLAY DEVICE I.D.
      MOV    PC,R0 ;GET START ADR OF ERROR MSG
      ADD    #ERMBAS-.,R0
      ADD    (R0),R0
      MOV    #-1,R1 ;INITIALIZE MSG LENGTH
      10$: INC    R1 ;ADD 1 TO MSG LENGTH
      TSTB   (R0)+ ;MSG TERMINATOR?
      BNE    10$ ;Y,N-10$
      MOV    R1,ERMBAS+2 ;STORE MSG LENGTH
      JSR    R5,PRINT ;PRINT ERROR MSG SPECIFIED
      10$: .WORD XXXX
      10$: .WORD XXXX
      CMP    ERMBAS,#IVMODE-ERMBAS ;INV MODE MSG OR HIGHER?
      BHIS   ERRSNM ;N,Y-ERRSNM
      MOV    PC,R1 ;GET ADR OF CODE AREA IN ERR MSG
      ADD    #CODFLD-.,R1 ;SET UP ADR OF ERROR CODE TBL
      MOV    PC,R0
      ADD    #ERCDTB-.,R0 ;SET UP ADR OF STORED DEV REG'S
      MOV    PC,R2
      EBSBAS: ADD    (PC)+,R2
      EBSTAT: .WORD CSTAT-EBSBAS
      MOV    #11.,70$ ;INITIALIZE MSG LENGTH
      MOV    #20.,-(SP) ;INITIALIZE CODE FIELD CNT
      15$: MOV    (R2)+,R5 ;GET NEXT DEV REG WORD
      SWAB   R5 ;GET DESIRED BYTE IN LOW BYTE

```

E03

MAINDEC-11-DTUA-A D11 DEVICE ROUTINE FOR MPG
DTUAA.P11 SUBROUTINES FOR D11 FUNCTION ROUTINES

MACY11 27(732) 24-SEP-76 14:10 PAGE 10-4

SEQ 0059

1370	005474	112004		20\$:	MOVB	(R0)+,R4	:GET FLAG & LENGTH BYTE
1371	005476	005704			TST	R4	:END OF THE CODE TBL?
1372	005500	001434			BEQ	60\$	:N,Y-60\$
1373	005502	122704	000377		CMPB	#377,R4	:GO TO NXT DEV REG WORD?
1374	005506	001770			BEQ	15\$	:N,Y-15\$
1375	005510	131005			BITB	(R0),R5	:THIS ERROR BIT SET IN DEV REG BYTE?
1376	005512	001004			BNE	40\$	:N,Y-40\$
1377	005514	042704	177770		BIC	#177770,R4	:ISOLATE ENTRY LENGTH
1378	005520	060400			ADD	R4,R0	:POINT AT NXT CODE TBL ENTRY
1379	005522	000764			BR	20\$	:GO CK FOR NXT CODE
1380	005524	042704	177770	40\$:	BIC	#177770,R4	:ISOLATE I.D. NAME LENGTH + 1
1381	005530	020416			CMP	R4,(SP)	:ENOUGH ROOM FOR NAME?
1382	005532	101017			BHI	60\$	:Y,N-60\$
1383	005534	060467	00005C		ADD	R4,70\$	:ADJ MSG LENGTH FOR NAME
1384	005540	005304			DEC	R4	:ADJ FOR BIT MASK CHAR
1385	005542	005200			INC	R0	:POINT PAST BIT MASK
1386	005544	021627	000024		CMP	(SP),#20.	:FIRST ERROR CODE IN MSG?
1387	005550	001403			BEQ	50\$	:N,Y-50\$
1388	005552	112721	000054		MCVB	#'(R1 +	:MOVE COMMA TO MSG
1389	005556	005316			DEC	(SP)	:ADJ REMAINING ROOM IN MSG
1390	005560	112021		50\$:	MOVB	(R0)+,(R1)+	:MOVE ERROR CODE TO MSG
1391	005562	005316			DEC	(SP)	:ADJ REMAINING ROOM IN MSG
1392	005564	005304			DEC	R4	:MOVED ALL NAME CHARS?
1393	005566	001374			BNE	50\$	:Y,N-50\$
1394	005570	000741			BR	20\$	:GO CK FOR MORE ERROR BITS
1395	005572	005004		60\$:	CLR	R4	:SET USER MODE PRINT
1396	005574	022627	000024		CMP	(SP)+,#20.	:ANY ERROR CODES PUT IN MSG?
1397	005600	001404			BEQ	80\$	:Y,N-80\$
1398	005602	004567	000350		JSR	R5,PRINT	:GO ISSUE ERROR BITS MSG
1399	005606	001351			.WORD	ERBMSG-	
1400	005610	000040		70\$:	.WORD	32.	
1401	005612	004567	000236	80\$:	JSR	R5,DISPST	:DISPLAY DEVICE REG'S
1402	005616	000000		ERSTAD:	.WORD	XXXX	
1403	005620	016300	000022	ERRSNM:	MOV	PSRCST(F3),R0	:GET ADR OF SRC STMENTS
1404	005624	111001		110\$:	MOVB	(R0),R1	:SAVE STMT LENGTH
1405	005626	026067	000004 173520		CMP	4(R0),OBJADR	:ERROR OCCUR ON THIS STMT?
1406	005634	001402			BEQ	120\$	:N,Y-120\$
1407	005636	060100			ADD	R1,R0	:POINT AT NXT STMT
1408	005640	000771			BR	110\$	:GO CK NXT STMT
1409	005642	005720		120\$:	TST	(R0)+	:SET UP ADR OF STMT & DATA
1410	005644	010701			MOV	PC,R1	:SET UP DATA OUTPUT ADR
1411	005646	062701	001152		ADD	#STNUM-. ,R1	
1412	005652	004577	172204		JSR	R5,DEEASC	:CONVERT IT TO ASCII
1413	005656	012767	020040 001140		MOV	#20040,STNUM+4	:SET 2 LOW DIGITS TO SPACES
1414	005664	004567	000266		JSR	R5,PRINT	:ISSUE STMT & MSG
1415	005670	001120			.WORD	STNMG-	
1416	005672	177762			.WORD	-14.	
1417	005674	012605			MOV	(SP)+,R5	:RESTORE R5 & R4
1418	005676	012604			MOV	(SP)+,R4	
1419	005700	000205		ERREX:	R'S	R5	:EXIT IN-LINE

1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443

;ERROR MESSAGE CODE TABLE

;377 = GO TO NEXT DEVICE REGISTER WORD
 ;BYTE 0 CONTAINS FLAG BITS & I.D. NAME LENGTH
 ;
 ;BITS 0-2 = LENGTH OF BIT MASK + I.D. NAME
 ;
 ;BYTE 1 IS THE BIT MASK
 ;
 ;BYTES 2 THRU 7 ARE THE BIT'S ASCII I.D.

005702' 377
 005703' 003 051200 130
 005707' 004 047500 051126
 005714' 020004 051106 115
 005721' 004 050020 051101
 005726' 377
 005727' 004 042200 040516
 005734' 000
 005736'

ERCDTB: .BYTE 377
 .ASCII <003><200>/RX/ ;RBUF: BITS 15 - 8
 .ASCII <004><100>/OVR/
 .ASCII <004><040>/FRM/
 .ASCII <004><020>/PAR/
 .BYTE 377
 .ASCII <004><200>/DNA/ ;TCSR: BITS 15 - 8
 .BYTE 0 ;TABLE TERMINATOR
 .EVEN

.SBTTL SUBROUTINES FOR DUII DEVICE ROUTINE

;SAVE REGISTERS RO THRU R5

;JSR RO,SAVREG S/R CALL

SAVREG: MOV R1,-(SP) ;SAVE RO THRU R5
 MOV R2,-(SP)
 MOV R3,-(SP)
 MOV R4,-(SP)
 MOV R5,-(SP)
 MOV RO,PC ;EXIT IN-LINE

;RESTORE REGISTERS RO THRU R5

;JSR RO,RESREG S/R CALL

RESREG: TST (SP)+ ;RESTORE R5 THRU RO
 MOV (SP)+,R5
 MOV (SP)+,R4
 MOV (SP)+,R3
 MOV (SP)+,R2
 MOV (SP)+,R1
 RTS RO ;EXIT IN-LINE

;SET PROGRAM'S PROG TABLE ADR IN R3 & RCSR ADR IN R4

;JSR PC,SUPTAD S/R CALL

SUPTAD: MOV PC,R3 ;SET UP LOCATION ZERO ADR
 ADD #LOCZ-.,R3
 SUB -2(R3),R3 ;SUBTRACT PROG TBL LENGTH
 MOV DREGAD,R4 ;GET DEV REG BASE ADR (RCSR)
 RTS PC ;EXIT IN-LINE

;STORE DEVICE'S STATUS REGISTERS

;JSR R5,STSTAT S/R CALL
 ;.WORD STADR-. REL STORAGE ADR
 ;DESTROYS RO,R1

STSTAT: MOV R5,R1 ;GET REL STORAGE ADR & MAKE
 ADD (R5)+,R1 ;IT ABSOLUTE
 MOV DREGAD,RO ;GET DEV REG ADR
 MOV (RO)+,(R1)+ ;STORE ALL READABLE DEV REG'S
 MOV (RO)+,(R1)+
 MOV (RO)+,(R1)+
 RTS R5 ;EXIT IN-LINE

1445
 1446
 1447
 1448
 1449
 1450
 1451
 1452
 1453 005736' 010146
 1454 005740' 010246
 1455 005742' 010346
 1456 005744' 010446
 1457 005746' 010546
 1458 005750' 010007
 1459
 1460
 1461
 1462
 1463
 1464
 1465 005752' 005726
 1466 005754' 012605
 1467 005756' 012604
 1468 005760' 012603
 1469 005762' 012602
 1470 005764' 012601
 1471 005766' 000200
 1472
 1473
 1474
 1475
 1476
 1477
 1478 005770' 010703
 1479 005772' 062703 172006
 1480 005776' 166303 177776
 1481 006002' 016704 172016
 1482 006006' 000207
 1483
 1484
 1485
 1486
 1487
 1488
 1489
 1490
 1491
 1492 006010' 010501
 1493 006012' 062501
 1494 006014' 016700 172004
 1495 006020' 012021
 1496 006022' 012021
 1497 006024' 012021
 1498 006026' 000205

```

1500
1501
1502           ;DISPLAY DEVICE I.D. AND DEVICE REGISTER ADDRESS
1503
1504           ;JSR    PC,DISUNM          S/R CALL
1505
1506           ;R4 = CMND/USER MODE PRINT FLAG
1507           ;R3 = PROG TBL ADR
1508
1509           ;DESTROYS R0,R1,R2
1510
1511 006030' 016700 171770      DISUNM: MOV    DREGAD,R0          ;GET DUII DEV REG ADR
1512 006034' 004577 172016      JSR      R5,JBINASC          ;CONVERT BINARY # TO ASCII
1513 006040' 000345              .WORD    UNASCII-
1514 006042' 004567 000110      JSR      R5,PRINT          ;GO ISSUE DEV I.D. MSG
1515 006046' 000323              .WORD    UNITMG-
1516 006050' 000022              .WORD    18.
1517 006052' 000207      RTS      PC          ;EXIT IN-LINE
1518
1519
1520           ;TAILOR STATUS MSG & PRINT IT
1521
1522           ;JSR      R5,DISPST          S/R CALL
1523           ;.WORD    STATADR-          REL ADR OF STATUS DATA
1524
1525           ;DESTROYS R0,R1,R2
1526
1527 006054' 010502      DISPST: MOV    R5,R2          ;GET REL DATA ADR
1528 006056' 062502      ADD      (R5)+,R2          ;MAKE IT ABS
1529 006060' 010701      MOV      PC,R1          ;SET UP ADR OF REG NAMES IN ASCII
1530 006062' 062701 172034      ADD      #DVRGMS-,R1
1531 006066' 012746 000003      MOV      #3,-(SP)          ;STORE # OF REGISTERS TO DISPLAY
1532 006072' 012167 000316      10$: MOV      (R1)+,DVRGMG          ;MOVE REG NAME TO MSG
1533 006076' 012167 000314      MOV      (R1)+,DVRGMG+2
1534 006102' 005721      TST      (R1)+          ;BYPASS DISP VALUE
1535 006104' 012200      MOV      (R2)+,R0          ;GET REG'S STORED VALUE
1536 006106' 010746      MOV      PC,-(SP)          ;SET UP ADR OF WRITE
1537 006110' 062716 173234      ADD      #WITCSR-,(SP)          ;INT STATUS
1538 006114' 022602      CMP      (SP)+,R2          ;THIS THE UNUSED WD IN WP INT?
1539 006116' 001413      BEQ      20$          ;N.Y-20$
1540 006120' 010146      MOV      R1,-(SP)          ;SAVE R1 & R2
1541 006122' 010246      MOV      R2,-(SP)
1542 006124' 004577 171726      JSR      R5,JBINASC          ;CONVERT IT TO ASCII
1543 006130' 000272      .WORD    DVRGDT-
1544 006132' 004567 000020      JSR      R5,PRINT          ;PRINT THE STATUS MSG
1545 006136' 000256      .WORD    DVRGMG-
1546 006140' 000014      .WORD    12.
1547 006142' 012602      MOV      (SP)+,R2          ;RESTORE R1 & R2
1548 006144' 012601      MOV      (SP)+,R1
1549 006146' 005316      20$: DEC      (SP)          ;DECR REG CNT
1550 006150' 001350      BNE      10$          ;DONE ALL? (Y,N-10$)
1551 006152' 005726      TST      (SP)+          ;REMOVE CNT FROM STACK
1552 006154' 000205      RTS      R5          ;EXIT IN-LINE

```

```

1554
1555
1556                                     ;ISSUE MSG TO LIST DEVICE SUBROUTINE
1557
1558                                     ;JSR    R5,PRINT          S/R CALL
1559                                     ;.WORD  MSGADR-.          REL ADR OF MSG
1560                                     ;.WORD  BYTCNT          MSG BYTE CNT (IF NEGATIVE,
1561                                     ;                                     RESET PRT DEV DEDICATED.)
1562
1563                                     ;R3 = PROG TBL ADR
1564                                     ;R4 = FLAGWORD -- IF NEGATIVE, USE CMND MODE PRINT
1565
1566                                     ;DESTROYS R0,R1,R2
1567
1568 006156' 010500 PRINT: MOV R5,R0 ;GET MSG ADR & MAKE IT ABS
1569 006160' 062500 ADD (R5)+,R0
1570 006162' 012501 MOV (R5)+,R1 ;GET BYTE COUNT
1571 006164' 005704 TST R4 ;USE CMND MODE PRINT?
1572 006166' 100030 BPL 40$ ;Y,N-40$
1573 006170' 010702 MCV PC,R2 ;SET UP LINK INFO ADR
1574 006172' 062702 000040 ADD #20$-.,R2
1575 006176' 160200 SUB R2,R0 ;MAKE MSG ADR REL
1576 006200' 010022 MOV R0,(R2)+ ;STORE MSG ADR
1577 006202' 010112 MOV R1,(R2) ;STORE MSG'S BYTE COUNT
1578 006204' 100001 BPL 10$ ;CNT NEG? (Y,N-10$)
1579 006206' 005412 NEG (R2) ;MAKE IT POSITIVE
1580 006210' 016367 000006 000056 10$: MOV PASCIN(R3),PROGNM ;STORE PROG'S # IN MSG
1581 006216' 004577 171632 JSR R5,@CLIST ;ISSUE PROG #
1582 006222' 000050 .WORD PNMMSG-.
1583 006224' 000005 .WORD 5
1584 006226' 004577 171622 JSR R5,@CLIST ;ISSUE MSG SPECIFIED
1585 006232' 030000 20$: .WORD XXXX
1586 006234' 000000 .WORD XXXX
1587 006236' 004577 171612 JSR R5,@CLIST ;ISSUE A <CR> & <LF>
1588 006242' 000240 .WORD CRLF-.
1589 006244' 000002 .WORD 2
1590 006246' 000410 BR PRTEX ;GO TO EXIT
1591 006250' 010067 000010 40$: MOV R0,50$ ;STORE MSG'S ABS ADR
1592 006254' 010167 000006 MOV R1,60$ ;STORE ITS BYTE CNT
1593 006260' 004577 171566 JSR R5,@CLIST ;GO TO MPG TO ISSUE THE MSG
1594 006264' 000000 50$: .WORD XXXX
1595 006266' 000000 60$: .WORD XXXX
1596 006270' 000205 PRTEX: RTS R5 ;EXIT IN-LINE

```

```

1598 .SBTTL DUI: MESSAGE STORAGE AREA
1599
1600 .NLIST BEX
1601
1602 .EVEN
1603 006272' 021520 PNMMSG: .ASCII /P# /
1604 006274' 054130 011 PROGNM: .ASCII /XX/<011>
1605 006277' 101 020124 040514 LRIMSG: .ASCII /AT LAST READ INT: /
1606 006320' 052101 046040 051501 LWIMSG: .ASCII /AT LAST WRITE INT: /
1607 006342' 052503 051122 047105 CURMSG: .ASCII /CURRENTLY: /
1608 006354' 047105 020104 043117 RENDMG: .ASCII /END OF REPORT /
1609 006371' 052 025052 042052 UNITMG: .ASCII /****DUI: AT /
1610 006405' 130 054130 054130 UNASCI: .ASCII /XXXXXX /
1611 006414' 006414' .EVEN
1612 006414' 054130 054130 020075 DVRGMG: .ASCII /XXXX= /
1613 006422' 054130 054130 054130 DVRGDT: .ASCII /XXXXXX /
1614 006430' 054502 042524 035123 CNTSMG: .ASCII /BYTES: RD= /
1615 006444' 054130 054130 054130 BCMRD: .ASCII /XXXXXXXXXXXXX WR= /
1616 006466' 054130 054130 054130 BCMWR: .ASCII /XXXXXXXXXXXXX /
1617 006502' 005015 CRLF: .ASCII <015><012>
1618 006504' 041411 047115 051504 .ASCII <011>/CMNDS: RD= /
1619 006521' 130 054130 054130 CMDCRD: .ASCII /XXXXXX WR= /
1620 006534' 054130 054130 054130 CMDCWR: .ASCII /XXXXXX BRK= /
1621 006550' 054130 054130 054130 CMDBRK: .ASCII /XXXXXX MISC= /
1622 006565' 130 054130 054130 CMDCMS: .ASCII /XXXXXX/<015><012>
1623 006575' 011 051105 047522 .ASCII <011>/ERRORS: PAR= /
1624 006613' 130 054130 054130 CNTPAR: .ASCII /XXXXXX FRM= /
1625 006630' 054130 054130 054130 CNTFRM: .ASCII /XXXXXX OVR= /
1626 006645' 130 054130 054130 CNTOVR: .ASCII /XXXXXX DSC= /
1627 006662' 054130 054130 054130 CNTDSC: .ASCII /XXXXXX/<015><012><011><011>/DNA= /
1628 006701' 130 054130 054130 CNTDNA: .ASCII 'XXXXXX T/O= '
1629 006716' 054130 054130 054130 CNTTOE: .ASCII /XXXXXX DATA= /
1630 006734' 054130 054130 054130 CNTDER: .ASCII /XXXXXX/<015><012>
1631 006744' 044411 052116 051105 .ASCII <011>/INTERRUPTS: RD= /
1632 006766' 054130 054130 054130 CNTRDI: .ASCII /XXXXXX WR= /
1633 007002' 054130 054130 054130 CNTWRI: .ASCII /XXXXXX /
1634 007010' 007010' CNTSEN= .
1635 .EVEN
1636 007010' 052123 047115 020124 STMNMG: .ASCII /STMT # /
1637 007020' 054130 054130 054130 STMNUM: .ASCII /XXXXXX /
1638 007026' 051105 047522 020122 RXFERR: .ASCIZ 'ERROR ON READ DATA XFER'
1639 007056' 040504 040524 051440 DSCMSG: .ASCIZ 'DATA SET CHG INT ON READ'
1640 007107' 105 051122 051117 WXFERR: .ASCIZ 'ERROR ON WRITE DATA XFER'
1641 007140' 044524 042515 052517 IOTO: .ASCIZ 'TIMEOUT ON I/O'
1642 007157' 105 051122 051117 ERBMSG: .ASCII /ERROR BITS: /
1643 007173' 000024 CODFLD: .BLKB 20.
1644 007217' 115 042117 020105 IVMODE: .ASCIZ /MODE NOT 0, 2 OR 3 /
1645 007242' 020043 043117 041440 IVBITS: .ASCIZ /# OF CHAR BITS NOT 5, 6, 7 OR 8 /
1646
1647 .EVEN
1648
1649 .LIST BEX
1650
1651
1652 007302' DVREND= .

```

```

1654          .SBTTL FORMATS FOR PROGRAM & DEVICE ROUTINE TABLES
1655
1656          : PROGRAM TABLE FORMAT
1657
1658          000242      PTLGTH= 162.      ;PROGRAM TABLE LENGTH - NON MEM MGMNT VERSION OF MPG
1659
1660          : (PTLGTH= 212.      ;PROGRAM TABLE LENGTH - MEM MGMNT VERSION OF MPG)
1661
1662          000000      PFLGWD= +0.      ;PROGRAM FLAG WORD - 1 WORD
1663
1664          000002      URSTOP= 2          ; 1 = USER HAS STOPPED THIS PROGRAM
1665          000004      ERSTOP= 4          ; 1 = AN ERROR HAS STOPPED THIS PROGRAM
1666          000010      WT4IOT= 10         ; 1 = WAITING FOR I/O TERMINATION
1667          000020      CTPRIO= 20         ; 1 = CONSOLE OR PRINTER I/O IN PROGRESS
1668          000040      SETDED= 40         ; 1 = THIS PROG SET THE PRT DEV DEDICATED FLAG
1669          000100      OCPRES= 100        ; 1 = OBJ CODE IS PRESENT
1670          000200      USEUBM= 200        ; 1 = THIS PROG USES THE UNIBUS MAP (MEM MGMNT ONLY)
1671          100000      ACTIVE= 100000    ; 1 = PROGRAM IS ACTIVE (SPECIFIED FOR EXECUTION)
1672
1673          000002      POPSW= +2.         ;PROGRAM'S OPERATION SWITCHES - 1 WORD
1674
1675          100000      STONER= 100000     ; 1 = STOP PROG EXECUTION UPON ERROR
1676          040000      CYCPRG= 40000     ; 1 = CYCLE PROGRAM (ON CURRENT DEVICE)
1677          020000      PRONER= 20000     ; 1 = DO NOT PRINT ON ERROR
1678          010000      BIT12= 10000     ; 0 = NOT USED
1679          004000      BIT11= 4000      ; 0 = NOT USED
1680          002000      CYCDVL= 2000     ; 1 = CYCLE THE DEVICE LIST
1681          001000      GTNXTD= 1000     ; 1 = CYCLE ON SAME DEVICE UPON ERROR
1682          000400      DOERCK= 400      ; 1 = DON'T DO ERROR CHECKING
1683          000200      SPOPER= 200      ; 1 = DEVICE SPECIAL OPERATION
1684          000100      BIT6= 100        ; 0 = NOT USED
1685          000040      DOIOT= 40        ; 1 = DO NOT PERFORM I/O TIMEOUT
1686          000020      AUTORP= 20       ; 1 = DO NOT AUTOMATICALLY DISPLAY COUNTS
1687          000010      AURPEP= 10       ; 1 = AUTO DISPLAY COUNTS AT END OF FINAL PASS ONLY
1688          000004      HSKPEP= 4        ; 1 = HOUSEKEEP COUNTS ONLY AT RUN COMMAND
1689          000002      PFBBOV= 2        ; 1 = PRINT FIRST BAD BYTE ONLY ON VERIFY
1690          000001      NOCOMP= 1        ; 1 = DO NOT PRINT PROG COMPLETED MSG
1691
1692          000004      PFWADR= +4.        ;*;PROGRAM FLAGWORD ADDRESS - 1 WORD
1693
1694          000006      PASCIN= +6.        ;PROGRAM'S NUMBER IN ASCII - 1 WORD
1695
1696          000010      PNAME= +8.        ;PROGRAM'S NAME IN ASCII - 6 BYTES
1697
1698          000016      PRDIOA= +14.       ;ADDRESS OF READ I/O AREA - 1 WORD
1699
1700          000020      PWRIOA= +16.       ;ADDRESS OF WRITE I/O AREA - 1 WORD
1701
1702          000022      PSRCST= +18.       ;SOURCE STATEMENTS START ADDRESS - 1 WORD
1703
1704          000024      POBJST= +20.       ;OBJECT CODE START ADDRESS - 1 WORD
1705
1706          000026      PLNGTH= +22.       ;PROG AREA LENGTH (OBJ END MINUS PROG TBL START) - 1 WORD
1707
1708          000030      PTOCNT= +24.       ;I/O TIMEOUT COUNT - 1 WORD
1709

```

1710	000032	PMDLCD= +26.	;DEV ROUT MODEL # CODE - 1 WORD
1711			
1712	000034	PDPNTR= +28.	;CURRENT DEVICE NUMBER POINTER - 1 BYTE
1713			
1714	000035	PCURDV= +29.	;CURRENT DEVICE # - 1 BYTE
1715			
1716	000036	PDNUMS= +30.	;DEVICE NUMBERS - 16 BYTES
1717			
1718	000056	PTEM0= +46.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1719			
1720	000060	PTEM1= +48.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1721			
1722	000062	PTEM2= +50.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1723			
1724	000064	PTEM3= +52.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1725			
1726	000066	PTEM4= +54.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1727			
1728	000070	PTEM5= +56.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1729			
1730	000072	PTEM6= +58.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1731			
1732	000074	PTEM7= +60.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1733			
1734	000076	PTEM8= +62.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1735			
1736	000100	PTEM9= +64.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1737			
1738	000102	PTEM10= +66.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1739			
1740	000104	PTEM11= +68.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1741			
1742	000106	PTEM12= +70.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1743			
1744	000110	PTEM13= +72.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1745			
1746	000112	PTEM14= +74.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1747			
1748	000114	PTEM15= +76.	;USER PROGRAM TEMPORARY STORAGE - 1 WORD
1749			
1750	000116	PNBR= +78.	;NUMBER OF BYTES TO TRANSFER ON MOVE (NBR) - 1 WORD
1751			
1752	000120	PSRC= +80.	;DATA SOURCE ADDRESS ON MOVE (SRC) - 1 WORD
1753			
1754	000122	PDST= +82.	;DATA DESTINATION ADDRESS ON MOVE (DST) - 1 WORD
1755			
1756	000124	PSTKCT= +84.	;# OF WORDS (X 2) SAVED OFF STACK - 1 WORD
1757			
1758	000126	PSTKSV= +86.	;STACK WORDS STORAGE AREA - 30 WORDS
1759			
1760	000222	PSVREG= +146.	;USER'S R0 THRU R5 REGISTERS STORAGE AREA - 6 WORDS
1761			
1762	000236	PUSRPC= +158.	;USER'S CURRENT PROGRAM COUNTER - 1 WORD
1763			

M03

MAINDEC-11-DTDUA-A DU11 DEVICE ROUTINE FOR MPG MACY11 27(732) 24-SEP-76 14:10 PAGE 13-2
 DTDUA.P11 FORMATS FOR PROGRAM & DEVICE ROUTINE TABLES

SEQ 0067

1765		;FOLLOWING ENTRIES (PRDIOX THRU PUBMAP) ARE ONLY IN MEM MGMNT VERSION
1766		;(PRDIOX= +160. ;18/22 BIT ABSOLUTE ADDRESS OF READ I/O AREA - 2 WORDS)
1767		;(PRDIOV= +164. ;18 BIT VIRTUAL ADDRESS OF READ I/O AREA - 2 WORDS)
1768		;(PWRIOX= +168. ;18/22 BIT ABSOLUTE ADDRESS OF WRITE I/O AREA - 2 WORDS)
1769		;(PWRIOV= +172. ;18 BIT VIRTUAL ADDRESS OF WRITE I/O AREA - 2 WORDS)
1770		;(PUPARS= +176. ;STORAGE AREA FOR USER'S PAR'S 0 THRU 7 - 8 WORDS)
1771		;(PUPDRS= +192. ;STORAGE AREA FOR USER'S PDR'S 0 THRU 7 - 8 WORDS)
1772		;(PUBMAP= +208. ;1ST UNIBUS MAP REG # AND # OF REGS USED - 1 WORD)
1773		;END OF MEM MGMNT ONLY ENTRIES
1774	000240	PTSIZE= +160. ;PROGRAM TABLE SIZE IN BYTES - 1 WORD - NON MEM MGMNT
1775		;(PTSIZE= +210. ;PROGRAM TABLE SIZE IN BYTES - 1 WORD - MEM MGMNT VERSION)
1776		PTEND= +162. ;END OF PROGRAM TABLE - NON MEM MGMNT VERSION
1777	000242	;(PTEND= +212. ;END OF PROGRAM TABLE - MEM MGMNT VERSION)
1778		
1779		
1780		
1781		
1782		
1783		
1784		
1785		
1786		
1787		
1788		
1789		

```

1791          ;      DEVICE ROUTINE TABLE
1792
1793
1794          000116      DRTLTH= 78.      ;DEVICE ROUTINE TABLE LENGTH
1795          ;
1796          000000      DEVRSZ= +0.      ;DEVICE ROUTINE SIZE IN BYTES - 1 WORD
1797
1798          000002      DEVFWD= +2.      ;DEVICE ROUTINE FLAGWORD - 1 WORD
1799
1800          000004      DEVIW1= +4.      ;DEVICE INTERFACE WORD # 1 - 1 WORD
1801
1802          000006      DEVIW2= +6.      ;DEVICE INTERFACE WORD # 2 - 1 WORD
1803
1804          000010      DEVIW3= +8.      ;DEVICE INTERFACE WORD # 3 - 1 WORD
1805
1806          000012      DEVIW4= +10.     ;DEVICE INTERFACE WORD # 4 - 1 WORD
1807
1808          000014      DEVIW5= +12.     ;DEVICE INTERFACE WORD # 5 - 1 WORD
1809
1810          000016      DEVIW6= +14.     ;DEVICE INTERFACE WORD # 6 - 1 WORD
1811
1812          000020      DEVIW7= +16.     ;DEVICE INTERFACE WORD # 7 - 1 WORD (SIZE)
1813
1814          000022      DEVIW8= +18.     ;DEVICE INTERFACE WORD # 8 - 1 WORD (ERR)
1815
1816          000024      DEVDR= +20.      ;DEVICE REGISTERS ADDRESS - 1 WORD
1817
1818          000026      DEVIVA= +22.     ;DEVICE INTERRUPT VECTOR ADDRESS - 1 WORD
1819
1820          000030      DEVRPS= +24.     ;DEVICE READ PROCESSOR STATUS WORD (BUS REQ) - 1 WORD
1821
1822          000032      DEVPWS= +26.     ;DEVICE WRITE PROC STATUS WORD (BUS REQ) - 1 WORD
1823
1824          000034      DHKPAD= +28.     ;DEVICE ROUT HOUSEKEEPING ROUT REL ENTRY ADR - 1 WORD
1825
1826          000036      DERP= +30.      ;DEVICE ROUT REPORT ROUT REL ENTRY ADR - 1 WORD
1827
1828          000040      DKILAD= +32.     ;DEVICE ROUT KILL ROUTINE REL ENTRY ADR - 1 WORD
1829
1830          000042      DECTAD= +34.     ;DEVICE ROUT ERROR COUNTER REL ADR - 1 WORD
1831
1832          000044      DTOEAD= +36.     ;DEVICE ROUT TIMEOUT ERR ROUT REL ENTRY ADR - 1 WORD
1833
1834          000046      DEVI0B= +38.     ;DEVICE I/O BUSY BRANCH ADDRESS (CIOBSY) - 1 WORD
1835
1836          000050      DEVDER= +40.     ;DEVICE ERROR BRANCH ADDRESS (CUPGER) - 1 WORD
1837
1838          000052      DVUPRT= +42.     ;USER MODE PRINT BRANCH ADDRESS (ULIST) - 1 WORD
1839
1840          000054      DVCPR= +44.     ;CMND MODE PRINT BRANCH ADDRESS (CLIST) - 1 WORD
1841
1842          000056      DEVSTA= +46.     ;CONVERT BINARY TO ASCII BR ADR (BINASC) - 1 WORD
1843
1844          000060      DVBTDA= +48.     ;CONVERT BINARY TO DECIMAL ASCII BR ADR (BTASLZ) - 1 WORD
1845
1846

```

1862	000062	DVPODA= +50.	; CONVERT PACKED DECIMAL TO ASCII BR ADR (DECA5C) - 1 WORD
1863	000064	DVSFW= +52.	; SYSTEM FLAGWORD ADDRESS (CSYSFW) - 1 WORD
1864	000066	DVSVEC= +54.	; SET INTERRUPT VECTOR BR ADR (SETVEC) - 1 WORD
1865	000070	DVCLVEC= +56.	; CLEAR INTERRUPT VECTOR BR ADR (CLRVEC) - 1 WORD
1866	000072	DVTVEC= +58.	; TEST INTERRUPT VECTOR BR ADR (TSTVEC) - 1 WORD
1867	000074	DVRINT= +60.	; RETURN FROM INTERRUPT BR ADR (RTNINT) - 1 WORD
1868	000076	DVGETB= +62.	; GET DATA BYTE BR ADR (GETBYT) - 1 WORD
1869	000100	DVPUTB= +64.	; PUT DATA BYTE BR ADR (PUTBYT) - 1 WORD
1870	000102	DEVSTP= +66.	; DEVICE ROUT REL SYMBOL TABLE POINTER - 1 WORD
1871	000104	DEVETP= +68.	; DEVICE ROUT REL ENTRY TABLE POINTER - 1 WORD
1872	000106	DVPTEP= +70.	; PACK TABLE EXTEN. REL POINTER - 1 WORD
1873	000110	DVVTEP= +72.	; VECTOR TABLE EXTEN. REL POINTER - 1 WORD
1874	000112	DVCTEP= +74.	; COMPILER TBL EXTEN. REL POINTER - 1 WORD
1875	000114	DVIWSP= +76.	; DEVICE INTERFACE WORD SYMBOL TBL REL POINTER - 1 WORD
1876	000116	DRTEND= +78.	; END OF DEVICE ROUTINE TABLE
1877	000001		.END

ACTIVE= 100000		COUNTS 001404R	002	DSCMSG 007056R	002	GTNXTD= 001000		PATCH 001450R	002
ANSWER 002574R	002	CRESET 002770R	002	DSR = 001000		HANGUP 002716R	002	PC = 000007	
AURPEP= 000010		CRLF 006502R	002	DTOEAD= 000044		HOUPLEX 003050R	002	PCSR = 000002	
AUTORP= 000020		CSTAT 001346R	002	DTR = 000002		HLFDPX= 000010		PCSRV 001446R	002
BCMRD 006444R	002	CSYSFW 000064R	002	DURINT 004060R	002	HSKEEP 001520R	002	PCURDV= 000035	
BCMR 006466R	002	CTPRIO= 000020		DUMINT 004342R	002	HSKPEN= 001446R	002	PONUMS= 000036	
BINASC 000056R	002	CTS = 020000		DVBTD= 000060		HSKPEP= 000004		PDPNTR= 000034	
BITERR 003350R	002	CUPGER 000050R	002	DVCMD5 000154R	002	HSKPST= 001332R	002	POST = 000122	
BITS 003266R	002	CURMSG 006342R	002	DVCPT= 000054		ICONS 001556R	002	PFB80V= 000002	
BIT55 = 000000		CVSYNC 002426R	002	DVCPT= 001032R	002	INTEX 004252R	002	PFLGMD= 000000	
BIT56 = 002000		CYCDVL= 002000		DVCTEP= 000112		IOTO 007140R	002	PFWAOR= 000004	
BIT57 = 004000		CYCPRG= 040000		DVCVEC= 000070		ISCNT 001400R	002	PLNGTH= 000026	
BIT58 = 006000		DATAER 001440R	002	DVGETB= 000076		ISOCHM= 000000		PMOLCD= 000032	
BITTBL 003366R	002	DECASC 000062R	002	DVIWSP= 000114		ISYNCH= 030000		PNAME = 000010	
BIT11 = 004000		DECTAD= 000042		DVIWST 001306R	002	IVBITS 007242R	002	PNBR = 000116	
BIT12 = 010000		DERPAD= 000036		DVMVTE 000662R	002	IVCTAD 000026R	002	PNMSG 006272R	002
BIT6 = 000100		DEVSTA= 000056		DVPDTA= 000062		IVMODE 007217R	002	POBJST= 000024	
BREAK 003636R	002	DEVDER= 000050		DVPKTE 000342R	002	KILL 002262R	002	POPSW = 000002	
BRK = 000001		DEVORA= 000024		DVPTEP= 000106		LDPCSR 003150R	002	PRDIOA= 000016	
BRKCNT 001420R	002	DEVETP= 000104		DVPUTB= 000100		LISTEN 002626R	002	PRESET 003416R	002
BRKFLG= 000200		DEVFMD= 000002		DVREGE= 000154R	002	LOCZ 000000R	002	PRINT 006156R	002
BTASLZ 000060R	002	DEVI08= 000046		DVREGS 000116R	002	LRMSG 006277R	002	PROCEX 005110R	002
BYRD 001404R	002	DEVIVA= 000026		DVREND= 007302R	002	LWMSG 006320R	002	PROCTH 004724R	002
BYMR 001410R	002	DEVIW1= 000004		DVREX 002120R	002	MAINTM= 014000		PROGNM 006274R	002
CACHE = 000200		DEVIW2= 000006		DVRGOT 006422R	002	MISCNT 001422R	002	PRONER= 020000	
CALL 002574R	002	DEVIW3= 000010		DVRGMG 006414R	002	MODCOM 003242R	002	PRTEX 006270R	002
CARRIER= 010000		DEVIW4= 000012		DVRINT= 000074		MODE 003202R	002	PSRC = 000120	
CIOBSY 000046R	002	DEVIW5= 000014		DVSFWO= 000064		MODEBT= 030000		PSRCST= 000022	
CKBSY 004622R	002	DEVIW6= 000016		DVSVEC= 000066		MODERR 003256R	002	PSTKCT= 000124	
CKCOM 004626R	002	DEVIW7= 000020		DVTVEC= 000072		MSFMT1 001330R	002	PSTKSV= 000126	
CKRBSY 004606R	002	DEVIW8= 000022		DVUPRT= 000052		MSFMT2 001327R	002	PSVREG= 000222	
CKWBSY 004614R	002	DEVRRS= 000030		DVVTEP= 000110		MSFMT3 001324R	002	PTEMO = 000056	
CLIST 000054R	002	DEVRSZ= 000000		EBSBAS 005452R	002	MSTRST= 000400		PTEM1 = 000060	
CLAVEC 000070R	002	DEVSTP= 000102		EBSTAT 005454R	002	NIEREX 003356R	002	PTEM10= 000102	
CLPMTF 004246R	002	DEVWPS= 000032		ERBMSG 007157R	002	NINTEX 002620R	002	PTEM11= 000104	
CMAK 001374R	002	DFLGMD 000002R	002	ERCDB 005702R	002	NOCOMP= 000001		PTEM12= 000106	
CMDBRK 006550R	002	DHKPAD= 000034		ERMBAS 005420R	002	NOPAR 003142R	002	PTEM13= 000110	
CMDCMS 006565R	002	DISCNT 002020R	002	ERRCOM 005332R	002	NORMAL 003064R	002	PTEM14= 000112	
CMDCRD 006521R	002	DISPST 006054R	002	ERRCS 005262R	002	NOWAIT 002416R	002	PTEM15= 000114	
CMDCHR 006534R	002	DISUMM 006030R	002	ERREX 005700R	002	NSTRIP 003024R	002	PTEM2 = 000062	
CNTDER 006734R	002	DKILAD= 000040		ERRI 000022R	002	NSYNC = 000005		PTEM3 = 000064	
CNTDNA 006701R	002	DNA = 100000		ERRR 005300R	002	OCJADR 001354R	002	PTEM4 = 000066	
CNTDSC 006662R	002	DNAENT 001434R	002	ERRSNM 005620R	002	OCPRES= 000100		PTEM5 = 000070	
CNTFRM 006630R	002	DNAERR 004572R	002	ERRWIS 005316R	002	OOD 003124R	002	PTEM6 = 000072	
CNTNUM= 000021		DOERCK= 000400		ERSTAD 005616R	002	OVR = 040000		PTEM7 = 000074	
CNTOVR 006645R	002	DOIOT = 000340		ERSTOP= 000004		OVRCNT 001430R	002	PTEM8 = 000076	
CNTPAR 006613R	002	DREGAD 003024R	002	ESYNCH= 020000		PADCNT 001402R	002	PTEM9 = 000100	
CNTRDI 006766R	002	DRTEND= 000116		EVEN 003114R	002	PAR = 010000		PTEND = 000242	
CNTSEN= 007010R	002	DRTLTH= 000116		FDOPLX 003034R	002	PARB 001376R	002	PTLGH= 000242	
CNTSMG 006430R	002	DSC = 100000		FRM = 020000		PARCNT 001424R	002	PTOCNT= 000030	
CNTTGE 006716R	002	DSCCNT 001432R	002	FRMCNT 001426R	002	PAREN8= 001000		PTSIZE= 000240	
CNTWPT 007002R	002	DSCERR 004262R	002	GENPAR 002466R	002	PARSEN= 000400		PUSRPC= 000236	
COFFLE 007173R	002	DSCIE = 000040		GETBYT 000076R	002	PASCIN= 000006		PJTBYT 000100R	002

004

MAINDEC-11-DTDUA-A DUL1 DEVICE ROUTINE FOR MPG
 DTDUA.P11 SYMBOL TABLE

MACY11 27(732) 24-SEP-75 14:10 PAGE 14-1

SEQ 0071

PWRIOA= 000020	REPORT 001614R	002	R4 = %000004	TBIF = 000006	WISTAT 001340R	002
RBUF = 000002	REPTBL 002130R	002	R5 = %000005	TCSR = 000004	WITCSR 001344R	002
RCSR = 000000	RESREG 005752R	002	SAVREG 005736R	TDMAIE= 000040	WRADR 001362R	002
RDADR 001356R	RING = 040000		SCHCYC= 000020	TINTEN= 000100	WRBCNT 001364R	002
RDBCNT 001360R	RINTEN= 000100		SCNT 000006R	TOCNT 001372R	WRBRCH 003654R	002
RDBSY = 000001	RIRBUF 001334R	002	SEND 002672R	TOECNT 001436R	WRBSY = 000002	
RDCNT 001414R	RIRCSR 001332R	002	SETDED= 000040	TOUTER 002172R	WRCNT 001416R	002
RDERR 004274R	RISTAT 001332R	002	SETVEC 000066R	TRVECT 005174R	WRICNT 001444R	002
RDE1 004314R	RITCSR 001336R	002	SIZE 000020R	TSEND = 000020	WRIERR= 000100	
RDE2 004326R	RPTBAS 002064R	002	SP = %000006	TSTVEC 000072R	WRITE 003616R	002
RDICNT 001442R	RPTEND 002110R	002	SPOPER= 000200	TWVECT 005224R	WRPSWD 00032R	002
RDISC= 000040	RPTLP 002046R	002	STMADR 004710R	ULIST 000052R	WRRBSY 004524R	002
RDERR= 000020	RQTS = 000004		STMNMG 007010R	UNASCI 006405R	WRSIZE 001370R	002
RDPSWD 000030R	RRINTV 005116R	002	STMNUM 007020R	UNITMG 006371R	WRTERM= 000010	
RDRBSY 004206R	RTNINT 000074R	002	STONER= 100000	URSTOP= 000002	WT410T= 000010	
RDSIZE 001366R	RWINTV 005142R	002	STRIP 003014R	USEUBM= 000200	WXDATA 004420R	002
RDTERM= 000004	RXER = 100000		STRSYC= 000400	WAIT 002352R	WXFERR 007107R	002
RDWREX 003570R	RXFERR 007026R	002	STSTAT 006010R	WAITMD= 100000	XXXX = 000000	
READ 003446R	RC = %000000		SUPTAD 005770R	WCKPAD 004504R	. = 007302R	002
. ABS. 000000		000				
		001				
DUL1 007302		002				

ERRORS DETECTED: 0
 DEFAULT GLOBALS GENERATED: 0

* DTDUA/NL:TOC/DOC=DTDUA.P11
 RUN-TIME: 5 11 1 SECONDS
 RUN-TIME RATIO: 29/18=1.5
 CORE USED: 5K (9 PAGES)

DOCUMENT PAGES: 42

Spooler runtime 6 Seconds, 30 MCS, 172 disk reads, 3 disk writes, 42 pages

00000000111111111222222222333333333444444444555555555666666666777777777888888888999999999000000000111111111222222222333312